

## DEVICE LIST 12/18/2008

Total Manufacturers 183

Total Devices 33950

[ACT](#)      [ACTRANS](#)      [ADVANCE GROUP](#)      [ALI\(Acer\)](#)  
[ALL 24 SERIES\(ISP\)](#)      [ALLIANCE](#)      [ALTERA](#)  
[AMD](#)      [AMI SEMICONDUCTOR](#)      [AMIC](#)  
[ANACHIP](#)      [APLUS FLASH](#)      [ARTSCHIP](#)      [ASAHI KASEI\(AKM\)](#)  
[ASD](#)      [ASI](#)      [ASP](#)      [ATC](#)  
[ATMEL](#)      [ATMEL W&M](#)      [ATMEL-CUSTOMER](#)      [AUSTIN](#)  
[BELLING-SYSTRON](#)      [BENCHMARQ](#)      [BMT](#)      [BOSEN](#)  
[BRIGHT](#)      [CATALYST](#)      [CELESTICA](#)      [CERAMATE](#)  
[CHINA CORE](#)      [CHINGIS](#)      [CHIPCON](#)      [CHIPSWINNER](#)  
[CORERIVER](#)      [CWI](#)      [CYGNAL](#)      [CYPRESS](#)  
[DALLAS](#)      [DENSE-PAC](#)      [DEUTRON](#)      [EFST](#)  
[ELECTRONIC ARRAYS](#)      [EM](#)      [EMTC](#)  
[EON](#)      [EPSON](#)      [ESMT](#)      [EXCELSEMI](#)  
[EXEL](#)      [FAIRCHILD](#)      [FORCE TECHNOLOGIES](#)  
[FORWARD](#)      [FREESCALE](#)      [Fremont Micro Devices](#)  
[FUJITSU](#)      [GENCORE](#)      [GENERAL\(GI\)](#)      [GENERIC](#)  
[GIGADEVICE](#)      [GOAL](#)      [GREENWICH](#)      [HAIER](#)  
[HARRIS](#)      [HITACHI](#)      [HOLTEK](#)      [HONGKONG](#)  
[HYNIX](#)      [HYNIX-CUSTOMER](#)      [HYUNDAI](#)      [ICE](#)  
[ICMIC](#)      [ICSI](#)      [ICT](#)      [IMT](#)  
[INTEL](#)      [INTEL-CUSTOMER](#)      [INTELSIL](#)      [ISSI](#)  
[ITHINKO](#)      [LATTICE](#)      [LG Semicon](#)      [LINKSMART](#)  
[MACRONIX](#)      [MAXIM](#)      [MAXWELL](#)      [MEGAWIN](#)  
[MEMOCOM](#)      [MICON](#)      [MICROCHIP](#)      [MICRON](#)  
[MICRONAS](#)      [MICRON-CUSTOMER](#)      [MITSUBISHI](#)      [MOSEL-VITELIC](#)  
[MOSTEK](#)      [MOTOROLA](#)      [MYSON](#)      [NEC](#)  
[NEXFLASH](#)      [NJRC](#)      [NOVATEK](#)      [NSC](#)  
[NTE](#)      [NUMONYX](#)      [NUVOTON](#)      [NXP](#)  
[OKI](#)      [PARALLAX](#)      [PFLASH\(MSTAR\)](#)      [PHILIPS](#)  
[PJ](#)      [PMC](#)      [PSS](#)      [PTC](#)  
[QIXIN](#)      [Quick Pulse](#)      [RAMTRON](#)      [RATO](#)  
[RAYDIUM](#)      [RENESAS](#)      [RICOH](#)      [ROCKWELL](#)  
[ROHM](#)      [SAIFUN](#)      [SAMSUNG](#)      [SAMSUNG-CUSTOMER](#)

[SANYO](#)      [SCENIX](#)      [SEEQ](#)      [SEIKO](#)  
[SGS-THOMSON](#)      [SHARP](#)      [SHARP-CUSTOMER](#)      [SIEMENS](#)  
[SIGNETICS](#)      [Silicon Laboratories](#)      [SILICON7](#)  
[SIMTEK](#)      [SMOS](#)      [SONIX](#)      [SONY](#)  
[SPACE ELECTRONICS\[SEI\]](#)      [SPANSION](#)  
[SPANSION-CUSTOMER](#)      [SSSC](#)      [SST](#)  
[ST](#)      [STC](#)      [ST-CUSTOMER](#)      [SUMMIT](#)  
[SUNPLUS](#)      [SYNCMOS](#)      [SYNERTEK](#)      [SYNTEK](#)  
[TECHCODE](#)      [TEKMOS](#)      [TEMIC](#)      [TI](#)  
[TMC](#)      [TOPRO](#)      [TOSHIBA](#)      [TOSHIBA-CUSTOMER](#)  
[TURBO IC](#)      [UBICOM](#)      [UMC](#)      [UTRON](#)  
[VANTIS](#)      [VERSACHIPS](#)      [VLSI](#)      [WELTREND](#)  
[WHITE ELECTRONIC DESIGNS](#)      [WINBOND](#)      [WSI](#)  
[XELTEK](#)      [XICOR](#)      [XILINX](#)      [XILINX-CUSTOMER](#)  
[YMC](#)      [YSS](#)      [ZHIXIN](#)      [ZILOG](#)  
[ZMD](#)

## ACT

### E(E)PROM/FRAM/NVRAM

93LC46(08bit)	93LC46(08bit)@SOIC8 [(SA602A)]
93LC46(16bit)	93LC46(16bit)@SOIC8 [(SA602A)]
93LC56(08bit)	93LC56(08bit)@SOIC8 [(SA602A)]
93LC56(16bit)	93LC56(16bit)@SOIC8 [(SA602A)]
93LC66(08bit)	93LC66(08bit)@SOIC8 [(SA602A)]
93LC66(16bit)	93LC66(16bit)@SOIC8 [(SA602A)]
93LC86(08bit)	93LC86(08bit)@SOIC8 [(SA602A)]
93LC86(16bit)	93LC86(16bit)@SOIC8 [(SA602A)]

## ACTRANS

### E(E)PROM/FRAM/NVRAM

AC25010@SOIC8 [(SA602A)]	AC25512@SOIC8 [(SA602A)]
AC25LC010@SOIC8 [(SA602A)]	AC25LC512@SOIC8 [(SA602A)]
AC39LV010@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV010@PLCC32 [(SA015A1T)]	AC39LV010@VSOP32 [(SA620)]
AC39LV020@FBGA48 [(SA642B-B026A-Y072F001)]	

AC39LV020@PLCC32 [(SA015A1T)] AC39LV020@VSOP32 [(SA620)]  
AC39LV040@PLCC32 [(SA015A1T)] AC39LV040@VSOP32 [(SA620)]  
AC39LV080@FBGA48 [(SA642B-B026A-Y072F001)]  
AC39LV080@TSOP40 [(SA409T)] AC39LV088@TSOP48 [(SA247-B005)]  
AC39LV512@PLCC32 [(SA015A1T)] AC39LV512@VSOP32 [(SA620)]  
AC39VF800@FBGA48 [(SA642B-B026A-Y072F001)]  
AC39VF800@TSOP48 [(SA247-B005)]

## ADVANCE GROUP

### E(E)PROM/FRAM/NVRAM

AF24BC01 AF24BC01@SOIC8 [(SA602A)]  
AF24BC01@TSOP8 [(SA026)] AF24BC02  
AF24BC02@SOIC8 [(SA602A)] AF24BC02@TSOP8 [(SA026)]  
AF24BC04 AF24BC04@SOIC8 [(SA602A)]  
AF24BC04@TSOP8 [(SA026)] AF24BC08  
AF24BC08@SOIC8 [(SA602A)] AF24BC08@TSOP8 [(SA026)]  
AF24BC16 AF24BC16@SOIC8 [(SA602A)]  
AF24BC16@TSOP8 [(SA026)] AF24C128  
AF24C128@SOIC8 [(SA602A)] AF24C128@TSOP8 [(SA026)]  
AF24C256 AF24C256@SOIC8 [(SA602A)]  
AF24C256@TSOP8 [(SA026)] AF24C32  
AF24C32@SOIC8 [(SA602A)] AF24C32@TSOP8 [(SA026)]  
AF24C64 AF24C64@SOIC8 [(SA602A)]  
AF24C64@TSOP8 [(SA026)] AF93C46(08bit)  
AF93C46(08bit)@SOIC8 [(SA602A)] AF93C46(08bit)@TSOP8 [(SA026)]  
AF93C46(16bit) AF93C46(16bit)@SOIC8 [(SA602A)]  
AF93C46(16bit)@TSOP8 [(SA026)] AF93C56(08bit)  
AF93C56(08bit)@SOIC8 [(SA602A)] AF93C56(08bit)@TSOP8 [(SA026)]  
AF93C56(16bit) AF93C56(16bit)@SOIC8 [(SA602A)]  
AF93C56(16bit)@TSOP8 [(SA026)] AF93C66(08bit)  
AF93C66(08bit)@SOIC8 [(SA602A)] AF93C66(08bit)@TSOP8 [(SA026)]  
AF93C66(16bit) AF93C66(16bit)@SOIC8 [(SA602A)]  
AF93C66(16bit)@TSOP8 [(SA026)] AF93C86(08bit)  
AF93C86(08bit)@SOIC8 [(SA602A)] AF93C86(08bit)@TSOP8 [(SA026)]  
AF93C86(16bit) AF93C86(16bit)@SOIC8 [(SA602A)]  
AF93C86(16bit)@TSOP8 [(SA026)]

### MICROCONTROLLER

A1000A2                    A1000A2@PLCC44 [(SA244)]  
A1000A2@PQFP44 [(SA245A)]            A1000A3  
A1000A3@PLCC44 [(SA244)]            A1000A3@PQFP44 [(SA245A)]  
AG1001@SDIP42 [(SA028)]            AG89F516  
AG89F516@PLCC44 [(SA244)]            AG89F516@PQFP44 [(SA245A)]  
AG89F54                    AG89F54@PLCC44 [(SA244)]  
AG89F54@PQFP44 [(SA245A)]            AG89P51  
AG89P51@PLCC44 [(SA244)]            AG89P51@PQFP44 [(SA675)]  
AG89P516                    AG89P516@PLCC44 [(SA244)]  
AG89P516@PQFP44 [(SA675)]            AG89P51A  
AG89P51A@PLCC44 [(SA244)]            AG89P51A@PQFP44 [(SA675)]  
AG89P52                    AG89P52@PLCC44 [(SA244)]  
AG89P52@PQFP44 [(SA675)]

## ALI(Acer)

### E(E)PROM/FRAM/NVRAM

M8720                    M8720@PLCC32 [(SA015A1T)]

### MICROCONTROLLER

M6759  
M6759@PLCC44 [ordering number is marked above]  
M6759@TQFP44 [ordering number is marked above]

## ALL 24 SERIES(ISP)

### E(E)PROM/FRAM/NVRAM

24C01(ISP) [ISP-HEADER01]	24C02(ISP) [ISP-HEADER01]
24C04(ISP) [ISP-HEADER01]	24C08(ISP) [ISP-HEADER01]
24C128(ISP) [ISP-HEADER01]	24C16(ISP) [ISP-HEADER01]
24C256(ISP) [ISP-HEADER01]	24C32(ISP) [ISP-HEADER01]
24C64(ISP) [ISP-HEADER01]	

## ALLIANCE

## E(E)PROM/FRAM/NVRAM

AS29F200@PSOP44 [(SA638-B006)] AS29F200@TSOP48 [(SA247-B005)]  
 AS29F200B@PSOP44 [(SA638-B006)] AS29F200B@TSOP48 [(SA247-B005)]  
 AS29F200T@PSOP44 [(SA638-B006)] AS29F200T@TSOP48 [(SA247-B005)]

## ALTERA

## E(E)PROM/FRAM/NVRAM

EPC1(LC)@PLCC20 [(SA001A)] EPC1(LI)@PLCC20 [(SA001A)]  
 EPC1(PC) EPC1(PI)  
 EPC1441(LC)@PLCC20 [(SA001A)] EPC1441(LI)@PLCC20 [(SA001A)]  
 EPC1441(PC) EPC1441(PI)  
 EPC1441(TC)@TQFP32 [(SA663)] EPC1441(TI)@TQFP32 [(SA663)]  
 EPC2(LC)@PLCC20 [(SA001A)] EPC2(LI)@PLCC20 [(SA001A)]  
 EPC2(TC)@TQFP32 [(SA663)] EPC2(TI)@TQFP32 [(SA663)]  
 EPCS16SI16@SOIC16 [(SA404)] EPCS16SI8N@SOIC8 [(SA602A)]  
 EPCS1SI8@SOIC8 [(SA602A)] EPCS4SI8@SOIC8 [(SA602A)]  
 EPCS64SI16@SOIC16 [(SA404)]

## PLD

EP310 EP310@PLCC20 [(SA001A)]  
 EP320 EP320@PLCC20 [(SA001A)]  
 EP330 EP330@PLCC20 [(SA001A)]  
 EP600 EP600@PLCC28 [(SA008A)]  
 EP600@SOIC24 [(SA404)] EP600I  
 EP600I@PLCC28 [(SA008A)] EP600I@SOIC24 [(SA404)]  
 EP610 EP610@PLCC28 [(SA008A)]  
 EP610@SOIC24 [(SA404)] EP610A  
 EP610A@PLCC28 [(SA008A)] EP610A@SOIC24 [(SA404)]  
 EP610I EP610I@PLCC28 [(SA008A)]  
 EP610I@SOIC24 [(SA404)] EP610T  
 EP610T@PLCC28 [(SA008A)] EP610T@SOIC24 [(SA404)]  
 EP630 EP630@PLCC28 [(SA008A)]  
 EP630@SOIC24 [(SA404)] EP900  
 EP900@PLCC44 [(SA244)] EP900I  
 EP900I@PLC44 [(SA244)] EP910  
 EP910@PLCC44 [(SA244)] EP910A  
 EP910A@PLCC44 [(SA244)] EP910I

EP910I@PLCC44 [(SA244)]            EP910T  
EP910T@PLCC44 [(SA244)]            EPM3032A@PLCC44 [(SA244)]  
EPM3032A@TQFP44 [(SA245A)]        EPM3064A@PLCC44 [(SA244)]  
EPM3064A@TQFP44 [(SA245A)]        EPM7032@PLCC44 [(SA244)]  
EPM7032@TQFP44 [(SA245A)]  
EPM7032AE@JLCC44 (7032 mode) [(SA244)]  
EPM7032AE@PLCC44 (7032 mode) [(SA244)]  
EPM7032AE@PLCC44 (7032AE mode) [(SA244)]  
EPM7032AE@PLCC44 (7032S mode) [(SA244)]  
EPM7032AE@PQFP44 (7032 mode) [(SA245A)]  
EPM7032AE@TQFP44 (7032 mode) [(SA245A)]  
EPM7032AE@TQFP44 (7032AE mode) [(SA245A)]  
EPM7032AE@TQFP44 (7032S mode) [(SA245A)]  
EPM7032B@PLCC44 (7032AE mode) [(SA244)]  
EPM7032B@PLCC44 (7032B mode) [(SA244)]  
EPM7032B@PLCC44 (7032S mode) [(SA244)]  
EPM7032B@TQFP44 (7032AE mode) [(SA245A)]  
EPM7032B@TQFP44 (7032B mode) [(SA245A)]  
EPM7032B@TQFP44 (7032S mode) [(SA245A)]  
EPM7032B@TQFP48 (7032AE mode) [(SA248)]  
EPM7032B@TQFP48 (7032B mode) [(SA248)]  
EPM7032B@TQFP48 (7032S mode) [(SA248)]  
EPM7032S@PLCC44 (7032 mode) [(SA244)]  
EPM7032S@PLCC44 (7032S mode) [(SA244)]  
EPM7032S@TQFP44 (7032 mode) [(SA245A)]  
EPM7032S@TQFP44 (7032S mode) [(SA245A)]  
EPM7032V@PLCC44 [(SA244)]        EPM7032V@TQFP44 [(SA245A)]  
EPM7064@PLCC44 [(SA244)]        EPM7064@TQFP44 [(SA245A)]  
EPM7064AE@PLCC44 (7064S)(ISP) [ISP-HEADER01]  
EPM7064AE@PLCC44 (7064AE mode) [(SA244)]  
EPM7064AE@PLCC44 (7064AE)(ISP) [ISP-HEADER01]  
EPM7064AE@PLCC44 (7064S mode) [(SA244)]  
EPM7064AE@TQFP44 (7064S)(ISP) [ISP-HEADER01]  
EPM7064AE@TQFP44 (7064AE mode) [(SA245A)]  
EPM7064AE@TQFP44 (7064AE)(ISP) [ISP-HEADER01]  
EPM7064AE@TQFP44 (7064S mode) [(SA245A)]  
EPM7064B@PLCC44 (7064AE mode) [(SA244)]  
EPM7064B@PLCC44 (7064B mode) [(SA244)]  
EPM7064B@PLCC44 (7064S mode) [(SA244)]  
EPM7064B@TQFP44 (7064AE mode) [(SA245A)]  
EPM7064B@TQFP44 (7064B mode) [(SA245A)]  
EPM7064B@TQFP44 (7064S mode) [(SA245A)]  
EPM7064B@TQFP48 (7064AE mode) [(SA248)]

EPM7064B@TQFP48 (7064B mode) [(SA248)]  
 EPM7064B@TQFP48 (7064S mode) [(SA248)]  
 EPM7064S@PLCC44 (7064 mode) [(SA244)]  
 EPM7064S@PLCC44 (7064S mode) [(SA244)]  
 EPM7064S@TQFP44 (7064 mode) [(SA245A)]  
 EPM7064S@TQFP44 (7064S mode) [(SA245A)]

## AMD

### E(E)PROM/FRAM/NVRAM

1736 1736@SOIC8 [(SA602A)]  
 1765 1765@SOIC8 [(SA602A)]  
 AM25FL005D@SOIC8 [(SA602A)] AM25FL005D@USON8 [(SA683)]  
 AM25FL010D@SOIC8 [(SA602A)] AM25FL010D@USON8 [(SA683)]  
 AM25FL016A@SOIC16 [(SA404)]  
 AM25FL016A@SOIC16(ISP) [ISP-HEADER01]  
 AM25FL016A@WSON8 [(SA684)]  
 AM25FL016A@WSON8(ISP) [ISP-HEADER01]  
 AM25FL020D@SOIC8 [(SA602A)] AM25FL020D@USON8 [(SA683)]  
 AM25FL032A@SOIC16 [(SA404)]  
 AM25FL032A@SOIC16(ISP) [ISP-HEADER01]  
 AM25FL032A@WSON8 [(SA684)]  
 AM25FL032A@WSON8(ISP) [ISP-HEADER01]  
 AM25FL040D@SOIC8 [(SA602A)] AM25FL040D@USON8 [(SA683)]  
 AM25FL080D@SOIC8 [(SA602A)] AM25FL080D@USON8 [(SA683)]  
 AM27128 AM27128(DC)  
 AM27128(DC)@PLCC32 [(SA015A1T)] AM27128@PLCC32 [(SA015A1T)]  
 AM27128A AM27128A(F)  
 AM27128A(F)@PLCC32 [(SA015A1T)] AM27128A(PC)  
 AM27128A(PC)@PLCC32 [(SA015A1T)] AM27128A@PLCC32 [(SA015A1T)]  
 AM2716 AM2716B  
 AM27256 AM27256@PLCC32 [(SA015A1T)]  
 AM27256AP AM27256AP@PLCC32 [(SA015A1T)]  
 AM27256F AM27256F@PLCC32 [(SA015A1T)]  
 AM27256PC AM27256PC@PLCC32 [(SA015A1T)]  
 AM2732 AM2732A  
 AM2732B AM27512  
 AM27512@PLCC32 [(SA015A1T)] AM27512DC  
 AM27512DC@PLCC32 [(SA015A1T)] AM27512F  
 AM27512F@PLCC32 [(SA015A1T)] AM27512PC  
 AM27512PC@PLCC32 [(SA015A1T)] AM27513

AM2764 AM2764@PLCC32 [(SA015A1T)]  
AM2764A AM2764A(DC)  
AM2764A(DC)@PLCC32 [(SA015A1T)] AM2764A(DCB)  
AM2764A(DI) AM2764A(DIB)  
AM2764A(F) AM2764A(F)@PLCC32 [(SA015A1T)]  
AM2764A(JC) AM2764A(LC)  
AM2764A(LCB) AM2764A(LE)  
AM2764A(LEB) AM2764A(PC)  
AM2764A(PC)@PLCC32 [(SA015A1T)] AM2764A@PLCC32 [(SA015A1T)]  
AM27C010 AM27C010@PLCC32 [(SA015A1T)]  
AM27C010@TSOP32 [(SA410T)] AM27C020  
AM27C020@PLCC32 [(SA015A1T)] AM27C020@TSOP32 [(SA410T)]  
AM27C040 AM27C040@PLCC32 [(SA015A1T)]  
AM27C040@TSOP32 [(SA410T)] AM27C080  
AM27C080@PLCC32 [(SA015A1T)] AM27C080@TSOP32 [(SA410T)]  
AM27C100 AM27C100@PLCC32 [(SA015A1T)]  
AM27C100@TSOP32 [(SA410T)] AM27C1024  
AM27C1024@PLCC44 [(SA244)] AM27C128  
AM27C128@PLCC32 [(SA015A1T)] AM27C2048  
AM27C2048@PLCC44 [(SA244)] AM27C2048@TSOP40 [(SA409T)]  
AM27C256 AM27C256(F)  
AM27C256(F)@PLCC32 [(SA015A1T)] AM27C256(PC)  
AM27C256(PC)@PLCC32 [(SA015A1T)] AM27C256@PLCC32 [(SA015A1T)]  
AM27C400 AM27C400@PLCC44 [(SA244)]  
AM27C4096 AM27C4096@PLCC44 [(SA244)]  
AM27C512 AM27C512(P)  
AM27C512(P)@PLCC32 [(SA015A1T)] AM27C512@PLCC32 [(SA015A1T)]  
AM27C64 AM27C64@PLCC32 [(SA015A1T)]  
AM27H010 AM27H010@PLCC32 [(SA015A1T)]  
AM27H010@TSOP32 [(SA410T)] AM27H256  
AM27H256@PLCC32 [(SA015A1T)] AM27HB010  
AM27HB010@PLCC32 [(SA015A1T)] AM27HB010@TSOP32 [(SA410T)]  
AM27LV010 AM27LV010@PLCC32 [(SA015A1T)]  
AM27LV010@TSOP32 [(SA410T)] AM27LV010B  
AM27LV010B@PLCC32 [(SA015A1T)] AM27LV010B@TSOP32 [(SA410T)]  
AM27LV020 AM27LV020@PLCC32 [(SA015A1T)]  
AM27LV020@TSOP32 [(SA410T)] AM27LV020B  
AM27LV020B@PLCC32 [(SA015A1T)] AM27LV020B@TSOP32 [(SA410T)]  
AM2816A AM2817A  
AM2817A@PLCC32 [(SA015A1T)] AM2817A@SOIC28 [(SA404)]  
AM2864A AM2864A(E)  
AM2864A(E)@PLCC32 [(SA015A1T)] AM2864A@PLCC32 [(SA015A1T)]  
AM2864B AM2864B(E)



AM2864B(E)@PLCC32 [(SA015A1T)] AM2864B@PLCC32 [(SA015A1T)]  
AM28F001 AM28F001@PLCC32 [(SA015A1T)]  
AM28F001@TSOP32 [(SA410T)] AM28F010  
AM28F010@PLCC32 [(SA015A1T)] AM28F010@TSOP32 [(SA410T)]  
AM28F010A AM28F010A@PLCC32 [(SA015A1T)]  
AM28F010A@TSOP32 [(SA410T)] AM28F020  
AM28F020@PLCC32 [(SA015A1T)] AM28F020@TSOP32 [(SA410T)]  
AM28F020A AM28F020A@PLCC32 [(SA015A1T)]  
AM28F020A@TSOP32 [(SA410T)] AM28F256  
AM28F256@PLCC32 [(SA015A1T)] AM28F256@TSOP32 [(SA410T)]  
AM28F256A AM28F256A@PLCC32 [(SA015A1T)]  
AM28F256A@TSOP32 [(SA410T)] AM28F512  
AM28F512(F) AM28F512(F)@PLCC32 [(SA015A1T)]  
AM28F512(F)@TSOP32 [(SA410T)] AM28F512@PLCC32 [(SA015A1T)]  
AM28F512@TSOP32 [(SA410T)] AM28F512A  
AM28F512A(F) AM28F512A(F)@PLCC32 [(SA015A1T)]  
AM28F512A(F)@TSOP32 [(SA410T)] AM28F512A@PLCC32 [(SA015A1T)]  
AM28F512A@TSOP32 [(SA410T)]  
AM29BL162CB@SSOP56 [(SA629A-B022)]  
AM29BL802CB@SSOP56 [(SA629A-B022)]  
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL161DB@TSOP48 [(SA247-B005)]  
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL161DT@TSOP48 [(SA247-B005)]  
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162CB@TSOP48 [(SA247-B005)]  
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162CT@TSOP48 [(SA247-B005)]  
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL162DB@TSOP48 [(SA247-B005)]  
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL162DT@TSOP48 [(SA247-B005)]

AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CB@TSOP48 [(SA247-B005)]  
AM29DL163CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CT@TSOP48 [(SA247-B005)]  
AM29DL163DB@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29DL163DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL163DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL163DB@TSOP48 [(SA247-B005)]  
AM29DL163DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163DT@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29DL163DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL163DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL163DT@TSOP48 [(SA247-B005)]  
AM29DL163DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CB@TSOP48 [(SA247-B005)]  
AM29DL164CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CT@TSOP48 [(SA247-B005)]  
AM29DL164DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL164DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL164DB@TSOP48 [(SA247-B005)]  
AM29DL164DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL164DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL164DT@TSOP48 [(SA247-B005)]  
AM29DL164DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL320GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL320GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL320GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL320GB@TSOP48 [(SA247-B005)]  
AM29DL320GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL320GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL320GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL320GT@TSOP48 [(SA247-B005)]  
AM29DL321CB@TSOP48 [(SA247-B005)]  
AM29DL321CT@TSOP48 [(SA247-B005)]  
AM29DL322CB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322CB@TSOP48 [(SA247-B005)]  
AM29DL322CT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322CT@TSOP48 [(SA247-B005)]

AM29DL322DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322DB@TSOP48 [(SA247-B005)]  
AM29DL322DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322DT@TSOP48 [(SA247-B005)]  
AM29DL322GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL322GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL322GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL322GB@TSOP48 [(SA247-B005)]  
AM29DL322GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL322GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL322GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL322GT@TSOP48 [(SA247-B005)]  
AM29DL323CB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323CB@TSOP48 [(SA247-B005)]  
AM29DL323CT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323CT@TSOP48 [(SA247-B005)]  
AM29DL323DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323DB@TSOP48 [(SA247-B005)]  
AM29DL323DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323DT@TSOP48 [(SA247-B005)]  
AM29DL323GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL323GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL323GB@TSOP48 [(SA247-B005)]  
AM29DL323GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL323GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL323GT@TSOP48 [(SA247-B005)]  
AM29DL324CB@TSOP48 [(SA247-B005)]  
AM29DL324CT@TSOP48 [(SA247-B005)]  
AM29DL324DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL324DB@TSOP48 [(SA247-B005)]  
AM29DL324DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL324DT@TSOP48 [(SA247-B005)]  
AM29DL324GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL324GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL324GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL324GB@TSOP48 [(SA247-B005)]  
AM29DL324GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL324GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL324GT@FBGA64 [(SA655D-B044A-W064F001Y)]

AM29DL324GT@TSOP48 [(SA247-B005)]  
AM29DL400BB@PSOP44 [(SA638-B006)]  
AM29DL400BB@TSOP48 [(SA247-B005)]  
AM29DL400BT@PLCC44 [(SA638-B006)]  
AM29DL400BT@TSOP48 [(SA247-B005)]  
AM29DL640D@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL640D@TSOP48 [(SA247-B005)]  
AM29DL640G@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL640G@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL640G@TSOP48 [(SA247-B005)]  
AM29DL642G@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]  
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29DL800BB@PSOP44 [(SA638)]  
AM29DL800BB@TSOP48 [(SA247-B005)]  
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29DL800BT@PSOP44 [(SA638)]  
AM29DL800BT@TSOP48 [(SA247-B005)]  
AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]  
AM29DS163CB@TSOP48 [(SA247-B005)]  
AM29DS163CT@TSOP48 [(SA247-B005)]  
AM29DS163DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS163DB@TSOP48 [(SA247-B005)]  
AM29DS163DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS163DT@TSOP48 [(SA247-B005)]  
AM29DS323DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS323DB@TSOP48 [(SA247-B005)]  
AM29DS323DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS323DT@TSOP48 [(SA247-B005)]  
AM29F002B AM29F002B@PLCC32 [(SA015A1T)]  
AM29F002B@TSOP32 [(SA410T)] AM29F002BB  
AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32 [(SA410T)]  
AM29F002BT AM29F002BT@PLCC32 [(SA015A1T)]  
AM29F002BT@TSOP32 [(SA410T)] AM29F002NB  
AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32 [(SA410T)]  
AM29F002NBB AM29F002NBB@PLCC32 [(SA015A1T)]  
AM29F002NBB@TSOP32 [(SA410T)] AM29F002NBT  
AM29F002NBT@PLCC32 [(SA015A1T)] AM29F002NBT@TSOP32 [(SA410T)]  
AM29F002NT AM29F002NT@PLCC32 [(SA015A1T)]  
AM29F002NT@TSOP32 [(SA410T)] AM29F002T  
AM29F002T@PLCC32 [(SA015A1T)] AM29F002T@TSOP32 [(SA410T)]  
AM29F004BB@PLCC32 [(SA015A1T)] AM29F004BB@TSOP32 [(SA410T)]  
AM29F004BT@PLCC32 [(SA015A1T)] AM29F004BT@TSOP32 [(SA410T)]

AM29F010 AM29F010@PLCC32 [(SA015A1T)]  
AM29F010@TSOP32 [(SA410T)] AM29F010A  
AM29F010A@PLCC32 [(SA015A1T)] AM29F010A@TSOP32 [(SA410T)]  
AM29F010B AM29F010B@PLCC32 [(SA015A1T)]  
AM29F010B@TSOP32 [(SA410T)] AM29F016@PSOP44 [(SA638)]  
AM29F016@TSOP40 [(SA409T)] AM29F016@TSOP48 [(SA247-B005)]  
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]  
AM29F016B@PSOP44 [(SA638)] AM29F016B@TSOP40 [(SA409T)]  
AM29F016B@TSOP48 [(SA247-B005)]  
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]  
AM29F016D@PSOP44 [(SA638)] AM29F016D@TSOP40 [(SA409T)]  
AM29F016D@TSOP48 [(SA247-B005)] AM29F017B@TSOP48 [(SA247-B005)]  
AM29F017D@TSOP40 [(SA409T)] AM29F017D@TSOP48 [(SA247-B005)]  
AM29F032B@PSOP44 [(SA638)] AM29F032B@TSOP40 [(SA409T)]  
AM29F040 AM29F040@PLCC32 [(SA015A1T)]  
AM29F040@TSOP32 [(SA410T)] AM29F040A  
AM29F040A@PLCC32 [(SA015A1T)] AM29F040A@TSOP32 [(SA410T)]  
AM29F040B  
AM29F040B(Reverse)@TSOP32 [(SA410T)]  
AM29F040B@PLCC32 [(SA015A1T)] AM29F040B@TSOP32 [(SA410T)]  
AM29F080@PSOP44 [(SA638)] AM29F080@TSOP40 [(SA409T)]  
AM29F080B@PSOP44 [(SA638)] AM29F080B@TSOP40 [(SA409T)]  
AM29F100BE@PSOP44 [(SA638-B006)] AM29F100BE@TSOP48 [(SA247-B005)]  
AM29F100BS@PSOP44 [(SA638-B006)] AM29F100BS@TSOP48 [(SA247-B005)]  
AM29F100TE@PSOP44 [(SA638-B006)] AM29F100TE@TSOP48 [(SA247-B005)]  
AM29F100TS@PSOP44 [(SA638-B006)] AM29F100TS@TSOP48 [(SA247-B005)]  
AM29F160DB@TSOP48 [(SA247-B005)] AM29F160DT@TSOP48 [(SA247-B005)]  
AM29F200AB@PSOP44 [(SA638-B006)] AM29F200AB@TSOP48 [(SA247-B005)]  
AM29F200AT@PSOP44 [(SA638-B006)] AM29F200AT@TSOP48 [(SA247-B005)]  
AM29F200BB@PSOP44 [(SA638-B006)] AM29F200BB@TSOP48 [(SA247-B005)]  
AM29F200BE@PSOP44 [(SA638-B006)] AM29F200BE@TSOP48 [(SA247-B005)]  
AM29F200BS@PSOP44 [(SA638-B006)] AM29F200BS@TSOP48 [(SA247-B005)]  
AM29F200BT@PSOP44 [(SA638-B006)] AM29F200BT@TSOP48 [(SA247-B005)]  
AM29F200TE@PSOP44 [(SA638-B006)] AM29F200TE@TSOP48 [(SA247-B005)]  
AM29F200TS@PSOP44 [(SA638-B006)] AM29F200TS@TSOP48 [(SA247-B005)]  
AM29F400AB@PSOP44 [(SA638-B006)] AM29F400AB@TSOP48 [(SA247-B005)]  
AM29F400AT@PSOP44 [(SA638-B006)] AM29F400AT@TSOP48 [(SA247-B005)]  
AM29F400BB@PSOP44 [(SA638-B006)] AM29F400BB@TSOP48 [(SA247-B005)]  
AM29F400BBE@PSOP44 [(SA638-B006)]  
AM29F400BBE@TSOP48 [(SA247-B005)]  
AM29F400BBF@PSOP44 [(SA638-B006)]  
AM29F400BBF@TSOP48 [(SA247-B005)]  
AM29F400BBS@PSOP44 [(SA638-B006)]

AM29F400BBS@TSOP48 [(SA247-B005)]  
AM29F400BE@PSOP44 [(SA638-B006)] AM29F400BE@TSOP48 [(SA247-B005)]  
AM29F400BF@PSOP44 [(SA638-B006)] AM29F400BF@TSOP48 [(SA247-B005)]  
AM29F400BS@PSOP44 [(SA638-B006)] AM29F400BS@TSOP48 [(SA247-B005)]  
AM29F400BT@PSOP44 [(SA638-B006)] AM29F400BT@TSOP48 [(SA247-B005)]  
AM29F400BTE@PSOP44 [(SA638-B006)]  
AM29F400BTE@TSOP48 [(SA247-B005)]  
AM29F400BTF@PSOP44 [(SA638-B006)]  
AM29F400BTF@TSOP48 [(SA247-B005)]  
AM29F400BTS@PSOP44 [(SA638-B006)]  
AM29F400BTS@TSOP48 [(SA247-B005)]  
AM29F800B@PSOP44 [(SA638-B006)] AM29F800B@TSOP48 [(SA247-B005)]  
AM29F800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BB@PSOP44 [(SA638-B006)] AM29F800BB@TSOP48 [(SA247-B005)]  
AM29F800BBF@PSOP44 [(SA638-B006)]  
AM29F800BBF@TSOP48 [(SA247-B005)]  
AM29F800BF@PSOP44 [(SA638-B006)] AM29F800BF@TSOP48 [(SA247-B005)]  
AM29F800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BT@PSOP44 [(SA638-B006)] AM29F800BT@TSOP48 [(SA247-B005)]  
AM29F800BTF@PSOP44 [(SA638-B006)]  
AM29F800BTF@TSOP48 [(SA247-B005)]  
AM29F800T@PSOP44 [(SA638-B006)] AM29F800T@TSOP48 [(SA247-B005)]  
AM29F800TB@PSOP44 [(SA638-B006)] AM29F800TB@TSOP48 [(SA247-B005)]  
AM29F800TF@PSOP44 [(SA638-B006)] AM29F800TF@TSOP48 [(SA247-B005)]  
AM29LL800B@TSOP48 [(SA247-B005)]  
AM29LL800BB@TSOP48 [(SA247-B005)]  
AM29LL800BT@TSOP48 [(SA247-B005)]  
AM29LL800T@TSOP48 [(SA247-B005)] AM29LV001BB@PLCC32 [(SA015A1T)]  
AM29LV001BB@TSOP32 [(SA410T)] AM29LV001BT@PLCC32 [(SA015A1T)]  
AM29LV001BT@TSOP32 [(SA410T)] AM29LV002@TSOP40 [(SA409T)]  
AM29LV002B@TSOP40 [(SA409T)] AM29LV002BB@TSOP40 [(SA409T)]  
AM29LV002BT@TSOP40 [(SA409T)] AM29LV004B@PSOP44 [(SA638)]  
AM29LV004B@TSOP40 [(SA409T)] AM29LV004BB@TSOP40 [(SA409T)]  
AM29LV004BT@TSOP40 [(SA409T)] AM29LV004T@PSOP44 [(SA638)]  
AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44 [(SA638)]  
AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40 [(SA409T)]  
AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44 [(SA638)]  
AM29LV008T@TSOP40 [(SA409T)] AM29LV010B@PLCC32 [(SA015A1T)]  
AM29LV010B@TSOP32 [(SA410T)] AM29LV017B@TSOP40 [(SA409T)]  
AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32 [(SA015A1T)]  
AM29LV020B@TSOP32 [(SA410T)]  
AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]

AM29LV033C@TSOP40 [(SA409T)]  
AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32 [(SA015A1T)]  
AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32 [(SA015A1T)]  
AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32 [(SA015A1T)]  
AM29LV040J@TSOP32 [(SA410T)]  
AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29LV065D@TSOP48 [(SA247-B005)]  
AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29LV065MU@TSOP48 [(SA247-B005)]  
AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40 [(SA409T)]  
AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40 [(SA409T)]  
AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40 [(SA409T)]  
AM29LV116DT@TSOP40 [(SA409T)]  
AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV128MH@TSOP56 [(SA628-B067)]  
AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV128ML@TSOP56 [(SA628-B067)]  
AM29LV160BB@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160BB@PSOP44 [(SA638)]  
AM29LV160BB@TSOP48 [(SA247-B005)]  
AM29LV160BT@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160BT@PSOP44 [(SA638)]  
AM29LV160BT@TSOP48 [(SA247-B005)]  
AM29LV160DB(REVERSE)@TSOP48 [(SA247-B005)]  
AM29LV160DB@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160DB@PSOP44 [(SA638)]  
AM29LV160DB@TSOP48 [(SA247-B005)]  
AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]  
AM29LV160DT@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160DT@PSOP44 [(SA638)]  
AM29LV160DT@TSOP48 [(SA247-B005)]  
AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MB@PSOP44 [(SA638)]  
AM29LV160MB@TSOP48 [(SA247-B005)]  
AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MT@PSOP44 [(SA638)]  
AM29LV160MT@TSOP48 [(SA247-B005)]  
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]  
AM29LV200BB@PSOP44 [(SA638-B006)]  
AM29LV200BB@TSOP48 [(SA247-B005)]

AM29LV200BE@PSOP44 [(SA638-B006)]  
AM29LV200BE@TSOP48 [(SA247-B005)]  
AM29LV200BF@PSOP44 [(SA638-B006)]  
AM29LV200BF@TSOP48 [(SA247-B005)]  
AM29LV200BS@PSOP44 [(SA638-B006)]  
AM29LV200BS@TSOP48 [(SA247-B005)]  
AM29LV200BT@PSOP44 [(SA638-B006)]  
AM29LV200BT@TSOP48 [(SA247-B005)]  
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]  
AM29LV200TE@PSOP44 [(SA638-B006)]  
AM29LV200TE@TSOP48 [(SA247-B005)]  
AM29LV200TF@PSOP44 [(SA638-B006)]  
AM29LV200TF@TSOP48 [(SA247-B005)]  
AM29LV200TS@PSOP44 [(SA638-B006)]  
AM29LV200TS@TSOP48 [(SA247-B005)]  
AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256MH@TSOP56 [(SA628-B067)]  
AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256ML@TSOP56 [(SA628-B067)]  
AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DB@TSOP48 [(SA247-B005)]  
AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DT@TSOP48 [(SA247-B005)]  
AM29LV320FB@TSOP48 [(SA247-B005)]  
AM29LV320FT@TSOP48 [(SA247-B005)]  
AM29LV320MB@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29LV320MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MB@TSOP48 [(SA247-B005)]  
AM29LV320MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MH@TSOP56 [(SA628-B067)]  
AM29LV320ML@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320ML@TSOP56 [(SA628-B067)]  
AM29LV320MT@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29LV320MT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MT@TSOP48 [(SA247-B005)]  
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]  
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29LV400BB@PSOP44 [(SA638-B006)]  
AM29LV400BB@TSOP48 [(SA247-B005)]  
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29LV400BT@PSOP44 [(SA638-B006)]  
AM29LV400BT@TSOP48 [(SA247-B005)]  
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]



AM29LV640DH@SSOP56 [(SA629A-B020)]  
AM29LV640DL@SSOP56 [(SA629A-B020)]  
AM29LV640DU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640DU@FBGA64 [(SA655D-B044A-W064F001)]  
AM29LV640GU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640GU@FBGA64 [(SA655D-B044A-W064F001)]  
AM29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MB@TSOP48 [(SA247-B005)]  
AM29LV640MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MH@TSOP56 [(SA628-B067)]  
AM29LV640ML@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640ML@TSOP56 [(SA628-B067)]  
AM29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MT@TSOP48 [(SA247-B005)]  
AM29LV640MU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MU@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV641DH@TSOP48 [(SA247-B005)]  
AM29LV641DHR@TSOP48 [(SA247-B005)]  
AM29LV641DL@TSOP48 [(SA247-B005)]  
AM29LV641DLR@TSOP48 [(SA247-B005)]  
AM29LV641GH@TSOP48 [(SA247-B005)]  
AM29LV641GHR@TSOP48 [(SA247-B005)]  
AM29LV641GL@TSOP48 [(SA247-B005)]  
AM29LV641GLR@TSOP48 [(SA247-B005)]  
AM29LV641MH@TSOP48 [(SA247-B005)]  
AM29LV641ML@TSOP48 [(SA247-B005)]  
AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]  
AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]  
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800BB@PSOP44 [(SA638-B006)]  
AM29LV800BB@TSOP48 [(SA247-B005)]  
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800BT@PSOP44 [(SA638-B006)]  
AM29LV800BT@TSOP48 [(SA247-B005)]  
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29LV800DB@PSOP44 [(SA638)]  
AM29LV800DB@TSOP48 [(SA247-B005)]  
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]

AM29LV800DT@PSOP44 [(SA638)]  
AM29LV800DT@TSOP48 [(SA247-B005)]  
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]  
AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PL160CB@PSOP44 [(SA638-B006)]  
AM29PL160CB@TSOP48 [(SA247-B005)]  
AM29PL160CT@PSOP44 [(SA638-B006)]  
AM29PL160CT@TSOP48 [(SA247-B005)]  
AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CB@TSOP48 [(SA247-B005)]  
AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CT@TSOP48 [(SA247-B005)]  
AM29SL400CB@TSOP48 [(SA247-B005)]  
AM29SL400CT@TSOP48 [(SA247-B005)]  
AM29SL800BB@TSOP48 [(SA247-B005)]  
AM29SL800BT@TSOP48 [(SA247-B005)]  
AM29SL800CB@TSOP48 [(SA247-B005)]  
AM29SL800CT@TSOP48 [(SA247-B005)]  
AM29SL800DB@TSOP48 [(SA247-B005)]  
AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM29SL800DT@TSOP48 [(SA247-B005)]  
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM9716 AM9732  
AM9732A AM9764  
AM9764@PLCC32 [(SA015A1T)]  
BS128HD8V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HD9V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE8V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE9V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF8V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF9V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS640HD8V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HD9V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HE8V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]

BS640HE9V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF8V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF9V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000005(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000006(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000007(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000008(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000009(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000A(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000B(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000C(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000D(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000E(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000F(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000G(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000000H(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001W(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001X(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Y(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Z(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000020(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]

M410000021(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000022(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000023(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000024(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000025(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000026(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000027(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002L(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002M(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002N(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002O(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002P(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002Q(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002R(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002S(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002T(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002U(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002V(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002W(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003D(AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003E(AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003F(AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003G(AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000095(AM41LV3204MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000096(AM41LV3204MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000009B(AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009C(AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009D(AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000000(AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000001(AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000004(AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000005(AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000006(AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000007(AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000I(AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000J(AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000K(AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000L(AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000M(AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000N(AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000O(AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000P(AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000Q(AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]

M42000000R(AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000S(AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000T(AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000U(AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000V(AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000W(AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000X(AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001A(AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001B(AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001C(AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001D(AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001E(AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001F(AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001G(AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001H(AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001I(AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001J(AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001K(AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001L(AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001M(AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001N(AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001O(AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001P(AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000022(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000023(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000024(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000025(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000026(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000027(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000028(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000029(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002A(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002B(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002C(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002D(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002U(AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002V(AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002Y(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000002Z(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000030(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000031(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000032(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000033(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]

M420000034(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000035(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Y(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Z(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000050(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000051(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000052(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000053(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000054(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000055(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000005M(AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005N(AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005W(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005X(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Y(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Z(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000060(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000061(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000070(AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000071(AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072(AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073(AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074(AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075(AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076(AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077(AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000078(AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000079(AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000000(AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000001(AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000008(AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000009(AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000A(AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000B(AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000S(AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000T(AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000U(AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000V(AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001C(AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001D(AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001E(AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001F(AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001W(AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]

M45000001X(AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Y(AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Z(AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000000(AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000001(AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000G(AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000H(AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000J(AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000K(AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000L(AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000M(AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000N(AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000O(AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000P(AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000Q(AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000R(AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000S(AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000T(AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000U(AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001A(AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001B(AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001Y(AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]  
M49000001Z(AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]  
M490000025(AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000026(AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000028(AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000029(AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002I(AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002J(AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002T(AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002U(AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002V(AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002X(AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000030(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000031(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000032(AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000032(AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000034(AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000035(AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000003A(AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003B(AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003C(AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003D(AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]

M49000003E(AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003F(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003G(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003H(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003I(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003J(AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003X(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003Y(AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003Z(AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000004A(AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000004B(AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]  
M49000004C(AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]  
M49000004D(AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]  
M49000004E(AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]  
M49000004H(AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004J(AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004K(AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004L(AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004S(AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004T(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004U(AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004V(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000000(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000001(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000008(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M500000009(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004J(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004K(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004L(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004M(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004N(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004P(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M550000000(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
M550000001(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]



PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

## PLD

M4A3-32/32@PLCC44 [(SA244)]      M4A3-32/32@TQFP44 [(SA245A)]  
M4A3-32/32@TQFP48 [(SA248)]      M4A3-64/32@PLCC44 [(SA244)]  
M4A3-64/32@TQFP44 [(SA245A)]      M4A3-64/32@TQFP48 [(SA248)]  
M4A5-32/32@PLCC44 [(SA244)]      M4A5-32/32@TQFP44 [(SA245A)]  
M4A5-32/32@TQFP48 [(SA248)]      M4A5-64/32@PLCC44 [(SA244)]  
M4A5-64/32@TQFP44 [(SA245A)]      M4A5-64/32@TQFP48 [(SA248)]  
PALC16L8Q                      PALC16L8Q@PLCC20 [(SA001A)]  
PALC16L8Z                      PALC16L8Z@PLCC20 [(SA001A)]  
PALC16R4Q                      PALC16R4Q@PLCC20 [(SA001A)]  
PALC16R4Z                      PALC16R4Z@PLCC20 [(SA001A)]  
PALC16R6Q                      PALC16R6Q@PLCC20 [(SA001A)]  
PALC16R6Z                      PALC16R6Z@PLCC20 [(SA001A)]  
PALC16R8Q                      PALC16R8Q@PLCC20 [(SA001A)]  
PALC16R8Z                      PALC16R8Z@PLCC20 [(SA001A)]  
PALCE16V8H                      PALCE16V8H@PLCC20 [(SA001A)]  
PALCE16V8H@SOIC20 [(SA404)]      PALCE16V8Q  
PALCE16V8Q@PLCC20 [(SA001A)]      PALCE16V8Q@SOIC20 [(SA404)]  
PALCE16V8Z                      PALCE16V8Z@PLCC20 [(SA001A)]  
PALCE16V8Z@SOIC20 [(SA404)]      PALCE20RA10  
PALCE20RA10@PLCC28 [(SA008A)]      PALCE20RA10@SOIC24 [(SA404)]  
PALCE20RA10H                      PALCE20RA10H@PLCC28 [(SA008A)]  
PALCE20RA10H@SOIC24 [(SA404)]      PALCE20RA10Q  
PALCE20RA10Q@PLCC28 [(SA008A)]      PALCE20RA10Q@SOIC24 [(SA404)]  
PALCE20V8H                      PALCE20V8H@PLCC28 [(SA008A)]  
PALCE20V8H@SOIC24 [(SA404)]      PALCE20V8Q  
PALCE20V8Q@PLCC28 [(SA008A)]      PALCE20V8Q@SOIC24 [(SA404)]  
PALCE22V10H                      PALCE22V10H@PLCC28 [(SA008A)]  
PALCE22V10H@SOIC24 [(SA404)]      PALCE22V10Q  
PALCE22V10Q@PLCC28 [(SA008A)]      PALCE22V10Q@SOIC24 [(SA404)]  
PALCE22V10Z                      PALCE22V10Z@PLCC28 [(SA008A)]  
PALCE22V10Z@SOIC24 [(SA404)]      PALLV16V8  
PALLV16V8@PLCC20 [(SA001A)]      PALLV16V8@SOIC20 [(SA404)]  
PALLV16V8Z                      PALLV16V8Z@PLCC20 [(SA001A)]  
PALLV16V8Z@SOIC20 [(SA404)]

## MICROCONTROLLER

AM87C51                    AM87C51@PLCC44 [(SA244)]  
AM87C51@TQFP44 [(SA245A)]        AM87C521  
AM87C521@PLCC44 [(SA244)]        AM87C521@TQFP44 [(SA245A)]  
AM87C541                    AM87C541@PLCC44 [(SA244)]  
AM87C541@TQFP44 [(SA245A)]

## AMI SEMICONDUCTOR

### E(E)PROM/FRAM/NVRAM

N256S0818HDA                N256S0818HDA@SOIC8 [(SA602A)]  
N256S0818HDA@TSSOP8 [(SA026)]    N256S0830HDA  
N256S0830HDA@SOIC8 [(SA602A)]    N256S0830HDA@TSSOP8 [(SA026)]  
N64S0818HDA                N64S0818HDA@SOIC8 [(SA602A)]  
N64S0818HDA@TSSOP8 [(SA026)]    N64S0830HDA  
N64S0830HDA@SOIC8 [(SA602A)]    N64S0830HDA@TSSOP8 [(SA026)]

## AMIC

### E(E)PROM/FRAM/NVRAM

A25L010                    A25L010[150mil]@SOP8 [(SA602A)]  
A25L010[209mil]@SOP8 [(SA605A)]    A25L016  
A25L016@SOP8 [(SA023A)]        A25L020  
A25L020[150mil]@SOP8 [(SA602A)]    A25L020[209mil]@SOP8 [(SA605A)]  
A25L032                    A25L032@SOP8 [(SA023A)]  
A25L040P                    A25L040P@QFN8 [(SA683)]  
A25L040P@SOP16 [(SA404)]        A25L040P@SOP8 [(SA602A)]  
A25L05P(Bottom)            A25L05P(Bottom)@QFN8 [(SA683)]  
A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]  
A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]  
A25L05P(Top)                A25L05P(Top)@QFN8 [(SA683)]  
A25L05P(Top)[150mil]@SOP8 [(SA602A)]  
A25L05P(Top)[209mil]@SOP8 [(SA605A)]  
A25L080P                    A25L080P@QFN8 [(SA683)]  
A25L080P@SOP16 [(SA404)]        A25L080P@SOP8 [(SA023A)]  
A25L10P(Bottom)            A25L10P(Bottom)@QFN8 [(SA683)]  
A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]  
A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]  
A25L10P(Top)                A25L10P(Top)@QFN8 [(SA683)]

A25L10P(Top)[150mil]@SOP8 [(SA602A)]  
A25L10P(Top)[209mil]@SOP8 [(SA605A)]  
A25L16P(Bottom)@QFN8 [(SA683)]  
A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]  
A25L16P(Bottom)@SOP16 [(SA404)]  
A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]  
A25L16P(Bottom)@SOP8 [(SA023A)]  
A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]  
A25L16P(Top)@QFN8 [(SA683)]  
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP16 [(SA404)]  
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP8 [(SA023A)]  
A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]  
A25L20P(Bottom) A25L20P(Bottom)@QFN8 [(SA683)]  
A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]  
A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]  
A25L20P(Top) A25L20P(Top)@QFN8 [(SA683)]  
A25L20P(Top)[150mil]@SOP8 [(SA602A)]  
A25L20P(Top)[209mil]@SOP8 [(SA605A)]  
A25L40P(Bottom Boot)  
A25L40P(Bottom Boot)@QFN8 [(SA683)]  
A25L40P(Bottom Boot)@SOP16 [(SA404)]  
A25L40P(Bottom Boot)@SOP8 [(SA602A)]  
A25L40P(Top Boot) A25L40P(Top Boot)@QFN8 [(SA683)]  
A25L40P(Top Boot)@SOP16 [(SA404)]  
A25L40P(Top Boot)@SOP8 [(SA602A)]  
A25L42P(Bottom Boot)  
A25L42P(Bottom Boot)@QFN8 [(SA683)]  
A25L42P(Bottom Boot)@SOP16 [(SA404)]  
A25L42P(Bottom Boot)@SOP8 [(SA602A)]  
A25L42P(Top Boot) A25L42P(Top Boot)@QFN8 [(SA683)]  
A25L42P(Top Boot)@SOP16 [(SA404)]  
A25L42P(Top Boot)@SOP8 [(SA602A)]  
A25L512 A25L512[150mil]@SOP8 [(SA602A)]  
A25L512[209mil]@SOP8 [(SA605A)] A25L80P  
A25L80P@QFN8 [(SA683)] A25L80P@SOP16 [(SA404)]  
A25L80P@SOP8 [(SA023A)] A25L82P(Bottom Boot)  
A25L82P(Bottom Boot)@QFN8 [(SA683)]  
A25L82P(Bottom Boot)@SOP16 [(SA404)]  
A25L82P(Bottom Boot)@SOP8 [(SA023A)]  
A25L82P(Top Boot) A25L82P(Top Boot)@QFN8 [(SA683)]  
A25L82P(Top Boot)@SOP16 [(SA404)]

A25L82P(Top Boot)@SOP8 [(SA023A)]  
A25LS080P A25LS080P@QFN8 [(SA683)]  
A25LS080P@SOP16 [(SA404)] A25LS080P@SOP8 [(SA023A)]  
A27020 A27020@PLCC32 [(SA015A1T)]  
A27020@TSOP32 [(SA410T)] A27020L  
A27020L@PLCC32 [(SA015A1T)] A27020L@TSOP32 [(SA410T)]  
A275308 A275308@PLCC32 [(SA015A1T)]  
A276308 A276308(E)  
A276308(E)@PLCC32 [(SA015A1T)] A276308(E)@SOIC28 [(SA404)]  
A276308@PLCC32 [(SA015A1T)] A276308@SOIC28 [(SA404)]  
A276308A A276308A(L)  
A276308A(L)@PLCC32 [(SA015A1T)] A276308A(L)@SOIC28 [(SA404)]  
A276308A@PLCC32 [(SA015A1T)] A276308A@SOIC28 [(SA404)]  
A277308 A277308@PLCC32 [(SA015A1T)]  
A277308A A277308A@PLCC32 [(SA015A1T)]  
A278308 A278308@PLCC32 [(SA015A1T)]  
A278308A A278308A(L)  
A278308A(L)@PLCC32 [(SA015A1T)] A278308A@PLCC32 [(SA015A1T)]  
A279308 A279308@PLCC32 [(SA015A1T)]  
A290011T A290011T@PLCC32 [(SA015A1T)]  
A290011T@TSOP32 [(SA410T)] A290011U  
A290011U@PLCC32 [(SA015A1T)] A290011U@TSOP32 [(SA410T)]  
A29001T A29001T@PLCC32 [(SA015A1T)]  
A29001T@TSOP32 [(SA410T)] A29001U  
A29001U@PLCC32 [(SA015A1T)] A29001U@TSOP32 [(SA410T)]  
A290021T A290021T@PLCC32 [(SA015A1T)]  
A290021T@TSOP32 [(SA410T)] A290021U  
A290021U@PLCC32 [(SA015A1T)] A290021U@TSOP32 [(SA410T)]  
A29002T A29002T@PLCC32 [(SA015A1T)]  
A29002T@TSOP32 [(SA410T)] A29002U  
A29002U@PLCC32 [(SA015A1T)] A29002U@TSOP32 [(SA410T)]  
A29010 A29010@PLCC32 [(SA015A1T)]  
A29010@TSOP32 [(SA410T)] A29040  
A29040@PLCC32 [(SA015A1T)] A29040@TSOP32 [(SA410T)]  
A29040A A29040A@PLCC32 [(SA015A1T)]  
A29040A@TSOP32 [(SA410T)] A29040B  
A29040B@PLCC32 [(SA015A1T)] A29040B@TSOP32 [(SA410T)]  
A29400TM@PSOP44 [(SA638)] A29400TV@TSOP48 [(SA247-B005)]  
A29400UM@PSOP44 [(SA638)] A29400UV@TSOP48 [(SA247-B005)]  
A29512 A29512@PLCC32 [(SA015A1T)]  
A29512@TSOP32 [(SA410T)] A29512A  
A29512A@PLCC32 [(SA015A1T)] A29512A@TSOP32 [(SA410T)]  
A29800TM@PSOP44 [(SA638)] A29800TV@TSOP48 [(SA247-B005)]

A29800UM@PSOP44 [(SA638)]      A29800UV@TSOP48 [(SA247-B005)]  
A29DL162TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL162TV@TSOP48 [(SA247-B005)]  
A29DL162UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL162UV@TSOP48 [(SA247-B005)]  
A29DL163TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL163TV@TSOP48 [(SA247-B005)]  
A29DL163UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL163UV@TSOP48 [(SA247-B005)]  
A29DL164TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL164TV@TSOP48 [(SA247-B005)]  
A29DL164UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL164UV@TSOP48 [(SA247-B005)]  
A29DL320FTV@TSOP48 [(SA247-B005)]  
A29DL320FUV@TSOP48 [(SA247-B005)]  
A29DL322TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL322TV@TSOP48 [(SA247-B005)]  
A29DL322UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL322UV@TSOP48 [(SA247-B005)]  
A29DL323TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL323TG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL323TV(New)@TSOP48 [(SA247-B005)]  
A29DL323TV@TSOP48 [(SA247-B005)]  
A29DL323UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL323UG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL323UV(New)@TSOP48 [(SA247-B005)]  
A29DL323UV@TSOP48 [(SA247-B005)]  
A29DL324TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL324TG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL324TV(New)@TSOP48 [(SA247-B005)]  
A29DL324TV@TSOP48 [(SA247-B005)]  
A29DL324UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL324UG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL324UV(New)@TSOP48 [(SA247-B005)]  
A29DL324UV@TSOP48 [(SA247-B005)]      A29L004ATL@PLCC32 [(SA015A1T)]  
A29L004ATV@TSOP32 [(SA410T)]      A29L004ATW@TSOP40 [(SA409T)]  
A29L004ATY@VSOP32 [(SA620)]      A29L004AUL@PLCC32 [(SA015A1T)]  
A29L004AUV@TSOP32 [(SA410T)]      A29L004AUW@TSOP40 [(SA409T)]  
A29L004AUY@VSOP32 [(SA620)]      A29L004T@PLCC32 [(SA015A1T)]  
A29L004T@TSOP32 [(SA410T)]      A29L004T@TSOP40 [(SA409T)]  
A29L004T@VSOP32 [(SA620)]      A29L004U@PLCC32 [(SA015A1T)]  
A29L004U@TSOP32 [(SA410T)]      A29L004U@TSOP40 [(SA409T)]  
A29L004U@VSOP32 [(SA620)]      A29L008ATV@TSOP40 [(SA409T)]

A29L008AUV@TSOP40 [(SA409T)]     A29L008T@TSOP40 [(SA409T)]  
A29L008U@TSOP40 [(SA409T)]     A29L040  
A29L040@PLCC32 [(SA015A1T)]     A29L040@TSOP32 [(SA410T)]  
A29L040@VSOP32 [(SA620)]  
A29L160ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160ATM@PSOP44 [(SA638)]     A29L160ATV@TSOP48 [(SA247-B005)]  
A29L160AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160AUM@PSOP44 [(SA638)]     A29L160AUV@TSOP48 [(SA247-B005)]  
A29L160BTG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BTGB@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BTM@PSOP44 [(SA638)]     A29L160BTV@TSOP48 [(SA247-B005)]  
A29L160BUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BUGB@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BUM@PSOP44 [(SA638)]     A29L160BUV@TSOP48 [(SA247-B005)]  
A29L160HTG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160HTV@TSOP48 [(SA247-B005)]  
A29L160HUG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160HUV@TSOP48 [(SA247-B005)]  
A29L160TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160TM@PSOP44 [(SA638)]     A29L160TV@TSOP48 [(SA247-B005)]  
A29L160UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160UM@PSOP44 [(SA638)]     A29L160UV@TSOP48 [(SA247-B005)]  
A29L320ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320ATV@TSOP48 [(SA247-B005)]  
A29L320AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320AUV@TSOP48 [(SA247-B005)]  
A29L400ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400ATM@PSOP44 [(SA638)]     A29L400ATV@TSOP48 [(SA247-B005)]  
A29L400AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400AUM@PSOP44 [(SA638)]     A29L400AUV@TSOP48 [(SA247-B005)]  
A29L400TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L400TM@PSOP44 [(SA638)]     A29L400TV@TSOP48 [(SA247-B005)]  
A29L400UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L400UM@PSOP44 [(SA638)]     A29L400UV@TSOP48 [(SA247-B005)]  
A29L800ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L800ATM@PSOP44 [(SA638)]     A29L800ATV@TSOP48 [(SA247-B005)]  
A29L800AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L800AUM@PSOP44 [(SA638)]     A29L800AUV@TSOP48 [(SA247-B005)]  
A29L800HTG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800HTM@PSOP44 [(SA638)]     A29L800HTV@TSOP48 [(SA247-B005)]  
A29L800HUG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800HUM@PSOP44 [(SA638)]     A29L800HUV@TSOP48 [(SA247-B005)]  
A29L800TG@FBGA48 [(SA642B-B026A-Y072F001)]

A29L800TM@PSOP44 [(SA638)]      A29L800TV@TSOP48 [(SA247-B005)]  
A29L800UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800UM@PSOP44 [(SA638)]      A29L800UV@TSOP48 [(SA247-B005)]  
A49LF004@PLCC32 [(SA015A1T)]      A49LF004@VSOP32 [(SA620)]  
A49LF004M@PLCC32 [(SA015A1T)]      A49LF004M@VSOP32 [(SA620)]  
A49LF040ATL@PLCC32 [(SA015A1T)]      A49LF040ATX@VSOP32 [(SA620)]  
A49LF040ATY@VSOP32 [(SA620)]      A49LF040TL@PLCC32 [(SA015A1T)]  
A49LF040TX@VSOP32 [(SA620)]      A50FW040@PLCC32 [(SA015A1T)]  
A50FW040@VSOP32 [(SA620)]      A50FW040M@PLCC32 [(SA015A1T)]  
A50FW040M@VSOP32 [(SA620)]      A50LPW040@PLCC32 [(SA015A1T)]  
A50LPW040@TSOP32 [(SA410T)]      A617308  
A617308@TSOP32 [(SA410T)]      A61L5308  
A61L5308@TSOP28 [(SA430T)]      A623308(M)  
A623308(R)@TSOP28 [(SA430T)]      A623308(V)@TSOP28 [(SA430T)]  
A625308(M)      A625308(R)@TSOP28 [(SA430T)]  
A625308(V)@TSOP28 [(SA430T)]      A62L256  
A62L256(M)      A62L256(R)@TSOP28 [(SA430T)]  
A62L256(V)@TSOP28 [(SA430T)]      A62S6308(M)  
A62S6308(X)@TSOP32 [(SA410T)]      A62S7308A(M)  
A62S7308A(X)@TSOP32 [(SA410T)]      A62S8308A(M)  
A62S8308A(X)@TSOP32 [(SA410T)]      A62W5308(M)  
A62W5308(R)@TSOP28 [(SA430T)]      A62W5308(V)@TSOP28 [(SA430T)]  
A81L801TG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
A81L801UG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
A82DL1622TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1622UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1624TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1624UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1632TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1632UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1634TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1634UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1642TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1642UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1644TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1644UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL32216TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32216UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3224TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3224UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3228TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3228UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32316TG@FBGA69 [(SA642A-B254A-Y096F001Y)]

A82DL32316UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3234TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3234UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3238TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3238UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL32416TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL32416UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3244TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3244UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3248TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
 A82DL3248UG@FBGA69 [(SA642A-B254A-Y096F001Y)]

## ANACHIP

### E(E)PROM/FRAM/NVRAM

27CX010                    27CX010@PLCC32 [(SA015A1T)]  
 27CX010@TSOP32 [(SA410T)]      27CX161  
 27CX162                    27CX256  
 27CX321                    27CX322  
 27CX641                    27CX642  
 93C46                      93C46@SOIC8 [(SA602A)]  
 93C46A                    93C46A@SOIC8 [(SA602A)]  
 93C56A                    93C56A@SOIC8 [(SA602A)]  
 93C66A                    93C66A@SOIC8 [(SA602A)]  
 93CX46                    93CX46@SOIC8 [(SA602A)]  
 93CX56                    93CX56@SOIC8 [(SA602A)]  
 93CX66                    93CX66@SOIC8 [(SA602A)]  
 AM24LC02                  AM24LC02@SOIC8 [(SA602A)]  
 AM24LC02@TSSOP8 [(SA026)]      AM24LC04  
 AM24LC04@SOIC8 [(SA602A)]      AM24LC04@TSSOP8 [(SA026)]  
 AM24LC08                  AM24LC08@SOIC8 [(SA602A)]  
 AM24LC08@TSSOP8 [(SA026)]      AM24LC16  
 AM24LC16@SOIC8 [(SA602A)]      AM24LC16@TSSOP8 [(SA026)]  
 AM24LC21                  AM24LC21@SOIC8 [(SA602A)]  
 AM24LC21@TSSOP8 [(SA026)]      AM24LC21B  
 AM24LC21B@SOIC8 [(SA602A)]      AM24LC21B@TSSOP8 [(SA026)]  
 AM93LC46(08bit)            AM93LC46(08bit)@SOIC8 [(SA602A)]  
 AM93LC46(08bit)@TSOP8 [(SA026)]    AM93LC46(16bit)  
 AM93LC46(16bit)@SOIC8 [(SA602A)]    AM93LC46(16bit)@TSOP8 [(SA026)]  
 AM93LC56(08bit)            AM93LC56(08bit)@SOIC8 [(SA602A)]  
 AM93LC56(08bit)@TSOP8 [(SA026)]    AM93LC56(16bit)



AM93LC56(16bit)@SOIC8 [(SA602A)] AM93LC56(16bit)@TSOP8 [(SA026)]  
 AM93LC66(08bit) AM93LC66(08bit)@SOIC8 [(SA602A)]  
 AM93LC66(08bit)@TSOP8 [(SA026)] AM93LC66(16bit)  
 AM93LC66(16bit)@SOIC8 [(SA602A)] AM93LC66(16bit)@TSOP8 [(SA026)]  
 AM93LC86(08bit) AM93LC86(08bit)@SOIC8 [(SA602A)]  
 AM93LC86(08bit)@TSOP8 [(SA026)] AM93LC86(16bit)  
 AM93LC86(16bit)@SOIC8 [(SA602A)] AM93LC86(16bit)@TSOP8 [(SA026)]

## PLD

PA7024 PA7024(J)@PLCC28 [(SA008A)]  
 PA7024(JN)@PLCC28 [(SA008A)] PA7024@SOIC24 [(SA404)]  
 PA7128 PA7128@PLCC28 [(SA008A)]  
 PA7128@SOIC28 [(SA404)] PA7140  
 PA7140@PLCC44 [(SA244)] PA7140@TQFP44 [(SA245A)]  
 PA7536 PA7536@PLCC28 [(SA008A)]  
 PA7536@SOIC28 [(SA404)] PA7540  
 PA7540(J)@PLCC28 [(SA008A)] PA7540(JN)@PLCC28 [(SA008A)]  
 PA7572 PA7572@PLCC44 [(SA244)]  
 PA7572@TQFP44 [(SA245A)] PEEL18CV8Z  
 PEEL18CV8Z@PLCC20 [(SA001A)] PEEL18CV8Z@SOIC20 [(SA404)]  
 PEEL18CV8Z@TSOP20 [(SA026)] PEEL18LV8Z  
 PEEL18LV8Z@PLCC20 [(SA001A)] PEEL18LV8Z@SOIC20 [(SA404)]  
 PEEL18LV8Z@TSOP20 [(SA026)] PEEL22CV10A  
 PEEL22CV10A@PLCC28 [(SA008A)] PEEL22CV10A@SOIC24 [(SA404)]  
 PEEL22CV10A@TSOP24 [(SA026)] PEEL22CV10A+  
 PEEL22CV10A+@PLCC28 [(SA008A)] PEEL22CV10A+@SOIC24 [(SA404)]  
 PEEL22CV10A+@TSOP24 [(SA026)] PEEL22CV10A++  
 PEEL22CV10A++@PLCC28 [(SA008A)] PEEL22CV10A++@SOIC24 [(SA404)]  
 PEEL22CV10A++@TSOP24 [(SA026)] PEEL22CV10AZ  
 PEEL22CV10AZ@PLCC28 [(SA008A)] PEEL22CV10AZ@SOIC24 [(SA404)]  
 PEEL22CV10AZ@TSOP24 [(SA026)] PEEL22CV10AZ+  
 PEEL22CV10AZ+@PLCC28 [(SA008A)] PEEL22CV10AZ+@SOIC24 [(SA404)]  
 PEEL22CV10AZ+@TSOP24 [(SA026)] PEEL22CV10AZ++  
 PEEL22CV10AZ++@PLCC28 [(SA008A)] PEEL22CV10AZ++@SOIC24 [(SA404)]  
 PEEL22CV10AZ++@TSOP24 [(SA026)] PEEL22LV10AZ  
 PEEL22LV10AZ@PLCC28 [(SA008A)] PEEL22LV10AZ@SOIC24 [(SA404)]  
 PEEL22LV10AZ@TSOP24 [(SA026)] PEEL22LV10AZ+  
 PEEL22LV10AZ+@PLCC28 [(SA008A)] PEEL22LV10AZ+@SOIC24 [(SA404)]  
 PEEL22LV10AZ+@TSOP24 [(SA026)] PEEL22LV10AZ++  
 PEEL22LV10AZ++@PLCC28 [(SA008A)] PEEL22LV10AZ++@SOIC24 [(SA404)]  
 PEEL22LV10AZ++@TSOP24 [(SA026)]

# APLUS FLASH

## E(E)PROM/FRAM/NVRAM

AF24BC01 AF24BC01@SOIC8 [(SA602A)]  
 AF24BC01@TSSOP8 [(SA026)] AF24BC02  
 AF24BC02@SOIC8 [(SA602A)] AF24BC02@TSSOP8 [(SA026)]  
 AF24BC04 AF24BC04@SOIC8 [(SA602A)]  
 AF24BC04@TSSOP8 [(SA026)] AF24BC08  
 AF24BC08@SOIC8 [(SA602A)] AF24BC08@TSSOP8 [(SA026)]  
 AF24BC128 AF24BC128@SOIC8 [(SA602A)]  
 AF24BC128@TSOP8 [(SA026)] AF24BC16  
 AF24BC16@SOIC8 [(SA602A)] AF24BC16@TSSOP8 [(SA026)]  
 AF24BC256 AF24BC256@SOIC8 [(SA602A)]  
 AF24BC256@TSOP8 [(SA026)] AF24BC32  
 AF24BC32@SOIC8 [(SA602A)] AF24BC32@TSOP8 [(SA026)]  
 AF24BC64 AF24BC64@SOIC8 [(SA602A)]  
 AF24BC64@TSOP8 [(SA026)] AF24C128  
 AF24C128@SOIC8 [(SA602A)] AF24C128@TSOP8 [(SA026)]  
 AF24C256 AF24C256@SOIC8 [(SA602A)]  
 AF24C256@TSOP8 [(SA026)] AF24C32  
 AF24C32@SOIC8 [(SA602A)] AF24C32@TSOP8 [(SA026)]  
 AF24C64 AF24C64@SOIC8 [(SA602A)]  
 AF24C64@TSOP8 [(SA026)] AF25BC128  
 AF25BC128@SOIC8 [(SA602A)] AF25BC128@TSOP8 [(SA026)]  
 AF25BC256 AF25BC256@SOIC8 [(SA602A)]  
 AF25BC256@TSOP8 [(SA026)] AF93BC46(08bit)  
 AF93BC46(08bit)@SOIC8 [(SA602A)] AF93BC46(08bit)@TSOP8 [(SA026)]  
 AF93BC46(16bit) AF93BC46(16bit)@SOIC8 [(SA602A)]  
 AF93BC46(16bit)@TSOP8 [(SA026)] AF93BC56(08bit)  
 AF93BC56(08bit)@SOIC8 [(SA602A)] AF93BC56(08bit)@TSOP8 [(SA026)]  
 AF93BC56(16bit) AF93BC56(16bit)@SOIC8 [(SA602A)]  
 AF93BC56(16bit)@TSOP8 [(SA026)] AF93BC66(08bit)  
 AF93BC66(08bit)@SOIC8 [(SA602A)] AF93BC66(08bit)@TSOP8 [(SA026)]  
 AF93BC66(16bit) AF93BC66(16bit)@SOIC8 [(SA602A)]  
 AF93BC66(16bit)@TSOP8 [(SA026)] AF93BC86(08bit)  
 AF93BC86(08bit)@SOIC8 [(SA602A)] AF93BC86(08bit)@TSOP8 [(SA026)]  
 AF93BC86(16bit) AF93BC86(16bit)@SOIC8 [(SA602A)]  
 AF93BC86(16bit)@TSOP8 [(SA026)] AF93C46(08bit)  
 AF93C46(08bit)@SOIC8 [(SA602A)] AF93C46(08bit)@TSOP8 [(SA026)]  
 AF93C46(16bit) AF93C46(16bit)@SOIC8 [(SA602A)]

AF93C46(16bit)@TSOP8 [(SA026)]    AF93C56(08bit)  
 AF93C56(08bit)@SOIC8 [(SA602A)]    AF93C56(08bit)@TSOP8 [(SA026)]  
 AF93C56(16bit)    AF93C56(16bit)@SOIC8 [(SA602A)]  
 AF93C56(16bit)@TSOP8 [(SA026)]    AF93C66(08bit)  
 AF93C66(08bit)@SOIC8 [(SA602A)]    AF93C66(08bit)@TSOP8 [(SA026)]  
 AF93C66(16bit)    AF93C66(16bit)@SOIC8 [(SA602A)]  
 AF93C66(16bit)@TSOP8 [(SA026)]    AF93C86(08bit)  
 AF93C86(08bit)@SOIC8 [(SA602A)]    AF93C86(08bit)@TSOP8 [(SA026)]  
 AF93C86(16bit)    AF93C86(16bit)@SOIC8 [(SA602A)]  
 AF93C86(16bit)@TSOP8 [(SA026)]

## ARTSCHIP

### E(E)PROM/FRAM/NVRAM

24AA02    24AA02@MSOP8 [(SA666)]  
 24AA02@SOIC8 [(SA602A)]    24AA02@SOT5 [(SA698)]  
 24AA02@TSSOP8 [(SA026)]    24LC01A  
 24LC01A@SOIC8 [(SA602A)]    24LC01A@SOT5 [(SA698)]  
 24LC01A@TSSOP8 [(SA026)]    24LC01B  
 24LC01B@SOIC8 [(SA602A)]    24LC01B@SOT5 [(SA698)]  
 24LC01B@TSSOP8 [(SA026)]    24LC02A  
 24LC02A@SOIC8 [(SA602A)]    24LC02A@SOT5 [(SA698)]  
 24LC02A@TSSOP8 [(SA026)]    24LC02B  
 24LC02B@MSOP8 [(SA666)]    24LC02B@SOIC8 [(SA602A)]  
 24LC02B@SOT5 [(SA698)]    24LC02B@TSSOP8 [(SA026)]  
 24LC04A    24LC04A@SOIC8 [(SA602A)]  
 24LC04A@SOT5 [(SA698)]    24LC04A@TSSOP8 [(SA026)]  
 24LC04B    24LC04B@MSOP8 [(SA666)]  
 24LC04B@SOIC8 [(SA602A)]    24LC04B@SOT5 [(SA698)]  
 24LC04B@TSSOP8 [(SA026)]    24LC08A  
 24LC08A@SOIC8 [(SA602A)]    24LC08A@SOT5 [(SA698)]  
 24LC08A@TSSOP8 [(SA026)]    24LC08B  
 24LC08B@MSOP8 [(SA666)]    24LC08B@SOIC8 [(SA602A)]  
 24LC08B@SOT5 [(SA698)]    24LC08B@TSSOP8 [(SA026)]  
 24LC16A    24LC16A@SOIC8 [(SA602A)]  
 24LC16A@SOT5 [(SA698)]    24LC16A@TSSOP8 [(SA026)]  
 24LC32    24LC32@SOIC14 [(SA026)]  
 24LC32@SOIC8 [(SA602A)]    24LC32@TSSOP8 [(SA026)]  
 24LC64    24LC64@SOIC14 [(SA026)]  
 24LC64@SOIC8 [(SA602A)]    24LC64@TSSOP8 [(SA026)]

## ASAHI KASEI(AKM)

## E(E)PROM/FRAM/NVRAM

AK27CX161	AK27CX162
AK27CX321	AK27CX322
AK27CX641	AK27CX642
AK6002A(F)@SOP8 [(SA602A)]	AK6002A(V)@TSSOP8 [(SA026)]
AK6003A(V)@TSSOP8 [(SA026)]	AK6004A(F)@SOP8 [(SA602A)]
AK6004A(M)@SSOP8 [(SA605A)]	AK6008A(F)@SOP8 [(SA602A)]
AK6010A(F)@SOP8 [(SA602A)]	AK6012A(F)@SOP8 [(SA602A)]
AK6416A(M)@SSOP8 [(SA026)]	AK6416C(F)@SOP8 [(SA602A)]
AK6420A(F)@SOP8 [(SA602A)]	AK6420A(M)@SSOP8 [(SA605A)]
AK6420B(H)@MSOP8 [(SA666)]	AK6440A(F)@SOP8 [(SA602A)]
AK6440A(M)@SSOP8 [(SA605A)]	AK6440B(H)@MSOP8 [(SA666)]
AK6480A(F)@SOP8 [(SA602A)]	AK6480A(M)@SSOP8 [(SA605A)]
AK6480B(H)@MSOP8 [(SA666)]	AK6480C(F)@SOP8 [(SA602A)]
AK6480C(H)@MSOP8 [(SA666)]	AK6480C(L)@SON8
AK6480C(M)@SSOP8 [(SA605A)]	AK6481C(H)@MSOP8 [(SA666)]
AK6481C(M)@SSOP8 [(SA605A)]	AK6508C(T)@MSOP8 [(SA666)]
AK6508C(U)@USON8	AK6510C(L)@SONW8
AK6510C(M)@SSOP8 [(SA026)]	AK6512C(L)@SONW8
AK6512C(M)@SSOP8 [(SA026)]	AK6514C(F)@SOP8 [(SA602A)]
AK6514C(N)@QFN20 [(SA692)]	AK6516C(F)@SOP8 [(SA602A)]
AK93C10A(F)@SOP8 [(SA602A)]	AK93C41A(V)@TSSOP8 [(SA026)]
AK93C45	AK93C45(F)@SOP8 [(SA602A)]
AK93C45A(F)@SOP8 [(SA602A)]	AK93C45A(NF)@SOP8 [(SA602A)]
AK93C45A(V)@TSSOP8 [(SA026)]	AK93C45B(H)@MSOP8 [(SA666)]
AK93C45B(L)@SON8	AK93C45C(T)@MSOP8 [(SA666)]
AK93C45C(U)@USON8	AK93C45L
AK93C45L(F)@SOP8 [(SA602A)]	AK93C46
AK93C46(F)@SOP8 [(SA602A)]	AK93C46A(F)@SOP8 [(SA602A)]
AK93C46A(NF)@SOP8 [(SA602A)]	AK93C46A(V)@TSSOP8 [(SA026)]
AK93C46B(H)@MSOP8 [(SA666)]	AK93C46B(L)@SON8
AK93C46C(T)@MSOP8 [(SA666)]	AK93C46C(U)@USON8
AK93C46L	AK93C46L(F)@SOP8 [(SA602A)]
AK93C51A(V)@TSSOP8 [(SA026)]	AK93C55
AK93C55(F)@SOP8 [(SA602A)]	AK93C55A(F)@SOP8 [(SA602A)]
AK93C55A(NF)@SOP8 [(SA602A)]	AK93C55A(V)@TSSOP8 [(SA026)]
AK93C55B(H)@MSOP8 [(SA666)]	AK93C55B(L)@SON8
AK93C55C(T)@MSOP8 [(SA666)]	AK93C55C(U)@USON8
AK93C55L	AK93C55L(F)@SOP8 [(SA602A)]

AK93C56 AK93C56(F)@SOP8 [(SA602A)]  
AK93C56A(F)@SOP8 [(SA602A)] AK93C56A(NF)@SOP8 [(SA602A)]  
AK93C56A(V)@TSSOP8 [(SA026)] AK93C56B(H)@MSOP8 [(SA666)]  
AK93C56B(L)@SON8 AK93C56C(T)@MSOP8 [(SA666)]  
AK93C56C(U)@USON8 AK93C56L  
AK93C56L(F)@SOP8 [(SA602A)] AK93C61A(V)@TSSOP8 [(SA026)]  
AK93C65 AK93C65(F)@SOP8 [(SA602A)]  
AK93C65A(F)@SOP8 [(SA602A)] AK93C65A(NF)@SOP8 [(SA602A)]  
AK93C65A(V)@TSSOP8 [(SA026)] AK93C65B(H)@MSOP8 [(SA666)]  
AK93C65B(L)@SON8 AK93C65C(T)@MSOP8 [(SA666)]  
AK93C65C(U)@USON8 AK93C65L  
AK93C65L(F)@SOP8 [(SA602A)] AK93C66  
AK93C66(F)@SOP8 [(SA602A)] AK93C66A(F)@SOP8 [(SA602A)]  
AK93C66A(NF)@SOP8 [(SA602A)] AK93C66A(V)@TSSOP8 [(SA026)]  
AK93C66B(H)@MSOP8 [(SA666)] AK93C66B(L)@SON8  
AK93C66C(T)@MSOP8 [(SA666)] AK93C66C(U)@USON8  
AK93C66L AK93C66L(F)@SOP8 [(SA602A)]  
AK93C75 AK93C75(F)@SOP8 [(SA602A)]  
AK93C75A(F)@SOP8 [(SA602A)] AK93C75A(NF)@SOP8 [(SA602A)]  
AK93C75A(V)@TSSOP8 [(SA026)] AK93C75B(H)@MSOP8 [(SA666)]  
AK93C75L AK93C75L(F)@SOP8 [(SA602A)]  
AK93C85 AK93C85(F)@SOP8 [(SA602A)]  
AK93C85L AK93C85L(F)@SOP8 [(SA602A)]  
AK93C95A(F)@SOP8 [(SA602A)] AK9822(M)@SSOP8 [(SA026)]  
AK9824(M)@SSOP8 [(SA026)] AK9844@SOIC14 [(SA602)]

## ASD

### E(E)PROM/FRAM/NVRAM

AE29F1008 AE29F2008

## ASI

### E(E)PROM/FRAM/NVRAM

AS58C1001 AS58C1001@PLCC32 [(SA015A1T)]  
AS58C1001@SSOP32 [(SA438T)]

## ASP

## MICROCONTROLLER

AP827C51	AP827C51@PLCC44 [(SA244)]
AP827C52	AP827C52@PLCC44 [(SA244)]
AP827C54	AP827C54@PLCC44 [(SA244)]
AP827C58	AP827C58@PLCC44 [(SA244)]

## ATC

## E(E)PROM/FRAM/NVRAM

ATC24C02	ATC24C02@SOIC8 [(SA602A)]
ATC24C02@TSSOP8 [(SA026)]	ATC24C04
ATC24C04@SOIC8 [(SA602A)]	ATC24C04@TSSOP8 [(SA026)]
ATC24C08	ATC24C08@SOIC8 [(SA602A)]
ATC24C08@TSSOP8 [(SA026)]	ATC24C16
ATC24C16@SOIC8 [(SA602A)]	ATC24C16@TSSOP8 [(SA026)]
ATC24LC02	ATC24LC02@SOIC8 [(SA602A)]
ATC24LC02@TSSOP8 [(SA026)]	ATC24LC02A
ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8 [(SA026)]
ATC24LC04	ATC24LC04@SOIC8 [(SA602A)]
ATC24LC04@TSSOP8 [(SA026)]	ATC24LC08
ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8 [(SA026)]
ATC24LC16	ATC24LC16@SOIC8 [(SA602A)]
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46(08bit)
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46(16bit)
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8 [(SA602A)]
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8 [(SA602A)]
ATC93C56R(08bit)@SOIC8 [(SA602A)]	
ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8 [(SA602A)]
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8 [(SA602A)]
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	

ATC93LC46(16bit)  
 ATC93LC46(16bit)@SOIC8 [(SA602A)]  
 ATC93LC46R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC46R(16bit)@SOIC8 [(SA602A)]  
 ATC93LC56(08bit)  
 ATC93LC56(08bit)@SOIC8 [(SA602A)]  
 ATC93LC56(16bit)  
 ATC93LC56(16bit)@SOIC8 [(SA602A)]  
 ATC93LC56R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC56R(16bit)@SOIC8 [(SA602A)]  
 ATC93LC66(08bit)  
 ATC93LC66(08bit)@SOIC8 [(SA602A)]  
 ATC93LC66(16bit)  
 ATC93LC66(16bit)@SOIC8 [(SA602A)]  
 ATC93LC66R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC66R(16bit)@SOIC8 [(SA602A)]

## ATMEL

### E(E)PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]      AT17C002@PLCC44 [(SA244)]  
 AT17C002@SOIC20 [(SA404)]      AT17C002@TQFP44 [(SA245A)]  
 AT17C002A@PLCC20 [(SA001A)]      AT17C002A@TQFP32 [(SA663)]  
 AT17C010      AT17C010@PLCC20 [(SA001A)]  
 AT17C010A      AT17C010A@PLCC20 [(SA001A)]  
 AT17C040@PLCC44 [(SA244)]      AT17C040@TQFP44 [(SA245A)]  
 AT17C128      AT17C128@PLCC20 [(SA001A)]  
 AT17C128@SOIC20 [(SA404)]      AT17C128@SOIC8 [(SA602A)]  
 AT17C128A@PLCC20 [(SA001A)]      AT17C256  
 AT17C256@PLCC20 [(SA001A)]      AT17C256@SOIC20 [(SA404)]  
 AT17C256@SOIC8 [(SA602A)]      AT17C256A@PLCC20 [(SA001A)]  
 AT17C512      AT17C512@PLCC20 [(SA001A)]  
 AT17C512A      AT17C512A@PLCC20 [(SA001A)]  
 AT17C65      AT17C65@PLCC20 [(SA001A)]  
 AT17C65@SOIC20 [(SA404)]      AT17C65@SOIC8 [(SA602A)]  
 AT17C65A@PLCC20 [(SA001A)]      AT17F040@LAP8 [(SA760)]  
 AT17F040@PLCC20 [(SA001A)]  
 AT17F040@PLCC20(Virtex Pinout) [(SA001A)]  
 AT17F040A@LAP8 [(SA760)]      AT17F040A@PLCC20 [(SA001A)]  
 AT17F040A@TQFP32 [(SA663)]      AT17F080@LAP8 [(SA760)]  
 AT17F080@PLCC20 [(SA001A)]      AT17F080@PLCC44 [(SA244)]

AT17F080@TQFP44 [(SA245A)] AT17F080A@LAP8 [(SA760)]  
AT17F080A@PLCC20 [(SA001A)] AT17F080A@TQFP32 [(SA001A)]  
AT17F16@LAP8 [(SA760)] AT17F16@PLCC20 [(SA001A)]  
AT17F16@PLCC44 [(SA244)] AT17F16@TQFP44 [(SA245A)]  
AT17F16A@LAP8 [(SA760)] AT17F16A@PLCC20 [(SA001A)]  
AT17F32@PLCC44 [(SA244)] AT17F32A@PLCC44 [(SA244)]  
AT17LV002@PLCC20 [(SA001A)] AT17LV002@PLCC44 [(SA244)]  
AT17LV002@SOIC20 [(SA404)] AT17LV002@TQFP44 [(SA245A)]  
AT17LV002A@PLCC20 [(SA001A)] AT17LV002A@TQFP32 [(SA663)]  
AT17LV010 AT17LV010@PLCC20 [(SA001A)]  
AT17LV010A AT17LV010A@PLCC20 [(SA001A)]  
AT17LV040@PLCC44 [(SA244)] AT17LV040@TQFP44 [(SA245A)]  
AT17LV128 AT17LV128@PLCC20 [(SA001A)]  
AT17LV128@SOIC20 [(SA404)] AT17LV128@SOIC8 [(SA602A)]  
AT17LV128A@PLCC20 [(SA001A)] AT17LV256  
AT17LV256@PLCC20 [(SA001A)] AT17LV256@SOIC20 [(SA404)]  
AT17LV256@SOIC8 [(SA602A)] AT17LV256A@PLCC20 [(SA001A)]  
AT17LV512 AT17LV512@PLCC20 [(SA001A)]  
AT17LV512A AT17LV512A@PLCC20 [(SA001A)]  
AT17LV65 AT17LV65@PLCC20 [(SA001A)]  
AT17LV65@SOIC20 [(SA404)] AT17LV65@SOIC8 [(SA602A)]  
AT17LV65A@PLCC20 [(SA001A)] AT17N002@SOIC20 [(SA404)]  
AT17N002@TQFP44 [(SA245A)] AT17N010  
AT17N010@SOIC20 [(SA404)] AT17N040@TQFP44 [(SA245A)]  
AT17N256 AT17N256@SOIC20 [(SA404)]  
AT17N256@SOIC8 [(SA602A)] AT17N512  
AT17N512@SOIC20 [(SA404)] AT24C01  
AT24C01@MSOP8 [(SA666)] AT24C01@SOIC8 [(SA602A)]  
AT24C01@TSSOP8 [(SA026)] AT24C01A  
AT24C01A@MAP8 [(SA724)] AT24C01A@SOIC8 [(SA602A)]  
AT24C01A@SOT23-5 [(SA717)] AT24C01A@TSSOP8 [(SA026)]  
AT24C01B AT24C01B@dBGA2  
AT24C01B@MAP8 [(SA724)] AT24C01B@SOIC8 [(SA602A)]  
AT24C01B@SOT23 [(SA717)] AT24C01B@TSSOP8 [(SA026)]  
AT24C02 AT24C02@SOIC8 [(SA602A)]  
AT24C02@TSSOP8 [(SA026)] AT24C02A  
AT24C02A@SOIC8 [(SA602A)] AT24C02A@TSSOP8 [(SA026)]  
AT24C02B AT24C02B@dBGA2  
AT24C02B@MAP8 [(SA724)] AT24C02B@SOIC8 [(SA602A)]  
AT24C02B@SOT23 [(SA717)] AT24C02B@TSSOP8 [(SA026)]  
AT24C04 AT24C04@MAP8 [(SA724)]  
AT24C04@SOIC8 [(SA602A)] AT24C04@SOT23-5 [(SA717)]  
AT24C04@TSSOP8 [(SA026)] AT24C04A



AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8 [(SA602A)]
AT24C04A@TSSOP8 [(SA026)]	AT24C08
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8 [(SA602A)]
AT24C08@TSSOP8 [(SA026)]	AT24C08A
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8 [(SA602A)]
AT24C08A@TSSOP8 [(SA026)]	AT24C1024
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8 [(SA684)]
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B(1.8V)
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8 [(SA684)]
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8 [(SA724)]
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8 [(SA602A)]
AT24C11@TSSOP8 [(SA026)]	AT24C128(1.8V)
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8 [(SA683)]
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8 [(SA026)]
AT24C128(2.7V)	AT24C128(2.7V)@MAP8 [(SA724)]
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8 [(SA602A)]
AT24C128(2.7V)@TSSOP8 [(SA026)]	AT24C128B
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8 [(SA683)]
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8 [(SA026)]
AT24C16	AT24C16@SOIC8 [(SA602A)]
AT24C16@TSSOP8 [(SA026)]	AT24C164
AT24C164@SOIC8 [(SA602A)]	AT24C16A
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8 [(SA602A)]
AT24C16A@TSSOP8 [(SA026)]	AT24C16B
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8 [(SA602A)]
AT24C16B@TSSOP8 [(SA026)]	AT24C21
AT24C21@SOIC8 [(SA602A)]	AT24C256(1.8V)
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8 [(SA683)]
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8 [(SA026)]
AT24C256(2.7V)	AT24C256(2.7V)@MAP8 [(SA724)]
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8 [(SA602A)]
AT24C256(2.7V)@TSSOP8 [(SA026)]	AT24C256B
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8 [(SA683)]
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8 [(SA026)]
AT24C32	AT24C32@SOIC8 [(SA602A)]
AT24C32@TSSOP8 [(SA026)]	AT24C32A
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8 [(SA602A)]
AT24C32A@TSSOP8 [(SA026)]	AT24C32C

AT24C32C@dBGA8 [(BBBB)] AT24C32C@MAP8 [(SA724)]  
AT24C32C@SAP8 [(SA683)] AT24C32C@SOIC8 [(SA602A)]  
AT24C32C@TSSOP8 [(SA026)] AT24C512(1.8V)  
AT24C512(1.8V)@LAP8 [(SA684)] AT24C512(1.8V)@SAP8 [(SA683)]  
AT24C512(1.8V)@SOIC8 [(SA602A)] AT24C512(1.8V)@TSSOP8 [(SA026)]  
AT24C512(2.7V) AT24C512(2.7V)@LAP8 [(SA684)]  
AT24C512(2.7V)@SAP8 [(SA683)] AT24C512(2.7V)@SOIC8 [(SA602A)]  
AT24C512(2.7V)@TSSOP8 [(SA026)] AT24C512B  
AT24C512B@LAP8 [(SA684)] AT24C512B@SAP8 [(SA683)]  
AT24C512B@SOIC8 [(SA602A)] AT24C512B@TSSOP8 [(SA026)]  
AT24C64 AT24C64@SOIC8 [(SA602A)]  
AT24C64@TSSOP8 [(SA026)] AT24C64A  
AT24C64A@MAP8 [(SA724)] AT24C64A@SOIC8 [(SA602A)]  
AT24C64A@TSSOP8 [(SA026)] AT24C64B  
AT24C64B@SOIC8 [(SA602A)] AT24C64B@TSSOP8 [(SA026)]  
AT24C64C AT24C64C@dBGA8 [(BBBB)]  
AT24C64C@MAP8 [(SA724)] AT24C64C@SAP8 [(SA683)]  
AT24C64C@SOIC8 [(SA602A)] AT24C64C@TSSOP8 [(SA026)]  
AT24CS128 AT24CS128@SOIC8 [(SA602A)]  
AT24HC02B AT24HC02B@SOIC8 [(SA602A)]  
AT24HC02B@TSSOP8 [(SA026)] AT24RF08AN@SOIC8 [(SA602A)]  
AT24RF08AT@TSSOP14 [(SA026)] AT24RF08BN@SOIC8 [(SA602A)]  
AT24RF08BT@TSSOP14 [(SA026)] AT24RF08CN@SOIC8 [(SA602A)]  
AT24RF08CT@TSSOP14 [(SA026)] AT25010  
AT25010@SOIC8 [(SA602A)] AT25010A  
AT25010A@SOIC8 [(SA602A)] AT25010A@TSSOP8 [(SA026)]  
AT25020 AT25020@SOIC8 [(SA602A)]  
AT25020A AT25020A@SOIC8 [(SA602A)]  
AT25020A@TSSOP8 [(SA026)] AT25040  
AT25040(ISP) [ISP-HEADER01] AT25040@SOIC8 [(SA602A)]  
AT25040@SOIC8(ISP) [ISP-HEADER01]  
AT25040A AT25040A(ISP) [ISP-HEADER01]  
AT25040A@SOIC8 [(SA602A)]  
AT25040A@SOIC8(ISP) [ISP-HEADER01]  
AT25080 AT25080@SOIC8 [(SA602A)]  
AT25080@TSSOP14 [(SA026)] AT25080@TSSOP20 [(SA026)]  
AT25080A AT25080A@SOIC8 [(SA602A)]  
AT25080A@TSSOP14 [(SA026)] AT25128  
AT25128@SOIC16 [(SA602)] AT25128@SOIC8 [(SA602A)]  
AT25128@TSSOP14 [(SA026)] AT25128@TSSOP20 [(SA026)]  
AT25128A AT25128A@dBGA8 [(BBBB)]  
AT25128A@SAP8 [(SA683)] AT25128A@SOIC8(4.0) [(SA602A)]  
AT25128A@SOIC8(5.4) [(SA605A)] AT25128A@TSSOP14 [(SA026)]

AT25128A@TSSOP8 [(SA026)] AT25160  
AT25160@SOIC8 [(SA602A)] AT25160@TSSOP14 [(SA026)]  
AT25160@TSSOP20 [(SA026)] AT25160A  
AT25160A@SOIC8 [(SA602A)] AT25160A@TSSOP14 [(SA026)]  
AT25256 AT25256@SOIC16 [(SA602)]  
AT25256@SOIC8 [(SA602A)] AT25256@TSSOP14 [(SA026)]  
AT25256@TSSOP20 [(SA026)] AT25256A  
AT25256A@dBGA8 [(BBBB)] AT25256A@SAP8 [(SA683)]  
AT25256A@SOIC8(4.0) [(SA602A)] AT25256A@SOIC8(5.4) [(SA605A)]  
AT25256A@TSSOP14 [(SA026)] AT25256A@TSSOP8 [(SA026)]  
AT25320 AT25320@SOIC8 [(SA602A)]  
AT25320@TSSOP14 [(SA026)] AT25320@TSSOP20 [(SA026)]  
AT25320A AT25320A@SOIC8 [(SA602A)]  
AT25320A@TSSOP14 [(SA026)] AT25640  
AT25640@SOIC8 [(SA602A)] AT25640@TSSOP14 [(SA026)]  
AT25640@TSSOP20 [(SA026)] AT25640A  
AT25640A@SOIC8 [(SA602A)] AT25640A@TSSOP14 [(SA026)]  
AT25DF021@SOIC8 [(SA602A)] AT25DF021@UDFN8 [(SA683)]  
AT25DF041A@MLF8 [(SA683)] AT25DF041A@SOIC8(4.0) [(SA602A)]  
AT25DF041A@SOIC8(5.4) [(SA605A)] AT25DF081@SOIC8 [(SA602A)]  
AT25DF081@UDFN8 [(SA683)] AT25DF161@MLF8 [(SA683)]  
AT25DF161@SOIC8(4.0) [(SA602A)] AT25DF161@SOIC8(5.4) [(SA605A)]  
AT25DF321@SOIC16 [(SA404)] AT25DF321@SOIC8 [(SA605A)]  
AT25DF641@SOIC16 [(SA404)] AT25DF641@VDFN8 [(SA683)]  
AT25F1024 AT25F1024(W)@SOIC8 [(SA605A)]  
AT25F1024(W)@VQFPN8 [(SA684)] AT25F1024@SOIC8 [(SA602A)]  
AT25F1024@VQFPN8 [(SA683)] AT25F1024A  
AT25F1024A(W)@SOIC8 [(SA605A)] AT25F1024A(W)@VQFPN8 [(SA684)]  
AT25F1024A@SOIC8 [(SA602A)] AT25F1024A@VQFPN8 [(SA683)]  
AT25F2048 AT25F2048(W)@SOIC8 [(SA605A)]  
AT25F2048(W)@VQFPN8 [(SA684)] AT25F2048@SOIC8 [(SA602A)]  
AT25F2048@VQFPN8 [(SA683)] AT25F2048A  
AT25F2048A(W)@SOIC8 [(SA605A)] AT25F2048A(W)@VQFPN8 [(SA684)]  
AT25F2048A@SOIC8 [(SA602A)] AT25F2048A@VQFPN8 [(SA683)]  
AT25F4096 AT25F4096(W)@SOIC8 [(SA605A)]  
AT25F4096(W)@VQFPN8 [(SA684)] AT25F4096@SOIC8 [(SA602A)]  
AT25F4096@VQFPN8 [(SA683)] AT25F4096A  
AT25F4096A(W)@SOIC8 [(SA605A)] AT25F4096A(W)@VQFPN8 [(SA684)]  
AT25F4096A@SOIC8 [(SA602A)] AT25F4096A@VQFPN8 [(SA683)]  
AT25F512 AT25F512(W)@SOIC8 [(SA605A)]  
AT25F512(W)@VQFPN8 [(SA684)] AT25F512@SOIC8 [(SA602A)]  
AT25F512@VQFPN8 [(SA683)] AT25F512A  
AT25F512A(W)@SOIC8 [(SA605A)] AT25F512A(W)@VQFPN8 [(SA684)]

AT25F512A@SOIC8 [(SA602A)]      AT25F512A@VQFPN8 [(SA683)]  
 AT25FS010@SAP8 [(SA683)]      AT25FS010@SOIC8 [(SA602A)]  
 AT25FS040@SAP8 [(SA683)]      AT25FS040@SOIC8 [(SA602A)]  
 AT25HP256      AT25HP256(W)@VQFPN8 [(SA684)]  
 AT25HP256@SOIC16 [(SA404)]      AT25HP256@SOIC8 [(SA602A)]  
 AT25HP256@VQFPN8 [(SA683)]      AT25HP512  
 AT25HP512(W)@VQFPN8 [(SA684)]      AT25HP512@SOIC16 [(SA404)]  
 AT25HP512@SOIC8 [(SA602A)]      AT25HP512@VQFPN8 [(SA683)]  
 AT25P1024@SOIC20 [(SA404)]      AT25P1024@VQFPN8 [(SA684)]  
 AT26DF041@MLF8 [(SA683)]      AT26DF041@SOIC8(4.0) [(SA602A)]  
 AT26DF041@SOIC8(5.4) [(SA605A)]      AT26DF081@SOIC8(4.0) [(SA602A)]  
 AT26DF081@SOIC8(5.4) [(SA605A)]      AT26DF081A@SOIC8(4.0) [(SA602A)]  
 AT26DF081A@SOIC8(5.4) [(SA605A)]      AT26DF161@MLF8 [(SA683)]  
 AT26DF161@SOIC8 [(SA605A)]      AT26DF161A@MLF8 [(SA683)]  
 AT26DF161A@SOIC8 [(SA605A)]      AT26DF321@MLF8(5\*6mm) [(SA683)]  
 AT26DF321@MLF8(6\*8mm) [(SA684)]      AT26DF321@SOIC16 [(SA404)]  
 AT26DF321@SOIC8 [(SA605A)]      AT26F004@MLF8 [(SA683)]  
 AT26F004@SOIC8(4.0) [(SA602A)]      AT26F004@SOIC8(5.4) [(SA605A)]  
 AT27011      AT27011@PLCC32 [(SA015A1T)]  
 AT27256      AT2732A  
 AT27BV010      AT27BV010@PLCC32 [(SA015A1T)]  
 AT27BV010@TSOP32 [(SA620)]      AT27BV020  
 AT27BV020@PLCC32 [(SA015A1T)]      AT27BV020@TSOP32 [(SA620)]  
 AT27BV040      AT27BV040@PLCC32 [(SA015A1T)]  
 AT27BV040@TSOP32 [(SA620)]      AT27BV1024@PLCC44 [(SA244)]  
 AT27BV1024@TSOP40 [(SA623)]      AT27BV256  
 AT27BV256@PLCC32 [(SA015A1T)]      AT27BV256@TSOP28 [(SA430T)]  
 AT27BV4096      AT27BV4096@PLCC44 [(SA244)]  
 AT27BV4096@TSOP40 [(SA623)]      AT27BV512  
 AT27BV512@PLCC32 [(SA015A1T)]      AT27BV512@SOIC28 [(SA630)]  
 AT27BV512@TSOP28 [(SA430T)]      AT27BV520@SOIC20 [(SA404)]  
 AT27BV520@TSOP28 [(SA430T)]      AT27BV520@TSSOP20 [(SA026)]  
 AT27C010      AT27C010@PLCC32 [(SA015A1T)]  
 AT27C010@TSOP32 [(SA410T)]      AT27C010L  
 AT27C010L@PLCC32 [(SA015A1T)]      AT27C010L@TSOP32 [(SA410T)]  
 AT27C020      AT27C020@PLCC32 [(SA015A1T)]  
 AT27C020@TSOP32 [(SA410T)]      AT27C040  
 AT27C040@PLCC32 [(SA015A1T)]      AT27C040@TSOP32 [(SA410T)]  
 AT27C080      AT27C080@PLCC32 [(SA015A1T)]  
 AT27C080@TSOP32 [(SA410T)]      AT27C1024  
 AT27C1024@PLCC44 [(SA244)]      AT27C1024@TSOP40 [(SA623)]  
 AT27C1024L      AT27C1024L@PLCC44 [(SA244)]  
 AT27C128      AT27C128@PLCC32 [(SA015A1T)]

AT27C2048 AT27C2048@PLCC44 [(SA244)]  
AT27C2048@TSOP40 [(SA623)] AT27C256  
AT27C256@PLCC32 [(SA015A1T)] AT27C256R  
AT27C256R@PLCC32 [(SA015A1T)] AT27C256R@SOIC28 [(SA630)]  
AT27C256R@TSOP28 [(SA430T)] AT27C4096  
AT27C4096@PLCC44 [(SA244)] AT27C4096@TSOP40 [(SA623)]  
AT27C512 AT27C512@PLCC32 [(SA015A1T)]  
AT27C512R AT27C512R@PLCC32 [(SA015A1T)]  
AT27C512R@SOIC28 [(SA630)] AT27C512R@TSOP28 [(SA430T)]  
AT27C513 AT27C513@PLCC32 [(SA015A1T)]  
AT27C513@SOIC28 [(SA630)] AT27C513R  
AT27C513R@PLCC32 [(SA015A1T)] AT27C513R@SOIC28 [(SA630)]  
AT27C515 AT27C515@PLCC32 [(SA015A1T)]  
AT27C516 AT27C516@PLCC44 [(SA244)]  
AT27C516@TSOP40 [(SA623)] AT27C520@SOIC20 [(SA404)]  
AT27C520@TSOP28 [(SA430T)] AT27C520@TSSOP20 [(SA026)]  
AT27C64 AT27C800  
AT27C800@PLCC44 [(SA244)] AT27C800@PSOP44 [(SA638)]  
AT27HC1024 AT27HC1024@PLCC44 [(SA244)]  
AT27HC256 AT27HC256@PLCC32 [(SA015A1T)]  
AT27HC256L AT27HC256L@PLCC32 [(SA015A1T)]  
AT27HC256R AT27HC256R@PLCC32 [(SA015A1T)]  
AT27HC256RL AT27HC256RL@PLCC32 [(SA015A1T)]  
AT27HC64 AT27HC64@PLCC32 [(SA015A1T)]  
AT27HC641 AT27HC641@PLCC28 [(SA008A)]  
AT27HC641R AT27HC641R@PLCC28 [(SA008A)]  
AT27HC642 AT27HC642@PLCC28 [(SA008A)]  
AT27HC642R AT27HC642R@PLCC28 [(SA008A)]  
AT27HC64L AT27HC64L@PLCC32 [(SA015A1T)]  
AT27LV010 AT27LV010@PLCC32 [(SA015A1T)]  
AT27LV010@TSOP32 [(SA620)] AT27LV010A  
AT27LV010A@PLCC32 [(SA015A1T)] AT27LV010A@TSOP32 [(SA620)]  
AT27LV020A AT27LV020A@PLCC32 [(SA015A1T)]  
AT27LV020A@TSOP32 [(SA620)] AT27LV040  
AT27LV040@PLCC32 [(SA015A1T)] AT27LV040@TSOP32 [(SA620)]  
AT27LV040A AT27LV040A@PLCC32 [(SA015A1T)]  
AT27LV040A@TSOP32 [(SA620)] AT27LV1024  
AT27LV1024@PLCC44 [(SA244)] AT27LV256A  
AT27LV256A@PLCC32 [(SA015A1T)] AT27LV256A@SOIC28 [(SA630)]  
AT27LV256A@TSOP28 [(SA430T)] AT27LV256R  
AT27LV256R@PLCC32 [(SA015A1T)] AT27LV256R@SOIC28 [(SA630)]  
AT27LV256R@TSOP28 [(SA430T)] AT27LV4096  
AT27LV4096@PLCC44 [(SA244)] AT27LV512A

AT27LV512A@PLCC32 [(SA015A1T)] AT27LV512A@SOIC28 [(SA630)]  
AT27LV512A@TSOP28 [(SA430T)] AT27LV512R  
AT27LV512R@PLCC32 [(SA015A1T)] AT27LV512R@TSOP28 [(SA430T)]  
AT27LV520@SOIC20 [(SA404)] AT27LV520@TSOP28 [(SA430T)]  
AT27LV520@TSSOP20 [(SA026)] AT27LV800  
AT27LV800@PSOP44 [(SA638)] AT28BV16  
AT28BV16@PLCC32 [(SA015A1T)] AT28BV16@SOIC24 [(SA404)]  
AT28BV16@TSOP28 [(SA430T)] AT28BV256  
AT28BV256@PLCC32 [(SA015A1T)] AT28BV256@SOIC28 [(SA404)]  
AT28BV256@TSOP28 [(SA430T)] AT28BV64  
AT28BV64@PLCC32 [(SA015A1T)] AT28BV64@SOIC28 [(SA404)]  
AT28BV64@TSOP28 [(SA430T)] AT28BV64B  
AT28BV64B@PLCC32 [(SA015A1T)] AT28BV64B@SOIC28 [(SA404)]  
AT28BV64B@TSOP28 [(SA430T)] AT28C010  
AT28C010@PLCC32 [(SA015A1T)] AT28C010@PLCC44 [(SA244)]  
AT28C010@TSOP32 [(SA410T)] AT28C010E  
AT28C010E@PLCC32 [(SA015A1T)] AT28C010E@PLCC44 [(SA244)]  
AT28C010E@TSOP32 [(SA410T)] AT28C04  
AT28C04@PLCC32 [(SA015A1T)] AT28C040  
AT28C040@PLCC32 [(SA015A1T)] AT28C04E  
AT28C04E@PLCC32 [(SA015A1T)] AT28C04F  
AT28C04F@PLCC32 [(SA015A1T)] AT28C16  
AT28C16@PLCC32 [(SA015A1T)] AT28C16@SOIC24 [(SA404)]  
AT28C16@TSOP28 [(SA430T)] AT28C16E  
AT28C16E@PLCC32 [(SA015A1T)] AT28C16F  
AT28C16F@PLCC32 [(SA015A1T)] AT28C17  
AT28C17@PLCC32 [(SA015A1T)] AT28C17@SOIC28 [(SA404)]  
AT28C17E AT28C17E@PLCC32 [(SA015A1T)]  
AT28C17F AT28C17F@PLCC32 [(SA015A1T)]  
AT28C256 AT28C256@PLCC32 [(SA015A1T)]  
AT28C256@SOIC28 [(SA404)] AT28C256@TSOP28 [(SA430T)]  
AT28C256E AT28C256E@PLCC32 [(SA015A1T)]  
AT28C256F AT28C256F@PLCC32 [(SA015A1T)]  
AT28C64 AT28C64@PLCC32 [(SA015A1T)]  
AT28C64@SOIC28 [(SA404)] AT28C64@TSOP28 [(SA430T)]  
AT28C64B AT28C64B@PLCC32 [(SA015A1T)]  
AT28C64B@SOIC28 [(SA404)] AT28C64B@TSOP28 [(SA430T)]  
AT28C64E AT28C64E@PLCC32 [(SA015A1T)]  
AT28C64E@TSOP28 [(SA430T)] AT28C64F  
AT28C64F@PLCC32 [(SA015A1T)] AT28C64F@TSOP28 [(SA430T)]  
AT28C64X AT28C64X@PLCC32 [(SA015A1T)]  
AT28C64X@SOIC28 [(SA404)] AT28C64X@TSOP28 [(SA430T)]  
AT28HC04 AT28HC16

AT28HC16L                    AT28HC191  
 AT28HC191L                  AT28HC256  
 AT28HC256@PLCC32 [(SA015A1T)]    AT28HC256@TSOP28 [(SA430T)]  
 AT28HC256E                  AT28HC256E@PLCC32 [(SA015A1T)]  
 AT28HC256F                  AT28HC256F@PLCC32 [(SA015A1T)]  
 AT28HC256L                  AT28HC256L@PLCC32 [(SA015A1T)]  
 AT28HC256LE                AT28HC256LE@PLCC32 [(SA015A1T)]  
 AT28HC291                   AT28HC291@PLCC28 [(SA008A)]  
 AT28HC291L                 AT28HC291L@PLCC28 [(SA008A)]  
 AT28HC64                    AT28HC64@PLCC32 [(SA015A1T)]  
 AT28HC64@TSOP28 [(SA430T)]    AT28HC64B  
 AT28HC64B@PLCC32 [(SA015A1T)]    AT28HC64B@SOIC28 [(SA404)]  
 AT28HC64B@TSOP28 [(SA430T)]    AT28HC64BF  
 AT28HC64BF@PLCC32 [(SA015A1T)]    AT28HC64BF@SOIC28 [(SA404)]  
 AT28HC64BF@TSOP28 [(SA430T)]    AT28HC64L  
 AT28HC64L@PLCC32 [(SA015A1T)]    AT28HC64L@TSOP28 [(SA430T)]  
 AT28LV010                   AT28LV010@PLCC32 [(SA015A1T)]  
 AT28LV010@TSOP32 [(SA410T)]    AT28LV256  
 AT28LV256@PLCC32 [(SA015A1T)]    AT28LV256@TSOP28 [(SA430T)]  
 AT28LV64                    AT28LV64@PLCC32 [(SA015A1T)]  
 AT28LV64B                   AT28LV64B@PLCC32 [(SA015A1T)]  
 AT28LV64B@SOIC28 [(SA404)]    AT28LV64B@TSOP28 [(SA430T)]  
 AT28MC010                   AT28MC010@PLCC32 [(SA015A1T)]  
 AT28MC010@PLCC44 [(SA244)]    AT28MC010@TSOP32 [(SA410T)]  
 AT28MC020                   AT28MC020@PLCC32 [(SA015A1T)]  
 AT28MC020@PLCC44 [(SA244)]    AT28MC020@TSOP32 [(SA410T)]  
 AT28MC040                   AT28MC040@PLCC32 [(SA015A1T)]  
 AT28MC040@PLCC44 [(SA244)]    AT28MC040@TSOP32 [(SA410T)]  
 AT28PC64                    AT28PC64@PLCC32 [(SA015A1T)]  
 AT28PC64@TSOP28 [(SA430T)]    AT28PC64E  
 AT28PC64E@PLCC32 [(SA015A1T)]    AT28PC64E@TSOP28 [(SA430T)]  
 AT29BV010A@PLCC32 [(SA015A1T)]    AT29BV010A@TSOP32 [(SA410T)]  
 AT29BV020@PLCC32 [(SA015A1T)]    AT29BV020@TSOP32 [(SA410T)]  
 AT29BV040A@TSOP32 [(SA410T)]    AT29C010  
 AT29C010@PLCC32 [(SA015A1T)]    AT29C010@TSOP32 [(SA410T)]  
 AT29C010A                   AT29C010A@PLCC32 [(SA015A1T)]  
 AT29C010A@TSOP32 [(SA410T)]    AT29C020  
 AT29C020@PLCC32 [(SA015A1T)]    AT29C020@TSOP32 [(SA410T)]  
 AT29C040                    AT29C040@PLCC32 [(SA015A1T)]  
 AT29C040@TSOP32 [(SA410T)]    AT29C040A  
 AT29C040A@PLCC32 [(SA015A1T)]    AT29C040A@TSOP32 [(SA410T)]  
 AT29C1024@PLCC44 [(SA244)]    AT29C1024@TSOP48 [(SA247-B005)]  
 AT29C256                    AT29C256@PLCC32 [(SA015A1T)]

AT29C256@TSOP28 [(SA430T)] AT29C257  
AT29C257@PLCC32 [(SA015A1T)] AT29C512  
AT29C512@PLCC32 [(SA015A1T)] AT29C512@TSOP32 [(SA410T)]  
AT29LV010 AT29LV010@PLCC32 [(SA015A1T)]  
AT29LV010@TSOP32 [(SA410T)] AT29LV010A@PLCC32 [(SA015A1T)]  
AT29LV010A@TSOP32 [(SA410T)] AT29LV020  
AT29LV020@PLCC32 [(SA015A1T)] AT29LV020@TSOP32 [(SA410T)]  
AT29LV040@TSOP32 [(SA410T)] AT29LV040A  
AT29LV040A@PLCC32 [(SA015A1T)] AT29LV040A@TSOP32 [(SA410T)]  
AT29LV1024@PLCC44 [(SA244)] AT29LV1024@TSOP48 [(SA247-B005)]  
AT29LV256 AT29LV256@PLCC32 [(SA015A1T)]  
AT29LV256@TSOP28 [(SA430T)] AT29LV512  
AT29LV512@PLCC32 [(SA015A1T)] AT29LV512@TSOP32 [(SA410T)]  
AT32C16 AT32C16@PLCC44 [(SA244)]  
AT34C02 AT34C02@SOIC8 [(SA602A)]  
AT34C02@TSSOP8 [(SA026)] AT34C02B  
AT34C02B@SOIC8 [(SA602A)] AT34C02B@TSSOP8 [(SA026)]  
AT34C02C AT34C02C@dBGA8 [(BBBB)]  
AT34C02C@MAP8 [(SA724)] AT34C02C@SOIC8 [(SA602A)]  
AT34C02C@TSSOP8 [(SA026)]  
AT45BCM021D(page256)@SOIC8 [(SA605A)]  
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45BCM021D(page264)@SOIC8 [(SA605A)]  
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45D011@PLCC32 [(SA015A1T)] AT45D011@SOIC8 [(SA605A)]  
AT45D011@TSSOP14 [(SA026)] AT45D021@PLCC32 [(SA015A1T)]  
AT45D021@SOIC28 [(SA630)] AT45D021@TSOP28 [(SA430T)]  
AT45D041@PLCC32 [(SA015A1T)] AT45D041@SOIC28 [(SA630)]  
AT45D041@TSOP28 [(SA430T)] AT45D081@SOIC28 [(SA630)]  
AT45D081@TSOP32 [(SA410T)] AT45D161@PLCC32 [(SA015A1T)]  
AT45D161@SOIC28 [(SA630)] AT45D161@TSOP28 [(SA430T)]  
AT45DB011@PLCC32 [(SA015A1T)] AT45DB011@SOIC8 [(SA605A)]  
AT45DB011@TSSOP14 [(SA026)] AT45DB011B@PLCC32 [(SA015A1T)]  
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]  
AT45DB011B@SOIC8 [(SA605A)]  
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB011B@TSSOP14 [(SA026)]  
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@QFN8 [ordering number is marked above]  
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@SOIC8 [ordering number is marked above]  
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28 [(SA630)]



AT45DB021@TSOP28 [(SA430T)]     AT45DB021A@PLCC32 [(SA015A1T)]  
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB021A@SOIC28 [(SA630)]  
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021A@TSOP28 [(SA430T)]  
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]  
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC28 [(SA630)]  
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC8 [(SA023A)]  
AT45DB021B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021B@TSOP28 [(SA430T)]  
AT45DB021B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@CASON8 [ordering number is marked above]  
AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@SOIC8 [ordering number is marked above]  
AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041@PLCC32 [(SA015A1T)]     AT45DB041@SOIC28 [(SA630)]  
AT45DB041@TSOP28 [(SA430T)]     AT45DB041A@PLCC32 [(SA015A1T)]  
AT45DB041A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB041A@SOIC28 [(SA630)]  
AT45DB041A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041A@TSOP28 [(SA430T)]  
AT45DB041A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041B@CASON8 [(SA684)]     AT45DB041B@CASON8(ISP) [(SA684)]  
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB041B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC28 [(SA630)]  
AT45DB041B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC8 [(SA605A)]  
AT45DB041B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041B@TSOP28 [(SA430T)]  
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@QFN8 [(SA683)]  
AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@SOIC8 [(SA605A)]  
AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@QFN8 [(SA683)]  
AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@SOIC8 [(SA605A)]  
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081@SOIC28 [(SA630)]     AT45DB081@TSOP32 [(SA410T)]

AT45DB081A@PLCC32 [(SA015A1T)]  
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB081A@SOIC28 [(SA630)]  
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081A@TSOP28 [(SA430T)]  
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP) [(SA684)]  
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB081B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC28 [(SA630)]  
AT45DB081B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC8 [(SA605A)]  
AT45DB081B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081B@TSOP28 [(SA430T)]  
AT45DB081B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@MLF8 [(SA683)]  
AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@SOIC8 [(SA023A)]  
AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@MLF8 [(SA683)]  
AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@SOIC8 [(SA023A)]  
AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28 [(SA630)]  
AT45DB161@TSOP28 [(SA430T)]  
AT45DB161B@CASON8(ISP) [ISP-HEADER01]  
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28 [(SA630)]  
AT45DB161B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB161B@TSOP28 [(SA430T)]  
AT45DB161B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@QFN8 [(SA683)]  
AT45DB161D(page512)@QFN8(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@SOIC8 [(SA605A)]  
AT45DB161D(page512)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161D(page512)@TSOP28 [(SA430T)]  
AT45DB161D(page512)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@QFN8 [(SA683)]  
AT45DB161D(page528)@QFN8(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@SOIC8 [(SA605A)]  
AT45DB161D(page528)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161D(page528)@TSOP28 [(SA430T)]  
AT45DB161D(page528)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28 [(SA630)]

AT45DB321B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB321B@TSOP32 [(SA410T)]  
AT45DB321B@TSOP32(ISP) [ISP-HEADER01]  
AT45DB321C@CAS0N8 [(SA684)]  
AT45DB321C@CAS0N8(ISP) [ISP-HEADER01]  
AT45DB321C@SOIC28 [(SA630)]  
AT45DB321C@SOIC28(ISP) [ISP-HEADER01]  
AT45DB321C@TSOP28 [(SA430T)]  
AT45DB321C@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@QFN8 [(SA683)]  
AT45DB321D(page512)@QFN8(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@SOIC8 [(SA023A)]  
AT45DB321D(page512)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@TSOP28 [(SA430T)]  
AT45DB321D(page512)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@QFN8 [(SA683)]  
AT45DB321D(page528)@QFN8(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@SOIC8 [(SA023A)]  
AT45DB321D(page528)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@TSOP28 [(SA430T)]  
AT45DB321D(page528)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB642@TSOP40 [(SA409T)]  
AT45DB642@TSOP40(ISP) [ISP-HEADER01]  
AT45DB642D(page1024)@CAS0N8 [(SA684)]  
AT45DB642D(page1024)@CAS0N8(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1024)@TSOP28 [(SA430)]  
AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@CAS0N8 [(SA684)]  
AT45DB642D(page1056)@CAS0N8(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@TSOP28 [(SA430)]  
AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]  
AT45DCB002 [(CARD005-B005)] AT45DCB002(ISP) [ISP-HEADER01]  
AT45DCB004 [(CARD005-B005)] AT45DCB004(ISP) [ISP-HEADER01]  
AT45DCB004C [(CARD005-B005)] AT45DCB004C(ISP) [ISP-HEADER01]  
AT45DCB008 [(CARD005-B005)] AT45DCB008(ISP) [ISP-HEADER01]  
AT45DCB008D4(page1024) [(CARD005-B005)]  
AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]  
AT45DCB008D6(page1056) [(CARD005-B005)]  
AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]  
AT49BV001 AT49BV001@PLCC32 [(SA015A1T)]  
AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32 [(SA620)]  
AT49BV001A AT49BV001A@PLCC32 [(SA015A1T)]  
AT49BV001A@TSOP32 [(SA410T)] AT49BV001A@VSOP32 [(SA620)]

AT49BV001AN AT49BV001AN@PLCC32 [(SA015A1T)]  
AT49BV001AN@TSOP32 [(SA410T)] AT49BV001AN@VSOP32 [(SA620)]  
AT49BV001ANT AT49BV001ANT@PLCC32 [(SA015A1T)]  
AT49BV001ANT@TSOP32 [(SA410T)] AT49BV001ANT@VSOP32 [(SA620)]  
AT49BV001AT AT49BV001AT@PLCC32 [(SA015A1T)]  
AT49BV001AT@TSOP32 [(SA410T)] AT49BV001AT@VSOP32 [(SA620)]  
AT49BV001N AT49BV001N@PLCC32 [(SA015A1T)]  
AT49BV001N@TSOP32 [(SA410T)] AT49BV001N@VSOP32 [(SA620)]  
AT49BV001NT AT49BV001NT@PLCC32 [(SA015A1T)]  
AT49BV001NT@TSOP32 [(SA410T)] AT49BV001NT@VSOP32 [(SA620)]  
AT49BV001T AT49BV001T@PLCC32 [(SA015A1T)]  
AT49BV001T@TSOP32 [(SA410T)] AT49BV001T@VSOP32 [(SA620)]  
AT49BV002 AT49BV002@PLCC32 [(SA015A1T)]  
AT49BV002@TSOP32 [(SA410T)] AT49BV002@VSOP32 [(SA620)]  
AT49BV002A AT49BV002A@PLCC32 [(SA015A1T)]  
AT49BV002A@TSOP32 [(SA410T)] AT49BV002A@VSOP32 [(SA620)]  
AT49BV002AN AT49BV002AN@PLCC32 [(SA015A1T)]  
AT49BV002AN@TSOP32 [(SA410T)] AT49BV002AN@VSOP32 [(SA620)]  
AT49BV002ANT AT49BV002ANT@PLCC32 [(SA015A1T)]  
AT49BV002ANT@TSOP32 [(SA410T)] AT49BV002ANT@VSOP32 [(SA620)]  
AT49BV002AT AT49BV002AT@PLCC32 [(SA015A1T)]  
AT49BV002AT@TSOP32 [(SA410T)] AT49BV002AT@VSOP32 [(SA620)]  
AT49BV002N AT49BV002N@PLCC32 [(SA015A1T)]  
AT49BV002N@TSOP32 [(SA410T)] AT49BV002N@VSOP32 [(SA620)]  
AT49BV002NT AT49BV002NT@PLCC32 [(SA015A1T)]  
AT49BV002NT@TSOP32 [(SA410T)] AT49BV002NT@VSOP32 [(SA620)]  
AT49BV002T AT49BV002T@PLCC32 [(SA015A1T)]  
AT49BV002T@TSOP32 [(SA410T)] AT49BV002T@VSOP32 [(SA620)]  
AT49BV008@TSOP40 [(SA409T)] AT49BV008A@TSOP40 [(SA409T)]  
AT49BV008A@uBGA48 [(SA634)] AT49BV008AT@TSOP40 [(SA409T)]  
AT49BV008AT@uBGA48 [(SA634)] AT49BV010  
AT49BV010@PLCC32 [(SA015A1T)] AT49BV010@TSOP32 [(SA410T)]  
AT49BV020 AT49BV020@PLCC32 [(SA015A1T)]  
AT49BV020@TSOP32 [(SA410T)] AT49BV040  
AT49BV040@PLCC32 [(SA015A1T)] AT49BV040@TSOP32 [(SA410T)]  
AT49BV040A@PLCC32 [(SA015A1T)] AT49BV040A@TSOP32 [(SA410T)]  
AT49BV040A@VSOP32 [(SA620)]  
AT49BV040B@PLCC32 [(SA015A1T-B001)]  
AT49BV040B@TSOP32 [(SA410T-B003)]  
AT49BV040B@VSOP32 [(SA620-B005)] AT49BV040T  
AT49BV040T@PLCC32 [(SA015A1T)] AT49BV040T@TSOP32 [(SA410T)]  
AT49BV080@PSOP44 [(SA638)] AT49BV080@TSOP40 [(SA409T)]  
AT49BV080T@PSOP44 [(SA638)] AT49BV080T@TSOP40 [(SA409T)]

AT49BV1024A@TSOP40 [(SA623)] AT49BV160@TSOP48 [(SA247-B005)]  
AT49BV160@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV1604@TSOP48 [(SA247-B005)]  
AT49BV1604@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV1604A@TSOP48 [(SA247-B005)]  
AT49BV1604A@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV1604AT@TSOP48 [(SA247-B005)]  
AT49BV1604AT@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV1604T@TSOP48 [(SA247-B005)]  
AT49BV1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV160C@TSOP48 [(SA247-B005)]  
AT49BV160C@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV160CT@TSOP48 [(SA247-B005)]  
AT49BV160CT@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV160D@TSOP48 [(SA247-B005)]  
AT49BV160DT@TSOP48 [(SA247-B005)]  
AT49BV160S@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV160ST@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV160T@TSOP48 [(SA247-B005)]  
AT49BV160T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV161@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV161@TSOP48 [(SA247-B005)]  
AT49BV1614@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1614@TSOP48 [(SA247-B005)]  
AT49BV1614A@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1614A@TSOP48 [(SA247-B005)]  
AT49BV1614AT@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1614AT@TSOP48 [(SA247-B005)]  
AT49BV1614T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1614T@TSOP48 [(SA247-B005)]  
AT49BV1618@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1618@TSOP48 [(SA247-B005)]  
AT49BV1618T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV1618T@TSOP48 [(SA247-B005)]  
AT49BV161T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV161T@TSOP48 [(SA247-B005)]  
AT49BV162A@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV162A@TSOP48 [(SA247-B005)]  
AT49BV162AT@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV162AT@TSOP48 [(SA247-B005)]  
AT49BV163A@CBGA48 [(SA642G-B026A-T048F001Y)]  
AT49BV163A@TSOP48 [(SA247-B005)]  
AT49BV163AT@CBGA48 [(SA642G-B026A-T048F001Y)]

AT49BV163AT@TSOP48 [(SA247-B005)]  
AT49BV163D@FBGA48 [(SA642G-B026A-T048F001Y)]  
AT49BV163D@TSOP48 [(SA247-B005)]  
AT49BV163DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
AT49BV163DT@TSOP48 [(SA247-B005)]  
AT49BV2048@PSOP44 [(SA638)] AT49BV2048@TSOP48 [(SA247-B005)]  
AT49BV2048A@PSOP44 [(SA638)]  
AT49BV2048A@TSOP48 [(SA247-B005)]  
AT49BV2048B@TSOP48 [(SA247-B005)]  
AT49BV320@TSOP48 [(SA247-B005)]  
AT49BV320@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV320C@TSOP48 [(SA247-B005)]  
AT49BV320C@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV320CT@TSOP48 [(SA247-B005)]  
AT49BV320CT@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV320D@FBGA48 [(SA634A-B005A-Y048F001Y)]  
AT49BV320D@TSOP48 [(SA247-B005)]  
AT49BV320DT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
AT49BV320DT@TSOP48 [(SA247-B005)]  
AT49BV320S@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV320ST@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV320T@TSOP48 [(SA247-B005)]  
AT49BV320T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV321@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV321@TSOP48 [(SA247-B005)]  
AT49BV3218@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV3218@TSOP48 [(SA247-B005)]  
AT49BV3218T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV3218T@TSOP48 [(SA247-B005)]  
AT49BV321T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49BV321T@TSOP48 [(SA247-B005)]  
AT49BV322A@FBGA48 [(SA642F-B026A-T064F001)]  
AT49BV322A@TSOP48 [(SA247-B005)]  
AT49BV322AT@FBGA48 [(SA642F-B026A-T064F001)]  
AT49BV322AT@TSOP48 [(SA247-B005)]  
AT49BV322D@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49BV322D@TSOP48 [(SA247-B005)]  
AT49BV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49BV322DT@TSOP48 [(SA247-B005)]  
AT49BV4096@PSOP44 [(SA638)] AT49BV4096@TSOP48 [(SA247-B005)]  
AT49BV4096A@PSOP44 [(SA638)]  
AT49BV4096A@TSOP48 [(SA247-B005)]  
AT49BV4096A@uBGA48 [(SA634A-B005A-Y048F001)]

AT49BV512 AT49BV512@PLCC32 [(SA015A1T)]  
AT49BV512@TSOP32 [(SA410T)] AT49BV512@VSOP32 [(SA620)]  
AT49BV640D@FBGA48 [(SA634A-B005A-Y048F001Y)]  
AT49BV640D@TSOP56 [(SA628-B131)]  
AT49BV640DT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
AT49BV640DT@TSOP56 [(SA628-B131)]  
AT49BV640S@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV640ST@FBGA64 [(SA705A-B147A-W064F001Y)]  
AT49BV6416@TSOP48 [(SA247-B005)]  
AT49BV6416T@TSOP48 [(SA247-B005)]  
AT49BV642D@TSOP48 [(SA247-B005)]  
AT49BV642DT@TSOP48 [(SA247-B005)]  
AT49BV8004@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV8004@TSOP48 [(SA247-B005)]  
AT49BV8004T@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV8004T@TSOP48 [(SA247-B005)]  
AT49BV8011@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV8011@TSOP48 [(SA247-B005)]  
AT49BV8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV8011T@TSOP48 [(SA247-B005)]  
AT49BV802A@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV802A@TSOP48 [(SA247-B005)]  
AT49BV802AT@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49BV802AT@TSOP48 [(SA247-B005)]  
AT49BV802D@CBGA48 [(SA642G-B026A-T048F001Y)]  
AT49BV802D@TSOP48 [(SA247)]  
AT49BV802DT@CBGA48 [(SA642G-B026A-T048F001Y)]  
AT49BV802DT@TSOP48 [(SA247)] AT49BV8192@PSOP44 [(SA638)]  
AT49BV8192@TSOP48 [(SA247-B005)]  
AT49BV8192A@TSOP48 [(SA247-B005)]  
AT49BV8192A@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV8192AT@TSOP48 [(SA247-B005)]  
AT49BV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49BV8192T@PSOP44 [(SA638)]  
AT49BV8192T@TSOP48 [(SA247-B005)]  
AT49F001 AT49F001@PLCC32 [(SA015A1T)]  
AT49F001@TSOP32 [(SA410T)] AT49F001@VSOP32 [(SA620)]  
AT49F001A AT49F001A@PLCC32 [(SA015A1T)]  
AT49F001A@TSOP32 [(SA410T)] AT49F001A@VSOP32 [(SA620)]  
AT49F001AN AT49F001AN@PLCC32 [(SA015A1T)]  
AT49F001AN@TSOP32 [(SA410T)] AT49F001AN@VSOP32 [(SA620)]  
AT49F001ANT AT49F001ANT@PLCC32 [(SA015A1T)]  
AT49F001ANT@TSOP32 [(SA410T)] AT49F001ANT@VSOP32 [(SA620)]

AT49F001AT AT49F001AT@PLCC32 [(SA015A1T)]  
AT49F001AT@TSOP32 [(SA410T)] AT49F001AT@VSOP32 [(SA620)]  
AT49F001N AT49F001N@PLCC32 [(SA015A1T)]  
AT49F001N@TSOP32 [(SA410T)] AT49F001N@VSOP32 [(SA620)]  
AT49F001NT AT49F001NT@PLCC32 [(SA015A1T)]  
AT49F001NT@TSOP32 [(SA410T)] AT49F001NT@VSOP32 [(SA620)]  
AT49F001T AT49F001T@PLCC32 [(SA015A1T)]  
AT49F001T@TSOP32 [(SA410T)] AT49F001T@VSOP32 [(SA620)]  
AT49F002 AT49F002@PLCC32 [(SA015A1T)]  
AT49F002@TSOP32 [(SA410T)] AT49F002@VSOP32 [(SA620)]  
AT49F002A AT49F002A@PLCC32 [(SA015A1T)]  
AT49F002A@TSOP32 [(SA410T)] AT49F002A@VSOP32 [(SA620)]  
AT49F002AN AT49F002AN@PLCC32 [(SA015A1T)]  
AT49F002AN@TSOP32 [(SA410T)] AT49F002AN@VSOP32 [(SA620)]  
AT49F002ANT AT49F002ANT@PLCC32 [(SA015A1T)]  
AT49F002ANT@TSOP32 [(SA410T)] AT49F002ANT@VSOP32 [(SA620)]  
AT49F002AT AT49F002AT@PLCC32 [(SA015A1T)]  
AT49F002AT@TSOP32 [(SA410T)] AT49F002AT@VSOP32 [(SA620)]  
AT49F002N AT49F002N@PLCC32 [(SA015A1T)]  
AT49F002N@TSOP32 [(SA410T)] AT49F002N@VSOP32 [(SA620)]  
AT49F002NT AT49F002NT@PLCC32 [(SA015A1T)]  
AT49F002NT@TSOP32 [(SA410T)] AT49F002NT@VSOP32 [(SA620)]  
AT49F002T AT49F002T@PLCC32 [(SA015A1T)]  
AT49F002T@TSOP32 [(SA410T)] AT49F002T@VSOP32 [(SA620)]  
AT49F008@TSOP40 [(SA409T)] AT49F008A@TSOP40 [(SA409T)]  
AT49F008AT@TSOP40 [(SA409T)] AT49F010  
AT49F010@PLCC32 [(SA015A1T)] AT49F010@TSOP32 [(SA410T)]  
AT49F020 AT49F020@PLCC32 [(SA015A1T)]  
AT49F020@TSOP32 [(SA410T)] AT49F040  
AT49F040@PLCC32 [(SA015A1T)] AT49F040@TSOP32 [(SA410T)]  
AT49F040A AT49F040A@PLCC32 [(SA015A1T)]  
AT49F040A@TSOP32 [(SA410T)] AT49F080@PSOP44 [(SA638)]  
AT49F080@TSOP40 [(SA409T)] AT49F080T@PSOP44 [(SA638)]  
AT49F080T@TSOP40 [(SA409T)] AT49F1024@TSOP40 [(SA623)]  
AT49F1024A@TSOP40 [(SA623)] AT49F1025@PLCC44 [(SA244)]  
AT49F1604@TSOP48 [(SA247-B005)]  
AT49F1604@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49F1604T@TSOP48 [(SA247-B005)]  
AT49F1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49F1614@CBGA48 [(SA642F-B026A-T064F001)]  
AT49F1614@TSOP48 [(SA247-B005)]  
AT49F1614T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49F1614T@TSOP48 [(SA247-B005)] AT49F2048@PSOP44 [(SA638)]



AT49F2048@TSOP48 [(SA247-B005)] AT49F2048A@PSOP44 [(SA638)]  
AT49F2048A@TSOP48 [(SA247-B005)] AT49F4096@PSOP44 [(SA638)]  
AT49F4096@TSOP48 [(SA247-B005)]  
AT49F4096A@CBGA48 [(SA642F-B026A-T064F001)]  
AT49F4096A@PSOP44 [(SA638)] AT49F4096A@TSOP48 [(SA247-B005)]  
AT49F4096A@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49F512 AT49F512@PLCC32 [(SA015A1T)]  
AT49F512@TSOP32 [(SA410T)] AT49F512@VSOP32 [(SA620)]  
AT49F516@PLCC44 [(SA244)] AT49F516@TSOP40 [(SA623)]  
AT49F8004@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49F8004@TSOP48 [(SA247-B005)]  
AT49F8004T@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49F8004T@TSOP48 [(SA247-B005)]  
AT49F8011@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49F8011@TSOP48 [(SA247-B005)]  
AT49F8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49F8011T@TSOP48 [(SA247-B005)] AT49F8192@PSOP44 [(SA638)]  
AT49F8192@TSOP48 [(SA247-B005)] AT49F8192A@PSOP44 [(SA638)]  
AT49F8192A@TSOP48 [(SA247-B005)] AT49F8192AT@PSOP44 [(SA638)]  
AT49F8192AT@TSOP48 [(SA247-B005)]  
AT49F8192T@PSOP44 [(SA638)] AT49F8192T@TSOP48 [(SA247-B005)]  
AT49HBV010 AT49HBV010@PLCC32 [(SA015A1T)]  
AT49HBV010@TSOP32 [(SA410T)] AT49HF010  
AT49HF010@PLCC32 [(SA015A1T)] AT49HF010@TSOP32 [(SA410T)]  
AT49HLV010 AT49HLV010@PLCC32 [(SA015A1T)]  
AT49HLV010@TSOP32 [(SA410T)] AT49LH002@PLCC32 [(SA015A1T)]  
AT49LH002@TSOP40 [(SA409T)] AT49LH004@PLCC32 [(SA015A1T)]  
AT49LH004@TSOP40 [(SA409T)] AT49LH00B4@PLCC32 [(SA015A1T)]  
AT49LH00B4@TSOP40 [(SA409T)] AT49LL020@PLCC32 [(SA015A1T)]  
AT49LL020@TSOP40 [(SA409T)] AT49LL040@PLCC32 [(SA015A1T)]  
AT49LL040@TSOP40 [(SA409T)] AT49LL080@PLCC32 [(SA015A1T)]  
AT49LL080@TSOP40 [(SA409T)] AT49LV001  
AT49LV001@PLCC32 [(SA015A1T)] AT49LV001@TSOP32 [(SA410T)]  
AT49LV001@VSOP32 [(SA620)] AT49LV001N  
AT49LV001N@PLCC32 [(SA015A1T)] AT49LV001N@TSOP32 [(SA410T)]  
AT49LV001N@VSOP32 [(SA620)] AT49LV001NT  
AT49LV001NT@PLCC32 [(SA015A1T)] AT49LV001NT@TSOP32 [(SA410T)]  
AT49LV001NT@VSOP32 [(SA620)] AT49LV001T  
AT49LV001T@PLCC32 [(SA015A1T)] AT49LV001T@TSOP32 [(SA410T)]  
AT49LV001T@VSOP32 [(SA620)] AT49LV002  
AT49LV002@PLCC32 [(SA015A1T)] AT49LV002@TSOP32 [(SA410T)]  
AT49LV002@VSOP32 [(SA620)] AT49LV002N  
AT49LV002N@PLCC32 [(SA015A1T)] AT49LV002N@TSOP32 [(SA410T)]

AT49LV002N@VSOP32 [(SA620)] AT49LV002NT  
AT49LV002NT@PLCC32 [(SA015A1T)] AT49LV002NT@TSOP32 [(SA410T)]  
AT49LV002NT@VSOP32 [(SA620)] AT49LV002T  
AT49LV002T@PLCC32 [(SA015A1T)] AT49LV002T@TSOP32 [(SA410T)]  
AT49LV002T@VSOP32 [(SA620)] AT49LV008@TSOP40 [(SA409T)]  
AT49LV008A@TSOP40 [(SA409T)] AT49LV008A@uBGA48 [(SA634)]  
AT49LV008AT@TSOP40 [(SA409T)] AT49LV008AT@uBGA48 [(SA634)]  
AT49LV010 AT49LV010@PLCC32 [(SA015A1T)]  
AT49LV010@TSOP32 [(SA410T)] AT49LV020  
AT49LV020@PLCC32 [(SA015A1T)] AT49LV020@TSOP32 [(SA410T)]  
AT49LV040 AT49LV040@PLCC32 [(SA015A1T)]  
AT49LV040@TSOP32 [(SA410T)] AT49LV040T  
AT49LV040T@PLCC32 [(SA015A1T)] AT49LV040T@TSOP32 [(SA410T)]  
AT49LV080@PSOP44 [(SA638)] AT49LV080@TSOP40 [(SA409T)]  
AT49LV080T@PSOP44 [(SA638)] AT49LV080T@TSOP40 [(SA409T)]  
AT49LV1024@TSOP40 [(SA623)] AT49LV1024A@TSOP40 [(SA623)]  
AT49LV1025@PLCC44 [(SA244)] AT49LV160@TSOP48 [(SA247-B005)]  
AT49LV160@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV1604@TSOP48 [(SA247-B005)]  
AT49LV1604@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV1604T@TSOP48 [(SA247-B005)]  
AT49LV1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV161@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV161@TSOP48 [(SA247-B005)]  
AT49LV1614@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV1614@TSOP48 [(SA247-B005)]  
AT49LV1614A@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV1614A@TSOP48 [(SA247-B005)]  
AT49LV1614AT@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV1614AT@TSOP48 [(SA247-B005)]  
AT49LV1614T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV1614T@TSOP48 [(SA247-B005)]  
AT49LV161T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV161T@TSOP48 [(SA247-B005)] AT49LV2048@PSOP44 [(SA638)]  
AT49LV2048@TSOP48 [(SA247-B005)] AT49LV2048A@PSOP44 [(SA638)]  
AT49LV2048A@TSOP48 [(SA247-B005)]  
AT49LV2048B@TSOP48 [(SA247-B005)]  
AT49LV320@TSOP48 [(SA247-B005)]  
AT49LV320@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV320T@TSOP48 [(SA247-B005)]  
AT49LV320T@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV321@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV321@TSOP48 [(SA247-B005)]

AT49LV3218@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV3218@TSOP48 [(SA247-B005)]  
AT49LV3218T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV3218T@TSOP48 [(SA247-B005)]  
AT49LV321T@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV321T@TSOP48 [(SA247-B005)]  
AT49LV4096A@CBGA48 [(SA642F-B026A-T064F001)]  
AT49LV4096A@PSOP44 [(SA638)]  
AT49LV4096A@TSOP48 [(SA247-B005)]  
AT49LV4096A@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV8011@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49LV8011@TSOP48 [(SA247-B005)]  
AT49LV8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
AT49LV8011T@TSOP48 [(SA247-B005)]  
AT49LV8192@PSOP44 [(SA638)] AT49LV8192@TSOP48 [(SA247-B005)]  
AT49LV8192A@TSOP48 [(SA247-B005)]  
AT49LV8192A@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LV8192AT@TSOP48 [(SA247-B005)]  
AT49LV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]  
AT49LW040@PLCC32 [(SA015A1T)] AT49LW040@TSOP40 [(SA409T)]  
AT49LW080@PLCC32 [(SA015A1T)] AT49LW080@TSOP40 [(SA409T)]  
AT49SV163D@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV163D@TSOP48 [(SA247-B005)]  
AT49SV163DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV163DT@TSOP48 [(SA247-B005)]  
AT49SV322A@CBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV322A@TSOP48 [(SA247-B005)]  
AT49SV322AT@CBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV322AT@TSOP48 [(SA247-B005)]  
AT49SV322D@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV322D@TSOP48 [(SA247-B005)]  
AT49SV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
AT49SV322DT@TSOP48 [(SA247-B005)]  
AT49SV802A@CBGA48 [(SA642G-B026A-T048F001Y)]  
AT49SV802A@TSOP48 [(SA247-B005)]  
AT49SV802AT@CBGA48 [(SA642G-B026A-T048F001Y)]  
AT49SV802AT@TSOP48 [(SA247-B005)]  
AT52BC1660A@FBGA66 [(SA642R-B023A-T096F001Y)]  
AT52BC1660AT@FBGA66 [(SA642R-B023A-T096F001Y)]  
AT52BC1661A@FBGA66 [(SA642R-B023A-T096F001Y)]  
AT52BC1661AT@FBGA66 [(SA642R-B023A-T096F001Y)]  
AT52BC3221A@FBGA66 [(SA642R-B023A-T080F001Y)]  
AT52BC3221AT@FBGA66 [(SA642R-B023A-T080F001Y)]

AT52BC3221D@FBGA66 [(SA642R-B023A-T080F001Y)]  
AT52BC3221DT@FBGA66 [(SA642R-B023A-T080F001Y)]  
AT52BC6402A@FBGA66 [(SA642B-B023A-Y072F001Y)]  
AT52BC6402AT@FBGA66 [(SA642B-B023A-Y072F001Y)]  
AT52BR1662@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1662A@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1662AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1662T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1664@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1664A@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1664AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1664T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1672@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1672T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1674@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR1674T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3224@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3224A@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3224AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3224T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228A@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]  
AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]  
AT59C11                    AT59C11@SOIC8 [(SA602A)]  
AT59C12                    AT59C12@SOIC8 [(SA602A)]  
AT59C13                    AT59C13@SOIC8 [(SA602A)]  
AT59C22                    AT59C22@SOIC8 [(SA602A)]  
AT93C46(08bit)            AT93C46(08bit)@SOIC8 [(SA602A)]  
AT93C46(08bit)@TSSOP8 [(SA026)]    AT93C46(16bit)  
AT93C46(16bit)@SOIC8 [(SA602A)]    AT93C46(16bit)@TSSOP8 [(SA026)]  
AT93C46A                    AT93C46A@SOIC8 [(SA602A)]  
AT93C46A@TSSOP8 [(SA026)]            AT93C46C  
AT93C46C@SOIC8 [(SA602A)]            AT93C46C@TSSOP8 [(SA026)]  
AT93C46D(08bit)            AT93C46D(08bit)@dBGA8 [(BBBB)]  
AT93C46D(08bit)@MAP8 [(SA724)]    AT93C46D(08bit)@SOIC8 [(SA602A)]  
AT93C46D(08bit)@TSSOP8 [(SA026)]    AT93C46D(16bit)

AT93C46D(16bit)@dBGA8 [(BBBB)] AT93C46D(16bit)@MAP8 [(SA724)]  
 AT93C46D(16bit)@SOIC8 [(SA602A)] AT93C46D(16bit)@TSSOP8 [(SA026)]  
 AT93C46E AT93C46E@SOIC8 [(SA602A)]  
 AT93C46E@TSSOP8 [(SA026)] AT93C56(08bit)  
 AT93C56(08bit)@SOIC8 [(SA602A)] AT93C56(16bit)  
 AT93C56(16bit)@SOIC8 [(SA602A)] AT93C56A(08bit)  
 AT93C56A(08bit)@SOIC8 [(SA602A)] AT93C56A(08bit)@TSSOP8 [(SA026)]  
 AT93C56A(16bit) AT93C56A(16bit)@SOIC8 [(SA602A)]  
 AT93C56A(16bit)@TSSOP8 [(SA026)] AT93C57  
 AT93C57@SOIC8 [(SA602A)] AT93C66(08bit)  
 AT93C66(08bit)@SOIC8 [(SA602A)] AT93C66(16bit)  
 AT93C66(16bit)@SOIC8 [(SA602A)] AT93C66A(08bit)  
 AT93C66A(08bit)@SOIC8 [(SA602A)] AT93C66A(08bit)@TSSOP8 [(SA026)]  
 AT93C66A(16bit) AT93C66A(16bit)@SOIC8 [(SA602A)]  
 AT93C66A(16bit)@TSSOP8 [(SA026)] AT93C86(08bit)  
 AT93C86(08bit)@SOIC8 [(SA602A)] AT93C86(08bit)@TSSOP8 [(SA026)]  
 AT93C86(16bit) AT93C86(16bit)@SOIC8 [(SA602A)]  
 AT93C86(16bit)@TSSOP8 [(SA026)] AT93C86A(08bit)  
 AT93C86A(08bit)@SOIC8 [(SA602A)] AT93C86A(08bit)@TSSOP8 [(SA026)]  
 AT93C86A(16bit) AT93C86A(16bit)@SOIC8 [(SA602A)]  
 AT93C86A(16bit)@TSSOP8 [(SA026)]

## DRAM & SRAM

AT3864L AT3864L@TSOP28 [(SA643)]  
 AT38H256 AT38H256@TSOP28 [(SA643)]

## PLD

ATF16LV8C ATF16LV8C@PLCC20 [(SA001A)]  
 ATF16LV8C@SOIC20 [(SA404)] ATF16LV8C@TSOP20 [(SA026)]  
 ATF16LV8CEXT ATF16LV8CEXT@PLCC20 [(SA001A)]  
 ATF16LV8CEXT@SOIC20 [(SA404)] ATF16LV8CEXT@TSOP20 [(SA026)]  
 ATF16V8B ATF16V8B@PLCC20 [(SA001A)]  
 ATF16V8B@SOIC20 [(SA404)] ATF16V8B@TSOP20 [(SA026)]  
 ATF16V8BL ATF16V8BL@PLCC20 [(SA001A)]  
 ATF16V8BL@SOIC20 [(SA404)] ATF16V8BL@TSOP20 [(SA026)]  
 ATF16V8BQ ATF16V8BQ@PLCC20 [(SA001A)]  
 ATF16V8BQ@SOIC20 [(SA404)] ATF16V8BQ@TSOP20 [(SA026)]  
 ATF16V8BQL ATF16V8BQL@PLCC20 [(SA001A)]  
 ATF16V8BQL@SOIC20 [(SA404)] ATF16V8BQL@TSOP20 [(SA026)]

ATF16V8C ATF16V8C@PLCC20 [(SA001A)]  
ATF16V8C@SOIC20 [(SA404)] ATF16V8C@TSOP20 [(SA026)]  
ATF16V8CEXT ATF16V8CEXT@PLCC20 [(SA001A)]  
ATF16V8CEXT@SOIC20 [(SA404)] ATF16V8CEXT@TSOP20 [(SA026)]  
ATF16V8CZ ATF16V8CZ@PLCC20 [(SA001A)]  
ATF16V8CZ@SOIC20 [(SA404)] ATF16V8CZ@TSOP20 [(SA026)]  
ATF20V8B ATF20V8B@PLCC28 [(SA008A)]  
ATF20V8B@SOIC24 [(SA404)] ATF20V8BL  
ATF20V8BL@PLCC28 [(SA008A)] ATF20V8BL@SOIC24 [(SA404)]  
ATF20V8BQ ATF20V8BQ@PLCC28 [(SA008A)]  
ATF20V8BQ@SOIC24 [(SA404)] ATF20V8BQL  
ATF20V8BQL@PLCC28 [(SA008A)] ATF20V8BQL@SOIC24 [(SA404)]  
ATF22LV10C ATF22LV10C(UES)  
ATF22LV10C(UES)@PLCC28 [(SA008A)]  
ATF22LV10C(UES)@SOIC24 [(SA404)]  
ATF22LV10C(UES)@TSSOP24 [(SA643)]  
ATF22LV10C@PLCC28 [(SA008A)] ATF22LV10C@SOIC24 [(SA404)]  
ATF22LV10C@TSSOP24 [(SA643)] ATF22LV10CEXT  
ATF22LV10CEXT@PLCC28 [(SA008A)] ATF22LV10CEXT@SOIC24 [(SA404)]  
ATF22LV10CEXT@TSSOP24 [(SA643)] ATF22LV10CQ  
ATF22LV10CQ(UES)  
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQ@PLCC28 [(SA008A)] ATF22LV10CQ@SOIC24 [(SA404)]  
ATF22LV10CQ@TSSOP24 [(SA643)] ATF22LV10CQZ  
ATF22LV10CQZ(UES)  
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQZ@PLCC28 [(SA008A)] ATF22LV10CQZ@SOIC24 [(SA404)]  
ATF22LV10CQZ@TSSOP24 [(SA643)] ATF22LV10CZ  
ATF22LV10CZ(UES)  
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CZ@PLCC28 [(SA008A)] ATF22LV10CZ@SOIC24 [(SA404)]  
ATF22LV10CZ@TSSOP24 [(SA643)] ATF22V10B  
ATF22V10B(UES) ATF22V10B(UES)@PLCC28 [(SA008A)]  
ATF22V10B(UES)@SOIC24 [(SA404)] ATF22V10B@PLCC28 [(SA008A)]  
ATF22V10B@SOIC24 [(SA404)] ATF22V10BL  
ATF22V10BL(UES)  
ATF22V10BL(UES)@PLCC28 [(SA008A)]

ATF22V10BL(UES)@SOIC24 [(SA404)] ATF22V10BL@PLCC28 [(SA008A)]  
ATF22V10BL@SOIC24 [(SA404)] ATF22V10BQ  
ATF22V10BQ(UES)  
ATF22V10BQ(UES)@PLCC28 [(SA008A)]  
ATF22V10BQ(UES)@SOIC24 [(SA404)] ATF22V10BQ@PLCC28 [(SA008A)]  
ATF22V10BQ@SOIC24 [(SA404)] ATF22V10BQL  
ATF22V10BQL(UES)  
ATF22V10BQL(UES)@PLCC28 [(SA008A)]  
ATF22V10BQL(UES)@SOIC24 [(SA404)]  
ATF22V10BQL@PLCC28 [(SA008A)] ATF22V10BQL@SOIC24 [(SA404)]  
ATF22V10C ATF22V10C(UES)  
ATF22V10C(UES)@PLCC28 [(SA008A)] ATF22V10C(UES)@SOIC24 [(SA404)]  
ATF22V10C(UES)@TSSOP24 [(SA643)] ATF22V10C@PLCC28 [(SA008A)]  
ATF22V10C@SOIC24 [(SA404)] ATF22V10C@TSSOP24 [(SA643)]  
ATF22V10CEXT ATF22V10CEXT@PLCC28 [(SA008A)]  
ATF22V10CEXT@SOIC24 [(SA404)] ATF22V10CEXT@TSSOP24 [(SA643)]  
ATF22V10CQ ATF22V10CQ(UES)  
ATF22V10CQ(UES)@PLCC28 [(SA008A)]  
ATF22V10CQ(UES)@SOIC24 [(SA404)]  
ATF22V10CQ(UES)@TSSOP24 [(SA643)]  
ATF22V10CQ@PLCC28 [(SA008A)] ATF22V10CQ@SOIC24 [(SA404)]  
ATF22V10CQ@TSSOP24 [(SA643)] ATF22V10CQZ  
ATF22V10CQZ(UES)  
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]  
ATF22V10CQZ(UES)@SOIC24 [(SA404)]  
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22V10CQZ@PLCC28 [(SA008A)] ATF22V10CQZ@SOIC24 [(SA404)]  
ATF22V10CQZ@TSSOP24 [(SA643)] ATF22V10CZ  
ATF22V10CZ(UES)  
ATF22V10CZ(UES)@PLCC28 [(SA008A)]  
ATF22V10CZ(UES)@SOIC24 [(SA404)]  
ATF22V10CZ(UES)@TSSOP24 [(SA643)]  
ATF22V10CZ@PLCC28 [(SA008A)] ATF22V10CZ@SOIC24 [(SA404)]  
ATF22V10CZ@TSSOP24 [(SA643)] ATF750C (ATF750C mode)  
ATF750C (ATV750 mode) ATF750C (ATV750B mode)  
ATF750C@PLCC28 (ATF750C mode) [(SA008A)]  
ATF750C@PLCC28 (ATV750 mode) [(SA008A)]  
ATF750C@PLCC28 (ATV750B mode) [(SA008A)]  
ATF750C@SOIC24 (ATF750C mode) [(SA404)]  
ATF750C@SOIC24 (ATV750 mode) [(SA404)]  
ATF750C@SOIC24 (ATV750B mode) [(SA404)]  
ATF750CEXT (ATF750C mode)  
ATF750CEXT@PLCC28 (ATF750C mode) [(SA008A)]

ATF750CEXT@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750CL (ATV750 mode) ATF750CL (ATV750B mode)  
 ATF750CL@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750CL@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750CL@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750CL@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)  
 ATF750LVC (ATV750B mode)  
 ATF750LVC@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750LVC@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750LVC@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750LVCEXT (ATF750C mode)  
 ATF750LVCEXT@PLCC28(ATF750Cmode) [(SA008A)]  
 ATF750LVCEXT@SOIC24(ATF750Cmode) [(SA404)]  
 ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)  
 ATF750LVCL (ATV750B mode)  
 ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]  
 ATV750 ATF750@PLCC28 [(SA008A)]  
 ATV750@SOIC24 [(SA404)] ATF750B  
 ATV750B@PLCC28 [(SA008A)] ATF750B@SOIC24 [(SA404)]  
 ATV750BL ATF750BL@PLCC28 [(SA008A)]  
 ATV750BL@SOIC24 [(SA404)] ATF750L  
 ATV750L@PLCC28 [(SA008A)] ATF750L@SOIC24 [(SA404)]

## MICROCONTROLLER

AT80F51 AT80F51@PLCC44 [(SA244)]  
 AT80F51@TQFP44 [(SA245A)] AT80F52  
 AT80F52@PLCC44 [(SA244)] AT80F52@TQFP44 [(SA245A)]  
 AT87F51 AT87F51@PLCC44 [(SA244)]  
 AT87F51@TQFP44 [(SA245A)] AT87F51RC  
 AT87F51RC@PLCC44 [(SA244)] AT87F51RC@TQFP44 [(SA245A)]  
 AT87F52 AT87F52@PLCC44 [(SA244)]  
 AT87F52@TQFP44 [(SA245A)] AT87F55



AT87F55@PLCC44 [(SA244)] AT87F55@TQFP44 [(SA245A)]  
AT87F55WD AT87F55WD@PLCC44 [(SA244)]  
AT87F55WD@TQFP44 [(SA245A)] AT87LV51  
AT87LV51@PLCC44 [(SA244)] AT87LV51@TQFP44 [(SA245A)]  
AT87LV52 AT87LV52@PLCC44 [(SA244)]  
AT87LV52@TQFP44 [(SA245A)] AT89C1051  
AT89C1051@SOIC20 [(SA404)] AT89C1051U  
AT89C1051U@SOIC20 [(SA404)] AT89C2051  
AT89C2051@SOIC20 [(SA404)] AT89C2051X2  
AT89C2051X2@SOIC20 [(SA404)] AT89C4051  
AT89C4051@SOIC20 [(SA404)] AT89C51  
AT89C51@PLCC44 [(SA244)] AT89C51@TQFP44 [(SA245A)]  
AT89C5130A@QFN32 [(SA686)] AT89C5130A@SOIC28 [(SA404)]  
AT89C5130AM@QFN32 [(SA686)] AT89C5130AM@SOIC28 [(SA404)]  
AT89C5131@MLF48 [(SA696)] AT89C5131@SOIC28 [(SA404)]  
AT89C5131A@QFN32 [(SA701)] AT89C5131A@SOIC28 [(SA404)]  
AT89C5131AL@QFN32 [(SA701)] AT89C5131AL@SOIC28 [(SA404)]  
AT89C5131AM@QFN32 [(SA701)] AT89C5131AM@SOIC28 [(SA404)]  
AT89C51AC2@PLCC44 [(SA244)] AT89C51AC2@TQFP44 [(SA245A)]  
AT89C51AC3@PLCC44 [(SA244)] AT89C51AC3@TQFP44 [(SA245A)]  
AT89C51CC01@PLCC44 [(SA244)] AT89C51CC01@TQFP44 [(SA245A)]  
AT89C51CC03C@PLCC44 [(SA244)] AT89C51CC03C@TQFP44 [(SA245A)]  
AT89C51CC03U@PLCC44 [(SA244)] AT89C51CC03U@TQFP44 [(SA245A)]  
AT89C51ED2 AT89C51ED2@PLCC44 [(SA244)]  
AT89C51ED2@TQFP44 [(SA245A)] AT89C51IC2@PLCC44 [(SA244)]  
AT89C51IC2@TQFP44 [(SA245A)] AT89C51ID2  
AT89C51ID2@PLCC44 [(SA244)] AT89C51ID2@TQFP44 [(SA245A)]  
AT89C51RB2 AT89C51RB2@PLCC44 [(SA244)]  
AT89C51RB2@TQFP44 [(SA245A)] AT89C51RC  
AT89C51RC@PLCC44 [(SA244)] AT89C51RC@TQFP44 [(SA245A)]  
AT89C51RC2 AT89C51RC2@PLCC44 [(SA244)]  
AT89C51RC2@TQFP44 [(SA245A)] AT89C51RD2  
AT89C51RD2@PLCC44 [(SA244)] AT89C51RD2@TQFP44 [(SA245A)]  
AT89C51RE2@PLCC44 [(SA244)] AT89C51RE2@TQFP44 [(SA675)]  
AT89C52 AT89C52@PLCC44 [(SA244)]  
AT89C52@TQFP44 [(SA245A)] AT89C55  
AT89C55@PLCC44 [(SA244)] AT89C55@TQFP44 [(SA245A)]  
AT89C55WD AT89C55WD@PLCC44 [(SA244)]  
AT89C55WD@TQFP44 [(SA245A)] AT89LP2051  
AT89LP2051@SOIC20 [(SA404)] AT89LP2051@TSSOP20 [(SA026)]  
AT89LP2052 AT89LP2052(ISP) [ISP-HEADER01]  
AT89LP2052@SOIC20 [(SA404)]  
AT89LP2052@SOIC20(ISP) [ISP-HEADER01]

AT89LP2052@TSSOP20 [(SA026)]  
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP213 AT89LP213(ISP) [ISP-HEADER01]  
AT89LP213@TSSOP14 [(SA026)]  
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP214 AT89LP214(ISP) [ISP-HEADER01]  
AT89LP214@TSSOP14 [(SA026)]  
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP216 AT89LP216(ISP) [ISP-HEADER01]  
AT89LP216@TSSOP16 [(SA026)]  
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]  
AT89LP4051 AT89LP4051@SOIC20 [(SA404)]  
AT89LP4051@TSSOP20 [(SA026)] AT89LP4052  
AT89LP4052(ISP) [ISP-HEADER01] AT89LP4052@SOIC20 [(SA404)]  
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP4052@TSSOP20 [(SA026)]  
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LS51 AT89LS51(ISP) [ISP-HEADER01]  
AT89LS51@PLCC44 [(SA244)]  
AT89LS51@PLCC44(ISP) [ISP-HEADER01]  
AT89LS51@TQFP44 [(SA245A)]  
AT89LS51@TQFP44(ISP) [ISP-HEADER01]  
AT89LS52 AT89LS52(ISP) [ISP-HEADER01]  
AT89LS52@PLCC44 [(SA244)]  
AT89LS52@PLCC44(ISP) [ISP-HEADER01]  
AT89LS52@TQFP44 [(SA245A)]  
AT89LS52@TQFP44(ISP) [ISP-HEADER01]  
AT89LS53 AT89LS53(ISP) [ISP-HEADER01]  
AT89LS53@PLCC44 [(SA244)]  
AT89LS53@PLCC44(ISP) [ISP-HEADER01]  
AT89LS53@TQFP44 [(SA245A)]  
AT89LS53@TQFP44(ISP) [ISP-HEADER01]  
AT89LS8252 AT89LS8252(ISP) [ISP-HEADER01]  
AT89LS8252@PLCC44 [(SA244)]  
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]  
AT89LS8252@TQFP44 [(SA245A)]  
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]  
AT89LV51 AT89LV51@PLCC44 [(SA244)]  
AT89LV51@TQFP44 [(SA245A)] AT89LV52  
AT89LV52@PLCC44 [(SA244)] AT89LV52@TQFP44 [(SA245A)]  
AT89LV55 AT89LV55@PLCC44 [(SA244)]  
AT89LV55@TQFP44 [(SA245A)] AT89S2051  
AT89S2051@SOIC20 [(SA404)] AT89S4051

AT89S4051@SOIC20 [(SA404)] AT89S51  
AT89S51(ISP) [ISP-HEADER01] AT89S51@PLCC44 [(SA244)]  
AT89S51@PLCC44(ISP) [ISP-HEADER01]  
AT89S51@TQFP44 [(SA245A)]  
AT89S51@TQFP44(ISP) [ISP-HEADER01]  
AT89S52 AT89S52(ISP) [ISP-HEADER01]  
AT89S52@PLCC44 [(SA244)]  
AT89S52@PLCC44(ISP) [ISP-HEADER01]  
AT89S52@TQFP44 [(SA245A)]  
AT89S52@TQFP44(ISP) [ISP-HEADER01]  
AT89S53 AT89S53(ISP) [ISP-HEADER01]  
AT89S53@PLCC44 [(SA244)]  
AT89S53@PLCC44(ISP) [ISP-HEADER01]  
AT89S53@TQFP44 [(SA245A)]  
AT89S53@TQFP44(ISP) [ISP-HEADER01]  
AT89S54 AT89S54@PLCC44 [(SA244)]  
AT89S54@TQFP44 [(SA245A)] AT89S58  
AT89S58@PLCC44 [(SA244)] AT89S58@TQFP44 [(SA245A)]  
AT89S64 AT89S64@PLCC44 [(SA244)]  
AT89S64@TQFP44 [(SA245A)] AT89S8252  
AT89S8252(ISP) [ISP-HEADER01] AT89S8252@PLCC44 [(SA244)]  
AT89S8252@PLCC44(ISP) [ISP-HEADER01]  
AT89S8252@TQFP44 [(SA245A)]  
AT89S8252@TQFP44(ISP) [ISP-HEADER01]  
AT89S8253 AT89S8253(ISP) [ISP-HEADER01]  
AT89S8253@PLCC44 [(SA244)]  
AT89S8253@PLCC44(ISP) [ISP-HEADER01]  
AT89S8253@TQFP44 [(SA245A)]  
AT89S8253@TQFP44(ISP) [ISP-HEADER01]  
AT90CAN128@QFN64(ISP) [ISP-HEADER01]  
AT90CAN128@TQFP64(ISP) [ISP-HEADER01]  
AT90CAN32@QFN64(ISP) [ISP-HEADER01]  
AT90CAN32@TQFP64(ISP) [ISP-HEADER01]  
AT90CAN64@QFN64(ISP) [ISP-HEADER01]  
AT90CAN64@TQFP64(ISP) [ISP-HEADER01]  
AT90LS2323 AT90LS2323(ISP) [ISP-HEADER01]  
AT90LS2323@SOIC8 [(SA605A)]  
AT90LS2323@SOIC8(ISP) [ISP-HEADER01]  
AT90LS2333 AT90LS2333(ISP) [ISP-HEADER01]  
AT90LS2333@TQFP32 [(SA663)]  
AT90LS2333@TQFP32(ISP) [ISP-HEADER01]  
AT90LS2343 AT90LS2343(ISP) [ISP-HEADER01]  
AT90LS2343@SOIC8 [(SA605A)]

AT90LS2343@SOIC8(ISP) [ISP-HEADER01]  
AT90LS4433 AT90LS4433(ISP) [ISP-HEADER01]  
AT90LS4433@TQFP32 [(SA663)]  
AT90LS4433@TQFP32(ISP) [ISP-HEADER01]  
AT90LS4434 AT90LS4434(ISP) [ISP-HEADER01]  
AT90LS4434@PLCC44 [(SA244)]  
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]  
AT90LS4434@TQFP44 [(SA245A)]  
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]  
AT90LS8535 AT90LS8535(ISP) [ISP-HEADER01]  
AT90LS8535@PLCC44 [(SA244)]  
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]  
AT90LS8535@TQFP44 [(SA245A)]  
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]  
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24 [(SA404)]  
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24 [(SA404)]  
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM3@QFN32 [(SA701)]  
AT90PWM3@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3@SOIC32 [(SA715)]  
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]  
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32 [(SA715)]  
AT90PWM3B@QFN32 [(SA701)]  
AT90PWM3B@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3B@SOIC32 [(SA715)]  
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]  
AT90S1200 AT90S1200(ISP) [ISP-HEADER01]  
AT90S1200@SOIC20 [(SA404)]  
AT90S1200@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200@SSOP20 [(SA626A)]  
AT90S1200@SSOP20(ISP) [ISP-HEADER01]  
AT90S1200A AT90S1200A(ISP) [ISP-HEADER01]  
AT90S1200A@SOIC20 [(SA404)]  
AT90S1200A@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200A@SSOP20 [(SA626A)]  
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]  
AT90S2313 AT90S2313(ISP) [ISP-HEADER01]  
AT90S2313@SOIC20 [(SA404)]  
AT90S2313@SOIC20(ISP) [ISP-HEADER01]  
AT90S2323 AT90S2323(ISP) [ISP-HEADER01]  
AT90S2323@SOIC8 [(SA605A)]  
AT90S2323@SOIC8(ISP) [ISP-HEADER01]

AT90S2333 AT90S2333(ISP) [ISP-HEADER01]  
AT90S2333@TQFP32 [(SA663)]  
AT90S2333@TQFP32(ISP) [ISP-HEADER01]  
AT90S2343 AT90S2343(ISP) [ISP-HEADER01]  
AT90S2343@SOIC8 [(SA605A)]  
AT90S2343@SOIC8(ISP) [ISP-HEADER01]  
AT90S4414 AT90S4414(ISP) [ISP-HEADER01]  
AT90S4414@PLCC44 [(SA244)]  
AT90S4414@PLCC44(ISP) [ISP-HEADER01]  
AT90S4414@TQFP44 [(SA245A)]  
AT90S4414@TQFP44(ISP) [ISP-HEADER01]  
AT90S4433 AT90S4433(ISP) [ISP-HEADER01]  
AT90S4433@TQFP32 [(SA663)]  
AT90S4433@TQFP32(ISP) [ISP-HEADER01]  
AT90S4434 AT90S4434(ISP) [ISP-HEADER01]  
AT90S4434@PLCC44 [(SA244)]  
AT90S4434@PLCC44(ISP) [ISP-HEADER01]  
AT90S4434@TQFP44 [(SA245A)]  
AT90S4434@TQFP44(ISP) [ISP-HEADER01]  
AT90S8515 AT90S8515(ISP) [ISP-HEADER01]  
AT90S8515@PLCC44 [(SA244)]  
AT90S8515@PLCC44(ISP) [ISP-HEADER01]  
AT90S8515@TQFP44 [(SA245A)]  
AT90S8515@TQFP44(ISP) [ISP-HEADER01]  
AT90S8535 AT90S8535(ISP) [ISP-HEADER01]  
AT90S8535@PLCC44 [(SA244)]  
AT90S8535@PLCC44(ISP) [ISP-HEADER01]  
AT90S8535@TQFP44 [(SA245A)]  
AT90S8535@TQFP44(ISP) [ISP-HEADER01]  
AT90USB1286@QFN64(ISP) [ISP-HEADER01]  
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]  
AT90USB1287@QFN64(ISP) [ISP-HEADER01]  
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]  
AT90USB646@QFN64(ISP) [ISP-HEADER01]  
AT90USB646@TQFP64(ISP) [ISP-HEADER01]  
AT90USB647@QFN64(ISP) [ISP-HEADER01]  
AT90USB647@TQFP64(ISP) [ISP-HEADER01]  
ATAM862@SSO24 [(SA026)] ATAM893@SSO20 [(SA026)]  
ATAM894@SSO24 [(SA026)]  
ATMEGA128@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]

ATMEGA128L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16 ATMEGA16(fast)  
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44 [(SA245A)]  
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44 [(SA712)]  
ATMEGA16@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16@TQFP44 [(SA245A)]  
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA161 ATMEGA161@TQFP44 [(SA245A)]  
ATMEGA161L ATMEGA161L@TQFP44 [(SA245A)]  
ATMEGA162 ATMEGA162(ISP) [ISP-HEADER01]  
ATMEGA162@MLF44 [(SA712)]  
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA162@TQFP44 [(SA245A)]  
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA162V ATMEGA162V@MLF44 [(SA712)]  
ATMEGA162V@TQFP44 [(SA245A)] ATMEGA163  
ATMEGA163@TQFP44 [(SA245A)] ATMEGA163L  
ATMEGA163L@TQFP44 [(SA245A)] ATMEGA164P  
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44 [(SA245A)]  
ATMEGA164PL ATMEGA164PL@MLP44 [(SA712)]  
ATMEGA164PL@TQFP44 [(SA245A)]  
ATMEGA165@QFN64(ISP) [ISP-HEADER01]  
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA168 ATMEGA168(ISP) [ISP-HEADER01]  
ATMEGA168@MLP32 [(SA686)]  
ATMEGA168@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168@TQFP32 [(SA663)]  
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168P ATMEGA168P(ISP) [ISP-HEADER01]  
ATMEGA168P@MLP32 [(SA686)]  
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168P@TQFP32 [(SA663)]  
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168PV ATMEGA168PV(ISP) [ISP-HEADER01]  
ATMEGA168PV@MLP32 [(SA686)]  
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168PV@TQFP32 [(SA663)]  
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168V ATMEGA168V(ISP) [ISP-HEADER01]  
ATMEGA168V@MLP32 [(SA686)]  
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168V@TQFP32 [(SA663)]

ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA169@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16L                    ATMEGA16L(fast)  
ATMEGA16L(fast)@MLF44 [(SA712)]  
ATMEGA16L(fast)@TQFP44 [(SA245A)]  
ATMEGA16L(ISP) [ISP-HEADER01]    ATMEGA16L@MLF44 [(SA712)]  
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16L@TQFP44 [(SA245A)]  
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA2561@QFN64(ISP) [ISP-HEADER01]  
ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA32                    ATMEGA32(ISP) [ISP-HEADER01]  
ATMEGA32(new)                ATMEGA32(new)(fast)  
ATMEGA32(new)(fast)@MLF44 [(SA712)]  
ATMEGA32(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32(new)@MLF44 [(SA712)]    ATMEGA32(new)@PLCC44 [(SA244)]  
ATMEGA32(new)@TQFP44 [(SA245A)]    ATMEGA32@MLF44 [(SA712)]  
ATMEGA32@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32@PLCC44 [(SA244)]    ATMEGA32@TQFP44 [(SA245A)]  
ATMEGA32@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA323                    ATMEGA323@TQFP44 [(SA245A)]  
ATMEGA323L                    ATMEGA323L@TQFP44 [(SA245A)]  
ATMEGA324P                    ATMEGA324P@MLP44 [(SA712)]  
ATMEGA324P@TQFP44 [(SA245A)]    ATMEGA324PL  
ATMEGA324PL@MLP44 [(SA712)]    ATMEGA324PL@TQFP44 [(SA245A)]  
ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA325V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA328P                    ATMEGA328P(ISP) [ISP-HEADER01]  
ATMEGA328P@MLP32 [(SA686)]  
ATMEGA328P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328P@TQFP32 [(SA663)]  
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA328PV                    ATMEGA328PV(ISP) [ISP-HEADER01]  
ATMEGA328PV@MLP32 [(SA686)]

ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328PV@TQFP32 [(SA663)]  
ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA329@QFN64(ISP) [ISP-HEADER01]  
ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA32L                   ATMEGA32L(ISP) [ISP-HEADER01]  
ATMEGA32L(new)               ATMEGA32L(new)(fast)  
ATMEGA32L(new)(fast)@MLF44 [(SA712)]  
ATMEGA32L(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32L(new)@MLF44 [(SA712)]   ATMEGA32L(new)@PLCC44 [(SA244)]  
ATMEGA32L(new)@TQFP44 [(SA245A)]   ATMEGA32L@MLF44 [(SA712)]  
ATMEGA32L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32L@PLCC44 [(SA244)]   ATMEGA32L@TQFP44 [(SA245A)]  
ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA406@LQFP48 [(SA248)]   ATMEGA48  
ATMEGA48(ISP) [ISP-HEADER01]   ATMEGA48@MLP32 [(SA686)]  
ATMEGA48@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48@TQFP32 [(SA663)]  
ATMEGA48@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA48P                   ATMEGA48P@MLP32 [(SA686)]  
ATMEGA48P@TQFP32 [(SA663)]   ATMEGA48PV  
ATMEGA48PV@MLP32 [(SA686)]   ATMEGA48PV@TQFP32 [(SA663)]  
ATMEGA48V                   ATMEGA48V(ISP) [ISP-HEADER01]  
ATMEGA48V@MLP32 [(SA686)]  
ATMEGA48V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48V@TQFP32 [(SA663)]  
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA64@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA644                   ATMEGA644(ISP) [ISP-HEADER01]  
ATMEGA644@MLF44 [(SA712)]  
ATMEGA644@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644@TQFP44 [(SA245A)]  
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644P                   ATMEGA644P(ISP) [ISP-HEADER01]  
ATMEGA644P@MLF44 [(SA712)]  
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644P@TQFP44 [(SA245A)]  
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644PV                   ATMEGA644PV(ISP) [ISP-HEADER01]  
ATMEGA644PV@MLF44 [(SA712)]



ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644PV@TQFP44 [(SA245A)]  
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644V                   ATMEGA644V(ISP) [ISP-HEADER01]  
ATMEGA644V@MLF44 [(SA712)]  
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644V@TQFP44 [(SA245A)]  
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA645@QFN64(ISP) [ISP-HEADER01]  
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA8                    ATMEGA8(fast)  
ATMEGA8(fast)@TQFP32 [(SA663)]   ATMEGA8(ISP) [ISP-HEADER01]  
ATMEGA8@MLF32 [(SA686)]  
ATMEGA8@MLF32(ISP) [ISP-HEADER01]  
ATMEGA8@TQFP32 [(SA663)]  
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA8515                ATMEGA8515(fast)  
ATMEGA8515(fast)@PLCC44 [(SA244)]  
ATMEGA8515(fast)@TQFP44 [(SA245A)]  
ATMEGA8515(ISP) [ISP-HEADER01]   ATMEGA8515@PLCC44 [(SA244)]  
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8515@TQFP44 [(SA245A)]  
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8515L               ATMEGA8515L(fast)  
ATMEGA8515L(fast)@PLCC44 [(SA244)]  
ATMEGA8515L(fast)@TQFP44 [(SA245A)]  
ATMEGA8515L(ISP) [ISP-HEADER01]   ATMEGA8515L@PLCC44 [(SA244)]  
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8515L@TQFP44 [(SA245A)]  
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8535                ATMEGA8535(fast)  
ATMEGA8535(fast)@MLF44 [(SA712)]  
ATMEGA8535(fast)@PLCC44 [(SA244)]  
ATMEGA8535(fast)@TQFP44 [(SA245A)]  
ATMEGA8535(ISP) [ISP-HEADER01]   ATMEGA8535@PLCC44 [(SA244)]  
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8535@TQFP44 [(SA245A)]

ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8535L ATMEGA8535L(fast)  
ATMEGA8535L(fast)@MLF44 [(SA712)]  
ATMEGA8535L(fast)@PLCC44 [(SA244)]  
ATMEGA8535L(fast)@TQFP44 [(SA245A)]  
ATMEGA8535L(ISP) [ISP-HEADER01] ATMEGA8535L@PLCC44 [(SA244)]  
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8535L@TQFP44 [(SA245A)]  
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA88 ATMEGA88(ISP) [ISP-HEADER01]  
ATMEGA88@MLP32 [(SA686)]  
ATMEGA88@MLP32(ISP) [ISP-HEADER01]  
ATMEGA88@TQFP32 [(SA663)]  
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA88P ATMEGA88P@MLP32 [(SA686)]  
ATMEGA88P@TQFP32 [(SA663)] ATMEGA88PV  
ATMEGA88PV@MLP32 [(SA686)] ATMEGA88PV@TQFP32 [(SA663)]  
ATMEGA88V ATMEGA88V(ISP) [ISP-HEADER01]  
ATMEGA88V@MLP32 [(SA686)]  
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA88V@TQFP32 [(SA663)]  
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA8L ATMEGA8L(fast)  
ATMEGA8L(fast)@TQFP32 [(SA663)] ATMEGA8L(ISP) [ISP-HEADER01]  
ATMEGA8L@MLF32 [(SA686)]  
ATMEGA8L@MLF32(ISP) [ISP-HEADER01]  
ATMEGA8L@TQFP32 [(SA663)]  
ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]  
ATtiny10 ATtiny10(ISP) [ISP-HEADER01]  
ATtiny10@SOIC8 [(SA605A)]  
ATtiny10@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11 ATtiny11(ISP) [ISP-HEADER01]  
ATtiny11@SOIC8 [(SA605A)]  
ATtiny11@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11L ATtiny11L(ISP) [ISP-HEADER01]  
ATtiny11L@SOIC8 [(SA605A)]  
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12 ATtiny12(ISP) [ISP-HEADER01]  
ATtiny12@SOIC8 [(SA605A)]  
ATtiny12@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12L ATtiny12L(ISP) [ISP-HEADER01]  
ATtiny12L@SOIC8 [(SA605A)]  
ATtiny12L@SOIC8(ISP) [ISP-HEADER01]

ATtiny12V                    ATtiny12V(ISP) [ISP-HEADER01]  
ATtiny12V@SOIC8 [(SA605A)]  
ATtiny12V@SOIC8(ISP) [ISP-HEADER01]  
ATtiny13                    ATtiny13(Fuse)  
ATtiny13(Fuse)@QFN10 [(SA695A)]    ATtiny13(Fuse)@QFN20 [(SA692)]  
ATtiny13(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]  
ATtiny13(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13(ISP) [ISP-HEADER01]    ATtiny13@QFN10 [(SA695A)]  
ATtiny13@QFN10(ISP) [ISP-HEADER01]  
ATtiny13@QFN20 [(SA692)]  
ATtiny13@QFN20(ISP) [ISP-HEADER01]  
ATtiny13@SOIC8(3.9\*6.2) [(SA602A)]  
ATtiny13@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
ATtiny13@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
ATtiny13V                    ATtiny13V(Fuse)  
ATtiny13V(Fuse)@QFN10 [(SA695A)]    ATtiny13V(Fuse)@QFN20 [(SA692)]  
ATtiny13V(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]  
ATtiny13V(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13V(ISP) [ISP-HEADER01]    ATtiny13V@QFN10 [(SA695A)]  
ATtiny13V@QFN10(ISP) [ISP-HEADER01]  
ATtiny13V@QFN20 [(SA692)]  
ATtiny13V@QFN20(ISP) [ISP-HEADER01]  
ATtiny13V@SOIC8(3.9\*6.2) [(SA602A)]  
ATtiny13V@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
ATtiny13V@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13V@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
ATtiny15                    ATtiny15(ISP) [ISP-HEADER01]  
ATtiny15@SOIC8 [(SA605A)]  
ATtiny15@SOIC8(ISP) [ISP-HEADER01]  
ATtiny15L                    ATtiny15L(ISP) [ISP-HEADER01]  
ATtiny15L@SOIC8 [(SA605A)]  
ATtiny15L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny2313                    ATtiny2313(ISP) [ISP-HEADER01]  
ATtiny2313@MLF20 [(SA692)]  
ATtiny2313@MLF20(ISP) [ISP-HEADER01]  
ATtiny2313@SOIC20 [(SA404)]  
ATtiny2313@SOIC20(ISP) [ISP-HEADER01]  
ATtiny2313V                    ATtiny2313V(ISP) [ISP-HEADER01]  
ATtiny2313V@MLF20 [(SA692)]  
ATtiny2313V@MLF20(ISP) [ISP-HEADER01]  
ATtiny2313V@SOIC20 [(SA404)]  
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]

ATtiny24                    ATtiny24(ISP) [ISP-HEADER01]  
ATtiny24@QFN20 [(SA692)]  
ATtiny24@QFN20(ISP) [ISP-HEADER01]  
ATtiny24@SOIC14 [(SA602)]  
ATtiny24@SOIC14(ISP) [ISP-HEADER01]  
ATtiny24V                    ATtiny24V(ISP) [ISP-HEADER01]  
ATtiny24V@QFN20 [(SA692)]  
ATtiny24V@QFN20(ISP) [ISP-HEADER01]  
ATtiny24V@SOIC14 [(SA602)]  
ATtiny24V@SOIC14(ISP) [ISP-HEADER01]  
ATtiny25                    ATtiny25(ISP) [ISP-HEADER01]  
ATtiny25@QFN20 [(SA692)]  
ATtiny25@QFN20(ISP) [ISP-HEADER01]  
ATtiny25@SOIC8 [(SA023A)]  
ATtiny25@SOIC8(ISP) [ISP-HEADER01]  
ATtiny26                    ATtiny26(ISP) [ISP-HEADER01]  
ATtiny26(new)  
ATtiny26(new)(ISP) [ISP-HEADER01]  
ATtiny26(new)@QFN32 [(SA686)]    ATtiny26(new)@SOIC20 [(SA404)]  
ATtiny26(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26(new)@TSSOP20 [(SA026)]  
ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26@QFN32 [(SA686)]    ATtiny26@SOIC20 [(SA404)]  
ATtiny26@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26@TSSOP20 [(SA026)]  
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny261                    ATtiny261@MLP32 [(SA686)]  
ATtiny261@SOIC20 [(SA404)]    ATtiny261V  
ATtiny261V@MLP32 [(SA686)]    ATtiny261V@SOIC20 [(SA404)]  
ATtiny26L                    ATtiny26L(ISP) [ISP-HEADER01]  
ATtiny26L(new)  
ATtiny26L(new)(ISP) [ISP-HEADER01]  
ATtiny26L(new)@QFN32 [(SA686)]    ATtiny26L(new)@SOIC20 [(SA404)]  
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L(new)@TSSOP20 [(SA026)]  
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26L@QFN32 [(SA686)]    ATtiny26L@SOIC20 [(SA404)]  
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L@TSSOP20 [(SA026)]  
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny28L                    ATtiny28L@TQFP32 [(SA663)]  
ATtiny28V                    ATtiny28V@TQFP32 [(SA663)]  
ATtiny44                    ATtiny44(ISP) [ISP-HEADER01]

ATtiny44@QFN20 [(SA692)]  
ATtiny44@QFN20(ISP) [ISP-HEADER01]  
ATtiny44@SOIC14 [(SA602)]  
ATtiny44@SOIC14(ISP) [ISP-HEADER01]  
ATtiny45  
ATtiny45(ISP)(12V) [ISP-HEADER01]  
ATtiny45(ISP)(5V) [ISP-HEADER01] ATtiny45@QFN20 [(SA692)]  
ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny45@SOIC8 [(S605)]  
ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny461 ATtiny461@MLP32 [(SA686)]  
ATtiny461@SOIC20 [(SA404)] ATtiny461V  
ATtiny461V@MLP32 [(SA686)] ATtiny461V@SOIC20 [(SA404)]  
ATtiny48 ATtiny48@MLF32 [(SA686)]  
ATtiny48@TQFP32 [(SA663)] ATtiny48V  
ATtiny48V@MLF32 [(SA686)] ATtiny48V@TQFP32 [(SA663)]  
ATtiny84 ATtiny84(ISP) [ISP-HEADER01]  
ATtiny84@QFN20 [(SA692)]  
ATtiny84@QFN20(ISP) [ISP-HEADER01]  
ATtiny84@SOIC14 [(SA602)]  
ATtiny84@SOIC14(ISP) [ISP-HEADER01]  
ATtiny85  
ATtiny85(ISP)(12V) [ISP-HEADER01]  
ATtiny85(ISP)(5V) [ISP-HEADER01] ATtiny85@QFN20 [(SA692)]  
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny85@SOIC8 [(S605)]  
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny861 ATtiny861@MLP32 [(SA686)]  
ATtiny861@SOIC20 [(SA404)] ATtiny861V  
ATtiny861V@MLP32 [(SA686)] ATtiny861V@SOIC20 [(SA404)]  
ATtiny88 ATtiny88@MLF32 [(SA686)]  
ATtiny88@TQFP32 [(SA663)] ATtiny88V  
ATtiny88V@MLF32 [(SA686)] ATtiny88V@TQFP32 [(SA663)]  
T89F64 T89F64@PLCC44 [(SA244)]  
T89F64@TQFP44 [(SA245A)]

**ATMEL W&M**

## MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)]	AT89C5115@SOIC28 [(SA404)]
AT89C5115@TQFP32 [(SA663)]	AT89C51CC02@PLCC28 [(SA008A)]
AT89C51CC02@SOIC28 [(SA404)]	AT89C51CC02@TQFP32 [(SA663)]
T89C5115@PLCC28 [(SA008A)]	T89C5115@SOIC28 [(SA404)]
T89C5115@TQFP32 [(SA663)]	T89C51AC2@PLCC44 [(SA244)]
T89C51AC2@TQFP44 [(SA245A)]	T89C51CC01@PLCC44 [(SA244)]
T89C51CC01@TQFP44 [(SA245A)]	T89C51CC02@PLCC28 [(SA008A)]
T89C51CC02@SOIC24 [(SA404)]	T89C51CC02@SOIC28 [(SA404)]
T89C51CC02@TQFP32 [(SA663)]	T89C51IB2@PLCC44 [(SA244)]
T89C51IB2@TQFP44 [(SA245A)]	T89C51IC2@PLCC44 [(SA244)]
T89C51IC2@TQFP44 [(SA245A)]	T89C51RB2
T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44 [(SA245A)]
T89C51RC2	T89C51RC2@PLCC44 [(SA244)]
T89C51RC2@TQFP44 [(SA245A)]	T89C51RD2
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44 [(SA245A)]
T89F64	T89F64@PLCC44 [(SA244)]
T89F64@TQFP44 [(SA245A)]	TS87C51RB2
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44 [(SA245A)]
TS87C51RC2	TS87C51RC2@PLCC44 [(SA244)]
TS87C51RC2@TQFP44 [(SA245A)]	TS87C51RD2
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44 [(SA245A)]
TS87C51U2	TS87C51U2@PLCC44 [(SA244)]
TS87C51U2@TQFP44 [(SA245A)]	TS87C52X2
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44 [(SA245A)]
TS87C54X2	TS87C54X2@PLCC44 [(SA244)]
TS87C54X2@TQFP44 [(SA245A)]	TS87C58X2
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44 [(SA245A)]
TSC87251A1@PLCC44 [(SA244)]	TSC87251G1
TSC87251G1@PLCC44 [(SA244)]	TSC87251G1A
TSC87251G1A@PLCC44 [(SA244)]	TSC87251G2D
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44 [(SA245A)]
TSC87C51	TSC87C51@PLCC44 [(SA244)]
TSC87C51@TQFP44 [(SA245A)]	

## ATMEL-CUSTOMER

### E(E)PROM/FRAM/NVRAM

AT24C01	AT24C02
AT24C04	AT24C08

AT24C16

AUSTIN

E(E)PROM/FRAM/NVRAM

AS8E512K8 AS8E512K8@SOJ32 [(SA661)]

BELLING-SYSTRON

MICROCONTROLLER

CM5001

BENCHMARQ

E(E)PROM/FRAM/NVRAM

BQ4010	BQ4010Y
BQ4011	BQ4011Y
BQ4013	BQ4013Y
BQ4014	BQ4014Y
BQ4015	BQ4015Y
BQ4832Y	BQ4842Y

BMT

E(E)PROM/FRAM/NVRAM

BM29LV160B@FBGA48 [(SA642Z-B026A-W048F001Y)]  
BM29LV160B@TSOP48 [(SA247-B005)]  
BM29LV160T@FBGA48 [(SA642Z-B026A-W048F001Y)]  
BM29LV160T@TSOP48 [(SA247-B005)]

BOSEN

## E(E)PROM/FRAM/NVRAM

M28W320FST@FBGA47 [(SA714B-B026A-T048F001Y)]  
 M28W640FSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
 PC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 S71WS256NC0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 S71WS256NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 SST39VF800@TSOP48 [(SA247)]  
 SST39VF800A@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF800A@TSOP48 [(SA247)]      SST39VF800Q@TSOP48 [(SA247)]

## BRIGHT

## E(E)PROM/FRAM/NVRAM

BM29F040                      BM29F040@PLCC32 [(SA015A1T)]  
 BM29F040@TSOP32 [(SA410T)]      BM29F400B@PSOP44 [(SA638-B006)]  
 BM29F400B@TSOP48 [(SA247-B005)]      BM29F400T@PSOP44 [(SA638-B006)]  
 BM29F400T@TSOP48 [(SA247-B005)]

## CATALYST

## E(E)PROM/FRAM/NVRAM

CAT1021(L)                      CAT1021(P)  
 CAT1021(R)@MSOP8 [(SA026)]      CAT1021(S)@SOIC8 [(SA602A)]  
 CAT1021(U)@TSSOP8 [(SA026)]      CAT1021(V)@SOIC8 [(SA602A)]  
 CAT1021(Y)@TSSOP8 [(SA026)]      CAT1021(Z)@MSOP8 [(SA026)]  
 CAT1022(L)                      CAT1022(P)  
 CAT1022(R)@MSOP8 [(SA026)]      CAT1022(S)@SOIC8 [(SA602A)]  
 CAT1022(U)@TSSOP8 [(SA026)]      CAT1022(V)@SOIC8 [(SA602A)]  
 CAT1022(Y)@TSSOP8 [(SA026)]      CAT1022(Z)@MSOP8 [(SA026)]  
 CAT1023(L)                      CAT1023(P)  
 CAT1023(R)@MSOP8 [(SA026)]      CAT1023(S)@SOIC8 [(SA602A)]  
 CAT1023(U)@TSSOP8 [(SA026)]      CAT1023(V)@SOIC8 [(SA602A)]  
 CAT1023(Y)@TSSOP8 [(SA026)]      CAT1023(Z)@MSOP8 [(SA026)]  
 CAT1024(L)                      CAT1024(P)  
 CAT1024(R)@MSOP8 [(SA026)]      CAT1024(S)@SOIC8 [(SA602A)]  
 CAT1024(U)@TSSOP8 [(SA026)]      CAT1024(V)@SOIC8 [(SA602A)]



CAT1024(Y)@TSSOP8 [(SA026)]      CAT1024(Z)@MSOP8 [(SA026)]  
CAT1025(L)                              CAT1025(P)  
CAT1025(R)@MSOP8 [(SA026)]      CAT1025(S)@SOIC8 [(SA602A)]  
CAT1025(U)@TSSOP8 [(SA026)]      CAT1025(V)@SOIC8 [(SA602A)]  
CAT1025(Y)@TSSOP8 [(SA026)]      CAT1025(Z)@MSOP8 [(SA026)]  
CAT1026(L)                              CAT1026(P)  
CAT1026(R)@MSOP8 [(SA026)]      CAT1026(S)@SOIC8 [(SA602A)]  
CAT1026(U)@TSSOP8 [(SA026)]      CAT1026(V)@SOIC8 [(SA602A)]  
CAT1026(Y)@TSSOP8 [(SA026)]      CAT1026(Z)@MSOP8 [(SA026)]  
CAT1027(L)                              CAT1027(P)  
CAT1027(R)@MSOP8 [(SA026)]      CAT1027(S)@SOIC8 [(SA602A)]  
CAT1027(U)@TSSOP8 [(SA026)]      CAT1027(V)@SOIC8 [(SA602A)]  
CAT1027(Y)@TSSOP8 [(SA026)]      CAT1027(Z)@MSOP8 [(SA026)]  
CAT1161(J)@SOIC8 [(SA602A)]      CAT1161(P)  
CAT1162(J)@SOIC8 [(SA602A)]      CAT1162(P)  
CAT1163(J)@SOIC8 [(SA602A)]      CAT1163(P)  
CAT2210                              CAT2210@SOIC16 [(SA404)]  
CAT2210I                              CAT2210I@SOIC16 [(SA404)]  
CAT2212                              CAT2212@SOIC20 [(SA404)]  
CAT2212I                              CAT2212I@SOIC20 [(SA404)]  
CAT22C10                              CAT22C10@SOIC16 [(SA404)]  
CAT22C10I                              CAT22C10I@SOIC16 [(SA404)]  
CAT22C12                              CAT22C12@SOIC20 [(SA404)]  
CAT22C12I                              CAT22C12I@SOIC20 [(SA404)]  
CAT24AC128                              CAT24AC128@SOIC8 [(SA602A)]  
CAT24AC128@TSSOP14 [(SA026)]      CAT24AC128@UDFN8 [(SA724)]  
CAT24C00                              CAT24C00@SOIC8 [(SA602A)]  
CAT24C00@TSSOP8 [(SA026)]      CAT24C01  
CAT24C01@SOIC14 [(SA602)]      CAT24C01@SOIC8 [(SA602A)]  
CAT24C01@TSSOP8 [(SA026)]      CAT24C01B(J)@SOIC8 [(SA602A)]  
CAT24C01B(L)                              CAT24C01B(P)  
CAT24C01B(R)@MSOP8 [(SA026)]      CAT24C01B(U)@TSSOP8 [(SA026)]  
CAT24C01B(W)@SOIC8 [(SA602A)]      CAT24C01B(Y)@TSSOP8 [(SA026)]  
CAT24C01B(Z)@MSOP8 [(SA026)]      CAT24C02  
CAT24C02@SOIC14 [(SA602)]      CAT24C02@SOIC8 [(SA602A)]  
CAT24C02@TSSOP8 [(SA026)]      CAT24C021  
CAT24C022                              CAT24C023  
CAT24C03                              CAT24C03@SOIC8 [(SA602A)]  
CAT24C03@TSSOP8 [(SA026)]      CAT24C04  
CAT24C04@SOIC14 [(SA602)]      CAT24C04@SOIC8 [(SA602A)]  
CAT24C04@TSSOP8 [(SA026)]      CAT24C041  
CAT24C042                              CAT24C043  
CAT24C05                              CAT24C05@SOIC8 [(SA602A)]

CAT24C05@TSSOP8 [(SA026)]      CAT24C08  
CAT24C08@SOIC14 [(SA602)]      CAT24C08@SOIC8 [(SA602A)]  
CAT24C08@TSSOP8 [(SA026)]      CAT24C081  
CAT24C082                      CAT24C083  
CAT24C08I                      CAT24C08I@SOIC8 [(SA602A)]  
CAT24C09                      CAT24C09@SOIC8 [(SA602A)]  
CAT24C09@TSSOP8 [(SA026)]      CAT24C128  
CAT24C128@SOIC8 [(SA602A)]      CAT24C128@UDFN8 [(SA724)]  
CAT24C16                      CAT24C16@SOIC14 [(SA602)]  
CAT24C16@SOIC8 [(SA602A)]      CAT24C16@TSSOP8 [(SA026)]  
CAT24C161                      CAT24C162  
CAT24C163                      CAT24C164  
CAT24C164@SOIC8 [(SA602A)]      CAT24C164@TSSOP8 [(SA026)]  
CAT24C16I                      CAT24C16I@SOIC8 [(SA602A)]  
CAT24C208(J)@SOIC8 [(SA602A)]    CAT24C208(L)  
CAT24C208(P)                      CAT24C208(R)@MSOP8 [(SA666)]  
CAT24C208(U)@TSSOP8 [(SA026)]    CAT24C208(W)@SOIC8 [(SA602A)]  
CAT24C208(Y)@TSSOP8 [(SA026)]    CAT24C208(Z)@MSOP8 [(SA666)]  
CAT24C21                      CAT24C21@SOIC8 [(SA602A)]  
CAT24C21@TSSOP8 [(SA026)]      CAT24C256  
CAT24C256@SOIC8 [(SA602A)]      CAT24C256@TDFN8 [(SA683)]  
CAT24C256@TSSOP8 [(SA026)]      CAT24C32  
CAT24C32@SOIC8 [(SA602A)]      CAT24C44  
CAT24C44@SOIC8 [(SA602A)]      CAT24C64  
CAT24C64@SOIC8 [(SA602A)]      CAT24F32  
CAT24F32@SOIC8 [(SA602A)]      CAT24F32@TSSOP8 [(SA026)]  
CAT24F32A                      CAT24F32A@SOIC8 [(SA602A)]  
CAT24F32A@TSSOP8 [(SA026)]      CAT24FC01  
CAT24FC01@SOIC14 [(SA602)]      CAT24FC01@SOIC8 [(SA602A)]  
CAT24FC01@TSSOP8 [(SA026)]      CAT24FC02  
CAT24FC02@SOIC14 [(SA602)]      CAT24FC02@SOIC8 [(SA602A)]  
CAT24FC02@TSSOP8 [(SA026)]      CAT24FC16  
CAT24FC16@SOIC14 [(SA602)]      CAT24FC16@SOIC8 [(SA602A)]  
CAT24FC16@TSSOP8 [(SA026)]      CAT24FC17  
CAT24FC17@SOIC8 [(SA602A)]      CAT24FC17@TSSOP8 [(SA026)]  
CAT24FC256                      CAT24FC256@SOIC8 [(SA602A)]  
CAT24FC256@TDFN8 [(SA683)]      CAT24FC256@TSSOP8 [(SA026)]  
CAT24FC32                      CAT24FC32@SOIC8 [(SA602A)]  
CAT24FC32@TDFN8 [(SA683)]      CAT24FC32@TSSOP8 [(SA026)]  
CAT24FC64                      CAT24FC64@SOIC8 [(SA602A)]  
CAT24FC64@TDFN8 [(SA683)]      CAT24FC64@TSSOP8 [(SA026)]  
CAT24FC65                      CAT24FC65@SOIC8 [(SA602A)]  
CAT24FC65@TDFN8 [(SA683)]      CAT24FC65@TSSOP8 [(SA026)]

CAT24FC66 CAT24FC66@SOIC8 [(SA602A)]  
CAT24FC66@TDFN8 [(SA683)] CAT24FC66@TSSOP8 [(SA026)]  
CAT24LC02 CAT24LC02@SOIC8 [(SA602A)]  
CAT24LC02@TSSOP8 [(SA026)] CAT24WC01  
CAT24WC01@SOIC8 [(SA602A)] CAT24WC01@TSSOP8 [(SA026)]  
CAT24WC02 CAT24WC02@SOIC8 [(SA602A)]  
CAT24WC02@TSSOP8 [(SA026)] CAT24WC03  
CAT24WC03@SOIC8 [(SA602A)] CAT24WC03@TSSOP8 [(SA026)]  
CAT24WC04 CAT24WC04@SOIC8 [(SA602A)]  
CAT24WC04@TSSOP8 [(SA026)] CAT24WC05  
CAT24WC05@SOIC8 [(SA602A)] CAT24WC05@TSSOP8 [(SA026)]  
CAT24WC08 CAT24WC08@SOIC8 [(SA602A)]  
CAT24WC08@TSSOP8 [(SA026)] CAT24WC09  
CAT24WC09@SOIC8 [(SA602A)] CAT24WC09@TSSOP8 [(SA026)]  
CAT24WC128 CAT24WC128@SOIC8 [(SA602A)]  
CAT24WC129 CAT24WC129@SOIC8 [(SA602A)]  
CAT24WC16 CAT24WC16@SOIC8 [(SA602A)]  
CAT24WC16@TSSOP8 [(SA026)] CAT24WC164  
CAT24WC164@SOIC8 [(SA602A)] CAT24WC164@TSSOP8 [(SA026)]  
CAT24WC17 CAT24WC17@SOIC8 [(SA602A)]  
CAT24WC17@TSSOP8 [(SA026)] CAT24WC256  
CAT24WC256@SOIC8 [(SA602A)] CAT24WC256@TDFN8 [(SA683)]  
CAT24WC256@TSSOP8 [(SA026)] CAT24WC257  
CAT24WC257@SOIC8 [(SA605A)] CAT24WC32  
CAT24WC32@SOIC8 [(SA602A)] CAT24WC33  
CAT24WC33@SOIC8 [(SA602A)] CAT24WC64  
CAT24WC64@SOIC8 [(SA602A)] CAT24WC65  
CAT24WC65@SOIC8 [(SA602A)] CAT24WC66  
CAT24WC66@SOIC8 [(SA602A)] CAT25010  
CAT25010(S)@SOIC8 [(SA605A)] CAT25010(U)@TSSOP8 [(SA602A)]  
CAT25020 CAT25020(S)@SOIC8 [(SA605A)]  
CAT25020(U)@TSSOP8 [(SA602A)] CAT25040  
CAT25040(S)@SOIC8 [(SA605A)] CAT25040(U)@TSSOP8 [(SA602A)]  
CAT25080 CAT25080@SOIC8 [(SA602A)]  
CAT25080@TDFN8 [(SA724)] CAT25080@TSSOP8 [(SA026)]  
CAT25080@UDFN8 [(BBBB)] CAT25128  
CAT25128@SOIC8 [(SA602A)] CAT25128@TDFN8 [(SA724)]  
CAT25128@TSSOP8 [(SA026)] CAT25160  
CAT25160@SOIC8 [(SA602A)] CAT25160@TDFN8 [(SA724)]  
CAT25160@TSSOP8 [(SA026)] CAT25160@UDFN8 [(BBBB)]  
CAT25256 CAT25256@SOIC8 [(SA602A)]  
CAT25256@TDFN8 [(SA602A)] CAT25256@TSSOP8 [(SA026)]  
CAT25320 CAT25320@SOIC8 [(SA602A)]

CAT25320@TDFN8 [(SA724)]      CAT25320@TSSOP8 [(SA026)]  
CAT25640                      CAT25640@SOIC8 [(SA602A)]  
CAT25640@TDFN8 [(SA724)]      CAT25640@TSSOP8 [(SA026)]  
CAT25C01                      CAT25C01@SOIC16 [(SA602)]  
CAT25C01@SOIC8 [(SA602A)]      CAT25C01@TSSOP14 [(SA026)]  
CAT25C01@TSSOP8 [(SA026)]      CAT25C02  
CAT25C02@SOIC16 [(SA602)]      CAT25C02@SOIC8 [(SA602A)]  
CAT25C02@TSSOP14 [(SA026)]      CAT25C02@TSSOP8 [(SA026)]  
CAT25C03                      CAT25C03@SOIC8 [(SA602A)]  
CAT25C03@TSSOP14 [(SA026)]      CAT25C03@TSSOP8 [(SA026)]  
CAT25C04                      CAT25C04@SOIC16 [(SA602)]  
CAT25C04@SOIC8 [(SA602A)]      CAT25C04@TSSOP14 [(SA026)]  
CAT25C04@TSSOP8 [(SA026)]      CAT25C05  
CAT25C05@SOIC8 [(SA602A)]      CAT25C05@TSSOP14 [(SA026)]  
CAT25C05@TSSOP8 [(SA026)]      CAT25C08  
CAT25C08@SOIC16 [(SA602)]      CAT25C08@SOIC8 [(SA602A)]  
CAT25C08@TSSOP14 [(SA026)]      CAT25C08@TSSOP8 [(SA026)]  
CAT25C09                      CAT25C09@SOIC8 [(SA602A)]  
CAT25C09@TSSOP14 [(SA026)]      CAT25C09@TSSOP8 [(SA026)]  
CAT25C11                      CAT25C11@SOIC8 [(SA602A)]  
CAT25C11@TSSOP14 [(SA026)]      CAT25C11@TSSOP8 [(SA026)]  
CAT25C128                      CAT25C128@SOIC16 [(SA602)]  
CAT25C128@SOIC8 [(SA602A)]      CAT25C128@TSSOP14 [(SA026)]  
CAT25C128@TSSOP20 [(SA026)]      CAT25C16  
CAT25C16@SOIC16 [(SA602)]      CAT25C16@SOIC8 [(SA602A)]  
CAT25C16@TSSOP14 [(SA026)]      CAT25C16@TSSOP8 [(SA026)]  
CAT25C17                      CAT25C17@SOIC8 [(SA602A)]  
CAT25C17@TSSOP14 [(SA026)]      CAT25C17@TSSOP8 [(SA026)]  
CAT25C256                      CAT25C256@SOIC16 [(SA602)]  
CAT25C256@SOIC8 [(SA602A)]      CAT25C256@TSSOP14 [(SA026)]  
CAT25C256@TSSOP20 [(SA026)]      CAT25C32  
CAT25C32@SOIC8 [(SA602A)]      CAT25C32@TSSOP14 [(SA026)]  
CAT25C32@TSSOP20 [(SA026)]      CAT25C33  
CAT25C33@SOIC8 [(SA602A)]      CAT25C33@TSSOP14 [(SA026)]  
CAT25C64                      CAT25C64@SOIC8 [(SA602A)]  
CAT25C64@TSSOP14 [(SA026)]      CAT25C64@TSSOP20 [(SA026)]  
CAT25C65                      CAT25C65@SOIC8 [(SA602A)]  
CAT25C65@TSSOP14 [(SA026)]      CAT27010  
CAT27010@PLCC32 [(SA015A1T)]      CAT27010@TSOP32 [(SA410T)]  
CAT27128A                      CAT27256  
CAT27512                      CAT27512@PLCC32 [(SA015A1T)]  
CAT2764A                      CAT27C16A  
CAT27C210                      CAT27C210@PLCC44 [(SA244)]

CAT27HC256 CAT27HC256@PLCC32 [(SA015A1T)]  
CAT27HC256I CAT27HC256I@PLCC32 [(SA015A1T)]  
CAT28C16A CAT28C16A@PLCC32 [(SA015A1T)]  
CAT28C16A@SOIC24 [(SA404)] CAT28C16AI  
CAT28C16AI@PLCC32 [(SA015A1T)] CAT28C16AI@SOIC24 [(SA404)]  
CAT28C17A CAT28C17A@PLCC32 [(SA015A1T)]  
CAT28C17AI CAT28C17AI@PLCC32 [(SA015A1T)]  
CAT28C256 CAT28C256@PLCC32 [(SA015A1T)]  
CAT28C256@TSOP28 [(SA430T)] CAT28C256I  
CAT28C256I@PLCC32 [(SA015A1T)] CAT28C256I@TSOP28 [(SA430T)]  
CAT28C257 CAT28C257@PLCC32 [(SA015A1T)]  
CAT28C257@TSOP28 [(SA430T)] CAT28C512  
CAT28C512@PLCC32 [(SA015A1T)] CAT28C512@TSOP32 [(SA410T)]  
CAT28C512@TSOP40 [(SA409T)] CAT28C513@PLCC32 [(SA015A1T)]  
CAT28C64A CAT28C64A@PLCC32 [(SA015A1T)]  
CAT28C64A@SOIC28 [(SA404)] CAT28C64AI  
CAT28C64AI@PLCC32 [(SA015A1T)] CAT28C64AI@SOIC28 [(SA404)]  
CAT28C64B CAT28C64B@PLCC32 [(SA015A1T)]  
CAT28C64B@TSOP28 [(SA430T)] CAT28C64BI  
CAT28C64BI@PLCC32 [(SA015A1T)] CAT28C64BI@TSOP28 [(SA430T)]  
CAT28C65B CAT28C65B@PLCC32 [(SA015A1T)]  
CAT28C65B@TSOP28 [(SA430T)] CAT28C65BI  
CAT28C65BI@PLCC32 [(SA015A1T)] CAT28C65BI@TSOP28 [(SA430T)]  
CAT28F001N-B@PLCC32 [(SA015A1T)] CAT28F001N-T@PLCC32 [(SA015A1T)]  
CAT28F001P-B CAT28F001P-T  
CAT28F001T-B@TSOP32 [(SA410T)] CAT28F001T-T@TSOP32 [(SA410T)]  
CAT28F002 CAT28F002@TSOP40 [(SA409T)]  
CAT28F010 CAT28F010@PLCC32 [(SA015A1T)]  
CAT28F010@TSOP32 [(SA410T)] CAT28F010I  
CAT28F010I@PLCC32 [(SA015A1T)] CAT28F010I@TSOP32 [(SA410T)]  
CAT28F020  
CAT28F020(REVERSE)@TSOP32 [(SA410T)]  
CAT28F020@PLCC32 [(SA015A1T)] CAT28F020@TSOP32 [(SA410T)]  
CAT28F020I CAT28F020I@PLCC32 [(SA015A1T)]  
CAT28F020I@TSOP32 [(SA410T)] CAT28F102  
CAT28F102@PLCC44 [(SA244)] CAT28F102@TSOP40 [(SA409T)]  
CAT28F512 CAT28F512@PLCC32 [(SA015A1T)]  
CAT28F512@TSOP32 [(SA410T)] CAT28F512I  
CAT28F512I@PLCC32 [(SA015A1T)] CAT28F512I@TSOP32 [(SA410T)]  
CAT28LV256 CAT28LV256@PLCC32 [(SA015A1T)]  
CAT28LV256@TSOP28 [(SA430T)] CAT28LV64  
CAT28LV64@PLCC32 [(SA015A1T)] CAT28LV64@TSOP28 [(SA430T)]  
CAT28LV65 CAT28LV65@PLCC32 [(SA015A1T)]

CAT28LV65@TSOP28 [(SA430T)]      CAT33C101(08bit)  
 CAT33C101(08bit)@SOIC8 [(SA602A)]  
 CAT33C101(16bit)  
 CAT33C101(16bit)@SOIC8 [(SA602A)]  
 CAT33C101H(08bit)  
 CAT33C101H(08bit)@SOIC8 [(SA602A)]  
 CAT33C101H(16bit)  
 CAT33C101H(16bit)@SOIC8 [(SA602A)]  
 CAT33C101I(08bit)  
 CAT33C101I(08bit)@SOIC8 [(SA602A)]  
 CAT33C101I(16bit)  
 CAT33C101I(16bit)@SOIC8 [(SA602A)]  
 CAT33C104(08bit)  
 CAT33C104(08bit)@SOIC8 [(SA602A)]  
 CAT33C104(16bit)  
 CAT33C104(16bit)@SOIC8 [(SA602A)]  
 CAT33C104I(08bit)  
 CAT33C104I(08bit)@SOIC8 [(SA602A)]  
 CAT33C104I(16bit)  
 CAT33C104I(16bit)@SOIC8 [(SA602A)]  
 CAT34AC02                      CAT34AC02@SOIC8 [(SA602A)]  
 CAT34AC02@TSSOP8 [(SA026)]      CAT34C02  
 CAT34C02@SOIC8 [(SA602A)]      CAT34C02@TDFN8 [(SA694)]  
 CAT34C02@TSSOP8 [(SA026)]      CAT34FC02  
 CAT34FC02@SOIC8 [(SA602A)]      CAT34FC02@TDFN8 [(SA694)]  
 CAT34FC02@TSSOP8 [(SA026)]      CAT34RC02  
 CAT34RC02@SOIC8 [(SA602A)]      CAT34RC02@TDFN8 [(SA694)]  
 CAT34RC02@TSSOP8 [(SA026)]      CAT34WC02  
 CAT34WC02@SOIC8 [(SA602A)]      CAT34WC02@TDFN8 [(SA694)]  
 CAT34WC02@TSSOP8 [(SA026)]      CAT35C102  
 CAT35C102H                      CAT35C102I  
 CAT35C104(08bit)  
 CAT35C104(08bit)@SOIC8 [(SA602A)]  
 CAT35C104(16bit)  
 CAT35C104(16bit)@SOIC8 [(SA602A)]  
 CAT35C104H(08bit)  
 CAT35C104H(08bit)@SOIC8 [(SA602A)]  
 CAT35C104I(08bit)  
 CAT35C104I(08bit)@SOIC8 [(SA602A)]  
 CAT35C104I(16bit)  
 CAT35C104I(16bit)@SOIC8 [(SA602A)]  
 CAT59C11                      CAT59C11@SOIC8 [(SA602A)]  
 CAT59C11A                      CAT59C11A@SOIC8 [(SA602A)]

CAT59C11H CAT59C11H@SOIC8 [(SA602A)]  
CAT59C11I CAT59C11I@SOIC8 [(SA602A)]  
CAT64LC10(J)@SOIC8 [(SA602A)] CAT64LC10(P)  
CAT64LC10(S)@SOIC8 [(SA602A)] CAT64LC10(U)@TSSOP8 [(SA026)]  
CAT64LC10(UR)@TSSOP8 [(SA026)] CAT64LC20(J)@SOIC8 [(SA602A)]  
CAT64LC20(P) CAT64LC20(S)@SOIC8 [(SA602A)]  
CAT64LC20(U)@TSSOP8 [(SA026)] CAT64LC20(UR)@TSSOP8 [(SA026)]  
CAT64LC40(J)@SOIC8 [(SA602A)] CAT64LC40(P)  
CAT64LC40(S)@SOIC8 [(SA602A)] CAT64LC40(U)@TSSOP8 [(SA026)]  
CAT64LC40(UR)@TSSOP8 [(SA026)] CAT93C46(08bit)  
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C46(16bit)  
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93C46A CAT93C56(08bit)  
CAT93C56(08bit)@SOIC8 [(SA602A)] CAT93C56(16bit)  
CAT93C56(16bit)@SOIC8 [(SA602A)] CAT93C56A  
CAT93C57 CAT93C66(08bit)  
CAT93C66(08bit)@SOIC8 [(SA602A)] CAT93C66(08bit)@TSSOP8 [(SA026)]  
CAT93C66(16bit) CAT93C66(16bit)@SOIC8 [(SA602A)]  
CAT93C66(16bit)@TSSOP8 [(SA026)] CAT93C66A  
CAT93C76(08bit)  
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C76(16bit)  
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(08bit)  
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(16bit)  
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]

CAT93C86(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(08bit)  
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(16bit)  
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(08bit)  
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(16bit)  
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

## DRAM & SRAM

CAT71C256                    CAT71C256@TSOP28 [(SA643)]  
CAT71C256L                 CAT71C256L@TSOP28 [(SA643)]

## CELESTICA

### E(E)PROM/FRAM/NVRAM

SST49LF160C@TSOP40 [(SA409T)]

## CERAMATE

### E(E)PROM/FRAM/NVRAM



24LC02	24LC02@SOIC8 [(SA602A)]
24LC02@TSSOP8 [(SA026)]	24LC08
24LC08@SOIC8 [(SA602A)]	24LC08@TSSOP8 [(SA026)]
24LC16	24LC16@SOIC8 [(SA602A)]
24LC16@TSSOP8 [(SA026)]	24LLC02
24LLC02@SOIC8 [(SA602A)]	24LLC02@TSSOP8 [(SA026)]
24LLC08	24LLC08@SOIC8 [(SA602A)]
24LLC08@TSSOP8 [(SA026)]	93LC46
93LC46@SOIC8 [(SA602A)]	93LC46R
93LC46R@SOIC8 [(SA602A)]	93LC56
93LC56@SOIC8 [(SA602A)]	93LC66
93LC66@SOIC8 [(SA602A)]	

## CHINA CORE

### MICROCONTROLLER

CCM89C51	CCM89C51@PLCC44 [(SA244)]
CCM89C51@TQFP44 [(SA245A)]	CCM89C52
CCM89C52@PLCC44 [(SA244)]	CCM89C52@TQFP44 [(SA245A)]

## CHINGIS

### E(E)PROM/FRAM/NVRAM

PM24C64	PM24C64@SOIC8 [(SA602A)]
PM24C64@TSOP8 [(SA026)]	PM25LV010(B)@SOIC8 [(SA023A)]
PM25LV010(Q)@WSON8 [(SA683)]	PM25LV010(S)@SOIC8 [(SA602A)]
PM25LV010A@SOIC8 [(SA602A)]	PM25LV010A@WSON8 [(SA683)]
PM25LV016@SOIC8 [(SA605A)]	PM25LV016@WSON8 [(SA683)]
PM25LV016A@SOIC8 [(SA605A)]	PM25LV016A@WSON8 [(SA683)]
PM25LV020(B)@SOIC8 [(SA023A)]	PM25LV020(Q)@WSON8 [(SA683)]
PM25LV020(S)@SOIC8 [(SA602A)]	PM25LV040(B)@SOIC8 [(SA023A)]
PM25LV040(Q)@WSON8 [(SA683)]	PM25LV040(S)@SOIC8 [(SA602A)]
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8 [(SA683)]
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8 [(SA683)]
PM25LV512(B)@SOIC8 [(SA023A)]	PM25LV512(Q)@WSON8 [(SA683)]
PM25LV512(S)@SOIC8 [(SA602A)]	PM29F002B
PM29F002B@PLCC32 [(SA015A1T)]	PM29F002T
PM29F002T@PLCC32 [(SA015A1T)]	PM29F004B

PM29F004B@PLCC32 [(SA015A1T)]    PM29F004T  
PM29F004T@PLCC32 [(SA015A1T)]    PM29LV002B  
PM29LV002B@PLCC32 [(SA015A1T)]    PM29LV002B@VSOP32 [(SA620)]  
PM29LV002T                            PM29LV002T@PLCC32 [(SA015A1T)]  
PM29LV002T@VSOP32 [(SA620)]        PM29LV004B@PLCC32 [(SA015A1T)]  
PM29LV004B@VSOP32 [(SA620)]        PM29LV004T@PLCC32 [(SA015A1T)]  
PM29LV004T@VSOP32 [(SA620)]        PM29LV104RB@PLCC32 [(SA015A1T)]  
PM29LV104RB@VSOP32 [(SA620)]       PM29LV104RT@PLCC32 [(SA015A1T)]  
PM29LV104RT@VSOP32 [(SA620)]       PM37LV512  
PM37LV512@PLCC32 [(SA015A1T)]      PM37LV512@VSOP32 [(SA620)]  
PM39F010                                PM39F010@PLCC32 [(SA015A1T)]  
PM39F010@VSOP32 [(SA620)]          PM39F020  
PM39F020@PLCC32 [(SA015A1T)]        PM39F020@VSOP32 [(SA620)]  
PM39F040                                PM39F040@PLCC32 [(SA015A1T)]  
PM39F040@VSOP32 [(SA620)]          PM39LV010@PLCC32 [(SA015A1T)]  
PM39LV010@VSOP32 [(SA620)]         PM39LV010R@PLCC32 [(SA015A1T)]  
PM39LV010R@VSOP32 [(SA620)]         PM39LV020@PLCC32 [(SA015A1T)]  
PM39LV020@VSOP32 [(SA620)]         PM39LV040@PLCC32 [(SA015A1T)]  
PM39LV040@VSOP32 [(SA620)]         PM39LV512@PLCC32 [(SA015A1T)]  
PM39LV512@VSOP32 [(SA620)]         PM39LV512R@PLCC32 [(SA015A1T)]  
PM39LV512R@VSOP32 [(SA620)]        PM49FL002T@PLCC32 [(SA015A1T)]  
PM49FL002T@VSOP32 [(SA620)]  
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]  
PM49FL004T(Low)@VSOP32 [(SA620-B005)]  
PM49FL004T@PLCC32 [(SA015A1T)]     PM49FL004T@VSOP32 [(SA620)]  
PM49FL008T@PLCC32 [(SA015A1T)]     PM49FL008T@VSOP32 [(SA620)]  
PM49LP002T@PLCC32 [(SA015A1T)]     PM49LP002T@VSOP32 [(SA620)]

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64(ISP) [ISP-HEADER01]

## CHIPSWINNER

### E(E)PROM/FRAM/NVRAM

CW24C02                                CW24C02@SOIC8 [(SA602A)]  
CW24C04                                CW24C04@SOIC8 [(SA602A)]

CW24C08	CW24C08@SOIC8 [(SA602A)]
CW24C16	CW24C16@SOIC8 [(SA602A)]
CW24C32	CW24C32@SOIC8 [(SA602A)]
CW24C64	CW24C64@SOIC8 [(SA602A)]

## MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)]	CW88CS032@SDIP32 [(SA653)]
CW88CS128@SDIP28 [(SA653)]	CW88CS132@SDIP32 [(SA653)]
CW89F1050	CW89F2050
CW89F4050@SDIP28 [(SA653)]	CW89F4050@SOP28 [(SA404)]
CW89F52	CW89F52@LQFP44 [(SA675)]
CW89F54	CW89F54@LQFP44 [(SA675)]

## CORERIVER

### E(E)PROM/FRAM/NVRAM

CR24C02LI	CR24C02WI@SOIC8 [(SA602)]
CR24C08LI	CR24C08WI@SOIC8 [(SA602)]
CR24C16LI	CR24C16WI@SOIC8 [(SA602)]
CR24C256LI	CR24C256WI@SOIC8 [(SA602)]
CR24C32LI	CR24C32WI@SOIC8 [(SA602)]
CR24C64LI	CR24C64WI@SOIC8 [(SA602)]

## CWI

### E(E)PROM/FRAM/NVRAM

39LV040@VSOP32 [(SA620)]

## CYGNAL

### MICROCONTROLLER

C8051F000@TQFP64(ISP) [(PEP+S616)]	
C8051F001@TQFP48(ISP) [(SA248)]	C8051F002@TQFP32(ISP) [(SA663)]
C8051F005@TQFP64(ISP) [(PEP+S616)]	

C8051F006@TQFP48(ISP) [(SA248)] C8051F007@TQFP32(ISP) [(SA663)]  
C8051F010@TQFP64(ISP) [(PEP+S616)]  
C8051F011@TQFP48(ISP) [(SA248)] C8051F012@TQFP32(ISP) [(SA663)]  
C8051F015@TQFP64(ISP) [(PEP+S616)]  
C8051F016@TQFP48(ISP) [(SA248)] C8051F017@TQFP32(ISP) [(SA663)]  
C8051F018@TQFP64(ISP) [(PEP+S616)]  
C8051F019@TQFP48(ISP) [(SA248)]  
C8051F020@TQFP100(ISP) [ISP-HEADER01]  
C8051F021@TQFP64(ISP) [ISP-HEADER01]  
C8051F022@TQFP100(ISP) [ISP-HEADER01]  
C8051F023@TQFP64(ISP) [ISP-HEADER01]  
C8051F040@TQFP100(ISP) [ISP-HEADER01]  
C8051F041@TQFP64(ISP) [ISP-HEADER01]  
C8051F042@TQFP100(ISP) [ISP-HEADER01]  
C8051F043@TQFP64(ISP) [ISP-HEADER01]  
C8051F044@TQFP100(ISP) [ISP-HEADER01]  
C8051F045@TQFP64(ISP) [ISP-HEADER01]  
C8051F046@TQFP100(ISP) [ISP-HEADER01]  
C8051F047@TQFP64(ISP) [ISP-HEADER01]  
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48 [(SA248)]  
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48 [(SA248)]  
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32 [(SA663)]  
C8051F236@TQFP48 [(SA248)] C8051F300 [(SA695A)]  
C8051F301 [(SA695A)] C8051F302 [(SA695A)]  
C8051F303 [(SA695A)] C8051F304 [(SA695A)]  
C8051F305 [(SA695A)] C8051F310@TQFP32 [(SA663)]  
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-B006)]  
C8051F311-GM@QFN28 [(SA697-B006)]  
C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32 [(SA663)]  
C8051F313@QFN28 [(SA697-B006)]  
C8051F313-GM@QFN28 [(SA697-B006)]  
C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32 [(SA663)]  
C8051F315@QFN28 [(SA697-B006)]  
C8051F315-GM@QFN28 [(SA697-B006)]  
C8051F316-GM@QFN24 [(SA710-B006)]  
C8051F317-GM@QFN24 [(SA710-B006)]  
C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-B006)]  
C8051F326@QFN28 [(SA697-B006)]  
C8051F326-GQ@QFN28 [(SA697-B006)]  
C8051F327@QFN28 [(SA697-B006)]  
C8051F327-GQ@QFN28 [(SA697-B006)]  
C8051F330@MLP20 [(SA692)] C8051F330D  
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20 [(SA692)]

C8051F333-GM@MLP20 [(SA692)]      C8051F334-GM@MLP20 [(SA692)]  
 C8051F335-GM@MLP20 [(SA692)]      C8051F336-GM@QFN20 [(SA692)]  
 C8051F337-GM@QFN20 [(SA692)]      C8051F338-GM@QFN24 [(SA710)]  
 C8051F339-GM@QFN24 [(SA710)]      C8051F340-GQ@TQFP48 [(SA248)]  
 C8051F341-GQ@TQFP48 [(SA248)]      C8051F342-GQ@LQFP32 [(SA663)]  
 C8051F343-GQ@LQFP32 [(SA663)]      C8051F344-GQ@TQFP48 [(SA248)]  
 C8051F345-GQ@TQFP48 [(SA248)]      C8051F346-GQ@LQFP32 [(SA663)]  
 C8051F347-GQ@LQFP32 [(SA663)]      C8051F350-GQ@LQFP32 [(SA663)]  
 C8051F351-GM@QFN28 [(SA697-B006)]  
 C8051F352-GQ@LQFP32 [(SA663)]  
 C8051F353-GM@QFN28 [(SA697-B006)]  
 C8051F360@QFP48 [(SA248)]      C8051F361@QFP32 [(SA663)]  
 C8051F362@QFN28 [(SA697)]      C8051F363@QFP48 [(SA248)]  
 C8051F364@QFP32 [(SA663)]      C8051F365@QFN28 [(SA697)]  
 C8051F366@QFP32 [(SA663)]      C8051F367@QFN28 [(SA697)]  
 C8051F368@QFP32 [(SA663)]      C8051F369@QFN28 [(SA697)]  
 C8051F410-GQ@LQFP32 [ordering number is marked above]  
 C8051F411-GM@QFN28 [ordering number is marked above]  
 C8051F412-GQ@LQFP32 [ordering number is marked above]  
 C8051F413-GM@QFN28 [ordering number is marked above]  
 C8051F520-IM@QFN10 [(SA695A)]      C8051F521-IM@QFN10 [(SA695A)]  
 C8051F523-IM@QFN10 [(SA695A)]      C8051F524-IM@QFN10 [(SA695A)]  
 C8051F526-IM@QFN10 [(SA695A)]      C8051F527-IM@QFN10 [(SA695A)]  
 C8051F530-IM@QFN20 [(SA692)]      C8051F530-IT@TSSOP20 [(SA026)]  
 C8051F531-IM@QFN20 [(SA692)]      C8051F531-IT@TSSOP20 [(SA026)]  
 C8051F533-IM@QFN20 [(SA692)]      C8051F533-IT@TSSOP20 [(SA026)]  
 C8051F534-IM@QFN20 [(SA692)]      C8051F534-IT@TSSOP20 [(SA026)]  
 C8051F536-IM@QFN20 [(SA692)]      C8051F536-IT@TSSOP20 [(SA026)]  
 C8051F537-IM@QFN20 [(SA692)]      C8051F537-IT@TSSOP20 [(SA026)]  
 C8051F610-GQ@QFP32 [(SA663)]  
 C8051F611-GM@QFN28 [(SA697-B006)]  
 C8051F612-GQ@QFP32 [(SA663)]  
 C8051F613-GM@QFN28 [(SA697-B006)]  
 C8051F614-GQ@QFP32 [(SA663)]  
 C8051F615-GM@QFN28 [(SA697-B006)]  
 C8051F616-GM@QFN24 [(SA710-B006)]  
 C8051F617-GM@QFN24 [(SA710-B006)]  
 SI8250@LQFP32 [(SA663)]      SI8250@QFN28 [(SA697)]  
 SI8251@LQFP32 [(SA663)]      SI8251@QFN28 [(SA697)]  
 SI8252@LQFP32 [(SA663)]      SI8252@QFN28 [(SA697)]

CYPRESS

## E(E)PROM/FRAM/NVRAM

CY14B256L@SOIC32 [(SA715)]      CY27C010  
 CY27C010@PLCC32 [(SA015A1T)]      CY27C010@TSOP32 [(SA410T)]  
 CY27C020      CY27C020@PLCC32 [(SA015A1T)]  
 CY27C020@TSOP32 [(SA410T)]      CY27C040  
 CY27C040@PLCC32 [(SA015A1T)]      CY27C040@TSOP32 [(SA410T)]  
 CY27C128      CY27C128@PLCC32 [(SA015A1T)]  
 CY27C256      CY27C256@PLCC32 [(SA015A1T)]  
 CY27C256@TSOP28 [(SA430T)]      CY27C512  
 CY27C512@PLCC32 [(SA015A1T)]      CY27C512@TSOP28 [(SA430T)]  
 CY27H010      CY27H010@PLCC32 [(SA015A1T)]  
 CY27H010@TSOP32 [(SA410T)]      CY27H256  
 CY27H256@PLCC32 [(SA015A1T)]      CY27H256@TSOP28 [(SA430T)]  
 CY27H512      CY27H512@PLCC32 [(SA015A1T)]  
 CY27H512@TSOP28 [(SA430T)]      CY7C225A  
 CY7C225A@PLCC28 [(SA008A)]      CY7C243  
 CY7C243@PLCC28 [(SA008A)]      CY7C244  
 CY7C244@PLCC28 [(SA008A)]      CY7C245  
 CY7C245@PLCC28 [(SA008A)]      CY7C245A  
 CY7C245A@PLCC28 [(SA008A)]      CY7C251  
 CY7C251@PLCC32 [(SA015A1T)]      CY7C254  
 CY7C254@PLCC32 [(SA015A1T)]      CY7C256  
 CY7C256@PLCC32 [(SA015A1T)]      CY7C261  
 CY7C261@PLCC28 [(SA008A)]      CY7C263  
 CY7C263@PLCC28 [(SA008A)]      CY7C264  
 CY7C264@PLCC28 [(SA008A)]      CY7C265  
 CY7C265@PLCC28 [(SA008A)]      CY7C266  
 CY7C266@PLCC32 [(SA015A1T)]      CY7C268  
 CY7C268@PLCC32 [(SA015A1T)]      CY7C271  
 CY7C271@PLCC32 [(SA015A1T)]      CY7C271A  
 CY7C271A@PLCC32 [(SA015A1T)]      CY7C274  
 CY7C274@PLCC32 [(SA015A1T)]      CY7C276(25HC)@PLCC44 [(SA244)]  
 CY7C276(25JC)@PLCC44 [(SA244)]      CY7C276(30JC)@PLCC44 [(SA244)]  
 CY7C281      CY7C281@PLCC28 [(SA008A)]  
 CY7C281A      CY7C281A@PLCC28 [(SA008A)]  
 CY7C282      CY7C282@PLCC28 [(SA008A)]  
 CY7C282A      CY7C282A@PLCC28 [(SA008A)]  
 CY7C285      CY7C285@PLCC32 [(SA015A1T)]  
 CY7C286      CY7C286@PLCC32 [(SA015A1T)]  
 CY7C287      CY7C287@PLCC32 [(SA015A1T)]  
 CY7C291      CY7C291@PLCC28 [(SA008A)]

CY7C291A                    CY7C291A@PLCC28 [(SA008A)]  
 CY7C292                    CY7C292@PLCC28 [(SA008A)]  
 CY7C292A                   CY7C292A@PLCC28 [(SA008A)]  
 CY7C293A                   CY7C293A@PLCC28 [(SA008A)]  
 CY8C9520@SSOP28 [(SA626A)]    CY8C9540@SSOP48 [(SA669)]

## DRAM & SRAM

CY62128@SOIC32 [(SA687)]            CY62128@SOJ32 [(SA661)]  
 CY62128@VSOP32 [(SA620)]            CY62128L@SOIC32 [(SA687)]  
 CY62128L@SOJ32 [(SA661)]            CY62128L@VSOP32 [(SA620)]  
 CY62128LL@SOIC32 [(SA687)]            CY62128LL@SOJ32 [(SA661)]  
 CY62128LL@VSOP32 [(SA620)]            CY7C1011@TSOP44 [(SA645)]  
 CY7C1020@TSOP44 [(SA645)]            CY7C1021@TSOP44 [(SA645)]  
 CY7C1049@SOJ36 [(SA027)]            CY7C1049@TSOP44 [(SA645)]  
 CY7C107                    CY7C107@SOJ28 [(SA661)]  
 CY7C147                    CY7C167  
 CY7C167@PLCC20 [(SA001A)]            CY7C167A  
 CY7C167A@PLCC20 [(SA001A)]            CY7C185  
 CY7C185@SOIC28 [(SA404)]            CY7C185@SOJ28 [(SA646)]  
 CY7C186                    CY7C187  
 CY7C187@SOJ24 [(SA646)]            CY7C187A  
 CY7C187A@SOJ24 [(SA646)]            CY7C193  
 CY7C193@SOJ28 [(SA646)]            CY7C199  
 CY7C199@PLCC28 [(SA008A)]            CY7C199@SOJ28 [(SA646)]  
 CY7C199@TSOP28 [(SA430T)]

## PLD

CY2291@SOIC20 [(SA404)]            CY2292@SOIC16 [(SA602)]  
 CY2295@SSOP28 [(SA626A)]            CY37032@PLCC44 [(SA244)]  
 CY37032@TQFP44 [(SA245A)]            CY37032V@PLCC44 [(SA244)]  
 CY37032V@TQFP44 [(SA245A)]            CY37064@PLCC44 [(SA244)]  
 CY37064@PLCC44(ISP) [ISP-HEADER01]  
 CY37064@TQFP44 [(SA245A)]  
 CY37064@TQFP44(ISP) [ISP-HEADER01]  
 CY37064V@PLCC44 [(SA244)]  
 CY37064V@PLCC44(ISP) [ISP-HEADER01]  
 CY37064V@TQFP44 [(SA245A)]  
 CY37064V@TQFP44(ISP) [ISP-HEADER01]  
 CY7C371@PLCC44 [(SA244)]            CY7C371@TQFP44 [(SA245A)]

CY7C371I@PLCC44 [(SA244)]	CY7C371I@TQFP44 [(SA245A)]
CY7C372@PLCC44 [(SA244)]	CY7C372@TQFP44 [(SA245A)]
CY7C372I@PLCC44 [(SA244)]	CY7C372I@TQFP44 [(SA245A)]
PALC16L8	PALC16L8@PLCC20 [(SA001A)]
PALC16L8L	PALC16L8L@PLCC20 [(SA001A)]
PALC16R4	PALC16R4@PLCC20 [(SA001A)]
PALC16R4L	PALC16R4L@PLCC20 [(SA001A)]
PALC16R6	PALC16R6@PLCC20 [(SA001A)]
PALC16R6L	PALC16R6L@PLCC20 [(SA001A)]
PALC16R8	PALC16R8@PLCC20 [(SA001A)]
PALC16R8L	PALC16R8L@PLCC20 [(SA001A)]
PALC22V10	
PALC22V10@PLCC28 [ordering number is marked above]	
PALC22V10A	
PALC22V10A@PLCC28 [ordering number is marked above]	
PALC22V10B	
PALC22V10B@PLCC28 [ordering number is marked above]	
PALC22V10D	PALC22V10D@PLCC28 [(SA008A)]
PALC22V10L	
PALC22V10L@PLCC28 [ordering number is marked above]	
PALCE16V8	PALCE16V8@PLCC20 [(SA001A)]
PALCE20V8	PALCE20V8@PLCC28 [(SA008A)]
PALCE20V8L	PALCE20V8L@PLCC28 [(SA008A)]
PALCE22V10	PALCE22V10@PLCC28 [(SA008A)]

## MICROCONTROLLER

CY7C63722	CY7C63722@SOIC18 [(SA404)]
CY7C63722C	CY7C63722C@SOIC18 [(SA404)]
CY7C63723	CY7C63723@SOIC18 [(SA404)]
CY7C63723C	CY7C63723C@SOIC18 [(SA404)]
CY7C63742	CY7C63742@QSOP24 [(SA674)]
CY7C63742@SOIC24 [(SA404)]	CY7C63742C
CY7C63742C@QSOP24 [(SA674)]	CY7C63742C@SOIC24 [(SA404)]
CY7C63743	CY7C63743@QSOP24 [(SA674)]
CY7C63743@SOIC24 [(SA404)]	CY7C63743C
CY7C63743C@QSOP24 [(SA674)]	CY7C63743C@SOIC24 [(SA404)]
CY7C63813	CY7C63813@SOIC18 [(SA404)]

## DALLAS



## E(E)PROM/FRAM/NVRAM

DS1073M-100	DS1073M-60
DS1073M-66	DS1073M-80
DS1073Z-100@SOIC8 [(SA602A)]	DS1073Z-60@SOIC8 [(SA602A)]
DS1073Z-66@SOIC8 [(SA602A)]	DS1073Z-80@SOIC8 [(SA602A)]
DS1077LZ-40@SOIC8 [(SA602A)]	DS1077LZ-50@SOIC8 [(SA602A)]
DS1077LZ-60@SOIC8 [(SA602A)]	DS1077LZ-66@SOIC8 [(SA602A)]
DS1077Z-40@SOIC8 [(SA602A)]	DS1077Z-50@SOIC8 [(SA602A)]
DS1077Z-60@SOIC8 [(SA602A)]	DS1077Z-66@SOIC8 [(SA602A)]
DS1220AB	DS1220AD
DS1220Y	DS1225AB
DS1225AD	DS1225D
DS1225E	DS1225Y
DS1230AB	DS1230W
DS1230Y	DS1235AB
DS1235Y	DS1243Y
DS1244	DS1244Y
DS1245AB	DS1245EE
DS1245P	DS1245W
DS1245Y	DS1248P
DS1248W	DS1248Y
DS1249AB	DS1249W
DS1249Y	DS1250AB
DS1250W	DS1250Y
DS1251AB	DS1251W
DS1251Y	DS1256P
DS1256W	DS1256Y
DS1258AB	DS1258W
DS1258Y	DS1265AB
DS1265W	DS1265Y
DS1270AB	DS1270W
DS1270Y	DS1284
DS1284N	DS1284Q@PLCC28 [(SA008A)]
DS1284QN@PLCC28 [(SA008A)]	DS1286
DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1330AB
DS1330WP	DS1330Y
DS1345AB	DS1345P
DS1345W	DS1345Y
DS1350AB	DS1350P

DS1350W	DS1350Y
DS1386(32K)	DS1386(8K)
DS14285	DS14287
DS1485	DS1485@SOIC28 [(SA630)]
DS1486	DS1488
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1630AB
DS1630Y	DS1642
DS1643	DS1644
DS1644P [ordering number is marked above]	
DS1644PS [(PEP+S414T)]	DS1645AB
DS1645EE	DS1645Y
DS1646	DS1647
DS1647LPM	DS1650AB
DS1650Y	DS1687-3
DS1687-5	DS17287-3
DS17287-5	DS1742
DS1742W	DS1743
DS1743P	DS1743W
DS1743WP	DS1744
DS1744P	DS1744W
DS1744WP	DS1746
DS1747	
DS1747P [ordering number is marked above]	
DS1747PS [(PEP+S414T)]	DS1747W
DS1747WP [ordering number is marked above]	
DS1747WPS [(PEP+S414T)]	DS17487-3
DS17487-5	DS17887-3
DS17887-5	DS2406@TO-92
DS2406P@TSOC6	DS2430A@TO-92
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-92
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6 [(SA602A)]
DS2433@PR-35	DS2433S(3.9)@SOIC8 [(SA602A)]
DS2433S(5.5)@SOIC8 [(SA605A)]	DS2502
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8 [(SA602A)]
DS2502UNW	DS2502UNW@SOIC8 [(SA602A)]
DS2502UNW@TSOC6 [(SA602A)]	DS2506
DS2506S@SOIC8 [(SA023A)]	DS4510@uSOP10
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20 [(SA026)]

## MICROCONTROLLER

DS87C520 DS87C520@PLCC44 [(SA244)]  
DS87C520@TQFP44 [(SA245A)] DS89C420  
DS89C420(rev.A) DS89C420(rev.A)@PLCC44 [(SA244)]  
DS89C420(rev.A)@TQFP44 [(SA245A)]  
DS89C420@PLCC44 [(SA244)] DS89C420@TQFP44 [(SA245A)]  
DS89C430 DS89C430@PLCC44 [(SA244)]  
DS89C430@TQFP44 [(SA245A)] DS89C440  
DS89C440@PLCC44 [(SA244)] DS89C440@TQFP44 [(SA245A)]  
DS89C450 DS89C450@PLCC44 [(SA244)]  
DS89C450@TQFP44 [(SA245A)]

## DENSE-PAC

### E(E)PROM/FRAM/NVRAM

DPV27C101 DPV27C101@PLCC32 [(SA015A1T)]  
DPV27C256 DPV27C256@PLCC32 [(SA015A1T)]  
DPV27C512 DPV27C512@PLCC32 [(SA015A1T)]

## DEUTRON

### E(E)PROM/FRAM/NVRAM

AC25LV010 AC25LV010@SOIC8 [(SA602A)]  
AC25LV512 AC25LV512@SOIC8 [(SA602A)]  
P439LV010@PLCC32 [(SA015A1T)] P439LV010@VSOP32 [(SA620)]  
P439LV040@PLCC32 [(SA015A1T)] P439LV040@VSOP32 [(SA620)]  
P439LV088@TSOP48 [(SA247-B005)] P439VF800@TSOP48 [(SA247-B005)]

## EFST

### E(E)PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)] EM25LV010@VFQFPN8 [(SA684)]  
EM25LV512@SOIC8 [(SA602A)] EM25LV512@VFQFPN8 [(SA684)]  
F25L004A@SOIC8 [(SA602A)] F49B002UA  
F49B002UA@PLCC32 [(SA015A1T)] F49L004BA@PLCC32 [(SA015A1T)]  
F49L004BA@TSOP40 [(SA409T)] F49L004UA@PLCC32 [(SA015A1T)]

F49L004UA@TSOP40 [(SA409T)]      F49L040A@PLCC32 [(SA015A1T)]  
F49L040A@VSOP32 [(SA620)]      F49L400BA@TSOP48 [(SA247-B005)]  
F49L400UA@TSOP48 [(SA247-B005)]      F49L800BA@TSOP48 [(SA247)]  
F49L800UA@TSOP48 [(SA247)]

## ELECTRONIC ARRAYS

### E(E)PROM/FRAM/NVRAM

EA2716

## EM

### MICROCONTROLLER

EM6503@SOIC24 [(SA404)]  
EM6503@SOIC24(ISP) [ISP-HEADER01]  
EM6504@SOIC24 [(SA404)]  
EM6504@SOIC24(ISP) [ISP-HEADER01]  
EM6505@SOIC24 [(SA404)]  
EM6505@SOIC24(ISP) [ISP-HEADER01]  
EM6517@SOIC28 [(SA404)]  
EM6517@SOIC28(ISP) [ISP-HEADER01]  
EM6520@TQFP44 [(SA245A)]  
EM6520@TQFP44(ISP) [ISP-HEADER01]  
EM6521@TQFP52(ISP) [ISP-HEADER01]  
EM6522@TQFP64(ISP) [ISP-HEADER01]  
EM6540@SOIC18 [(SA404)]  
EM6540@SOIC18(ISP) [ISP-HEADER01]  
EM6580                      EM6580(ISP) [ISP-HEADER01]  
EM6580@SOIC14 [(SA602)]  
EM6580@SOIC14(ISP) [ISP-HEADER01]  
EM6580@SOIC8 [(SA602A)]      EM6580@SOIC8(ISP) [ISP-HEADER01]  
EM6580@TSSOP14 [(SA026)]  
EM6580@TSSOP14(ISP) [ISP-HEADER01]  
EM6812\_2K                      EM6812\_2K(ISP) [ISP-HEADER01]  
EM6812\_2K@SOIC24 [(SA404)]  
EM6812\_2K@SOIC24(ISP) [ISP-HEADER01]  
EM6812\_2K@TSSOP24 [(SA026)]  
EM6812\_2K@TSSOP24(ISP) [ISP-HEADER01]

EM6812\_4K                    EM6812\_4K(ISP) [ISP-HEADER01]  
EM6812\_4K@SOIC24 [(SA404)]  
EM6812\_4K@SOIC24(ISP) [ISP-HEADER01]  
EM6812\_4K@TSSOP24 [(SA026)]  
EM6812\_4K@TSSOP24(ISP) [ISP-HEADER01]  
EM6812\_8K                    EM6812\_8K(ISP) [ISP-HEADER01]  
EM6812\_8K@SOIC24 [(SA404)]  
EM6812\_8K@SOIC24(ISP) [ISP-HEADER01]  
EM6812\_8K@TSSOP24 [(SA026)]  
EM6812\_8K@TSSOP24(ISP) [ISP-HEADER01]

## EMTC

### E(E)PROM/FRAM/NVRAM

EM24C02                    EM24C02@SOIC8 [(SA602A)]  
EM24C02@TSSOP8 [(SA026)]        EM24C04  
EM24C04@SOIC8 [(SA602A)]        EM24C04@TSSOP8 [(SA026)]  
EM24C08                    EM24C08@SOIC8 [(SA602A)]  
EM24C08@TSSOP8 [(SA026)]        EM24C16  
EM24C16@SOIC8 [(SA602A)]        EM24C16@TSSOP8 [(SA026)]  
EM25SL512@SOIC8 [(SA602A)]        EM29SF002AB  
EM29SF002AB@PLCC32 [(SA015A1T)]    EM29SF002AB@TSOP32 [(SA410T)]  
EM29SF002AT                    EM29SF002AT@PLCC32 [(SA015A1T)]  
EM29SF002AT@TSOP32 [(SA410T)]    EM29SF002NAB  
EM29SF002NAB@PLCC32 [(SA015A1T)]    EM29SF002NAB@TSOP32 [(SA410T)]  
EM29SF002NAT                    EM29SF002NAT@PLCC32 [(SA015A1T)]  
EM29SF002NAT@TSOP32 [(SA410T)]

## EON

### E(E)PROM/FRAM/NVRAM

EN25B05(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B05(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B05(Bottom Boot)@VDFN8 [(SA683)]  
EN25B05(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B05(Top Boot)@VDFN8 [(SA683)]  
EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]

EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B10(Bottom Boot)@VDFN8 [(SA683)]  
EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B10(Top Boot)@VDFN8 [(SA683)]  
EN25B16(Bottom Boot)@SOP8 [(SA605A)]  
EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]  
EN25B16(Top Boot)@SOP8 [(SA605A)]  
EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFPN8 [(SA684)]  
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Bottom Boot)@VDFN8 [(SA683)]  
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Top Boot)@VDFN8 [(SA683)]  
EN25B32(Bottom Boot)@SOIC16 [(SA404)]  
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Bottom Boot)@SOP8 [(SA605A)]  
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Bottom Boot)@VDFN8 [(SA684)]  
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
EN25B32(Top Boot)@SOIC16 [(SA404)]  
EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Top Boot)@SOP8 [(SA605A)]  
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Top Boot)@VDFN8 [(SA684)]  
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]  
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Bottom Boot)@VDFN8 [(SA683)]  
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@SOIC16 [(SA404)]  
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Bottom Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]  
EN25B64(Top Boot)@SOIC16 [(SA404)]  
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]

EN25B64(Top Boot)@VDFN8 [(SA683)]  
 EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]  
 EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B80(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B80(Top Boot)@VDFN8 [(SA683)]  
 EN25D16                    EN25D16@SOP16 [(SA404)]  
 EN25D16@SOP8 [(SA605A)]       EN25D16@VDFN8 [(SA684)]  
 EN25D80                    EN25D80@SOP8 [(SA605A)]  
 EN25D80@VDFN8 [(SA683)]       EN25F05@SOP8(4.0) [(SA602A)]  
 EN25F05@SOP8(5.4) [(SA605A)]    EN25F05@VDFN8 [(SA683)]  
 EN25F10@SOP8(4.0) [(SA602A)]    EN25F10@SOP8(5.4) [(SA605A)]  
 EN25F10@VDFN8 [(SA683)]       EN25F16  
 EN25F16@SOP16 [(SA404)]       EN25F16@SOP8 [(SA605A)]  
 EN25F16@VDFN8 [(SA684)]       EN25F20@SOP8 [(SA605A)]  
 EN25F20@VDFN8 [(SA683)]       EN25F40@SOP8(150mil) [(SA602A)]  
 EN25F40@SOP8(209mil) [(SA605A)]    EN25F40@VDFN8 [(SA683)]  
 EN25F80                    EN25F80@SOP8 [(SA605A)]  
 EN25F80@VDFN8 [(SA683)]       EN25LF05@SOP8(4.0) [(SA602A)]  
 EN25LF05@SOP8(5.4) [(SA605A)]    EN25LF05@VDFN8 [(SA683)]  
 EN25LF10@SOP8(4.0) [(SA602A)]    EN25LF10@SOP8(5.4) [(SA605A)]  
 EN25LF10@VDFN8 [(SA683)]       EN25LV010@SOIC8 [(SA602A)]  
 EN25LV010@VFQFPN8 [(SA684)]    EN25LV020@SOIC8 [(SA602A)]  
 EN25LV020@VFQFPN8 [(SA684)]    EN25LV040@SOIC8 [(SA602A)]  
 EN25LV040@VFQFPN8 [(SA684)]    EN25LV080@SOIC8 [(SA602A)]  
 EN25LV080@VFQFPN8 [(SA684)]    EN25LV160@SOIC8 [(SA602A)]  
 EN25LV160@SOIC8(ISP) [ISP-HEADER01]  
 EN25LV160@VFQFPN8 [(SA683)]  
 EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]  
 EN25LV512@SOIC8 [(SA602A)]       EN25LV512@VFQFPN8 [(SA684)]  
 EN25P05@SOP8(4.0) [(SA602A)]    EN25P05@SOP8(5.4) [(SA605A)]  
 EN25P05@VDFN8 [(SA683)]       EN25P10@SOP8(4.0) [(SA602A)]  
 EN25P10@SOP8(5.4) [(SA605A)]    EN25P10@VDFN8 [(SA683)]  
 EN25P16@SOP8 [(SA605A)]       EN25P16@SOP8(ISP) [ISP-HEADER01]  
 EN25P16@VFQFPN8 [(SA684)]  
 EN25P16@VFQFPN8(ISP) [ISP-HEADER01]  
 EN25P20@SOP8(4.0) [(SA602A)]    EN25P20@SOP8(5.4) [(SA605A)]  
 EN25P20@VDFN8 [(SA683)]       EN25P32@SOIC16 [(SA404)]  
 EN25P32@SOIC16(ISP) [(SA404)]    EN25P32@SOP8 [(SA605A)]  
 EN25P32@SOP8(ISP) [(SA605A)]    EN25P32@VDFN8 [(SA684)]  
 EN25P32@VDFN8(ISP) [(SA684)]    EN25P40@SOP8(4.0) [(SA602A)]

EN25P40@SOP8(5.4) [(SA605A)]      EN25P40@VDFN8 [(SA683)]  
EN25P64@SOIC16 [(SA404)]  
EN25P64@SOIC16(ISP) [ISP-HEADER01]  
EN25P64@VDFN8 [(SA683)]  
EN25P64@VDFN8(ISP) [ISP-HEADER01]  
EN25P80@SOP8(4.0) [(SA602A)]      EN25P80@SOP8(5.4) [(SA605A)]  
EN25P80@VDFN8 [(SA683)]      EN25S16@SOP8 [(SA605A)]  
EN25S16@VFQFPN8 [(SA684)]  
EN25S32(Bottom Boot)@SOIC16 [(SA404)]  
EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
EN25S32(Bottom Boot)@SOP8 [(SA605A)]  
EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
EN25S32(Bottom Boot)@VDFN8 [(SA684)]  
EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
EN25S32(Top Boot)@SOIC16 [(SA404)]  
EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]  
EN25S32(Top Boot)@SOP8 [(SA605A)]  
EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]  
EN25S32(Top Boot)@VDFN8 [(SA684)]  
EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]  
EN25T16@SOP8 [(SA605A)]      EN25T16@VFQFPN8 [(SA684)]  
EN25T80      EN25T80@SOP8 [(SA605A)]  
EN25T80@VDFN8 [(SA683)]      EN27C010  
EN27C010@PLCC32 [(SA015A1T)]      EN27C512  
EN27C512@PLCC32 [(SA015A1T)]      EN29F002AB  
EN29F002AB@PLCC32 [(SA015A1T)]      EN29F002AB@TSOP32 [(SA410T)]  
EN29F002ANB      EN29F002ANB@PLCC32 [(SA015A1T)]  
EN29F002ANB@TSOP32 [(SA410T)]      EN29F002ANT  
EN29F002ANT@PLCC32 [(SA015A1T)]      EN29F002ANT@TSOP32 [(SA410T)]  
EN29F002AT      EN29F002AT@PLCC32 [(SA015A1T)]  
EN29F002AT@TSOP32 [(SA410T)]      EN29F002B  
EN29F002B@PLCC32 [(SA015A1T)]      EN29F002B@TSOP32 [(SA410T)]  
EN29F002NB      EN29F002NB@PLCC32 [(SA015A1T)]  
EN29F002NB@TSOP32 [(SA410T)]      EN29F002NT  
EN29F002NT@PLCC32 [(SA015A1T)]      EN29F002NT@TSOP32 [(SA410T)]  
EN29F002T      EN29F002T@PLCC32 [(SA015A1T)]  
EN29F002T@TSOP32 [(SA410T)]      EN29F010  
EN29F010@PLCC32 [(SA015A1T)]      EN29F010@TSOP32 [(SA410T)]  
EN29F010@VSOP32 [(SA620)]      EN29F040  
EN29F040@PLCC32 [(SA015A1T)]      EN29F040@TSOP32 [(SA410T)]  
EN29F040A      EN29F040A@PLCC32 [(SA015A1T)]  
EN29F040A@TSOP32 [(SA410T)]      EN29F080@TSOP40 [(SA409T)]  
EN29F512      EN29F512@PLCC32 [(SA015A1T)]



EN29F512@TSOP32 [(SA410T)]      EN29F512@VSOP32 [(SA620)]  
EN29F800B@TSOP48 [(SA247-B005)]      EN29F800T@TSOP48 [(SA247-B005)]  
EN29LV010@PLCC32 [(SA015A1T)]      EN29LV010@TSOP32 [(SA410T)]  
EN29LV010@VSOP32 [(SA620)]      EN29LV040@PLCC32 [(SA015A1T)]  
EN29LV040@TSOP32 [(SA410T)]      EN29LV040@VSOP32 [(SA620)]  
EN29LV040A@PLCC32 [(SA015A1T)]      EN29LV040A@TSOP32 [(SA410T)]  
EN29LV040A@VSOP32 [(SA620)]  
EN29LV160AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV160AB@TSOP48 [(SA247-B005)]  
EN29LV160AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV160AT@TSOP48 [(SA247-B005)]  
EN29LV160B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV160B@TSOP48 [(SA247-B005)]  
EN29LV160T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV160T@TSOP48 [(SA247-B005)]  
EN29LV320AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV320AB@TSOP48 [(SA247-B005)]  
EN29LV320AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV320AT@TSOP48 [(SA247-B005)]  
EN29LV320B@FBGA48 [(SA642G-B026A-T048F001)]  
EN29LV320B@TSOP48 [(SA247-B005)]  
EN29LV320T@FBGA48 [(SA642G-B026A-T048F001)]  
EN29LV320T@TSOP48 [(SA247-B005)]  
EN29LV400AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV400AB@TSOP48 [(SA247-B005)]  
EN29LV400AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV400AT@TSOP48 [(SA247-B005)]  
EN29LV400B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV400B@TSOP48 [(SA247-B005)]  
EN29LV400T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV400T@TSOP48 [(SA247-B005)]      EN29LV512@PLCC32 [(SA015A1T)]  
EN29LV512@TSOP32 [(SA410T)]      EN29LV512@VSOP32 [(SA620)]  
EN29LV640B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV640B@TSOP48 [(SA247-B005)]  
EN29LV640H@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV640H@TSOP48 [(SA247-B005)]  
EN29LV640L@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV640L@TSOP48 [(SA247-B005)]  
EN29LV640T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV640T@TSOP48 [(SA247-B005)]  
EN29LV641H@FBGA63 [(SA642M-B026A-W048F001Y)]  
EN29LV641H@TSOP48 [(SA247-B005)]  
EN29LV641L@FBGA63 [(SA642M-B026A-W048F001Y)]

EN29LV641L@TSOP48 [(SA247-B005)]  
EN29LV800AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV800AB@TSOP48 [(SA247-B005)]  
EN29LV800AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV800AT@TSOP48 [(SA247-B005)]  
EN29LV800B@TSOP48 [(SA247-B005)]  
EN29LV800BB(Low)@TSOP48 [(SA247-B005)]  
EN29LV800BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV800BB@TSOP48 [(SA247-B005)]  
EN29LV800BT(Low)@TSOP48 [(SA247-B005)]  
EN29LV800BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29LV800BT@TSOP48 [(SA247-B005)]  
EN29LV800T@TSOP48 [(SA247-B005)]  
EN29PL032@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29PL032@FBGA56 [(SA642P-B079A-W056F001Y)]  
EN29PL032@TSOP48 [(SA247-B005)]  
EN29PL064@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29PL064@FBGA56 [(SA642P-B079A-W056F001Y)]  
EN29PL064@TSOP48 [(SA247-B005)]  
EN29SL160B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL160B@TSOP48 [(SA247-B005)]  
EN29SL160T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL160T@TSOP48 [(SA247-B005)]  
EN29SL400B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL400B@TSOP48 [(SA247-B005)]  
EN29SL400T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL400T@TSOP48 [(SA247-B005)]  
EN29SL800B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL800B@TSOP48 [(SA247-B005)]  
EN29SL800T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29SL800T@TSOP48 [(SA247-B005)]  
EN71PL03280@FBGA56 [(SA642P-B079A-W056F001Y)]  
EN71PL032A0@FBGA56 [(SA642P-B079A-W056F001Y)]  
EN71PL064A0@FBGA56 [(SA642P-B079A-W056F001Y)]  
EN71PL064B0@FBGA56 [(SA642P-B079A-W056F001Y)]

## EPSON

### E(E)PROM/FRAM/NVRAM

S1H0H324B2B1@FBGA66 [(SA642E-B023A-T072F001)]  
S1H0H324B2T1@FBGA66 [(SA642E-B023A-T072F001)]

S1H0H326B2B1@FBGA66 [(SA642E-B023A-T072F001)]  
S1H0H326B2T1@FBGA66 [(SA642E-B023A-T072F001)]  
S1H0H328B2B2@FBGA66 [(SA642E-B023A-T072F001)]  
S1H0H328B2T2@FBGA66 [(SA642E-B023A-T072F001)]  
S1H0J642B2B3@FBGA68 [(SA642E-B023A-T072F001)]  
S1H0J642B2T3@FBGA68 [(SA642E-B023A-T072F001)]  
S1H0J646B2B3@FBGA68 [(SA642E-B023A-T072F001)]  
S1H0J646B2T3@FBGA68 [(SA642E-B023A-T072F001)]  
S1H0J648B2B2@FBGA68 [(SA642E-B023A-T072F001)]  
S1H0J648B2T2@FBGA68 [(SA642E-B023A-T072F001)]

## ESMT

### E(E)PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]      EM25LV010@VFQFPN8 [(SA684)]  
EM25LV512@SOIC8 [(SA602A)]      EM25LV512@VFQFPN8 [(SA684)]  
F25L004AB  
F25L004AB@SOIC8(150mil) [(SA602A)]  
F25L004AB@SOIC8(200mil) [(SA605A)]  
F25L004AT  
F25L004AT@SOIC8(150mil) [(SA602A)]  
F25L004AT@SOIC8(200mil) [(SA605A)]  
F25L008AB@SOIC8 [(SA605A)]      F25L008AT@SOIC8 [(SA605A)]  
F25L016AB@SOIC8 [(SA605A)]      F25L016AT@SOIC8 [(SA605A)]  
F25L04UA@SOIC8 [(SA602A)]  
F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]  
F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]  
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]  
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]  
F25L32PA@SOIC16 [(SA404)]      F25L32PA@SOIC8 [(SA605A)]  
F49B002UA      F49B002UA@PLCC32 [(SA015A1T)]  
F49L004BA@PLCC32 [(SA015A1T)]      F49L004BA@TSOP40 [(SA409T)]  
F49L004UA@PLCC32 [(SA015A1T)]      F49L004UA@TSOP40 [(SA409T)]  
F49L040A@PLCC32 [(SA015A1T)]      F49L040A@VSOP32 [(SA620)]  
F49L160BA@TSOP48 [(SA247)]      F49L160UA@TSOP48 [(SA247)]  
F49L320BA@TSOP48 [(SA247)]      F49L320UA@TSOP48 [(SA247)]  
F49L400BA@TSOP48 [(SA247-B005)]      F49L400UA@TSOP48 [(SA247-B005)]  
F49L800BA@TSOP48 [(SA247)]      F49L800UA@TSOP48 [(SA247)]  
FM91L01604BA@FBGA56 [(SA642P-B207A-W056F001Y)]  
FM91L01604UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
FM91L03208BA@FBGA56 [(SA642P-B207A-W056F001Y)]

FM91L03208BIA@FBGA56 [(SA642P-B207A-W056F001Y)]  
FM91L03208UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
FM91L03208UIA@FBGA56 [(SA642P-B207A-W056F001Y)]

## EXCELSEMI

### E(E)PROM/FRAM/NVRAM

ES25M16 ES25M16@SOP16 [(SA404)]  
ES25M16@SOP8[150 mil] [(SA602A)] ES25M16@SOP8[208 mil] [(SA605A)]  
ES25M40 ES25M40@SOP16 [(SA404)]  
ES25M40@SOP8[150 mil] [(SA602A)] ES25M40@SOP8[208 mil] [(SA605A)]  
ES25M80 ES25M80@SOP16 [(SA404)]  
ES25M80@SOP8[150 mil] [(SA602A)] ES25M80@SOP8[208 mil] [(SA605A)]  
ES25P16@SOP8 [(SA605A)] ES25P40@SOP8 [(SA605A)]  
ES25P80@SOP8 [(SA605A)]  
ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160DB@PSOP44 [(SA638)]  
ES29LV160DB@TSOP48 [(SA247-B005)]  
ES29LV160DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160DT@PSOP44 [(SA638)]  
ES29LV160DT@TSOP48 [(SA247-B005)]  
ES29LV160EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160EB@TSOP48 [(SA247-B005)]  
ES29LV160ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160ET@TSOP48 [(SA247-B005)]  
ES29LV160FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160FB@TSOP48 [(SA247-B005)]  
ES29LV160FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV160FT@TSOP48 [(SA247-B005)]  
ES29LV320DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320DB@TSOP48 [(SA247-B005)]  
ES29LV320DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320DT@TSOP48 [(SA247-B005)]  
ES29LV320EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320EB@TSOP48 [(SA247-B005)]  
ES29LV320ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320ET@TSOP48 [(SA247-B005)]  
ES29LV320FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320FB@TSOP48 [(SA247-B005)]  
ES29LV320FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
ES29LV320FT@TSOP48 [(SA247-B005)]

ES29LV400DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400DB@TSOP48 [(SA247-B005)]  
 ES29LV400DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400DT@TSOP48 [(SA247-B005)]  
 ES29LV400EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400EB@TSOP48 [(SA247-B005)]  
 ES29LV400ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400ET@TSOP48 [(SA247-B005)]  
 ES29LV800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800DB@PSOP44 [(SA638)]  
 ES29LV800DB@TSOP48 [(SA247-B005)]  
 ES29LV800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800DT@PSOP44 [(SA638)]  
 ES29LV800DT@TSOP48 [(SA247-B005)]  
 ES29LV800EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800EB@TSOP48 [(SA247-B005)]  
 ES29LV800ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800ET@TSOP48 [(SA247-B005)]

## EXEL

### E(E)PROM/FRAM/NVRAM

XL24C01A                    XL24C02  
 XL24C04                    XL24C16  
 XL24C16@SOIC8 [(SA602A)]      XL24C32  
 XL28C256                    XL28C256@PLCC32 [(SA015A1T)]  
 XL28C256@TSOP28 [(SA430T)]      XL9010  
 XL9010(F) [(SA602A)]            XL9020  
 XL9020(F) [(SA602A)]            XL9040  
 XL9040(F) [(SA602A)]            XL9346  
 XL9346@SOIC8 [(SA602A)]        XL93CS56  
 XL93CS56@SOIC8 [(SA602A)]      XL93CS56@TSSOP8 [(SA026)]  
 XL93CS66                    XL93CS66@SOIC8 [(SA602A)]  
 XL93CS66@TSSOP8 [(SA026)]      XL93LC46  
 XL93LC46@SOIC8 [(SA602A)]      XL93LC46A  
 XL93LC46A@SOIC8 [(SA602A)]     XL93LC56  
 XL93LC56@SOIC8 [(SA602A)]      XL93LC56A  
 XL93LC56A@SOIC8 [(SA602A)]     XL93LC66A  
 XL93LC66A@SOIC8 [(SA602A)]     XL9764  
 XLE28C16A                  XLE28C16A@PLCC32 [(SA015A1T)]  
 XLE28C16B                  XLE28C16B@PLCC32 [(SA015A1T)]

XLE28C16B@SOIC24 [(SA404)]      XLM28C16A  
 XLM28C16A@PLCC32 [(SA015A1T)]      XLM46C15  
 XLM46P15                      XLS2804A  
 XLS2816A                      XLS2816A@PLCC32 [(SA015A1T)]  
 XLS2817A                      XLS28C16A  
 XLS28C16A@PLCC32 [(SA015A1T)]      XLS28C16B  
 XLS28C16B@PLCC32 [(SA015A1T)]      XLS28C16B@SOIC24 [(SA404)]  
 XLS28C64B                      XLS28C64B@PLCC32 [(SA015A1T)]  
 XLS28C64B@SOIC28 [(SA404)]      XLS46C15  
 XLS46P15                      XLS93C46  
 XLS93C46@SOIC8 [(SA602A)]      XLS93C56  
 XLS93C56@SOIC8 [(SA602A)]      XLS93C66  
 XLS93C66@SOIC8 [(SA602A)]      XLS93CS46  
 XLS93CS46@SOIC8 [(SA602A)]      XLS93CS46@TSSOP8 [(SA026)]  
 XLS93LC06                      XLS93LC06@SOIC8 [(SA602A)]  
 XLS93LC66                      XLS93LC66@SOIC8 [(SA602A)]

## PLD

XLE78C800P-25                      XLE78C800P-35  
 XLE78C800P-45                      XLE78C800S-25  
 XLE78C800S-35                      XLE78C800S-45  
 XLM78C800S-35                      XLM78C800S-45  
 XLS78C800P-25                      XLS78C800P-35  
 XLS78C800P-45                      XLS78C800S-25  
 XLS78C800S-35                      XLS78C800S-45

## FAIRCHILD

### E(E)PROM/FRAM/NVRAM

FM24C02(M8)@SOIC8 [(SA602A)]      FM24C02(MT8)@TSSOP8 [(SA026)]  
 FM24C02(N)                      FM24C03(M8)@SOIC8 [(SA602A)]  
 FM24C03(MT8)@TSSOP8 [(SA026)]      FM24C03(N)  
 FM24C04(M8)@SOIC8 [(SA602A)]      FM24C04(MT8)@TSSOP8 [(SA026)]  
 FM24C04(N)                      FM24C05(M8)@SOIC8 [(SA602A)]  
 FM24C05(MT8)@TSSOP8 [(SA026)]      FM24C05(N)  
 FM24C08(M8)@SOIC8 [(SA602A)]      FM24C08(MT8)@TSSOP8 [(SA026)]  
 FM24C08(N)                      FM24C09(M8)@SOIC8 [(SA602A)]  
 FM24C09(MT8)@TSSOP8 [(SA026)]      FM24C09(N)  
 FM24C128(MT8)@TSSOP8 [(SA026)]      FM24C128(MW8)@SOIC8 [(SA602A)]

FM24C128(N) FM24C16(M8)@SOIC8 [(SA602A)]  
FM24C16(MT8)@TSSOP8 [(SA026)] FM24C16(N)  
FM24C17(M8)@SOIC8 [(SA602A)] FM24C17(MT8)@TSSOP8 [(SA026)]  
FM24C17(N) FM24C256(M8)@SOIC8 [(SA602A)]  
FM24C256(N) FM24C32(M8)@SOIC8 [(SA602A)]  
FM24C32(N) FM27C010  
FM27C010@PLCC32 [(SA015A1T)] FM27C010@TSOP32 [(SA410T)]  
FM27C040 FM27C040@PLCC32 [(SA015A1T)]  
FM27C040@TSOP32 [(SA410T)] FM27C256  
FM27C256@PLCC32 [(SA015A1T)] FM27C256Q  
FM27C256Q@PLCC32 [(SA015A1T)] FM27C512  
FM27C512@PLCC32 [(SA015A1T)]  
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C06(N)(08bit) FM93C06(N)(16bit)  
FM93C14(16bit) FM93C46(M8)@SOIC8 [(SA602A)]  
FM93C46(MT8)@TSSOP8 [(SA026)] FM93C46(N)  
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C46A(N)(08bit) FM93C46A(N)(16bit)  
FM93C56(M8)@SOIC8 [(SA602A)] FM93C56(MT8)@TSSOP8 [(SA026)]  
FM93C56(N)  
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C56A(N)(08bit) FM93C56A(N)(16bit)  
FM93C66(M8)@SOIC8 [(SA602A)] FM93C66(MT8)@TSSOP8 [(SA026)]  
FM93C66(N)  
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C66A(N)(08bit) FM93C66A(N)(16bit)  
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C76(N)(16bit)  
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]

FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C76A(N)(08bit) FM93C76A(N)(16bit)  
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C86(N)(16bit)  
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]  
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]  
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]  
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]  
FM93C86A(N)(08bit) FM93C86A(N)(16bit)  
FM93CS06(M8)@SOIC8 [(SA602A)] FM93CS06(MT8)@TSSOP8 [(SA026)]  
FM93CS06(N) FM93CS46(M8)@SOIC8 [(SA602A)]  
FM93CS46(MT8)@TSSOP8 [(SA026)] FM93CS46(N)  
FM93CS56(M8)@SOIC8 [(SA602A)] FM93CS56(MT8)@TSSOP8 [(SA026)]  
FM93CS56(N) FM93CS66(M8)@SOIC8 [(SA602A)]  
FM93CS66(MT8)@TSSOP8 [(SA026)] FM93CS66(N)  
FM93S46(M8)@SOIC8 [(SA602A)] FM93S46(MT8)@TSSOP8 [(SA026)]  
FM93S46(N) FM93S56(M8)@SOIC8 [(SA602A)]  
FM93S56(MT8)@TSSOP8 [(SA026)] FM93S56(N)  
FM93S66(M8)@SOIC8 [(SA602A)] FM93S66(MT8)@TSSOP8 [(SA026)]  
FM93S66(N) MM2716  
MM2716E NM24C02(M8)@SOIC8 [(SA602A)]  
NM24C02(MT8)@TSSOP8 [(SA026)] NM24C02(N)  
NM24C02L(M8)@SOIC8 [(SA602A)] NM24C02L(MT8)@TSSOP8 [(SA026)]  
NM24C02L(N) NM24C03(M8)@SOIC8 [(SA602A)]  
NM24C03(MT8)@TSSOP8 [(SA026)] NM24C03(N)  
NM24C04(M8)@SOIC8 [(SA602A)] NM24C04(MT8)@TSSOP8 [(SA026)]  
NM24C04(N) NM24C05(M8)@SOIC8 [(SA602A)]  
NM24C05(MT8)@TSSOP8 [(SA026)] NM24C05(N)  
NM24C08(M8)@SOIC8 [(SA602A)] NM24C08(MT8)@TSSOP8 [(SA026)]  
NM24C08(N) NM24C09(M8)@SOIC8 [(SA602A)]  
NM24C09(MT8)@TSSOP8 [(SA026)] NM24C09(N)  
NM24C16(M8)@SOIC8 [(SA602A)] NM24C16(MT8)@TSSOP8 [(SA026)]  
NM24C16(N) NM24C17(M8)@SOIC8 [(SA602A)]  
NM24C17(MT8)@TSSOP8 [(SA026)] NM24C17(N)  
NM24C65(M8)SOIC8 [(SA602A)] NM24C65(N)  
NM27C010 NM27C010@PLCC32 [(SA015A1T)]  
NM27C010@TSOP32 [(SA410T)] NM27C020  
NM27C020@PLCC32 [(SA015A1T)] NM27C020@TSOP32 [(SA410T)]  
NM27C020Q NM27C020Q@PLCC32 [(SA015A1T)]  
NM27C020Q@TSOP32 [(SA410T)] NM27C040  
NM27C040@PLCC32 [(SA015A1T)] NM27C040@TSOP32 [(SA410T)]



NM27C128 NM27C128@PLCC32 [(SA015A1T)]  
 NM27C210 NM27C210@PLCC44 [(SA244)]  
 NM27C240 NM27C240@PLCC44 [(SA244)]  
 NM27C256 NM27C256@PLCC32 [(SA015A1T)]  
 NM27C512 NM27C512@PLCC32 [(SA015A1T)]  
 NM27C64Q NM27C64Q@PLCC32 [(SA015A1T)]  
 NM27LC256 NM27LC256@PLCC32 [(SA015A1T)]  
 NM27LC512 NM27LC512@PLCC32 [(SA015A1T)]  
 NM27LV010 NM27LV010@PLCC32 [(SA015A1T)]  
 NM27LV010@TSOP32 [(SA410T)] NM27LV210  
 NM27LV210@PLCC44 [(SA244)] NM27LV512  
 NM27LV512@PLCC32 [(SA015A1T)] NM27P040  
 NM27P040@PLCC32 [(SA015A1T)] NM27P040@TSOP32 [(SA410T)]  
 NM27P210 NM27P210@PLCC44 [(SA244)]  
 NM27P512 NM27P512@PLCC32 [(SA015A1T)]  
 NM93C66(M8)(16bit)@SOIC8 [(SA602A)]  
 NM93C66(MT8)(16bit)@TSSOP8 [(SA026)]  
 NM93C66(N)(16bit) NM93CS06(M8)@SOIC8 [(SA602A)]  
 NM93CS06(MT8)@TSSOP8 [(SA026)] NM93CS06(N)  
 NM93CS46(M8)@SOIC8 [(SA602A)] NM93CS46(MT8)@TSSOP8 [(SA026)]  
 NM93CS46(N) NM93CS56(M8)@SOIC8 [(SA602A)]  
 NM93CS56(MT8)@TSSOP8 [(SA026)] NM93CS56(N)  
 NM93CS66(M8)@SOIC8 [(SA602A)] NM93CS66(MT8)@TSSOP8 [(SA026)]  
 NM93CS66(N) NMC2732  
 NMC27C010 NMC27C010@PLCC32 [(SA015A1T)]  
 NMC27C010@TSOP32 [(SA410T)] NMC27C1024  
 NMC27C1024@PLCC44 [(SA244)] NMC27C128B  
 NMC27C128B@PLCC32 [(SA015A1T)] NMC27C128BN  
 NMC27C128BN@PLCC32 [(SA015A1T)] NMC27C128BQ  
 NMC27C128BQ@PLCC32 [(SA015A1T)] NMC27C128CQ  
 NMC27C16 NMC27C16BQ  
 NMC27C16BQE NMC27C16H  
 NMC27C16HQ NMC27C16Q  
 NMC27C256 NMC27C256@PLCC32 [(SA015A1T)]  
 NMC27C256B NMC27C256B@PLCC32 [(SA015A1T)]  
 NMC27C256Q NMC27C256Q@PLCC32 [(SA015A1T)]  
 NMC27C32 NMC27C32B  
 NMC27C32BQ NMC27C32E  
 NMC27C32EH NMC27C32H  
 NMC27C512 NMC27C512@PLCC32 [(SA015A1T)]  
 NMC27C512A NMC27C512A@PLCC32 [(SA015A1T)]  
 NMC27C512AN NMC27C512AN@PLCC32 [(SA015A1T)]  
 NMC27C64 NMC27C64(BN)

NMC27C64(N)                    NMC27CP128  
 NMC87C257Q                    NMC87C257Q@PLCC32 [(SA015A1T)]  
 NMC87C257V                    NMC87C257V@PLCC32 [(SA015A1T)]  
 NMC9346(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC9346(N)(16bit)  
 NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C46(N)(16bit)  
 NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C46A(N)(16bit)  
 NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C56(N)(16bit)  
 NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C66(N)(16bit)            NMC93CS06(M8)@SOIC8 [(SA602A)]  
 NMC93CS06(MT8)@TSSOP8 [(SA026)]    NMC93CS06(N)  
 NMC93CS46(M8)@SOIC8 [(SA602A)]    NMC93CS46(MT8)@TSSOP8 [(SA026)]  
 NMC93CS46(N)                    NMC93CS56(M8)@SOIC8 [(SA602A)]  
 NMC93CS56(MT8)@TSSOP8 [(SA026)]    NMC93CS56(N)  
 NMC93CS66(M8)@SOIC8 [(SA602A)]    NMC93CS66(MT8)@TSSOP8 [(SA026)]  
 NMC93CS66(N)                    NMC9817

## DRAM & SRAM

F1600                    F1600@SOJ24 [(SA646)]  
 F1601                    F1601@SOJ24 [(SA646)]  
 F1620                    F1621

## MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]    ACE1001(M8X)@SOIC8 [(SA602A)]  
 ACE1001(MT8)@TSSOP8 [(SA026)]    ACE1001(MT8X)@TSSOP8 [(SA026)]  
 ACE1001E(M8)@SOIC8 [(SA602A)]    ACE1001E(M8X)@SOIC8 [(SA602A)]  
 ACE1001E(MT8)@TSSOP8 [(SA026)]    ACE1001E(MT8X)@TSSOP8 [(SA026)]  
 ACE1001L(M8)@SOIC8 [(SA602A)]    ACE1001L(M8X)@SOIC8 [(SA602A)]  
 ACE1001L(MT8)@TSSOP8 [(SA026)]    ACE1001L(MT8X)@TSSOP8 [(SA026)]  
 ACE1101(EMT8)@TSSOP8 [(SA026)]    ACE1101(EMT8X)@TSSOP8 [(SA026)]  
 ACE1101(EN)                    ACE1101(EN14)

ACE1101(LMT8)@TSSOP8 [(SA026)] ACE1101(LMT8X)@TSSOP8 [(SA026)]  
ACE1101(LN) ACE1101(LN14)  
ACE1101(MT8)@TSSOP8 [(SA026)] ACE1101(MT8X)@TSSOP8 [(SA026)]  
ACE1101(N) ACE1101(N14)  
ACE1101(VMT8)@TSSOP8 [(SA026)] ACE1101(VMT8X)@TSSOP8 [(SA026)]  
ACE1101(VN) ACE1101(VN14)  
ACE1101B(EMT8)@TSSOP8 [(SA026)] ACE1101B(EMT8X)@TSSOP8 [(SA026)]  
ACE1101B(EN) ACE1101B(EN14)  
ACE1101B(MT8)@TSSOP8 [(SA026)] ACE1101B(MT8X)@TSSOP8 [(SA026)]  
ACE1101B(N) ACE1101B(N14)  
ACE1101B(VMT8)@TSSOP8 [(SA026)] ACE1101B(VMT8X)@TSSOP8 [(SA026)]  
ACE1101B(VN) ACE1101B(VN14)  
ACE1202(dip14) ACE1202(dip8)  
ACE1202(M14)@SOIC14 [(SA602)] ACE1202(M8)@SOIC8 [(SA602A)]  
ACE12022(dip14) ACE12022(dip8)  
ACE12022(M14)@SOIC14 [(SA602)] ACE12022(M8)@SOIC8 [(SA602A)]  
ACE12022B(dip14) ACE12022B(dip8)  
ACE12022B(M14)@SOIC14 [(SA602)] ACE12022B(M8)@SOIC8 [(SA602A)]  
ACE12022BE(dip14) ACE12022BE(dip8)  
ACE12022BE(M14)@SOIC14 [(SA602)] ACE12022BE(M8)@SOIC8 [(SA602A)]  
ACE12022BV(dip14) ACE12022BV(dip8)  
ACE12022BV(M14)@SOIC14 [(SA602)] ACE12022BV(M8)@SOIC8 [(SA602A)]  
ACE12022E(dip14) ACE12022E(dip8)  
ACE12022E(M14)@SOIC14 [(SA602)] ACE12022E(M8)@SOIC8 [(SA602A)]  
ACE1202B(dip14) ACE1202B(dip8)  
ACE1202B(M14)@SOIC14 [(SA602)] ACE1202B(M8)@SOIC8 [(SA602A)]  
ACE1202BE(dip14) ACE1202BE(dip8)  
ACE1202BE(M14)@SOIC14 [(SA602)] ACE1202BE(M8)@SOIC8 [(SA602A)]  
ACE1202BV(dip14) ACE1202BV(dip8)  
ACE1202BV(M14)@SOIC14 [(SA602)] ACE1202BV(M8)@SOIC8 [(SA602A)]  
ACE1202E(dip14) ACE1202E(dip8)  
ACE1202E(M14)@SOIC14 [(SA602)] ACE1202E(M8)@SOIC8 [(SA602A)]  
ACE1202L(dip14) ACE1202L(dip8)  
ACE1202L(M14)@SOIC14 [(SA602)] ACE1202L(M8)@SOIC8 [(SA602A)]  
ACE1202V(dip8) ACE1202V(M14)@SOIC14 [(SA602)]  
ACE1202V(M8)@SOIC8 [(SA602A)] ACE1501(EM)@SOIC14 [(SA602)]  
ACE1501(EM8)@SOIC8 [(SA602A)] ACE1501(EM8X)@SOIC8 [(SA602A)]  
ACE1501(EMT)@TSOP14 [(SA026)] ACE1501(EMT8)@TSSOP8 [(SA026)]  
ACE1501(EMT8X)@TSSOP8 [(SA026)] ACE1501(EMTX)@TSOP14 [(SA026)]  
ACE1501(EMX)@SOIC14 [(SA602)] ACE1501(EN)  
ACE1501(EN14) ACE1501(VM)@SOIC14 [(SA602)]  
ACE1501(VM8)@SOIC8 [(SA602A)] ACE1501(VM8X)@SOIC8 [(SA602A)]  
ACE1501(VMT)@TSOP14 [(SA026)] ACE1501(VMT8)@TSSOP8 [(SA026)]

ACE1501(VMT8X)@TSSOP8 [(SA026)] ACE1501(VMTX)@TSOP14 [(SA026)]  
 ACE1501(VMX)@SOIC14 [(SA602)] ACE1501(VN)  
 ACE1501(VN14) ACE1502(EM)@SOIC14 [(SA602)]  
 ACE1502(EM8)@SOIC8 [(SA602A)] ACE1502(EMT)@TSOP14 [(SA026)]  
 ACE1502(EMT8)@TSSOP8 [(SA026)] ACE1502(EN)  
 ACE1502(EN14) ACE1502(VM)@SOIC14 [(SA602)]  
 ACE1502(VM8)@SOIC8 [(SA602A)] ACE1502(VMT)@TSOP14 [(SA026)]  
 ACE1502(VMT8)@TSSOP8 [(SA026)] ACE1502(VN)  
 ACE1502(VN14) ACE8000(M8)@SOIC8 [(SA602A)]  
 ACE8000(M8X)@SOIC8 [(SA602A)] ACE8000E(M8)@SOIC8 [(SA602A)]  
 ACE8000E(M8X)@SOIC8 [(SA602A)] ACE8001(M8)@SOIC8 [(SA602A)]  
 ACE8001(M8X)@SOIC8 [(SA602A)] ACE8001(MT8)@TSSOP8 [(SA026)]  
 ACE8001(MT8X)@TSSOP8 [(SA026)] ACE8001E(M8)@SOIC8 [(SA602A)]  
 ACE8001E(M8X)@SOIC8 [(SA602A)] ACE8001E(MT8)@TSSOP8 [(SA026)]  
 ACE8001E(MT8X)@TSSOP8 [(SA026)] FMS7401L(EM8X)@SOIC8 [(SA602A)]  
 FMS7401L(EMT8X)@TSSOP8 [(SA026)] FMS7401L(EMTX)@TSOP14 [(SA026)]  
 FMS7401L(EMX)@SOIC14 [(SA602)] FMS7401L(EN)  
 FMS7401L(EN14) FMS7401L(VN)  
 FMS7401L(VN14)

## FORCE TECHNOLOGIES

### E(E)PROM/FRAM/NVRAM

FT24C01 FT24C01@SOIC8 [(SA602A)]  
 FT24C01@TSOP8 [(SA026)] FT24C01A  
 FT24C01A@SOIC8 [(SA602A)] FT24C01A@TSOP8 [(SA026)]  
 FT24C02 FT24C02@SOP8 [(SA602A)]  
 FT24C02@TSSOP8 [(SA026)] FT24C02A  
 FT24C02A@SOP8 [(SA602A)] FT24C02A@TSSOP8 [(SA026)]  
 FT24C04 FT24C04@SOP8 [(SA602A)]  
 FT24C04@TSSOP8 [(SA026)] FT24C04A  
 FT24C04A@SOP8 [(SA602A)] FT24C04A@TSSOP8 [(SA026)]  
 FT24C08 FT24C08@SOIC8 [(SA602A)]  
 FT24C08@TSOP8 [(SA026)] FT24C08A  
 FT24C08A@SOIC8 [(SA602A)] FT24C08A@TSOP8 [(SA026)]  
 FT24C128 FT24C128@SOIC8 [(SA602A)]  
 FT24C128@TSOP8 [(SA026)] FT24C128A  
 FT24C128A@SOIC8 [(SA602A)] FT24C128A@TSOP8 [(SA026)]  
 FT24C16 FT24C16@SOIC8 [(SA602A)]  
 FT24C16@TSOP8 [(SA026)] FT24C16A  
 FT24C16A@SOIC8 [(SA602A)] FT24C16A@TSOP8 [(SA026)]

FT24C256 FT24C256@SOIC8 [(SA602A)]  
FT24C256@TSOP8 [(SA026)] FT24C256A  
FT24C256A@SOIC8 [(SA602A)] FT24C256A@TSOP8 [(SA026)]  
FT24C32 FT24C32@SOIC8 [(SA602A)]  
FT24C32@TSOP8 [(SA026)] FT24C32A  
FT24C32A@SOIC8 [(SA602A)] FT24C32A@TSOP8 [(SA026)]  
FT24C64 FT24C64@SOIC8 [(SA602A)]  
FT24C64@TSOP8 [(SA026)] FT24C64A  
FT24C64A@SOIC8 [(SA602A)] FT24C64A@TSOP8 [(SA026)]  
FT27C010 FT27C010@PLCC32 [(SA015A1T)]  
FT27C010@TSOP32 [(SA410T)] FT27C020  
FT27C020@PLCC32 [(SA015A1T)] FT27C020@TSOP32 [(SA410T)]  
FT27C040 FT27C040@PLCC32 [(SA015A1T)]  
FT27C040@TSOP32 [(SA410T)] FT27C16  
FT27C256 FT27C256@PLCC32 [(SA015A1T)]  
FT27C64 FT27C64@PLCC32 [(SA015A1T)]  
FT27HC256 FT27HC256@PLCC32 [(SA015A1T)]  
FT27HC64 FT27HC64@PLCC32 [(SA015A1T)]  
FT28C010 FT28C010@JLCC32 [(SA412A)]  
FT28C010@PLCC32 [(SA015A1T)] FT28C010@PLCC44 [(SA244)]  
FT28C010@TSOP32 [(SA410T)] FT28C010E  
FT28C010E@JLCC32 [(SA412A)] FT28C010E@PLCC32 [(SA015A1T)]  
FT28C010E@PLCC44 [(SA244)] FT28C010E@TSOP32 [(SA410T)]  
FT28C020 FT28C020@JLCC32 [(SA412A)]  
FT28C020@PLCC32 [(SA015A1T)] FT28C020@PLCC44 [(SA244)]  
FT28C020@TSOP32 [(SA410T)] FT28C040  
FT28C040@JLCC32 [(SA412A)] FT28C040@PLCC32 [(SA015A1T)]  
FT28C040@PLCC44 [(SA244)] FT28C040@TSOP32 [(SA410T)]  
FT28C16 FT28C16@PLCC32 [(SA015A1T)]  
FT28C256 FT28C256@JLCC32 [(SA412A)]  
FT28C256@PLCC32 [(SA015A1T)] FT28C256@SOIC28 [(SA404)]  
FT28C256@TSOP28 [(SA430T)] FT28C256B  
FT28C256B@JLCC32 [(SA412A)] FT28C256B@PLCC32 [(SA015A1T)]  
FT28C256B@SOIC28 [(SA404)] FT28C256B@TSOP28 [(SA430T)]  
FT28C64 FT28C64@PLCC32 [(SA015A1T)]  
FT28C64@SOIC28 [(SA404)] FT28C64@TSOP28 [(SA430T)]  
FT28C64B FT28C64B@JLCC32 [(SA412A)]  
FT28C64B@PLCC32 [(SA015A1T)] FT28C64B@SOIC28 [(SA404)]  
FT28C64B@TSOP28 [(SA430T)] FT28C64X  
FT28C64X@PLCC32 [(SA015A1T)] FT28C64X@SOIC28 [(SA404)]  
FT28C64X@TSOP28 [(SA430T)] FT28HC64  
FT28HC64@PLCC32 [(SA015A1T)] FT28HC64@TSOP28 [(SA430T)]  
FT58C1001 FT58C1001@SSOP32 [(SA438T)]

FT58C1001@VSOP32 [(SA620)]

## FORWARD

### E(E)PROM/FRAM/NVRAM

24LC01	24LC01@SOIC8 [(SA602A)]
24LC02	24LC02@SOIC8 [(SA602A)]
24LC04	24LC04@SOIC8 [(SA602A)]
24LC08	24LC08@SOIC8 [(SA602A)]
24LC16	24LC16@SOIC8 [(SA602A)]
24LC32	24LC32@SOIC8 [(SA602A)]
24LC64	24LC64@SOIC8 [(SA602A)]

## FREESCALE

### MICROCONTROLLER

MC56F8011VFAE@QFP32 [(SA663+B005)]  
MC56F8013VFAE@QFP32 [(SA663+B005)]  
MC56F8014VFAE@QFP32 [(SA663+B005)]  
MC56F8023MFAE@QFP32 [(SA663+B005)]  
MC56F8023VFAE@QFP32 [(SA663+B005)]  
MC56F8025VLD@QFP44 [(SA245A+B005)]  
MC56F8036MFAE@QFP48 [(SA248+B005)]  
MC56F8036VFAE@QFP48 [(SA248+B005)]  
MC56F8037VLH@QFP64 [(PEP+S616)]  
MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]

MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
MC68HC908AP8CFA@@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32 [(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)] MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44 [(SA675)]  
MC68HC908GR16CFA@TQFP48 [(SA248)]  
MC68HC908GR16CFJ@TQFP32 [(SA663)]  
MC68HC908GR16MFA@TQFP48 [(SA248)]  
MC68HC908GR16MFJ@TQFP32 [(SA663)]  
MC68HC908GR16VFA@TQFP48 [(SA248)]  
MC68HC908GR16VFJ@TQFP32 [(SA663)]  
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32 [(SA663)]  
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28 [(SA404)]  
MC68HC908GR4MFA@TQFP32 [(SA663)] MC68HC908GR4MP  
MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32 [(SA663)]  
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28 [(SA404)]  
MC68HC908GR8CFA@TQFP32 [(SA663)] MC68HC908GR8CP  
MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32 [(SA663)]  
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28 [(SA404)]  
MC68HC908GR8VFA@TQFP32 [(SA663)] MC68HC908GR8VP  
MC68HC908JK1CDW@SOIC20 [(SA404)] MC68HC908JK1CP  
MC68HC908JK1ECDW@SOIC20 [(SA404)]  
MC68HC908JK1ECP  
MC68HC908JK1EMDW@SOIC20 [(SA404)]  
MC68HC908JK1EMP MC68HC908JK1MDW@SOIC20 [(SA404)]  
MC68HC908JK1MP MC68HC908JK3CDW@SOIC20 [(SA404)]  
MC68HC908JK3CP  
MC68HC908JK3ECDW@SOIC20 [(SA404)]  
MC68HC908JK3ECP  
MC68HC908JK3EMDW@SOIC20 [(SA404)]  
MC68HC908JK3EMP MC68HC908JK3MDW@SOIC20 [(SA404)]  
MC68HC908JK3MP MC68HC908JL3CDW@SOIC28 [(SA404)]  
MC68HC908JL3CFA@TQFP48 [(SA248)] MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [(SA404)]

MC68HC908JL3ECFA@TQFP48 [(SA248)]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [(SA404)]  
MC68HC908JL3EMFA@TQFP48 [(SA248)]  
MC68HC908JL3EMP                    MC68HC908JL3MDW@SOIC28 [(SA404)]  
MC68HC908JL3MFA@TQFP48 [(SA248)]    MC68HC908JL3MP  
MC68HC908LB8CDWE(S)@SOIC20        MC68HC908LB8CPE(S)  
MC68HC908LB8MDWE(S)@SOIC20        MC68HC908LB8MPE(S)  
MC68HC908LB8VDWE(S)@SOIC20        MC68HC908LB8VPE(S)  
MC68HC908QT1ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]  
MC68HC908QT1CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1CP                    MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1MP                    MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1VP  
MC68HC908QT2ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2CP                    MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2MP                    MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2VP  
MC68HC908QT4ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4CP                    MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4MP                    MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]    MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)]    MC68HC908QY1MP



MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)] MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)] MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)] MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)] MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]  
MC68HC908QY4CDW@SOIC16 [(SA404)] MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)] MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)] MC68HC908QY4VP  
MC68HRC908JK1CDW@SOIC20 [(SA404)]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [(SA404)]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [(SA404)]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [(SA404)]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [(SA404)]  
MC68HRC908JK3MP  
MC68HRC908JL3CDW@SOIC28 [(SA404)]  
MC68HRC908JL3CFA@TQFP48 [(SA248)]  
MC68HRC908JL3CP  
MC68HRC908JL3ECDW@SOIC28 [(SA404)]  
MC68HRC908JL3ECFA@TQFP48 [(SA248)]  
MC68HRC908JL3ECP  
MC68HRC908JL3EMDW@SOIC28 [(SA404)]  
MC68HRC908JL3EMFA@TQFP48 [(SA248)]  
MC68HRC908JL3EMP  
MC68HRC908JL3MDW@SOIC28 [(SA404)]  
MC68HRC908JL3MFA@TQFP48 [(SA248)]  
MC68HRC908JL3MP MC908AP16CBE@SDIP42 [(SA028)]  
MC908AP16CFAE@LQFP48 [(SA248)] MC908AP16CFBE@TQFP44 [(SA675)]

MC908AP32CBE@SDIP42 [(SA028)]    MC908AP32CFAE@LQFP48 [(SA248)]  
 MC908AP32CFBE@TQFP44 [(SA675)]    MC908AP64CBE@SDIP42 [(SA028)]  
 MC908AP64CFAE@LQFP48 [(SA248)]    MC908AP64CFBE@TQFP44 [(SA675)]  
 MC908AP8CBE@SDIP42 [(SA028)]    MC908AP8CFAE@LQFP48 [(SA248)]  
 MC908AP8CFBE@TQFP44 [(SA675)]    MC908EY16ACFJE@TQFP32 [(SA663)]  
 MC908EY16AKFJE@TQFP32 [(SA663)]    MC908EY16AMFJE@TQFP32 [(SA663)]  
 MC908EY16AVFJE@TQFP32 [(SA663)]    MC908EY8ACFJE@TQFP32 [(SA663)]  
 MC908EY8AKFJE@TQFP32 [(SA663)]    MC908EY8AMFJE@TQFP32 [(SA663)]  
 MC908EY8AVFJE@TQFP32 [(SA663)]    MC908JL16CDWE@SOIC28 [(SA404)]  
 MC908JL16CFJE@LQFP32 [(SA663)]    MC908JL16CPE  
 MC908JL16CSPE@SDIP32 [(SA653)]    MC908QT1ACDWE@SOIC8 [(SA605A)]  
 MC908QT1ACPE    MC908QT1AMDWE@SOIC8 [(SA605A)]  
 MC908QT1AMPE    MC908QT1AVDWE@SOIC8 [(SA605A)]  
 MC908QT1AVPE    MC908QT2ACDWE@SOIC8 [(SA605A)]  
 MC908QT2ACPE    MC908QT2AMDWE@SOIC8 [(SA605A)]  
 MC908QT2AMPE    MC908QT2AVDWE@SOIC8 [(SA605A)]  
 MC908QT2AVPE    MC908QT4ACDWE@SOIC8 [(SA605A)]  
 MC908QT4ACPE    MC908QT4AMDWE@SOIC8 [(SA605A)]  
 MC908QT4AMPE    MC908QT4AVDWE@SOIC8 [(SA605A)]  
 MC908QT4AVPE    MC908QY1ACDTE@TSSOP16 [(SA026)]  
 MC908QY1ACDWE@SOIC16 [(SA404)]    MC908QY1ACPE  
 MC908QY1AMDTE@TSSOP16 [(SA026)]    MC908QY1AMDWE@SOIC16 [(SA404)]  
 MC908QY1AMPE    MC908QY1AVDTE@TSSOP16 [(SA026)]  
 MC908QY1AVDWE@SOIC16 [(SA404)]    MC908QY1AVPE  
 MC908QY2ACDTE@TSSOP16 [(SA026)]    MC908QY2ACDWE@SOIC16 [(SA404)]  
 MC908QY2ACPE    MC908QY2AMDTE@TSSOP16 [(SA026)]  
 MC908QY2AMDWE@SOIC16 [(SA404)]    MC908QY2AMPE  
 MC908QY2AVDTE@TSSOP16 [(SA026)]    MC908QY2AVDWE@SOIC16 [(SA404)]  
 MC908QY2AVPE    MC908QY4ACDTE@TSSOP16 [(SA026)]  
 MC908QY4ACDWE@SOIC16 [(SA404)]    MC908QY4ACPE  
 MC908QY4AMDTE@TSSOP16 [(SA026)]    MC908QY4AMDWE@SOIC16 [(SA404)]  
 MC908QY4AMPE    MC908QY4AVDTE@TSSOP16 [(SA026)]  
 MC908QY4AVDWE@SOIC16 [(SA404)]    MC908QY4AVPE  
 MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
 MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
 MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
 MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
 MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
 MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
 MC9S08GT16CB@SDIP42 [(SA028-B167)]  
 MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
 MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
 MC9S08GT16CFBE@LQFP44 [(SA675-B168)]

MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
PC56F8011VFAE@QFP32 [(SA663+B005)]  
PC56F8013VFAE@QFP32 [(SA663+B005)]  
PC56F8014VFAE@QFP32 [(SA663+B005)]

## Fremont Micro Devices

### E(E)PROM/FRAM/NVRAM

FT24C02                    FT24C02@SOP8 [(SA602A)]  
FT24C02@TSSOP8 [(SA026)]        FT24C02A  
FT24C02A@SOP8 [(SA602A)]        FT24C02A@TSSOP8 [(SA026)]  
FT24C04                    FT24C04@SOP8 [(SA602A)]  
FT24C04@TSSOP8 [(SA026)]        FT24C04A  
FT24C04A@SOP8 [(SA602A)]        FT24C04A@TSSOP8 [(SA026)]  
FT24C08                    FT24C08@SOP8 [(SA602A)]  
FT24C08@TSSOP8 [(SA026)]        FT24C08A  
FT24C08A@SOP8 [(SA602A)]        FT24C08A@TSSOP8 [(SA026)]  
FT24C1024                  FT24C1024@SOP8 [(SA023A)]  
FT24C1024@TSSOP8 [(SA026)]        FT24C1024A  
FT24C1024A@SOP8 [(SA023A)]        FT24C1024A@TSSOP8 [(SA026)]  
FT24C128                    FT24C128@SOP8 [(SA602A)]  
FT24C128@TSSOP8 [(SA026)]        FT24C128A  
FT24C128A@SOP8 [(SA602A)]        FT24C128A@TSSOP8 [(SA026)]  
FT24C16                    FT24C16@SOP8 [(SA602A)]

FT24C16@TSSOP8 [(SA026)] FT24C16A  
FT24C16A@SOP8 [(SA602A)] FT24C16A@TSSOP8 [(SA026)]  
FT24C256 FT24C256@SOP8 [(SA602A)]  
FT24C256@TSSOP8 [(SA026)] FT24C256A  
FT24C256A@SOP8 [(SA602A)] FT24C256A@TSSOP8 [(SA026)]  
FT24C32 FT24C32@SOP8 [(SA602A)]  
FT24C32@TSSOP8 [(SA026)] FT24C32A  
FT24C32A@SOP8 [(SA602A)] FT24C32A@TSSOP8 [(SA026)]  
FT24C512 FT24C512@SOP8 [(SA602A)]  
FT24C512@TSSOP8 [(SA026)] FT24C512A  
FT24C512A@SOP8 [(SA602A)] FT24C512A@TSSOP8 [(SA026)]  
FT24C64 FT24C64@SOP8 [(SA602A)]  
FT24C64@TSSOP8 [(SA026)] FT24C64A  
FT24C64A@SOP8 [(SA602A)] FT24C64A@TSSOP8 [(SA026)]  
FT34C02 FT34C02@SOP8 [(SA602A)]  
FT34C02@TSSOP8 [(SA026)] FT34C02A  
FT34C02A@SOP8 [(SA602A)] FT34C02A@TSSOP8 [(SA026)]  
FT93C46(08bit) FT93C46(08bit)@SOP8 [(SA602A)]  
FT93C46(08bit)@TSSOP8 [(SA026)] FT93C46(16bit)  
FT93C46(16bit)@SOP8 [(SA602A)] FT93C46(16bit)@TSSOP8 [(SA026)]  
FT93C46A(08bit) FT93C46A(08bit)@SOP8 [(SA602A)]  
FT93C46A(08bit)@TSSOP8 [(SA026)] FT93C46A(16bit)  
FT93C46A(16bit)@SOP8 [(SA602A)] FT93C46A(16bit)@TSSOP8 [(SA026)]  
FT93C56(08bit) FT93C56(08bit)@SOP8 [(SA602A)]  
FT93C56(08bit)@TSSOP8 [(SA026)] FT93C56(16bit)  
FT93C56(16bit)@SOP8 [(SA602A)] FT93C56(16bit)@TSSOP8 [(SA026)]  
FT93C56A(08bit) FT93C56A(08bit)@SOP8 [(SA602A)]  
FT93C56A(08bit)@TSSOP8 [(SA026)] FT93C56A(16bit)  
FT93C56A(16bit)@SOP8 [(SA602A)] FT93C56A(16bit)@TSSOP8 [(SA026)]  
FT93C66(08bit) FT93C66(08bit)@SOP8 [(SA602A)]  
FT93C66(08bit)@TSSOP8 [(SA026)] FT93C66(16bit)  
FT93C66(16bit)@SOP8 [(SA602A)] FT93C66(16bit)@TSSOP8 [(SA026)]  
FT93C66A(08bit) FT93C66A(08bit)@SOP8 [(SA602A)]  
FT93C66A(08bit)@TSSOP8 [(SA026)] FT93C66A(16bit)  
FT93C66A(16bit)@SOP8 [(SA602A)] FT93C66A(16bit)@TSSOP8 [(SA026)]  
FT93C86(08bit) FT93C86(08bit)@SOP8 [(SA602A)]  
FT93C86(08bit)@TSSOP8 [(SA026)] FT93C86(16bit)  
FT93C86(16bit)@SOP8 [(SA602A)] FT93C86(16bit)@TSSOP8 [(SA026)]  
FT93C86A(08bit) FT93C86A(08bit)@SOP8 [(SA602A)]  
FT93C86A(08bit)@TSSOP8 [(SA026)] FT93C86A(16bit)  
FT93C86A(16bit)@SOP8 [(SA602A)] FT93C86A(16bit)@TSSOP8 [(SA026)]

# FUJITSU

## E(E)PROM/FRAM/NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21193DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21193EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21193EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21194DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21194EG@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21194EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD22180FA@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22180FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22181A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22181EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22181EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22181FM@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD22182A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22182EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22182EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22183A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22183EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22183EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22184EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184FM@FBGA56 [(SA642E-B032A-T072F001)]  
MB84VD22190FA@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22190FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22191A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22191EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22191EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22191FM@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD22192A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22192EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22192EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22193A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22193EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22193EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22194EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194FM@FBGA56 [(SA642E-B032A-T072F001)]  
MB84VD22280FE@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22282EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22283EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22284EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22290FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22292EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22293EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22294EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22386EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22387EJ@FBGA71 [(SA642F-B032A-T064F001)]

MB84VD22388EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]  
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]  
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB85R256@SOP28 [(SA630)] MB85R256@TSOP28 [(SA430T)]  
MB85R256A@SOP28 [(SA630)] MB85R256A@TSOP28 [(SA430T)]  
MBM271001 MBM271001@PLCC32 [(SA015A1T)]  
MBM271001@TSOP32 [(SA410T)] MBM27128  
MBM27128@PLCC32 [(SA015A1T)] MBM2716  
MBM2716H MBM27256  
MBM27256@PLCC32 [(SA015A1T)] MBM2732  
MBM2732A MBM2764  
MBM2764@PLCC32 [(SA015A1T)] MBM27C1000  
MBM27C1000@PLCC32 [(SA015A1T)] MBM27C1000@TSOP32 [(SA410T)]  
MBM27C1001 MBM27C1001@PLCC32 [(SA015A1T)]  
MBM27C1001@TSOP32 [(SA410T)] MBM27C1024  
MBM27C1024@PLCC44 [(SA244)] MBM27C1028  
MBM27C1028@PLCC32 [(SA015A1T)] MBM27C128  
MBM27C128@PLCC32 [(SA015A1T)] MBM27C128P  
MBM27C128P@PLCC32 [(SA015A1T)] MBM27C2000  
MBM27C2000@PLCC32 [(SA015A1T)] MBM27C2000@TSOP32 [(SA410T)]  
MBM27C2001 MBM27C2001@PLCC32 [(SA015A1T)]  
MBM27C2001@TSOP32 [(SA410T)] MBM27C2048  
MBM27C256 MBM27C256@PLCC32 [(SA015A1T)]  
MBM27C256A MBM27C256A@PLCC32 [(SA015A1T)]  
MBM27C256AP MBM27C256AP@PLCC32 [(SA015A1T)]  
MBM27C256H MBM27C256H@PLCC32 [(SA015A1T)]  
MBM27C32A MBM27C4001  
MBM27C4001@PLCC32 [(SA015A1T)] MBM27C4001@TSOP32 [(SA410T)]  
MBM27C4096 MBM27C512  
MBM27C512@PLCC32 [(SA015A1T)] MBM27C512P

MBM27C512P@PLCC32 [(SA015A1T)] MBM27C64  
MBM27C64@PLCC32 [(SA015A1T)] MBM28C64  
MBM28C65 MBM28F010  
MBM28F010@PLCC32 [(SA015A1T)] MBM28F010@TSOP32 [(SA410T)]  
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161BD@TSOP48 [(SA247-B005)]  
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@TSOP48 [(SA247-B005)]  
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@TSOP48 [(SA247-B005)]  
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BE@TSOP48 [(SA247-B005)]  
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TD@TSOP48 [(SA247-B005)]  
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TE@TSOP48 [(SA247-B005)]  
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BD@TSOP48 [(SA247-B005)]  
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BE@TSOP48 [(SA247-B005)]  
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TD@TSOP48 [(SA247-B005)]  
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TE@TSOP48 [(SA247-B005)]  
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BD@TSOP48 [(SA247-B005)]  
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BE@TSOP48 [(SA247-B005)]  
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TD@TSOP48 [(SA247-B005)]  
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TE@TSOP48 [(SA247-B005)]  
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320BF@TSOP48 [(SA247-B005)]  
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320TF@TSOP48 [(SA247-B005)]  
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321BD@TSOP48 [(SA247-B005)]  
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321TD@TSOP48 [(SA247-B005)]



MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL322BD@TSOP48 [(SA247-B005)]  
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BE@TSOP48 [(SA247-B005)]  
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL322TD@TSOP48 [(SA247-B005)]  
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322TE@TSOP48 [(SA247-B005)]  
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323BD@TSOP48 [(SA247-B005)]  
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323BE@TSOP48 [(SA247-B005)]  
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323BF@TSOP48 [(SA247-B005)]  
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323TD@TSOP48 [(SA247-B005)]  
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323TE@TSOP48 [(SA247-B005)]  
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323TF@TSOP48 [(SA247-B005)]  
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324BD@TSOP48 [(SA247-B005)]  
MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL324BE@TSOP48 [(SA247-B005)]  
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324TD@TSOP48 [(SA247-B005)]  
MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL324TE@TSOP48 [(SA247-B005)]  
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL32BF@TSOP48 [(SA247-B005)]  
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL32TF@TSOP48 [(SA247-B005)]  
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL34BF@TSOP48 [(SA247-B005)]  
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL34TF@TSOP48 [(SA247-B005)]  
MBM29DL400BB@PSOP44 [(SA638-B006)]  
MBM29DL400BB@TSOP48 [(SA247-B005)]  
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL400BC@PSOP44 [(SA638)]  
MBM29DL400BC@TSOP48 [(SA247-B005)]  
MBM29DL400BT@PSOP44 [(SA638-B006)]

MBM29DL400BT@TSOP48 [(SA247-B005)]  
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL400TC@PSOP44 [(SA638)]  
MBM29DL400TC@TSOP48 [(SA247-B005)]  
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]  
MBM29DL640E@TSOP48 [(SA247-B005)]  
MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]  
MBM29DL64DF@TSOP48 [(SA247-B005)]  
MBM29DL800B@PSOP44 [(SA638-B006)]  
MBM29DL800B@TSOP48 [(SA247-B005)]  
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL800BA@TSOP48 [(SA247-B005)]  
MBM29DL800BB@PSOP44 [(SA638-B006)]  
MBM29DL800BB@TSOP48 [(SA247-B005)]  
MBM29DL800BT@PSOP44 [(SA638-B006)]  
MBM29DL800BT@TSOP48 [(SA247-B005)]  
MBM29DL800T@PSOP44 [(SA638-B006)]  
MBM29DL800T@TSOP48 [(SA247-B005)]  
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL800TA@TSOP48 [(SA247-B005)]  
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
MBM29DS163BE@TSOP48 [(SA247-B005)]  
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
MBM29DS163TE@TSOP48 [(SA247-B005)]  
MBM29F001B MBM29F001B@PLCC32 [(SA015A1T)]  
MBM29F001B@TSOP32 [(SA410T)] MBM29F001T  
MBM29F001T@PLCC32 [(SA015A1T)] MBM29F001T@TSOP32 [(SA410T)]  
MBM29F002B MBM29F002B@PLCC32 [(SA015A1T)]  
MBM29F002B@TSOP32 [(SA410T)] MBM29F002NB  
MBM29F002NB@PLCC32 [(SA015A1T)] MBM29F002NB@TSOP32 [(SA410T)]  
MBM29F002NT MBM29F002NT@PLCC32 [(SA015A1T)]  
MBM29F002NT@TSOP32 [(SA410T)] MBM29F002T  
MBM29F002T@PLCC32 [(SA015A1T)] MBM29F002T@TSOP32 [(SA410T)]  
MBM29F010 MBM29F010@PLCC32 [(SA015A1T)]  
MBM29F010@TSOP32 [(SA410T)] MBM29F010A  
MBM29F010A@PLCC32 [(SA015A1T)] MBM29F010A@TSOP32 [(SA410T)]  
MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40 [(SA409T)]  
MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44 [(SA638)]  
MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-B005)]  
MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40 [(SA409T)]  
MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-B005)]  
MBM29F017D@TSOP40 [(SA409T)] MBM29F017D@TSOP48 [(SA247-B005)]  
MBM29F032B@PSOP44 [(SA638)] MBM29F032B@TSOP40 [(SA409T)]

MBM29F033C@TSOP40 [(SA409T)] MBM29F040  
MBM29F040@PLCC32 [(SA015A1T)] MBM29F040@TSOP32 [(SA410T)]  
MBM29F040B MBM29F040B@PLCC32 [(SA015A1T)]  
MBM29F040B@TSOP32 [(SA410T)] MBM29F040C@PLCC32 [(SA015A1T)]  
MBM29F040C@TSOP32 [(SA410T)] MBM29F080@PSOP44 [(SA638)]  
MBM29F080@TSOP40 [(SA409T)] MBM29F080A@TSOP48 [(SA247-B005)]  
MBM29F080B@PSOP44 [(SA638)] MBM29F080B@TSOP40 [(SA409T)]  
MBM29F100B@PSOP44 [(SA638-B006)] MBM29F100B@TSOP48 [(SA247-B005)]  
MBM29F100T@PSOP44 [(SA638-B006)] MBM29F100T@TSOP48 [(SA247-B005)]  
MBM29F160BE@TSOP48 [(SA247-B005)]  
MBM29F160TE@TSOP48 [(SA247-B005)]  
MBM29F200AB@PSOP44 [(SA638-B006)]  
MBM29F200AB@TSOP48 [(SA247-B005)]  
MBM29F200AT@PSOP44 [(SA638-B006)]  
MBM29F200AT@TSOP48 [(SA247-B005)]  
MBM29F200B@PSOP44 [(SA638-B006)] MBM29F200B@TSOP48 [(SA247-B005)]  
MBM29F200T@PSOP44 [(SA638-B006)] MBM29F200T@TSOP48 [(SA247-B005)]  
MBM29F400AB@PSOP44 [(SA638-B006)]  
MBM29F400AB@TSOP48 [(SA247-B005)]  
MBM29F400AT@PSOP44 [(SA638-B006)]  
MBM29F400AT@TSOP48 [(SA247-B005)]  
MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]  
MBM29F400BB@PSOP44 [(SA638-B006)]  
MBM29F400BB@TSOP48 [(SA247-B005)]  
MBM29F400BT@PSOP44 [(SA638-B006)]  
MBM29F400BT@TSOP48 [(SA247-B005)]  
MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]  
MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]  
MBM29F800BA@PSOP44 [(SA638-B006)]  
MBM29F800BA@TSOP48 [(SA247-B005)]  
MBM29F800BB@PSOP44 [(SA638-B006)]  
MBM29F800BB@TSOP48 [(SA247-B005)]  
MBM29F800BT@PSOP44 [(SA638-B006)]  
MBM29F800BT@TSOP48 [(SA247-B005)]  
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]  
MBM29F800TA@PSOP44 [(SA638-B006)]  
MBM29F800TA@TSOP48 [(SA247-B005)]  
MBM29LL800B@TSOP48 [(SA247-B005)]  
MBM29LL800BB@TSOP48 [(SA247-B005)]  
MBM29LL800BT@TSOP48 [(SA247-B005)]  
MBM29LL800T@TSOP48 [(SA247-B005)]  
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32 [(SA015A1T)]  
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]

MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]  
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32 [(SA410T)]  
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32 [(SA410T)]  
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40 [(SA409T)]  
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40 [(SA409T)]  
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40 [(SA409T)]  
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40 [(SA409T)]  
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40 [(SA409T)]  
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40 [(SA409T)]  
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40 [(SA409T)]  
MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40 [(SA409T)]  
MBM29LV016B@TSOP40 [(SA409T)]  
MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]  
MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40 [(SA409T)]  
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40 [(SA409T)]  
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40 [(SA409T)]  
MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40 [(SA409T)]  
MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46(\*)  
MBM29LV160BB@PSOP44 [(SA638-B006)]  
MBM29LV160BB@TSOP48 [(SA247-B005)]  
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160BE@TSOP48 [(SA247-B005)]  
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160BM@TSOP48 [(SA247-B005)]  
MBM29LV160BT@PSOP44 [(SA638-B006)]  
MBM29LV160BT@TSOP48 [(SA247-B005)]  
MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46(\*)  
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160TE@TSOP48 [(SA247-B005)]  
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160TM@TSOP48 [(SA247-B005)]  
MBM29LV200B@PSOP44 [(SA638-B006)]  
MBM29LV200B@TSOP48 [(SA247-B005)]  
MBM29LV200BB@PSOP44 [(SA638-B006)]  
MBM29LV200BB@TSOP48 [(SA247-B005)]  
MBM29LV200BC@PSOP44 [(SA638)]  
MBM29LV200BC@TSOP48 [(SA247-B005)]  
MBM29LV200BT@PSOP44 [(SA638-B006)]  
MBM29LV200BT@TSOP48 [(SA247-B005)]  
MBM29LV200T@PSOP44 [(SA638-B006)]  
MBM29LV200T@TSOP48 [(SA247-B005)]  
MBM29LV200TC@PSOP44 [(SA638)]  
MBM29LV200TC@TSOP48 [(SA247-B005)]

MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29LV320BE@TSOP48 [(SA247-B005)]  
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29LV320TE@TSOP48 [(SA247-B005)]  
MBM29LV400B@PSOP44 [(SA638-B006)]  
MBM29LV400B@TSOP48 [(SA247-B005)]  
MBM29LV400BB@PSOP44 [(SA638-B006)]  
MBM29LV400BB@TSOP48 [(SA247-B005)]  
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29LV400BC@PSOP44 [(SA638)]  
MBM29LV400BC@TSOP48 [(SA247-B005)]  
MBM29LV400BT@PSOP44 [(SA638-B006)]  
MBM29LV400BT@TSOP48 [(SA247-B005)]  
MBM29LV400T@PSOP44 [(SA638-B006)]  
MBM29LV400T@TSOP48 [(SA247-B005)]  
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29LV400TC@PSOP44 [(SA638)]  
MBM29LV400TC@TSOP48 [(SA247-B005)]  
MBM29LV650UE@TSOP48 [(SA247-B005)]  
MBM29LV651UE@TSOP48 [(SA247-B005)]  
MBM29LV652UE@FBGA63 [(SA642C-B026A-Y056F001)]  
MBM29LV800B@PSOP44 [(SA638-B006)]  
MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46(\*)  
MBM29LV800B@TSOP48 [(SA247-B005)]  
MBM29LV800BA@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800BA@PSOP44 [(SA638)]  
MBM29LV800BA@TSOP48 [(SA247-B005)]  
MBM29LV800BB@PSOP44 [(SA638-B006)]  
MBM29LV800BB@TSOP48 [(SA247-B005)]  
MBM29LV800BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800BE@PSOP44 [(SA638)]  
MBM29LV800BE@TSOP48 [(SA247-B005)]  
MBM29LV800BT@PSOP44 [(SA638-B006)]  
MBM29LV800BT@TSOP48 [(SA247-B005)]  
MBM29LV800T@PSOP44 [(SA638-B006)]  
MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46(\*)  
MBM29LV800T@TSOP48 [(SA247-B005)]  
MBM29LV800TA@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800TA@PSOP44 [(SA638)]  
MBM29LV800TA@TSOP48 [(SA247-B005)]  
MBM29LV800TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800TE@PSOP44 [(SA638)]  
MBM29LV800TE@TSOP48 [(SA247-B005)]

MBM29PDS323B@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29PDS323T@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29PL12LM@TSOP56 [(SA628-B102)]  
MBM29PL160BD@PSOP44 [(SA638)]  
MBM29PL160BD@TSOP48 [(SA247-B005)]  
MBM29PL160TD@PSOP44 [(SA638)]  
MBM29PL160TD@TSOP48 [(SA247-B005)]  
MBM29PL32BM@FBGA48 [(SA642G-B026A-T048F001)]  
MBM29PL32BM@TSOP48 [(SA247-B005)]  
MBM29PL32TM@FBGA48 [(SA642G-B026A-T048F001)]  
MBM29PL32TM@TSOP48 [(SA247-B005)]  
MBM29PL64LM@TSOP48 [(SA247-B005)]  
MBM29PL64LM@TSOP56 [(SA628-B067)]  
MBM29QM12DH@FBGA88 [(SA642J-B101A-W080F001)]  
MBM29QM12DH@TSOP56 [(SA628-B097)]  
MBM29SL160BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29SL160BD@TSOP48 [(SA247-B005)]  
MBM29SL160TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29SL160TD@TSOP48 [(SA247-B005)]  
MBM29SL800BB@TSOP48 [(SA247-B005)]  
MBM29SL800BT@TSOP48 [(SA247-B005)]

## DRAM & SRAM

MB81C78A                      MB81C78A@SOIC28 [(SA630)]

## MICROCONTROLLER

MB89F202@SDIP32 [(SA653)]              MB89F202@SSOP34 [(SA689)]  
MB89F202RA@QFP32 [(SA663)]            MB89F202RA@SDIP32 [(SA653)]  
MB89F202RA@SSOP34 [(SA689)]            MB89F482AS@LQFP44 [(SA245A)]  
MB89F482AS@SDIP42 [(SA028)]            MB89F482AW@LQFP44 [(SA245A)]  
MB89F482AW@SDIP42 [(SA028)]            MB89F482HS@LQFP44 [(SA245A)]  
MB89F482HS@SDIP42 [(SA028)]            MB89F482HW@LQFP44 [(SA245A)]  
MB89F482HW@SDIP42 [(SA028)]            MB89P195  
MB89P195(F)@SOIC28 [(SA630)]            MB89P195AP  
MB89P195AP(F)@SOIC28 [(SA630)]        MB89P195P  
MB89P195P(F)@SOIC28 [(SA630)]

## GENCORE

## MICROCONTROLLER

GC87C520A0                    GC87C520A0@PLCC44 [(SA244)]  
 GC87C520A0@TQFP44 [(SA245A)]    GC87C520G0  
 GC87C520G0@PLCC44 [(SA244)]    GC87C520G0@TQFP44 [(SA245A)]

## GENERAL(GI)

### E(E)PROM/FRAM/NVRAM

27256                    27C128  
 27C128@PLCC32 [(SA015A1T)]    27C256  
 27C256@PLCC32 [(SA015A1T)]    27C512  
 27C513                    27C64  
 27C64@PLCC32 [(SA015A1T)]    27HC191  
 27HC291                    27HC64  
 27HC641                    27HC641L  
 27HC64L                    28C04  
 28C04A                    28C04F  
 28C16                    28C16A  
 28C16F                    28C17  
 28C17F                    ER5911  
 ER5911@SOIC8 [(SA602A)]    GI5911  
 GI5911@SOIC8 [(SA602A)]    GI59C11  
 GI59C11@SOIC8 [(SA602A)]    GI59C12  
 GI59C12@SOIC8 [(SA602A)]    GR27C513

## GENERIC

### E(E)PROM/FRAM/NVRAM

27128(21V)                    27128A(12.5V)  
 2716(25V)                    27256(12.5V)  
 2732(25V)                    2732A(21V)  
 2732B(12.5V)                    27512(12.5V)  
 27512(21V)                    2764(21V)  
 2764A(12.5V)                    27C128(12.5V)  
 27C128(21V)                    27C16(25V)  
 27C256(12.5V)                    27C32(25V)

27C512(12.5V)                    27C64(12.5V)  
27C64(21V)

## GIGADEVICE

### E(E)PROM/FRAM/NVRAM

GD25D40@SOP8 [(SA605A)]	GD25D40@SOP8(ISP) [ISP-HEADER01]
GD25D80@SOP8 [(SA605A)]	GD25D80@SOP8(ISP) [ISP-HEADER01]
GD25F40@SOP8 [(SA605A)]	GD25F40@SOP8(ISP) [ISP-HEADER01]
GD25F80@SOP8 [(SA605A)]	GD25F80@SOP8(ISP) [ISP-HEADER01]
GD25T80@SOP8 [(SA605A)]	GD25T80@SOP8(ISP) [ISP-HEADER01]

## GOAL

### MICROCONTROLLER

VRS1000	VRS1000@PLCC44 [(SA244)]
VRS1000@TQFP44 [(SA245A)]	VRS1050
VRS1050@PLCC44 [(SA244)]	VRS1050@TQFP44 [(SA675)]
VRS1100	VRS1100@PLCC44 [(SA244)]
VRS1100@TQFP44 [(SA245A)]	VRS540
VRS540@PLCC44 [(SA244)]	VRS540@TQFP44 [(SA245A)]
VRS550	VRS550@PLCC44 [(SA244)]
VRS550@TQFP44 [(SA245A)]	VRS560
VRS560@PLCC44 [(SA244)]	VRS560@TQFP44 [(SA245A)]
VRS570	VRS570@PLCC44 [(SA244)]
VRS570@TQFP44 [(SA245A)]	VRS580
VRS580@PLCC44 [(SA244)]	VRS580@TQFP44 [(SA245A)]
VRS700	VRS700@PLCC44 [(SA244)]
VRS700@TQFP44 [(SA245A)]	VRS900
VRS900@PLCC44 [(SA244)]	VRS900@TQFP44 [(SA245A)]

## GREENWICH

### E(E)PROM/FRAM/NVRAM

GR27128	GR27256
GR27512	GR2764



# HAIER

## MICROCONTROLLER

HCM87CP311SP@SDIP42 [(SA028)] HR6P60P2DL  
 HR6P60P2EL HR6P60P2SL@SOP20 [(SA404)]  
 HR6P60P2SL@SSOP20 [(SA626A)] HR6P60P2XL@SOP18 [(SA404)]  
 HR6P60P2YL@SOP14 [(SA404)] HR6P62P4D  
 HR6P62P4DH HR6P62P4DHL  
 HR6P62P4DHL(INTOSC) HR6P62P4DHL-D  
 HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]  
 HR6P62P4NHL@SSOP20 [(SA626A)] HR6P62P4NHL-D@SSOP20 [(SA626A)]  
 HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]  
 HR6P62P4RHL@SSOP20 [(SA626A)] HR6P62P4RHL-D@SSOP20 [(SA626A)]  
 HR6P62P4SH@SOP20 [(SA404+B003)]  
 HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]  
 HR6P62P4SHL@SOP20 [(SA404)] HR6P62P4SHL-D@SOP20 [(SA404)]  
 HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]  
 HR6P62P4XHL@SOP18 [(SA404)] HR6P62P4XHL-D@SOP18 [(SA404)]  
 HR6P62P4YHL@SOIC14 [(SA602)] HR6P67P4D  
 HR6P67P4DL HR6P67P4DL(REVERSE)  
 HR6P67P4SL(REVERSE)@SOP14 [(SA404+B003)]  
 HR6P67P4SL@SOP14 [(SA404+B003)] HR6P71F8D  
 HR6P71F8D(REVERSE)  
 HR6P71F8S(REVERSE)@SOP20 [(SA404)]  
 HR6P71F8S@SOP20 [(SA404)] HR6P72P4D  
 HR6P72P4DL HR6P72P4S@SOP28 [(SA404)]  
 HR6P72P4SL@SOP28 [(SA404+B003)] HR6P73P8DB  
 HR6P73P8DBL HR6P73P8SB@SOP28 [(SA404)]  
 HR6P73P8SBL@SOP28 [(SA404-B003)] HR6P73PGD  
 HR6P73PGDH HR6P73PGDHL  
 HR6P73PGS@SOP28 [(SA404+B003)] HR6P73PGSH@SOP28 [(SA404)]  
 HR6P73PGSHL@SOP28 [(SA404-B003)] HR6P76PGD  
 HR6P76PGDL HR6P76PGS@SOP28 [(SA404)]  
 HR6P76PGSL@SOP28 [(SA404-B003)] HR6P77PGD  
 HR6P77PGDL HR6P77PGL@LQFP44 [(SA245-B005)]  
 HR6P77PGLL@LQFP44 [(SA245-B005)] HR6P78P4SL@SOP32 [(SA715+B006)]  
 HR6P90FGD HR6P90FGS@SOP28 [(SA404)]  
 HR6P90FHD HR6P90FHS@SOP28 [(SA404)]  
 HR6P91FGS@SOP32 [(SA715)] HR6P91FHS@SOP32 [(SA715)]  
 HR6P92FGD HR6P92FGL@LQFP44 [(SA245A)]

HR6P92FHD                   HR6P92FHL@LQFP44 [(SA245A)]  
HR6P95F8D                   HR6P95F8S@SOP28 [(SA404)]  
HR6P97FGD                   HR6P97FGD(EEPROM)  
HR6P97FGS(EEPROM)@SOP28 [(SA404)]  
HR6P97FGS@SOP28 [(SA404)]       HR6P98FGD  
HR6P98FGD(EEPROM)  
HR6P98FGL(EEPROM)@LQFP44 [(SA245A)]  
HR6P98FGL@LQFP44 [(SA245A)]       HR7T46P8V@SDIP42 [(SA028)]  
HR7T46PGV@SDIP42 [(SA028+B005)]   HR7T47P8L@LQFP44 [(SA245A)]  
HR7T47PGL@LQFP44 [(SA245A+B005)]

## HARRIS

### DRAM & SRAM

HM6516                   HM6516@PLCC32 [(SA015A1T)]  
HM65162                  HM65162@PLCC32 [(SA015A1T)]  
HM65642                  HM65642@TSOP28 [(SA643)]

## HITACHI

### E(E)PROM/FRAM/NVRAM

HN27128AG                HN27128AP  
HN27256G                HN27256P  
HN27512G                HN27512P  
HN27C101AG              HN27C101AP  
HN27C101G                HN27C101P  
HN27C1024HG             HN27C1024HG@PLCC44 [(SA244)]  
HN27C256AG              HN27C256FP  
HN27C256G                HN27C256HG  
HN27C301AG              HN27C301AP  
HN27C301G                HN27C301P  
HN27C4000FP             HN27C4000G  
HN27C4001                HN27C4001@TSOP32 [(SA410T)]  
HN27C4001G              HN27C4096A  
HN27C4096A@PLCC44 [(SA244)]    HN27C4096FP  
HN27C4096FP@PLCC44 [(SA244)]    HN27C4096G  
HN27C4096G@PLCC44 [(SA244)]    HN27C512G  
HN27C512G@PLCC32 [(SA015A1T)]   HN27C64G

HN28F101                   HN28F101@PLCC32 [(SA015A1T)]  
HN28F101@SOP32 [(SA438T)]       HN28F101@TSOP32 [(SA410T)]  
HN29A128A0A@CSP95 [(SA642A-B066A-Y096N001)]  
HN29A128A0A@TSOP48 [(SA247-B005)]  
HN29V128A0A@CSP95 [(SA642A-B066A-Y096N001)]  
HN29V128A0A@TSOP48 [(SA247-B005)]  
HN29V128A0E@CSP95 [(SA642A-B066A-Y096N001)]  
HN29V51211@TSOP48 [(SA247-B005)]   HN462716G  
HN462732G                   HN48016(P)  
HN4827128G                  HN4827128P  
HN482732AG                  HN482764G  
HN482764P                   HN58064(FP)@SOIC28 [(SA404)]  
HN58064(P)                  HN58C1001(FP)@SSOP32 [(SA438T)]  
HN58C1001(P)                HN58C1001(T)@VSOP32 [(SA620)]  
HN58C256A(FP)@SOP28 [(SA630)]   HN58C256A(P)  
HN58C256A(T)@TSOP28 [(SA643)]   HN58C257A(T)@TSOP32 [(SA620)]  
HN58C65(FP)@SOIC28 [(SA404)]   HN58C65(P)  
HN58C66                    HN58C66@SOP28 [(SA630)]  
HN58C66@TSOP28 [(SA430T)]        HN58V24256  
HN58V24256@SOIC8 [(SA602A)]       HN58V24256@TSSOP14 [(SA026)]  
HN58V24512                 HN58V24512@SOIC8 [(SA602A)]  
HN58V256A                  HN58V256A@TSOP28 [(SA430T)]  
HN58V65A                   HN58V65A@SOIC28 [(SA630)]  
HN58V65A@TSOP28 [(SA430T)]        HN58V66A  
HN58V66A@SOIC28 [(SA630)]        HN58V66A@TSOP28 [(SA430T)]  
HN58W241000                HN58W241000@SOIC8 [(SA602A)]  
HN58X2402                  HN58X2402@SOIC8 [(SA602A)]  
HN58X2402@TSSOP8 [(SA026)]        HN58X2404  
HN58X2404@SOIC8 [(SA602A)]        HN58X2404@TSSOP8 [(SA026)]  
HN58X2408                  HN58X2408@SOIC8 [(SA602A)]  
HN58X2408@TSSOP8 [(SA026)]        HN58X24128  
HN58X24128@SOIC8 [(SA602A)]        HN58X2416  
HN58X2416@SOIC8 [(SA602A)]        HN58X2416@TSSOP8 [(SA026)]  
HN58X24256                 HN58X24256@SOIC8 [(SA602A)]  
HN58X2432                  HN58X2432@SOIC8 [(SA602A)]  
HN58X2432@TSSOP8 [(SA026)]        HN58X24512  
HN58X24512@SOIC8 [(SA602A)]        HN58X2464  
HN58X2464@SOIC8 [(SA602A)]        HN58X2464@TSSOP8 [(SA026)]  
HN58X2502@SOIC8 [(SA602A)]        HN58X2502@TSSOP8 [(SA026)]  
HN58X2504@SOIC8 [(SA602A)]        HN58X2504@TSSOP8 [(SA026)]  
HN58X25128@SOIC8 [(SA602A)]        HN58X25128@TSSOP14 [(SA026)]  
HN58X25256@SOIC8 [(SA602A)]        HN58X25256@TSSOP14 [(SA026)]  
HN58X2532@SOIC8 [(SA602A)]        HN58X2532@TSSOP8 [(SA026)]

HN58X2564@SOIC8 [(SA602A)]      HN58X2564@TSSOP8 [(SA026)]  
 HT29VB800@TSOP48 [(SA247-B005)]      HT29VT800@TSOP48 [(SA247-B005)]  
 HT29WB800@TSOP48 [(SA247-B005)]      HT29WT800@TSOP48 [(SA247-B005)]  
 V128128A0E@CSP95 [(SA642A-B105A-Y096N001)]

## DRAM & SRAM

HM6116                      HM6116@PLCC32 [(SA015A1T)]  
 HM6116A                    HM6116A@PLCC32 [(SA015A1T)]  
 HM6208                      HM6208@SOJ24 [(SA646)]  
 HM6208H                    HM6208H@SOJ24 [(SA646)]  
 HM62256                    HM62256@TSOP28 [(SA643)]  
 HM62256B                  HM62256B@TSOP28 [(SA643)]  
 HM624256                  HM624256@SOJ28 [(SA646)]  
 HM6264A                    HM6264A@TSOP28 [(SA643)]  
 HM6267                      HM6268  
 HM628128                  HM628128@TSOP32 [(SA410T)]  
 HM628128A                 HM628128A@TSOP32 [(SA410T)]  
 HM62832                    HM62832@TSOP28 [(SA643)]  
 HM62832H                  HM62832H@TSOP28 [(SA643)]  
 HM628512                  HM628512@TSOP32 [(SA729)]  
 HM6287                      HM6287HP  
 HM6288                      HM6288@SOJ22 [(SA646)]  
 HM65256B                  HM65256B@TSOP28 [(SA643)]  
 HM658128                  HM658128@TSOP32 [(SA410T)]  
 HM66204                    HM66204@TSOP32 [(SA410T)]  
 HM6707                      HM6707@SOJ24 [(SA646)]  
 HM6707A                    HM6707A@SOJ24 [(SA646)]  
 HM6708                      HM6708@SOJ24 [(SA646)]  
 HM6708A                    HM6708A@SOJ24 [(SA646)]  
 HM6716                      HM6716@PLCC32 [(SA015A1T)]  
 HM6787                      HM6787HP  
 HM6788                      HM6788@SOJ22 [(SA646)]  
 HM6788H                    HM6788H@SOJ22 [(SA646)]  
 HM6788HA                  HM6788HA@SOJ22 [(SA646)]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]      HD4074344@SOIC28 [(SA404)]  
 HD4074394@SDIP28 [(SA022A)]      HD4074394@SOIC28 [(SA404)]  
 HD64F3694FX@TQFP48 [(SA671)]      HD64F3694FY@TQFP48 [(SA248)]

HD64F3694GFX@TQFP48 [(SA671)] HD64F3694GFY@TQFP48 [(SA248)]

## HOLTEK

## E(E)PROM/FRAM/NVRAM

HT24C01 HT24C01@SOIC8 [(SA602A)]  
 HT24C02 HT24C02@SOIC8 [(SA602A)]  
 HT24C04 HT24C04@SOIC8 [(SA602A)]  
 HT24C08 HT24C16  
 HT24LC01 HT24LC01@SOIC8 [(SA602A)]  
 HT24LC01@TSSOP8 [(SA026)] HT24LC02  
 HT24LC02@SOIC8 [(SA602A)] HT24LC02@TSSOP8 [(SA026)]  
 HT24LC04 HT24LC04@SOIC8 [(SA602A)]  
 HT24LC08 HT24LC08@SOIC8 [(SA602A)]  
 HT24LC16 HT24LC16@SOIC8 [(SA602A)]  
 HT24LC32 HT24LC32@SOIC8 [(SA602A)]  
 HT24LC64 HT24LC64@SOIC8 [(SA602A)]  
 HT25LC512@SOIC8 [(SA602A)] HT27C010  
 HT27C010@PLCC32 [(SA015A1T)] HT27C010@TSOP32 [(SA410T)]  
 HT27C020 HT27C020@PLCC32 [(SA015A1T)]  
 HT27C020@TSOP32 [(SA410T)] HT27C040  
 HT27C040@PLCC32 [(SA015A1T)] HT27C040@TSOP32 [(SA410T)]  
 HT27C4096 HT27C4096@PLCC44 [(SA244)]  
 HT27C512 HT27C512@PLCC32 [(SA015A1T)]  
 HT27C512@TSOP28 [(SA430T)] HT27LC010  
 HT27LC010@PLCC32 [(SA015A1T)] HT27LC010@TSOP32 [(SA410T)]  
 HT27LC020 HT27LC020@PLCC32 [(SA015A1T)]  
 HT27LC020@TSOP32 [(SA410T)] HT27LC040  
 HT27LC040@PLCC32 [(SA015A1T)] HT27LC040@TSOP32 [(SA410T)]  
 HT27LC4096 HT27LC4096@PLCC44 [(SA244)]  
 HT27LC512 HT27LC512@PLCC32 [(SA015A1T)]  
 HT27LC512@TSOP28 [(SA430T)] HT93C46(16bit)  
 HT93C46(16bit)@SOP8-A [(SA602A)] HT93C46(16bit)@SOP8-B [(SA602A)]  
 HT93C46(16bit)@TSSOP8 [(SA026)] HT93C56(16bit)  
 HT93C56(16bit)@SOP8-A [(SA602A)] HT93C56(16bit)@SOP8-B [(SA602A)]  
 HT93C56(16bit)@TSSOP8 [(SA026)] HT93C66(16bit)  
 HT93C66(16bit)@SOP8-A [(SA602A)] HT93C66(16bit)@SOP8-B [(SA602A)]  
 HT93C66(16bit)@TSSOP8 [(SA026)] HT93LC46A(08bit)  
 HT93LC46A(08bit)@SOP8-A [(SA602A)]  
 HT93LC46A(08bit)@SOP8-B [(SA602A)]  
 HT93LC46A(08bit)@TSSOP8 [(SA026)]

HT93LC46A(16bit)  
HT93LC46A(16bit)@SOP8-A [(SA602A)]  
HT93LC46A(16bit)@SOP8-B [(SA602A)]  
HT93LC46A(16bit)@TSSOP8 [(SA026)]  
HT93LC46B(08bit)  
HT93LC46B(08bit)@SOP8-A [(SA602A)]  
HT93LC46B(08bit)@SOP8-B [(SA602A)]  
HT93LC46B(08bit)@TSSOP8 [(SA026)]  
HT93LC46B(16bit)  
HT93LC46B(16bit)@SOP8-A [(SA602A)]  
HT93LC46B(16bit)@SOP8-B [(SA602A)]  
HT93LC46B(16bit)@TSSOP8 [(SA026)]  
HT93LC56A(08bit)  
HT93LC56A(08bit)@SOP8-A [(SA602A)]  
HT93LC56A(08bit)@SOP8-B [(SA602A)]  
HT93LC56A(08bit)@TSSOP8 [(SA026)]  
HT93LC56A(16bit)  
HT93LC56A(16bit)@SOP8-A [(SA602A)]  
HT93LC56A(16bit)@SOP8-B [(SA602A)]  
HT93LC56A(16bit)@TSSOP8 [(SA026)]  
HT93LC56B(08bit)  
HT93LC56B(08bit)@SOP8-A [(SA602A)]  
HT93LC56B(08bit)@SOP8-B [(SA026)]  
HT93LC56B(08bit)@TSSOP8 [(SA026)]  
HT93LC56B(16bit)  
HT93LC56B(16bit)@SOP8-A [(SA602A)]  
HT93LC56B(16bit)@SOP8-B [(SA602A)]  
HT93LC56B(16bit)@TSSOP8 [(SA026)]  
HT93LC66A(08bit)  
HT93LC66A(08bit)@SOP8-A [(SA602A)]  
HT93LC66A(08bit)@SOP8-B [(SA602A)]  
HT93LC66A(08bit)@TSSOP8 [(SA026)]  
HT93LC66A(16bit)  
HT93LC66A(16bit)@SOP8-A [(SA602A)]  
HT93LC66A(16bit)@SOP8-B [(SA602A)]  
HT93LC66A(16bit)@TSSOP8 [(SA026)]  
HT93LC66B(08bit)  
HT93LC66B(08bit)@SOP8-A [(SA602A)]  
HT93LC66B(08bit)@SOP8-B [(SA026)]  
HT93LC66B(08bit)@TSSOP8 [(SA026)]  
HT93LC66B(16bit)  
HT93LC66B(16bit)@SOP8-A [(SA602A)]  
HT93LC66B(16bit)@SOP8-B [(SA602A)]

HT93LC66B(16bit)@TSSOP8 [(SA026)]  
 HT93LC76(08bit)  
 HT93LC76(08bit)@SOP8-A [(SA602A)]  
 HT93LC76(08bit)@SOP8-B [(SA602A)]  
 HT93LC76(08bit)@TSSOP8 [(SA026)] HT93LC76(16bit)  
 HT93LC76(16bit)@SOP8-A [(SA602A)]  
 HT93LC76(16bit)@SOP8-B [(SA602A)]  
 HT93LC76(16bit)@TSSOP8 [(SA026)] HT93LC86(08bit)  
 HT93LC86(08bit)@SOP8-A [(SA602A)]  
 HT93LC86(08bit)@SOP8-B [(SA602A)]  
 HT93LC86(08bit)@TSSOP8 [(SA026)] HT93LC86(16bit)  
 HT93LC86(16bit)@SOP8-A [(SA602A)]  
 HT93LC86(16bit)@SOP8-B [(SA602A)]  
 HT93LC86(16bit)@TSSOP8 [(SA026)]

## MICROCONTROLLER

HT46R22 HT46R22@SOP24 [(SA404)]  
 HT46R23(dip24) HT46R23(dip28)  
 HT46R23@SOP24 [(SA404)] HT46R23@SOP28 [(SA404)]  
 HT46R24 HT46R24@SOP28 [(SA404)]  
 HT46R24@SSOP48 [(SA669)] HT46R46(dip18)  
 HT46R46(dip20) HT46R46@SOP18 [(SA404)]  
 HT46R46@SOP20 [(SA404)] HT46R46E(dip18)  
 HT46R46E@SOP18 [(SA404)] HT46R46-H  
 HT46R46-H@SOP18 [(SA404)] HT46R47(dip18)  
 HT46R47(dip20) HT46R47@SOP18 [(SA404)]  
 HT46R47@SOP20 [(SA404)] HT46R47@SSOP20 [(SA674)]  
 HT46R47E(dip18) HT46R47E@SOP18 [(SA404)]  
 HT46R47-H HT46R47-H@SOP18 [(SA404)]  
 HT46R48(dip20) HT46R48(dip24)  
 HT46R48@SOP20 [(SA404)] HT46R48@SOP24 [(SA404)]  
 HT46R48@SSOP24 [(SA674)] HT46R48E(dip24)  
 HT46R48E@SOP24 [(SA404)] HT46R48E@SSOP24 [(SA674)]  
 HT46R51A(dip18) HT46R51A@SOP20 [(SA404)]  
 HT46R51A@SSOP20 [(SA674)] HT46R52A(dip18)  
 HT46R52A@SOP20 [(SA404)] HT46R52A@SSOP20 [(SA674)]  
 HT46R53A(dip28) HT46R53A@SOP28 [(SA404)]  
 HT46R54A(dip28) HT46R54A@SOP28 [(SA404)]  
 HT46R65@PQFP100 [(PEP+S427)] HT46R65@SSOP56 [(SA669)]  
 HT46R71D@SSOP48 [(SA669)] HT46RB70  
 HT46RB70@SOP28 [(SA404)] HT46RB70@SSOP48 [(SA669)]

HT46RU22(dip24) HT46RU22@SOP24 [(SA404)]  
 HT46RU22@SSOP24 [(SA674)] HT47R10A@QFP44 [(SA245)]  
 HT48R05A HT48R05A@SOP16 [(SA026)]  
 HT48R05A@SOP18 [(SA404)] HT48R06A  
 HT48R06A@SOP16 [(SA026)] HT48R06A@SOP18 [(SA404)]  
 HT48R07A HT48R07A@SOP24 [(SA404)]  
 HT48R07A@SSOP24 [(SA674)] HT48R08A  
 HT48R08A@SOP16 [(SA026)] HT48R08A@SOP18 [(SA404)]  
 HT48R09A HT48R09A@SOP24 [(SA404)]  
 HT48R09A@SSOP24 [(SA674)] HT48R10A  
 HT48R10A@SOP24 [(SA404)] HT48R30A(dip24)  
 HT48R30A(dip28) HT48R30A@SOP24 [(SA404)]  
 HT48R30A@SOP28 [(SA404)] HT48R50A  
 HT48R50A@SOP28 [(SA404)] HT48R50A@SSOP48 [(SA669)]  
 HT48R52A@QFP44 [(SA245A)] HT48R70A@SSOP48 [(SA669)]  
 HT48RA0-1 HT48RA0-1@SOP24 [(SA404)]  
 HT48RA0-2 HT48RA0-2@SOP20 [(SA404)]  
 HT48RA0-2@SSOP20 [(SA674)] HT48RA0-3  
 HT48RA0-3@SOP20 [(SA404)] HT48RA1@SOP28 [(SA404)]  
 HT48RA1@SSOP28 [(SA626A)] HT48RA3(dip28)  
 HT48RA3@SOP28 [(SA404)] HT48RA3@SSOP28 [(SA626A)]  
 HT48RA5(dip28) HT48RA5@SOP28 [(SA404)]  
 HT48RA5@SSOP28 [(SA626A)] HT48RB50  
 HT48RB50@SOP28 [(SA404)] HT48RB50@SSOP48 [(SA669)]  
 HT48RB8@SOP28 [(SA404)] HT48RB8@SSOP48 [(SA669)]  
 HT49R30A@SSOP48 [(SA669)] HT49R50A@SSOP48 [(SA669)]  
 HT49RV5@SSOP56 [(SA669)] HT82A821R@SOP24 [(SA404)]  
 HT82A821R@SSOP24 [(SA674)] HT82A822R@SSOP48 [(SA669)]  
 HT82A832R@QFP48 [(SA248)] HT82A832R@SSOP48 [(SA669)]  
 HT82K68E HT82K68E@SOP20 [(SA404)]  
 HT82K68E@SOP28 [(SA404)] HT82K68E@SSOP48 [(SA669)]  
 HT82K94E@SSOP48 [(SA669)] HT82K96E(dip20)  
 HT82K96E(dip40) HT82K96E@SOP20 [(SA404)]  
 HT82K96E@SOP28 [(SA404)] HT82K96E@SSOP48 [(SA669)]  
 HT82M99E(dip18) HT82M99E(dip20)  
 HT82M99E@SOP18 [(SA404)] HT82M99E@SOP20 [(SA404)]  
 HT82M9AE@SOP20 [(SA404)] HT82M9AE@SOP24 [(SA404)]  
 HT82M9AE@SSOP20 [(SA674)] HT82M9AE@SSOP24 [(SA674)]  
 HT82M9BE@SOP24 [(SA404)] HT82M9BE@SOP28 [(SA404)]  
 HT82M9BE@SSOP24 [(SA674)] HT82M9BE@SSOP28 [(SA626A)]  
 HT95A100@SOP28 [(SA404)] HT95A10P@SOP28 [(SA404)]  
 HT95A200@SSOP48 [(SA669)] HT95A20P@SSOP48 [(SA669)]  
 HT95A300@SSOP48 [(SA669)] HT95A30P@SSOP48 [(SA669)]



## HONGKONG

### E(E)PROM/FRAM/NVRAM

HK1215	HK1225
HK1235	HK1245
HK1255	HK1265
HK1275	HK1285
HK1295	HK12A5
HK12B5	OKS1225
OKS1235	OKS1245
OKS1255	OKS1265
OKS1275	OKS1285
OKS1295	OKS12A5
OKS12B5	

## HYNIX

### E(E)PROM/FRAM/NVRAM

H8ACS0EJ0MCP@FBGA137 [(SA700E-B153A-M137F001Y)]  
HY2764                   HY27C64A  
HY27SF081G2A@FBGA63 [(SA642KK-B026A-W048F001Y)]  
HY27UA081G1M@TSOP48 [(SA247-B005)]  
HY27UF081G2A@FBGA63 [(SA642KK-B026-W048F001Y)]  
HY27UF081G2A@TSOP48 [(SA247-B005)]  
HY27UF081G2M@TSOP48 [(SA247-B005)]  
HY27UF082G2A@TSOP48 [(SA247-B005)]  
HY27UF082G2B@TSOP48 [(SA247-B005)]  
HY27UF082G2M@TSOP48 [(SA247-B005)]  
HY27UF084G2M@TSOP48 [(SA247-B005)]  
HY27UG082G2M@TSOP48 [(SA247-B005)]  
HY27UG088G5M@TSOP48 [(SA247+B005)]  
HY27US08121M@TSOP48 [(SA247-B005)]  
HY27US081G1M@USOP48 [(SA765-B005)]  
HY27US08281A@TSOP48 [(SA247-B005)]  
HY27US08561A@FBGA63 [(SA642KK-B026A-W048F001Y)]  
HY27US08561A@TSOP48 [(SA247-B005)]  
HY27US08561M@TSOP48 [(SA247-B005)]

HY27UT084G2M@TSOP48 [(SA247-B005)]  
HY27UT088G2A@TSOP48 [(SA247-B005)]  
HY27UT088G2M@TSOP48 [(SA247-B005)]  
HY27UV08BG5M@TSOP48 [(SA247-B005)]  
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162BT@TSOP48 [(SA247-B005)]  
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162TT@TSOP48 [(SA247-B005)]  
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163BT@TSOP48 [(SA247-B005)]  
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163TT@TSOP48 [(SA247-B005)]  
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162BT@TSOP48 [(SA247-B005)]  
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162TT@TSOP48 [(SA247-B005)]  
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163BT@TSOP48 [(SA247-B005)]  
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163TT@TSOP48 [(SA247-B005)]  
HY29F002T                   HY29F002T@PLCC32 [(SA015A1T)]  
HY29F002T@TSOP32 [(SA410T)]   HY29F040  
HY29F040@PLCC32 [(SA015A1T)]   HY29F040@TSOP32 [(SA410T)]  
HY29F040A                   HY29F040A@PLCC32 [(SA015A1T)]  
HY29F040A@TSOP32 [(SA410T)]   HY29F080@TSOP40 [(SA409T)]  
HY29F200B@PSOP44 [(SA638-B006)]   HY29F200B@TSOP48 [(SA247-B005)]  
HY29F200T@PSOP44 [(SA638-B006)]   HY29F200T@TSOP48 [(SA247-B005)]  
HY29F400ABG@PSOP44 [(SA638)]  
HY29F400ABT@TSOP48 [(SA247-B005)]  
HY29F400ATG@PSOP44 [(SA638)]  
HY29F400ATT@TSOP48 [(SA247-B005)]  
HY29F400BG@PSOP44 [(SA638)]   HY29F400BT@TSOP48 [(SA247-B005)]  
HY29F400TG@PSOP44 [(SA638)]   HY29F400TT@TSOP48 [(SA247-B005)]  
HY29F800ABG@PSOP44 [(SA638)]  
HY29F800ABT@TSOP48 [(SA247-B005)]  
HY29F800ATG@PSOP44 [(SA638)]  
HY29F800ATT@TSOP48 [(SA247-B005)]  
HY29F800BG@PSOP44 [(SA638)]   HY29F800BT@TSOP48 [(SA247-B005)]  
HY29F800TG@PSOP44 [(SA638)]   HY29F800TT@TSOP48 [(SA247-B005)]  
HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV160BT@TSOP48 [(SA247-B005)]  
HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV160TT@TSOP48 [(SA247-B005)]

HY29LV320BF@FBGA48 [(SA642E-B026A-T072F001)]  
HY29LV320BF@FBGA63 [(SA642E-B026A-T072F001)]  
HY29LV320BT@TSOP48 [(SA247-B005)]  
HY29LV320TF@FBGA48 [(SA642E-B026A-T072F001)]  
HY29LV320TF@FBGA63 [(SA642E-B026A-T072F001)]  
HY29LV320TT@TSOP48 [(SA247-B005)]  
HY29LV400BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV400BT@TSOP48 [(SA247-B005)]  
HY29LV400TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV400TT@TSOP48 [(SA247-B005)]  
HY29LV800BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV800BG@PSOP44 [(SA638)]  
HY29LV800BT@TSOP48 [(SA247-B005)]  
HY29LV800TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29LV800TG@PSOP44 [(SA638)]  
HY29LV800TT@TSOP48 [(SA247-B005)]  
HY93C46                   HY93C46@SOIC8 [(SA602A)]  
HY93C56                   HY93C56@SOIC8 [(SA602A)]  
HY93C66                   HY93C66@SOIC8 [(SA602A)]  
HY93C76                   HY93C76@SOIC8 [(SA602A)]  
HY93C86                   HY93C86@SOIC8 [(SA602A)]  
HYC0SEH0AF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
HYD0SFE0BF1P@BGA149 [(SA700I-B308-T149F001Y)]  
HYD0SFG0MF1P@BGA149 [(SA700I-B308-T149F001Y)]  
HYG0SEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]  
HYG0UEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]

## DRAM & SRAM

HY62256A                   HY62256A@TSOP28 [(SA643)]  
HY6264A                   HY6264A@TSOP28 [(SA643)]  
HY628100A                  HY628100A@SOP32 [(SA438T)]  
HY628100A@TSOP32 [(SA410T)]   HY628100B  
HY628100B@SOP32 [(SA438T)]   HY628100B@TSOP32 [(SA410T)]  
HY628400                  HY628400@SOP32 [(SA438T)]  
HY628400@TSOP32 [(SA410T)]   HY628400A  
HY628400A@SOP32 [(SA438T)]   HY628400A@TSOP32 [(SA410T)]  
HY62CT08081E               HY62CT08081E@SOP28 [(SA438T)]  
HY62CT08081E@TSOP28 [(SA643)]   HY62KT08081E  
HY62KT08081E@SOP28 [(SA438T)]   HY62KT08081E@TSOP28 [(SA643)]  
HY62U8100B                HY62U8100B@SOP32 [(SA438T)]  
HY62U8100B@TSOP32 [(SA410T)]   HY62U8200B

HY62U8200B@SOP32 [(SA438T)]      HY62U8200B@TSOP32 [(SA410T)]  
 HY62U8400A                      HY62U8400A@SOP32 [(SA438T)]  
 HY62U8400A@TSOP32 [(SA410T)]      HY62UT08081E  
 HY62UT08081E@SOP28 [(SA438T)]      HY62UT08081E@TSOP28 [(SA643)]  
 HY62V8100B                      HY62V8100B@SOP32 [(SA438T)]  
 HY62V8100B@TSOP32 [(SA410T)]      HY62V8200B  
 HY62V8200B@SOP32 [(SA438T)]      HY62V8200B@TSOP32 [(SA410T)]  
 HY62V8400A                      HY62V8400A@SOP32 [(SA438T)]  
 HY62V8400A@TSOP32 [(SA410T)]      HY62VT08081E  
 HY62VT08081E@SOP28 [(SA438T)]      HY62VT08081E@TSOP28 [(SA643)]  
 HY62WT08081E                      HY62WT08081E@SOP28 [(SA438T)]  
 HY62WT08081E@TSOP28 [(SA643)]

## MICROCONTROLLER

GMS97C1051                      GMS97C1051@SOIC20 [(SA404)]  
 GMS97C2051                      GMS97C2051@SOIC20 [(SA404)]  
 GMS97C51                      GMS97C51@PLCC44 [(SA244)]  
 GMS97C51@TQFP44 [(SA245A)]      GMS97C52  
 GMS97C52@PLCC44 [(SA244)]      GMS97C52@TQFP44 [(SA245A)]  
 GMS97C54                      GMS97C54@PLCC44 [(SA244)]  
 GMS97C54@TQFP44 [(SA245A)]      GMS97C56  
 GMS97C56@PLCC44 [(SA244)]      GMS97C56@TQFP44 [(SA245A)]  
 GMS97C58                      GMS97C58@PLCC44 [(SA244)]  
 GMS97C58@TQFP44 [(SA245A)]      GMS97L1051  
 GMS97L1051@SOIC20 [(SA404)]      GMS97L2051  
 GMS97L2051@SOIC20 [(SA404)]      GMS97L51  
 GMS97L51@PLCC44 [(SA244)]      GMS97L51@TQFP44 [(SA245A)]  
 GMS97L52                      GMS97L52@PLCC44 [(SA244)]  
 GMS97L52@TQFP44 [(SA245A)]      GMS97L54  
 GMS97L54@PLCC44 [(SA244)]      GMS97L54@TQFP44 [(SA245A)]  
 GMS97L56                      GMS97L56@PLCC44 [(SA244)]  
 GMS97L56@TQFP44 [(SA245A)]      GMS97L58  
 GMS97L58@PLCC44 [(SA244)]      GMS97L58@TQFP44 [(SA245A)]  
 GMS99C52                      GMS99C52@PLCC44 [(SA244)]  
 GMS99C52@TQFP44 [(SA245A)]      GMS99C58  
 GMS99C58@PLCC44 [(SA244)]      GMS99C58@TQFP44 [(SA245A)]  
 HMS99C52                      HMS99C52@PLCC44 [(SA244)]  
 HMS99C52@TQFP44 [(SA245A)]      HMS99C58  
 HMS99C58@PLCC44 [(SA244)]      HMS99C58@TQFP44 [(SA245A)]

## HYNIX-CUSTOMER

### E(E)PROM/FRAM/NVRAM

HY27UF081G2A(DD)@TSOP48 [(SA247-B005)]  
HY27UF081G2A(DD5)@TSOP48 [(SA247+B005)]  
HY27UF081G2A(MLT)@TSOP48 [(SA247-B005)]  
HY27UF082G2A(AMLOGIC)@TSOP48 [(SA247-B005)]  
HY27UF082G2A(MLT)@TSOP48 [(SA247-B005)]  
HY27UF084G2M(YH)@TSOP48 [(SA247-B005)]  
HY27US08281A(WS)@TSOP48 [(SA247-B005)]  
HY27UT088G2A(64M)@TSOP48 [(SA247-B005)]  
HY27UT088G2M(OMB)@TSOP48 [(SA247-B005)]

## HYUNDAI

### E(E)PROM/FRAM/NVRAM

HY2764                      HY27C64A  
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162BT@TSOP48 [(SA247-B005)]  
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162TT@TSOP48 [(SA247-B005)]  
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163BT@TSOP48 [(SA247-B005)]  
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163TT@TSOP48 [(SA247-B005)]  
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162BT@TSOP48 [(SA247-B005)]  
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162TT@TSOP48 [(SA247-B005)]  
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163BT@TSOP48 [(SA247-B005)]  
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163TT@TSOP48 [(SA247-B005)]  
HY29F002T                      HY29F002T@PLCC32 [(SA015A1T)]  
HY29F002T@TSOP32 [(SA410T)]      HY29F040  
HY29F040@PLCC32 [(SA015A1T)]      HY29F040@TSOP32 [(SA410T)]  
HY29F040A                      HY29F040A@PLCC32 [(SA015A1T)]  
HY29F040A@TSOP32 [(SA410T)]      HY29F080@TSOP40 [(SA409T)]  
HY29F200B@PSOP44 [(SA638-B006)]      HY29F200B@TSOP48 [(SA247-B005)]

HY29F200T@PSOP44 [(SA638-B006)]    HY29F200T@TSOP48 [(SA247-B005)]  
 HY29F400ABG@PSOP44 [(SA638)]  
 HY29F400ABT@TSOP48 [(SA247-B005)]  
 HY29F400ATG@PSOP44 [(SA638)]  
 HY29F400ATT@TSOP48 [(SA247-B005)]  
 HY29F400BG@PSOP44 [(SA638)]    HY29F400BT@TSOP48 [(SA247-B005)]  
 HY29F400TG@PSOP44 [(SA638)]    HY29F400TT@TSOP48 [(SA247-B005)]  
 HY29F800ABG@PSOP44 [(SA638)]  
 HY29F800ABT@TSOP48 [(SA247-B005)]  
 HY29F800ATG@PSOP44 [(SA638)]  
 HY29F800ATT@TSOP48 [(SA247-B005)]  
 HY29F800BG@PSOP44 [(SA638)]    HY29F800BT@TSOP48 [(SA247-B005)]  
 HY29F800TG@PSOP44 [(SA638)]    HY29F800TT@TSOP48 [(SA247-B005)]  
 HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV160BT@TSOP48 [(SA247-B005)]  
 HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV160TT@TSOP48 [(SA247-B005)]  
 HY29LV320BF@FBGA48 [(SA642E-B026A-T072F001)]  
 HY29LV320BF@FBGA63 [(SA642E-B026A-T072F001)]  
 HY29LV320BT@TSOP48 [(SA247-B005)]  
 HY29LV320TF@FBGA48 [(SA642E-B026A-T072F001)]  
 HY29LV320TF@FBGA63 [(SA642E-B026A-T072F001)]  
 HY29LV320TT@TSOP48 [(SA247-B005)]  
 HY29LV400BF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV400BT@TSOP48 [(SA247-B005)]  
 HY29LV400TF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV400TT@TSOP48 [(SA247-B005)]  
 HY29LV800BF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV800BG@PSOP44 [(SA638)]  
 HY29LV800BT@TSOP48 [(SA247-B005)]  
 HY29LV800TF@FBGA48 [(SA642F-B026A-T064F001)]  
 HY29LV800TG@PSOP44 [(SA638)]  
 HY29LV800TT@TSOP48 [(SA247-B005)]  
 HY93C46                    HY93C46@SOIC8 [(SA602A)]  
 HY93C56                    HY93C56@SOIC8 [(SA602A)]  
 HY93C66                    HY93C66@SOIC8 [(SA602A)]  
 HY93C76                    HY93C76@SOIC8 [(SA602A)]  
 HY93C86                    HY93C86@SOIC8 [(SA602A)]

## DRAM & SRAM

HY62256A                    HY62256A@TSOP28 [(SA643)]

HY6264A HY6264A@TSOP28 [(SA643)]  
 HY628100A HY628100A@SOP32 [(SA438T)]  
 HY628100A@TSOP32 [(SA410T)] HY628100B  
 HY628100B@SOP32 [(SA438T)] HY628100B@TSOP32 [(SA410T)]  
 HY628400 HY628400@SOP32 [(SA438T)]  
 HY628400@TSOP32 [(SA410T)] HY628400A  
 HY628400A@SOP32 [(SA438T)] HY628400A@TSOP32 [(SA410T)]  
 HY62CT08081E HY62CT08081E@SOP28 [(SA438T)]  
 HY62CT08081E@TSOP28 [(SA643)] HY62KT08081E  
 HY62KT08081E@SOP28 [(SA438T)] HY62KT08081E@TSOP28 [(SA643)]  
 HY62U8100B HY62U8100B@SOP32 [(SA438T)]  
 HY62U8100B@TSOP32 [(SA410T)] HY62U8200B  
 HY62U8200B@SOP32 [(SA438T)] HY62U8200B@TSOP32 [(SA410T)]  
 HY62U8400A HY62U8400A@SOP32 [(SA438T)]  
 HY62U8400A@TSOP32 [(SA410T)] HY62UT08081E  
 HY62UT08081E@SOP28 [(SA438T)] HY62UT08081E@TSOP28 [(SA643)]  
 HY62V8100B HY62V8100B@SOP32 [(SA438T)]  
 HY62V8100B@TSOP32 [(SA410T)] HY62V8200B  
 HY62V8200B@SOP32 [(SA438T)] HY62V8200B@TSOP32 [(SA410T)]  
 HY62V8400A HY62V8400A@SOP32 [(SA438T)]  
 HY62V8400A@TSOP32 [(SA410T)] HY62VT08081E  
 HY62VT08081E@SOP28 [(SA438T)] HY62VT08081E@TSOP28 [(SA643)]  
 HY62WT08081E HY62WT08081E@SOP28 [(SA438T)]  
 HY62WT08081E@TSOP28 [(SA643)]

## MICROCONTROLLER

GMS97C1051 GMS97C1051@SOIC20 [(SA404)]  
 GMS97C2051 GMS97C2051@SOIC20 [(SA404)]  
 GMS97C51 GMS97C51@PLCC44 [(SA244)]  
 GMS97C51@TQFP44 [(SA245A)] GMS97C52  
 GMS97C52@PLCC44 [(SA244)] GMS97C52@TQFP44 [(SA245A)]  
 GMS97C54 GMS97C54@PLCC44 [(SA244)]  
 GMS97C54@TQFP44 [(SA245A)] GMS97C56  
 GMS97C56@PLCC44 [(SA244)] GMS97C56@TQFP44 [(SA245A)]  
 GMS97C58 GMS97C58@PLCC44 [(SA244)]  
 GMS97C58@TQFP44 [(SA245A)] GMS97L1051  
 GMS97L1051@SOIC20 [(SA404)] GMS97L2051  
 GMS97L2051@SOIC20 [(SA404)] GMS97L51  
 GMS97L51@PLCC44 [(SA244)] GMS97L51@TQFP44 [(SA245A)]  
 GMS97L52 GMS97L52@PLCC44 [(SA244)]  
 GMS97L52@TQFP44 [(SA245A)] GMS97L54

GMS97L54@PLCC44 [(SA244)]      GMS97L54@TQFP44 [(SA245A)]  
GMS97L56                      GMS97L56@PLCC44 [(SA244)]  
GMS97L56@TQFP44 [(SA245A)]      GMS97L58  
GMS97L58@PLCC44 [(SA244)]      GMS97L58@TQFP44 [(SA245A)]  
GMS99C52                      GMS99C52@PLCC44 [(SA244)]  
GMS99C52@TQFP44 [(SA245A)]      GMS99C58  
GMS99C58@PLCC44 [(SA244)]      GMS99C58@TQFP44 [(SA245A)]  
HMS99C52                      HMS99C52@PLCC44 [(SA244)]  
HMS99C52@TQFP44 [(SA245A)]      HMS99C58  
HMS99C58@PLCC44 [(SA244)]      HMS99C58@TQFP44 [(SA245A)]

## ICE

### E(E)PROM/FRAM/NVRAM

ICE25P05                      ICE25P05@SOIC8 [(SA602A)]  
ICE27C010                      ICE27C010@PLCC32 [(SA015A1T)]  
ICE27C010@TSOP32 [(SA410T)]      ICE27C020  
ICE27C020@PLCC32 [(SA015A1T)]      ICE27C020@TSOP32 [(SA410T)]  
ICE27C512                      ICE27C512@PLCC32 [(SA015A1T)]  
ICE27C512@TSOP28 [(SA430T)]      ICE27LC010  
ICE27LC010@PLCC32 [(SA015A1T)]      ICE27LC010@TSOP32 [(SA410T)]  
ICE27LC020                      ICE27LC020@PLCC32 [(SA015A1T)]  
ICE27LC020@TSOP32 [(SA410T)]      ICE27LC512  
ICE27LC512@PLCC32 [(SA015A1T)]      ICE27LC512@TSOP28 [(SA430T)]  
ICE28LF010                      ICE28LF010@PLCC32 [(SA015A1T)]  
ICE37C512                      ICE37C512@PLCC32 [(SA015A1T)]  
ICE37C512@TSOP32 [(SA410T)]      ICE37LC512  
ICE37LC512@PLCC32 [(SA015A1T)]      ICE37LC512@TSOP32 [(SA410T)]

## ICMIC

### E(E)PROM/FRAM/NVRAM

X76F101                      X76F101@SOIC8 [(SA602A)]  
X76F400@SOIC8 [(SA602A)]      X76F400@TSSOP8 [(SA026)]

## ICSI



## E(E)PROM/FRAM/NVRAM

IC71V08F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32BS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32BS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32BS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32CS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32CS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32DS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32DS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32ES04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32ES08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32FS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V08F32FS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32BS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32BS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32BS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32CS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32CS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32DS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32DS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32ES04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V16F32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32ES08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32FS04@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32FS08@FBGA64 [(SA642A-B032A-Y096F001)]  
IC71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32GS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32HS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F32HS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F64IP16@FBGA73 [(SA642A-B032A-Y096F001)]  
IC71V16F64IS08@FBGA73 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

IC89LV51A                    IC89LV51A@PLCC44 [(SA244)]  
IC89LV51A@TQFP44 [(SA245A)]    IC89LV52A  
IC89LV52A@PLCC44 [(SA244)]    IC89LV52A@TQFP44 [(SA245A)]  
IS89C51A                    IS89C51A@PLCC44 [(SA244)]  
IS89C51A@TQFP44 [(SA245A)]    IS89C52A  
IS89C52A@PLCC44 [(SA244)]    IS89C52A@TQFP44 [(SA245A)]  
IS89C54                    IS89C54@PLCC44 [(SA244)]  
IS89C54@TQFP44 [(SA245A)]    IS89C58  
IS89C58@PLCC44 [(SA244)]    IS89C58@TQFP44 [(SA245A)]  
IS89C64                    IS89C64@PLCC44 [(SA244)]  
IS89C64@TQFP44 [(SA245A)]    IS89E54  
IS89E54@PLCC44 [(SA244)]    IS89E54@TQFP44 [(SA245A)]  
IS89E58                    IS89E58@PLCC44 [(SA244)]  
IS89E58@TQFP44 [(SA245A)]    IS89E64  
IS89E64@PLCC44 [(SA244)]    IS89E64@TQFP44 [(SA245A)]

## ICT

## E(E)PROM/FRAM/NVRAM

27CX010                    27CX010@PLCC32 [(SA015A1T)]  
27CX010@TSOP32 [(SA410T)]    27CX161  
27CX162                    27CX256  
27CX321                    27CX322  
27CX641                    27CX642

93C46                    93C46@SOIC8 [(SA602A)]  
 93C46A                  93C46A@SOIC8 [(SA602A)]  
 93C56A                  93C56A@SOIC8 [(SA602A)]  
 93C66A                  93C66A@SOIC8 [(SA602A)]  
 93CX46                  93CX46@SOIC8 [(SA602A)]  
 93CX56                  93CX56@SOIC8 [(SA602A)]  
 93CX66                  93CX66@SOIC8 [(SA602A)]

## PLD

PA7024                  PA7024(J)@PLCC28 [(SA008A)]  
 PA7024(JN)@PLCC28 [(SA008A)]    PA7024@SOIC24 [(SA404)]  
 PA7128                  PA7128@PLCC28 [(SA008A)]  
 PA7128@SOIC28 [(SA404)]          PA7140  
 PA7140@PLCC44 [(SA244)]          PA7140@TQFP44 [(SA245A)]  
 PA7536                  PA7536@PLCC28 [(SA008A)]  
 PA7536@SOIC28 [(SA404)]          PA7540  
 PA7540(J)@PLCC28 [(SA008A)]      PA7540(JN)@PLCC28 [(SA008A)]  
 PA7572                  PA7572@PLCC44 [(SA244)]  
 PA7572@TQFP44 [(SA245A)]      PEEL18CV8Z  
 PEEL18CV8Z@PLCC20 [(SA001A)]    PEEL18CV8Z@SOIC20 [(SA404)]  
 PEEL18CV8Z@TSOP20 [(SA026)]    PEEL18LV8Z  
 PEEL18LV8Z@PLCC20 [(SA001A)]    PEEL18LV8Z@SOIC20 [(SA404)]  
 PEEL18LV8Z@TSOP20 [(SA026)]    PEEL22CV10  
 PEEL22CV10@PLCC28 [(SA008A)]    PEEL22CV10A  
 PEEL22CV10A@PLCC28 [(SA008A)]    PEEL22CV10A@SOIC24 [(SA404)]  
 PEEL22CV10A@TSOP24 [(SA026)]    PEEL22CV10A+  
 PEEL22CV10A+@PLCC28 [(SA008A)]    PEEL22CV10A+@SOIC24 [(SA404)]  
 PEEL22CV10A+@TSOP24 [(SA026)]    PEEL22CV10A++  
 PEEL22CV10A++@PLCC28 [(SA008A)]    PEEL22CV10A++@SOIC24 [(SA404)]  
 PEEL22CV10A++@TSOP24 [(SA026)]    PEEL22CV10AZ  
 PEEL22CV10AZ@PLCC28 [(SA008A)]    PEEL22CV10AZ@SOIC24 [(SA404)]  
 PEEL22CV10AZ@TSOP24 [(SA026)]    PEEL22CV10AZ+  
 PEEL22CV10AZ+@PLCC28 [(SA008A)]    PEEL22CV10AZ+@SOIC24 [(SA404)]  
 PEEL22CV10AZ+@TSOP24 [(SA026)]    PEEL22CV10AZ++  
 PEEL22CV10AZ++@PLCC28 [(SA008A)]    PEEL22CV10AZ++@SOIC24 [(SA404)]  
 PEEL22CV10AZ++@TSOP24 [(SA026)]    PEEL22LV10AZ  
 PEEL22LV10AZ@PLCC28 [(SA008A)]    PEEL22LV10AZ@SOIC24 [(SA404)]  
 PEEL22LV10AZ@TSOP24 [(SA026)]    PEEL22LV10AZ+  
 PEEL22LV10AZ+@PLCC28 [(SA008A)]    PEEL22LV10AZ+@SOIC24 [(SA404)]  
 PEEL22LV10AZ+@TSOP24 [(SA026)]    PEEL22LV10AZ++  
 PEEL22LV10AZ++@PLCC28 [(SA008A)]    PEEL22LV10AZ++@SOIC24 [(SA404)]

PEEL22LV10AZ++@TSOP24 [(SA026)]

## IMT

## E(E)PROM/FRAM/NVRAM

IM29F001B	IM29F001B@PLCC32 [(SA015A1T)]
IM29F001B@TSOP32 [(SA410T)]	IM29F001B@VSOP32 [(SA620)]
IM29F001T	IM29F001T@PLCC32 [(SA015A1T)]
IM29F001T@TSOP32 [(SA410T)]	IM29F001T@VSOP32 [(SA620)]
IM29F002B	IM29F002B@PLCC32 [(SA015A1T)]
IM29F002B@TSOP32 [(SA410T)]	IM29F002B@VSOP32 [(SA620)]
IM29F002T	IM29F002T@PLCC32 [(SA015A1T)]
IM29F002T@TSOP32 [(SA410T)]	IM29F002T@VSOP32 [(SA620)]
IM29F004B	IM29F004B@PLCC32 [(SA015A1T)]
IM29F004B@TSOP32 [(SA410T)]	IM29F004B@VSOP32 [(SA620)]
IM29F004T	IM29F004T@PLCC32 [(SA015A1T)]
IM29F004T@TSOP32 [(SA410T)]	IM29F004T@VSOP32 [(SA620)]
IM29LV004B	IM29LV004B@PLCC32 [(SA015A1T)]
IM29LV004B@TSOP32 [(SA410T)]	IM29LV004B@VSOP32 [(SA620)]
IM29LV004T	IM29LV004T@PLCC32 [(SA015A1T)]
IM29LV004T@TSOP32 [(SA410T)]	IM29LV004T@VSOP32 [(SA620)]
IM29LV400B@PSOP44 [(SA638)]	IM29LV400B@TSOP48 [(SA247-B005)]
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-B005)]

## INTEL

## E(E)PROM/FRAM/NVRAM

27010	27010@PLCC32 [(SA015A1T)]
27010@TSOP32 [(SA410T)]	27128
27128A	27128B
2716	27210
27256	2732
2732A	27512
2764	2764A
27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C010A
27C010A@PLCC32 [(SA015A1T)]	27C010A@TSOP32 [(SA410T)]
27C020	27C020@PLCC32 [(SA015A1T)]

27C020@TSOP32 [(SA410T)]      27C040  
 27C040@PLCC32 [(SA015A1T)]      27C040@TSOP32 [(SA410T)]  
 27C100      27C100@PLCC32 [(SA015A1T)]  
 27C100@TSOP32 [(SA410T)]      27C128  
 27C128@PLCC32 [(SA015A1T)]      27C210  
 27C210@PLCC44 [(SA244)]      27C220  
 27C220@PLCC44 [(SA244)]      27C240  
 27C240@PLCC44 [(SA244)]      27C256  
 27C256@PLCC32 [(SA015A1T)]      27C400  
 27C400@PLCC44 [(SA244)]      27C512  
 27C512@PLCC32 [(SA015A1T)]      27C64  
 27C64@PLCC32 [(SA015A1T)]      27C800  
 27S512      2816A  
 2817A      2864A  
 68C257      68C257@PLCC32 [(SA015A1T)]  
 87C256      87C257  
 87C257@PLCC32 [(SA015A1T)]      87C64  
 D27011      D27513  
 D27C011      D27C513  
 D28F256      D28F256A  
 D28F512  
 DA28F016SA@SSOP56 [(SA629A-B013)]  
 DA28F016SV@SSOP56 [(SA629A-B013)]  
 DA28F320J5(low)@SSOP56 [(SA629-B013)]  
 DA28F320J5@SSOP56 [(SA629A-B013)]  
 DA28F320J5A(low)@SSOP56 [(SA629-B013)]  
 DA28F320J5A@SSOP56 [(SA629A-B013)]  
 DA28F640J5@SSOP56 [(SA629A-B013)]  
 DA28F640J5A@SSOP56 [(SA629A-B013)]  
 DD28F032SA@TSOP56 [(SA628-B011)]  
 DT28F016SA@SSOP56 [(SA629A-B013)]  
 DT28F016SA@TSOP56 [(SA628-B011)]  
 DT28F016SV@SSOP56 [(SA629A-B013)]  
 DT28F016SV@TSOP56 [(SA628-B011)]  
 DT28F160F3B@SSOP56 [(SA629A-B015)]  
 DT28F160F3T@SSOP56 [(SA629A-B015)]  
 DT28F160S3@SSOP56 [(SA629A-B013)]  
 DT28F160S5@SSOP56 [(SA629A-B013)]  
 DT28F320J5@SSOP56 [(SA629A-B013)]  
 DT28F320J5A@SSOP56 [(SA629A-B013)]  
 DT28F320S3@SSOP56 [(SA629A-B013)]  
 DT28F320S5@SSOP56 [(SA629A-B013)]  
 DT28F640J5@SSOP56 [(SA629A-B013)]

DT28F640J5A@SSOP56 [(SA629A-B013)]  
 DT28F800F3B@SSOP56 [(SA629A-B015)]  
 DT28F800F3T@SSOP56 [(SA629A-B015)]  
 E28F001BX-B@TSOP32 [(SA410T)]      E28F001BX-T@TSOP32 [(SA410T)]  
 E28F002BCT@TSOP40 [(SA409T)]      E28F002BEB@TSOP40 [(SA409T)]  
 E28F002BET@TSOP40 [(SA409T)]      E28F002BLB@TSOP40 [(SA409T)]  
 E28F002BLT@TSOP40 [(SA409T)]      E28F002BVB@TSOP40 [(SA409T)]  
 E28F002BVT@TSOP40 [(SA409T)]      E28F002BXB@TSOP40 [(SA409T)]  
 E28F002BXT@TSOP40 [(SA409T)]      E28F004B5B@TSOP40 [(SA409T)]  
 E28F004B5T@TSOP40 [(SA409T)]      E28F004BEB@TSOP40 [(SA409T)]  
 E28F004BET@TSOP40 [(SA409T)]      E28F004BLB@TSOP40 [(SA409T)]  
 E28F004BLT@TSOP40 [(SA409T)]      E28F004BVB@TSOP40 [(SA409T)]  
 E28F004BVT@TSOP40 [(SA409T)]      E28F004BXB@TSOP40 [(SA409T)]  
 E28F004BXT@TSOP40 [(SA409T)]      E28F004S3@TSOP40 [(SA409T)]  
 E28F004S5@TSOP40 [(SA409T)]      E28F004SC@TSOP40 [(SA409T)]  
 E28F008BEB@TSOP40 [(SA409T)]      E28F008BET@TSOP40 [(SA409T)]  
 E28F008BLB@TSOP40 [(SA409T)]      E28F008BLT@TSOP40 [(SA409T)]  
 E28F008BVB@TSOP40 [(SA409T)]      E28F008BVT@TSOP40 [(SA409T)]  
 E28F008BXB@TSOP40 [(SA409T)]      E28F008BXT@TSOP40 [(SA409T)]  
 E28F008S3@TSOP40 [(SA409T)]      E28F008S5@TSOP40 [(SA409T)]  
 E28F008SA@TSOP40 [(SA409T)]      E28F008SA-L@TSOP40 [(SA409T)]  
 E28F008SC@TSOP40 [(SA409T)]      E28F010@TSOP32 [(SA410T)]  
 E28F016S3@TSOP40 [(SA409T)]      E28F016S5@TSOP40 [(SA409T)]  
 E28F016SA@TSOP56 [(SA628-B011)]      E28F016SC@TSOP40 [(SA409T)]  
 E28F016SV@TSOP56 [(SA628-B011)]      E28F020@TSOP32 [(SA410T)]  
 E28F128J3A@TSOP56 [(SA628-B018)]      E28F200B5B@TSOP48 [(SA247-B005)]  
 E28F200B5T@TSOP48 [(SA247-B005)]      E28F200BVB@TSOP56 [(SA628-B012)]  
 E28F200BVT@TSOP56 [(SA628-B012)]      E28F200BXB@TSOP56 [(SA628-B012)]  
 E28F200BXT@TSOP56 [(SA628-B012)]      E28F200CVB@TSOP48 [(SA247-B005)]  
 E28F200CVT@TSOP48 [(SA247-B005)]      E28F256@TSOP32 [(SA410T)]  
 E28F256A@TSOP32 [(SA410T)]      E28F320J3A@TSOP56 [(SA628-B018)]  
 E28F320J5(low)@TSOP56 [(SA628-B011)]  
 E28F320J5@TSOP56 [(SA628-B011)]  
 E28F320J5A(low)@TSOP56 [(SA628-B011)]  
 E28F320J5A@TSOP56 [(SA628-B011)]      E28F400B5B@TSOP48 [(SA247-B005)]  
 E28F400B5T@TSOP48 [(SA247-B005)]      E28F400BVB@TSOP56 [(SA628-B012)]  
 E28F400BVT@TSOP56 [(SA628-B012)]      E28F400BXB@TSOP56 [(SA628-B012)]  
 E28F400BXT@TSOP56 [(SA628-B012)]      E28F400CVB@TSOP48 [(SA247-B005)]  
 E28F400CVT@TSOP48 [(SA247-B005)]      E28F512@TSOP32 [(SA410T)]  
 E28F640J3A@TSOP56 [(SA628-B018)]      E28F800B5B@TSOP48 [(SA247-B005)]  
 E28F800B5T@TSOP48 [(SA247-B005)]      E28F800CEB@TSOP48 [(SA247-B005)]  
 E28F800CET@TSOP48 [(SA247-B005)]      E28F800CVB@TSOP48 [(SA247-B005)]  
 E28F800CVT@TSOP48 [(SA247-B005)]      E82802AA@TSOP40 [(SA409T)]

E82802AB@TSOP40 [(SA409T)]      E82802AC@TSOP40 [(SA409T)]  
F28F010@TSOP32 [(SA410T)]  
F28F020(REVERSE)@TSOP32 [(SA410T)]  
F28F020@TSOP32 [(SA410T)]      F28F256@TSOP32 [(SA410T)]  
F28F256A@TSOP32 [(SA410T)]      F28F512@TSOP32 [(SA410T)]  
G28F640J5@uBGA56 [(SA644A-B028A-Y072F001Y)]  
G28F640J5A@uBGA56 [(SA644A-B028A-Y072F001Y)]  
GE28F008B3BA@uBGA48 [(SA634)]      GE28F008B3TA@uBGA48 [(SA634)]  
GE28F128K18C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128K3C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128L18B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L18T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]

GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BD(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TD(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320W18BC(NO EFP)VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W30BC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]



GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]

GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]  
JS28F128P30B@TSOP56 [(SA628-B131)]  
JS28F128P30T@TSOP56 [(SA628-B131)]  
JS28F128P33B@TSOP56 [(SA628-B131)]  
JS28F128P33T@TSOP56 [(SA628-B131)]  
JS28F160B3BD@TSOP48 [(SA247-B005)]  
JS28F160B3TD@TSOP48 [(SA247-B005)]  
JS28F160C3BD@TSOP48 [(SA247-B005)]  
JS28F160C3TD@TSOP48 [(SA247-B005)]  
JS28F256P30B@TSOP56 [(SA628-B131)]  
JS28F256P30T@TSOP56 [(SA628-B131)]  
JS28F256P33B@TSOP56 [(SA628-B131)]  
JS28F256P33T@TSOP56 [(SA628-B131)]  
JS28F320B3BD@TSOP48 [(SA247-B005)]  
JS28F320B3TD@TSOP48 [(SA247-B005)]  
JS28F320C3BD@TSOP48 [(SA247-B005)]  
JS28F320C3TD@TSOP48 [(SA247-B005)]  
JS28F320J3C@TSOP56 [(SA628-B018)]  
JS28F320J3D@TSOP56 [(SA628-B018)]  
JS28F640J3C@TSOP56 [(SA628-B018)]  
JS28F640J3D@TSOP56 [(SA628-B018)]  
JS28F640P30B(Low)@TSOP56 [(SA628-B131)]  
JS28F640P30B@TSOP56 [(SA628-B131)]  
JS28F640P30T@TSOP56 [(SA628-B131)]  
JS28F640P33B@TSOP56 [(SA628-B131)]  
JS28F640P33T@TSOP56 [(SA628-B131)]  
JS28F800C3BD@TSOP48 [(SA247-B005)]  
JS28F800C3TD@TSOP48 [(SA247-B005)]  
JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
M28F010                    M28F010@PLCC32 [(SA015A1T)]  
M28F010@TSOP32 [(SA410T)]        N28F001BN-B@PLCC32 [(SA015A1T)]

N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32 [(SA015A1T)]  
 N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32 [(SA015A1T)]  
 N28F020@PLCC32 [(SA015A1T)] N28F256@PLCC32 [(SA015A1T)]  
 N28F256A@PLCC32 [(SA015A1T)] N28F512@PLCC32 [(SA015A1T)]  
 N82802AA@PLCC32 [(SA015A1T)] N82802AB@PLCC32 [(SA015A1T)]  
 N82802AC@PLCC32 [(SA015A1T)]  
 NZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 P27011 P27128A  
 P27128A@PLCC32 [(SA015A1T)] P27128B  
 P27128B@PLCC32 [(SA015A1T)] P27256  
 P27256@PLCC32 [(SA015A1T)] P27512  
 P27513 P2764A  
 P2764A@PLCC32 [(SA015A1T)] P27C011  
 P27C128 P27C128@PLCC32 [(SA015A1T)]  
 P27C256 P27C256@PLCC32 [(SA015A1T)]  
 P27C513 P27C64  
 P27C64@PLCC32 [(SA015A1T)] P28F001BX-B  
 P28F001BX-T P28F002BCT@TSOP40 [(SA409T)]  
 P28F010 P28F020  
 P28F256 P28F256A  
 P28F512 P87C64  
 P87C64@PLCC32 [(SA015A1T)] PA28F004S3@PSOP44 [(SA638)]  
 PA28F004S5@PSOP44 [(SA638)] PA28F004SC@PSOP44 [(SA638)]  
 PA28F008S3@PSOP44 [(SA638)] PA28F008S5@PSOP44 [(SA638)]  
 PA28F008SA@PSOP44 [(SA638)] PA28F008SA-L@PSOP44 [(SA638)]  
 PA28F008SC@PSOP44 [(SA638)] PA28F016S3@PSOP44 [(SA638)]  
 PA28F016S5@PSOP44 [(SA638)] PA28F016SC@PSOP44 [(SA638)]  
 PA28F200B5B@PSOP44 [(SA638)] PA28F200B5T@PSOP44 [(SA638)]  
 PA28F200BVB@PSOP44 [(SA638)] PA28F200BVT@PSOP44 [(SA638)]  
 PA28F200BXB@PSOP44 [(SA638)] PA28F200BXT@PSOP44 [(SA638)]  
 PA28F400B5B@PSOP44 [(SA638)] PA28F400B5T@PSOP44 [(SA638)]  
 PA28F400BVB@PSOP44 [(SA638)] PA28F400BVT@PSOP44 [(SA638)]  
 PA28F400BXB@PSOP44 [(SA638)] PA28F400BXT@PSOP44 [(SA638)]  
 PA28F800B5B@PSOP44 [(SA638)] PA28F800B5T@PSOP44 [(SA638)]  
 PA28F800BVB@PSOP44 [(SA638)] PA28F800BVT@PSOP44 [(SA638)]  
 PC28F128J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]

PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
PC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F320J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
PC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
PC28F640J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
PC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
PC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
PC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
PC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
PC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PF38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030C0ZBL0@FBGA72 [(SA642R-B041A-T096F001Y)]  
PF38F1030C0ZTL0@FBGA72 [(SA642R-B041A-T096F001Y)]  
PF38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YQCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0ZTQ0(SLOW)@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YQCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]

PF38F2030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YCQ1@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YUQ1@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F2040W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040L0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040M0Y1QE@FBGA88 [(SA642R-B303A-T096F001Y)]  
PF38F3040M0Y3QE@FBGA88 [(SA642R-B303A-T096F001Y)]  
PF38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3350LLZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF38F3350W0ZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF38F3350WWZDQ1@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF38F4050L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]

PF38F4050L0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4055L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4055L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
PF38F4060L0YBB1@FBGA103 [(SA664F-B157A-W108F001Y)]  
PF38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
PF38F4060L0YTB1@FBGA103 [(SA664F-B157A-W108F001Y)]  
PF38F4450LLYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4450LLYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4450LVYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4450LVYTQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4450LVYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
PF38F4466LVYBQ0@FBGA88 [(SA642A-B125A-Y096N001N)]  
PF38F4466LVYTQ0@FBGA88 [(SA642A-B125A-Y096N001N)]  
PF48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]

PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
QB25F016S33B60@SOIC8 [(SA605A)]    QB25F016S33T60@SOIC8 [(SA605A)]  
QB25F160S33B60@SOIC16 [(SA404)]    QB25F160S33T60@SOIC16 [(SA404)]  
QB25F320S33B60@SOIC16 [(SA404)]    QB25F320S33T60@SOIC16 [(SA404)]  
QB25F640S33B60@SOIC16 [(SA404)]    QB25F640S33T60@SOIC16 [(SA404)]  
QH25F016S33B60@SOIC8 [(SA605A)]    QH25F016S33T60@SOIC8 [(SA605A)]  
QH25F160S33B60@SOIC16 [(SA404)]    QH25F160S33T60@SOIC16 [(SA404)]  
QH25F320S33B60@SOIC16 [(SA404)]    QH25F320S33T60@SOIC16 [(SA404)]

QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16 [(SA404)]  
RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F160C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F256J3A@FBGA96 [(SA642A-B273-Y096N001N)]  
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256K18C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256K3C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F320C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F640C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F640K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]



RC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F800C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RD28F1602C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1602C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]

RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZBQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZTQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2040W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2220WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]

RD38F2230WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD38F2240WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F3040L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F3340LLYDQ1@FBGA88 [(SA642A-B091A-Y096F001)]  
RD38F3350LLZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD38F3350W0ZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD38F3350WWZDQ1@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD38F4050L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]

RD38F4055L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYTQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD48F2000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F2000W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2100W0YBQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2100W0YDQE@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2100W0YTQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2200W0YBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0YDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0YTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]

RD48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
TB28F004S3@PSOP44 [(SA638)] TB28F004S5@PSOP44 [(SA638)]  
TB28F004SC@PSOP44 [(SA638)] TB28F008S3@PSOP44 [(SA638)]  
TB28F008S5@PSOP44 [(SA638)] TB28F008SA@PSOP44 [(SA638)]  
TB28F008SA-L@PSOP44 [(SA638)] TB28F008SC@PSOP44 [(SA638)]  
TB28F016S3@PSOP44 [(SA638)] TB28F016S5@PSOP44 [(SA638)]  
TB28F016SC@PSOP44 [(SA638)] TB28F200B5B@PSOP44 [(SA638)]  
TB28F200B5T@PSOP44 [(SA638)] TB28F200BVB@PSOP44 [(SA638)]  
TB28F200BVT@PSOP44 [(SA638)] TB28F200BXB@PSOP44 [(SA638)]  
TB28F200BXT@PSOP44 [(SA638)] TB28F400B5B@PSOP44 [(SA638)]  
TB28F400B5T@PSOP44 [(SA638)] TB28F400BVB@PSOP44 [(SA638)]  
TB28F400BVT@PSOP44 [(SA638)] TB28F400BXB@PSOP44 [(SA638)]  
TB28F400BXT@PSOP44 [(SA638)] TB28F800B5B@PSOP44 [(SA638)]  
TB28F800B5T@PSOP44 [(SA638)] TB28F800BVB@PSOP44 [(SA638)]  
TB28F800BVT@PSOP44 [(SA638)] TE28F002BEB@TSOP40 [(SA409T)]  
TE28F002BET@TSOP40 [(SA409T)] TE28F002BVB@TSOP40 [(SA409T)]  
TE28F002BVT@TSOP40 [(SA409T)] TE28F002BXB@TSOP40 [(SA409T)]  
TE28F002BXT@TSOP40 [(SA409T)] TE28F004BEB@TSOP40 [(SA409T)]  
TE28F004BET@TSOP40 [(SA409T)] TE28F004BVB@TSOP40 [(SA409T)]  
TE28F004BVT@TSOP40 [(SA409T)] TE28F004BXB@TSOP40 [(SA409T)]  
TE28F004BXT@TSOP40 [(SA409T)] TE28F004S3@TSOP40 [(SA409T)]  
TE28F004S5@TSOP40 [(SA409T)] TE28F004SC@TSOP40 [(SA409T)]  
TE28F008B3B@TSOP40 [(SA409T)] TE28F008B3BA@TSOP40 [(SA409T)]  
TE28F008B3T@TSOP40 [(SA409T)] TE28F008B3TA@TSOP40 [(SA409T)]  
TE28F008BEB@TSOP40 [(SA409T)] TE28F008BET@TSOP40 [(SA409T)]  
TE28F008BVB@TSOP40 [(SA409T)] TE28F008BVT@TSOP40 [(SA409T)]  
TE28F008C3BA@TSOP40 [(SA409T)] TE28F008C3TA@TSOP40 [(SA409T)]  
TE28F008S3@TSOP40 [(SA409T)] TE28F008S5@TSOP40 [(SA409T)]  
TE28F008SA@TSOP40 [(SA409T)] TE28F008SA-L@TSOP40 [(SA409T)]  
TE28F008SC@TSOP40 [(SA409T)] TE28F016B3B@TSOP40 [(SA409T)]  
TE28F016B3T@TSOP40 [(SA409T)] TE28F016C3BA@TSOP40 [(SA409T)]  
TE28F016C3TA@TSOP40 [(SA409T)] TE28F016S3@TSOP40 [(SA409T)]  
TE28F016S5@TSOP40 [(SA409T)] TE28F016SC@TSOP40 [(SA409T)]

TE28F128J3C@TSOP56 [(SA628-B018)]  
TE28F128J3D@TSOP56 [(SA628-B018)]  
TE28F128P30B@TSOP56 [(SA628-B131)]  
TE28F128P30T@TSOP56 [(SA628-B131)]  
TE28F128P33B@TSOP56 [(SA628-B131)]  
TE28F128P33T@TSOP56 [(SA628-B131)]  
TE28F160B3B@TSOP48 [(SA247-B005)]  
TE28F160B3BA@TSOP48 [(SA247-B005)]  
TE28F160B3BC@TSOP48 [(SA247-B005)]  
TE28F160B3BD@TSOP48 [(SA247-B005)]  
TE28F160B3T@TSOP48 [(SA247-B005)]  
TE28F160B3TA@TSOP48 [(SA247-B005)]  
TE28F160B3TC@TSOP48 [(SA247-B005)]  
TE28F160B3TD@TSOP48 [(SA247-B005)]  
TE28F160C3BA@TSOP48 [(SA247-B005)]  
TE28F160C3BC@TSOP48 [(SA247-B005)]  
TE28F160C3BD@TSOP48 [(SA247-B005)]  
TE28F160C3TA@TSOP48 [(SA247-B005)]  
TE28F160C3TC@TSOP48 [(SA247-B005)]  
TE28F160C3TD@TSOP48 [(SA247-B005)]  
TE28F160F3B@TSOP56 [(SA628-B014)]  
TE28F160F3T@TSOP56 [(SA628-B014)]  
TE28F160S3@TSOP56 [(SA628-B011)] TE28F160S5@TSOP56 [(SA628-B011)]  
TE28F200B5B@TSOP48 [(SA247-B005)]  
TE28F200B5T@TSOP48 [(SA247-B005)]  
TE28F200BVB@TSOP56 [(SA628-B012)]  
TE28F200BVT@TSOP56 [(SA628-B012)]  
TE28F200BXB@TSOP56 [(SA628-B012)]  
TE28F200BXT@TSOP56 [(SA628-B012)]  
TE28F200CEB@TSOP56 [(SA628-B012)]  
TE28F200CET@TSOP56 [(SA628-B012)]  
TE28F200CVB@TSOP48 [(SA247-B005)]  
TE28F200CVT@TSOP48 [(SA247-B005)]  
TE28F256J3C@TSOP56 [(SA628-B018)]  
TE28F256P30B@TSOP56 [(SA628-B131)]  
TE28F256P30T@TSOP56 [(SA628-B131)]  
TE28F256P33B@TSOP56 [(SA628-B131)]  
TE28F256P33T@TSOP56 [(SA628-B131)]  
TE28F320B3B@TSOP48 [(SA247-B005)]  
TE28F320B3BA@TSOP48 [(SA247-B005)]  
TE28F320B3BC@TSOP48 [(SA247-B005)]  
TE28F320B3BD@TSOP48 [(SA247-B005)]  
TE28F320B3T@TSOP48 [(SA247-B005)]

TE28F320B3TA@TSOP48 [(SA247-B005)]  
TE28F320B3TC@TSOP48 [(SA247-B005)]  
TE28F320B3TD@TSOP48 [(SA247-B005)]  
TE28F320C3BA@TSOP48 [(SA247-B005)]  
TE28F320C3BC@TSOP48 [(SA247-B005)]  
TE28F320C3BD@TSOP48 [(SA247-B005)]  
TE28F320C3TA@TSOP48 [(SA247-B005)]  
TE28F320C3TC@TSOP48 [(SA247-B005)]  
TE28F320C3TD@TSOP48 [(SA247-B005)]  
TE28F320J3C@TSOP56 [(SA628-B018)]  
TE28F320J3D@TSOP56 [(SA628-B018)]  
TE28F400B3B@TSOP48 [(SA247-B005)]  
TE28F400B3T@TSOP48 [(SA247-B005)]  
TE28F400B5B@TSOP48 [(SA247-B005)]  
TE28F400B5T@TSOP48 [(SA247-B005)]  
TE28F400BVB@TSOP56 [(SA628-B012)]  
TE28F400BVT@TSOP56 [(SA628-B012)]  
TE28F400BXB@TSOP56 [(SA628-B012)]  
TE28F400BXT@TSOP56 [(SA628-B012)]  
TE28F400CEB@TSOP48 [(SA247-B005)]  
TE28F400CET@TSOP48 [(SA247-B005)]  
TE28F400CVB@TSOP48 [(SA247-B005)]  
TE28F400CVT@TSOP48 [(SA247-B005)]  
TE28F640B3BC@TSOP48 [(SA247-B005)]  
TE28F640B3TC@TSOP48 [(SA247-B005)]  
TE28F640C3BC@TSOP48 [(SA247-B005)]  
TE28F640C3TC@TSOP48 [(SA247-B005)]  
TE28F640J3C@TSOP56 [(SA628-B018)]  
TE28F640J3D@TSOP56 [(SA628-B018)]  
TE28F640P30B@TSOP56 [(SA628-B131)]  
TE28F640P30T@TSOP56 [(SA628-B131)]  
TE28F640P33B@TSOP56 [(SA628-B131)]  
TE28F640P33T@TSOP56 [(SA628-B131)]  
TE28F800B3B@TSOP48 [(SA247-B005)]  
TE28F800B3BA@TSOP48 [(SA247-B005)]  
TE28F800B3T@TSOP48 [(SA247-B005)]  
TE28F800B3TA@TSOP48 [(SA247-B005)]  
TE28F800B5B@TSOP48 [(SA247-B005)]  
TE28F800B5T@TSOP48 [(SA247-B005)]  
TE28F800C3BA@TSOP48 [(SA247-B005)]  
TE28F800C3BD@TSOP48 [(SA247-B005)]  
TE28F800C3TA@TSOP48 [(SA247-B005)]  
TE28F800C3TD@TSOP48 [(SA247-B005)]

TE28F800CEB@TSOP48 [(SA247-B005)]  
 TE28F800CET@TSOP48 [(SA247-B005)]  
 TE28F800CVB@TSOP48 [(SA247-B005)]  
 TE28F800CVT@TSOP48 [(SA247-B005)]  
 TE28F800F3B@TSOP56 [(SA628-B014)]  
 TE28F800F3T@TSOP56 [(SA628-B014)]

## PLD

5C031                    5C031@PLCC20 [(SA001A)]  
 5C032                    5C032@PLCC20 [(SA001A)]  
 5C090                    5C090@PLCC44 [(SA244)]  
 85C090                   85C090-P44 [(SA244)]  
 85C220                   85C220@PLCC20 [(SA001A)]  
 IPLD910                 IPLD910-P44 [(SA244)]

## MICROCONTROLLER

8751BH                   8751BH@PLCC44 [(SA244)]  
 8752BH                   8752BH@PLCC44 [(SA244)]  
 8796BH@PLCC68(\*) [(SA648-B6803)]    8796JF@PLCC68(\*) [(SA648-B6803)]  
 8797BH@PGA68(\*) [(SA650-B6804)]    8797BH@PLCC68(\*) [(SA648-B6803)]  
 8797JF@PGA68(\*) [(SA650-B6804)]    8797JF@PLCC68(\*) [(SA648-B6803)]  
 87C151SA                87C151SA@PLCC44 [(SA244)]  
 87C151SB                87C151SB@PLCC44 [(SA244)]  
 87C196CA@PLCC68(\*) [(SA648-B6805)]  
 87C196JQ@PLCC52(\*) [(SA647-B5201)]  
 87C196JR@PLCC52(\*) [(SA647-B5201)]  
 87C196JT@PLCC52(\*) [(SA647-B5201)]  
 87C196JV@PLCC52(\*) [(SA647-B5201)]  
 87C196KB@PLCC68(\*) [(SA648-B6801)]  
 87C196KC@PLCC68(\*) [(SA648-B6801)]  
 87C196KD@PLCC68(\*) [(SA648-B6801)]  
 87C196KQ@PLCC68(\*) [(SA648-B6802)]  
 87C196KR@PLCC68(\*) [(SA648-B6802)]  
 87C196KS@PLCC68(\*) [(SA648-B6802)]  
 87C196KT@PLCC68(\*) [(SA648-B6802)]  
 87C196LA@PLCC52(\*) [(SA647-B5201)]  
 87C196MC@PLCC84(\*) [(SA649-B8401)]  
 87C196MC@PQFP80(\*) [(TA026-B006)]  
 87C196MC@SDIP64(\*) [(SA651)]



87C196MH@PLCC84(\*) [(SA649-B8401)]  
87C196MH@PQFP80(\*) [(TA026-B006)]  
87C196MH@SDIP64(\*) [(SA651)]      87C251SA  
87C251SA@PLCC44 [(SA244)]      87C251SB  
87C251SB@PLCC44 [(SA244)]      87C251SP  
87C251SP@PLCC44 [(SA244)]      87C251SQ  
87C251SQ@PLCC44 [(SA244)]      87C51  
87C51@PLCC44 [(SA244)]      87C51@TQFP44 [(SA245A)]  
87C51FA      87C51FA@PLCC44 [(SA244)]  
87C51FA@TQFP44 [(SA245A)]      87C51FB  
87C51FB@PLCC44 [(SA244)]      87C51FB@TQFP44 [(SA245A)]  
87C51FC      87C51FC@PLCC44 [(SA244)]  
87C51FC@TQFP44 [(SA245A)]      87C51RA  
87C51RA@PLCC44 [(SA244)]      87C51RA@TQFP44 [(SA245A)]  
87C51RB      87C51RB@PLCC44 [(SA244)]  
87C51RB@TQFP44 [(SA245A)]      87C51RC  
87C51RC@PLCC44 [(SA244)]      87C51RC@TQFP44 [(SA245A)]  
87C52      87C52@PLCC44 [(SA244)]  
87C52@TQFP44 [(SA245A)]      87C54  
87C54@PLCC44 [(SA244)]      87C54@TQFP44 [(SA245A)]  
87C58      87C58@PLCC44 [(SA244)]  
87C58@TQFP44 [(SA245A)]      87L51FA@PLCC44 [(SA244)]  
87L51FA@TQFP44 [(SA245A)]      87L51FB@PLCC44 [(SA244)]  
87L51FB@TQFP44 [(SA245A)]      87L51FC@PLCC44 [(SA244)]  
87L51FC@TQFP44 [(SA245A)]      87L52@PLCC44 [(SA244)]  
87L52@TQFP44 [(SA245A)]      87L54@PLCC44 [(SA244)]  
87L54@TQFP44 [(SA245A)]      87L58@PLCC44 [(SA244)]  
87L58@TQFP44 [(SA245A)]

## INTEL-CUSTOMER

### E(E)PROM/FRAM/NVRAM

TE28F800C3TD@TSOP48 [(SA247-B005)]

## INTELSIL

### E(E)PROM/FRAM/NVRAM

HS-6617RH      HS-6617RH@SOIC24 [(SA404)]

HS-6617RH-T	HS-6617RH-T@SOIC24 [(SA404)]
HS-6883RH	HS-6883RH@SOIC24 [(SA404)]
HS-6883RH-T	HS-6883RH-T@SOIC24 [(SA404)]

## ISSI

## E(E)PROM/FRAM/NVRAM

IS24C01	IS24C01@MSOP8 [(SA666)]
IS24C01@SOIC8 [(SA602A)]	IS24C01@TSSOP8 [(SA026)]
IS24C01B	IS24C01B@MSOP8 [(SA666)]
IS24C01B@SOIC8 [(SA602A)]	IS24C01B@TSSOP8 [(SA026)]
IS24C02	IS24C02@MSOP8 [(SA666)]
IS24C02@SOIC8 [(SA602A)]	IS24C02@TSSOP8 [(SA026)]
IS24C02A	IS24C02A@DFN8
IS24C02A@MSOP8 [(SA666)]	IS24C02A@SOIC8 [(SA602A)]
IS24C02A@TSSOP8 [(SA026)]	IS24C02B
IS24C02B@DFN8	IS24C02B@MSOP8 [(SA666)]
IS24C02B@SOIC8 [(SA602A)]	IS24C02B@TSSOP8 [(SA026)]
IS24C04	IS24C04@MSOP8 [(SA666)]
IS24C04@SOIC8 [(SA602A)]	IS24C04@TSSOP8 [(SA026)]
IS24C04A	IS24C04A@DFN8
IS24C04A@MSOP8 [(SA666)]	IS24C04A@SOIC8 [(SA602A)]
IS24C04A@TSSOP8 [(SA026)]	IS24C08
IS24C08@MSOP8 [(SA666)]	IS24C08@SOIC8 [(SA602A)]
IS24C08@TSSOP8 [(SA026)]	IS24C08A
IS24C08A@DFN8	IS24C08A@MSOP8 [(SA666)]
IS24C08A@SOIC8 [(SA602A)]	IS24C08A@TSSOP8 [(SA026)]
IS24C128	IS24C128@SOIC8 [(SA602A)]
IS24C128@TSSOP14 [(SA026)]	IS24C16
IS24C16@MSOP8 [(SA666)]	IS24C16@SOIC8 [(SA602A)]
IS24C16@TSSOP8 [(SA026)]	IS24C16A
IS24C16A@MSOP8 [(SA666)]	IS24C16A@SOIC8 [(SA602A)]
IS24C16A@TSSOP8 [(SA026)]	IS24C256
IS24C256@SOIC8 [(SA602A)]	IS24C256@TSSOP14 [(SA026)]
IS24C256A	IS24C256A@SOIC8 [(SA602A)]
IS24C256A@TSSOP14 [(SA026)]	IS24C32
IS24C32@SOIC8 [(SA602A)]	IS24C32@TSSOP8 [(SA026)]
IS24C32A	IS24C32A@MSOP8 [(SA666)]
IS24C32A@SOIC8 [(SA602A)]	IS24C32A@TSSOP8 [(SA026)]
IS24C32B	IS24C32B@SOIC8 [(SA602A)]
IS24C32B@TSSOP8 [(SA026)]	IS24C64

IS24C64@SOIC8 [(SA602A)]      IS24C64@TSSOP8 [(SA026)]  
IS24C64A      IS24C64A@MSOP8 [(SA666)]  
IS24C64A@SOIC8 [(SA602A)]      IS24C64A@TSSOP8 [(SA026)]  
IS24C64B      IS24C64B@SOIC8 [(SA602A)]  
IS24C64B@TSSOP8 [(SA026)]      IS24L128  
IS24L128@SOIC8(150mil) [(SA602A)]  
IS24L128@SOIC8(200mil) [(SA605A)]  
IS24L256  
IS24L256@SOIC8(150mil) [(SA602A)]  
IS24L256@SOIC8(200mil) [(SA605A)]  
IS25C01      IS25C01@SOIC8 [(SA602A)]  
IS25C01@TSSOP8 [(SA026)]      IS25C02  
IS25C02@SOIC8 [(SA602A)]      IS25C02@TSSOP8 [(SA026)]  
IS25C04      IS25C04@SOIC8 [(SA602A)]  
IS25C04@TSSOP8 [(SA026)]      IS25C08  
IS25C08@SOIC8 [(SA602A)]      IS25C08@TSSOP8 [(SA026)]  
IS25C128@SOIC8 [(SA602A)]      IS25C128@TSSOP8 [(SA026)]  
IS25C16      IS25C16@SOIC8 [(SA602A)]  
IS25C16@TSSOP8 [(SA026)]      IS25C256@SOIC8 [(SA602A)]  
IS25C256@TSSOP8 [(SA026)]      IS25C32A  
IS25C32A@SOIC8 [(SA602A)]      IS25C32A@TSSOP8 [(SA026)]  
IS25C64A      IS25C64A@SOIC8 [(SA602A)]  
IS25C64A@TSSOP8 [(SA026)]      IS27C010  
IS27C010@PLCC32 [(SA015A1T)]      IS27C010@TSOP32 [(SA410T)]  
IS27C020      IS27C020@PLCC32 [(SA015A1T)]  
IS27C020@TSOP32 [(SA410T)]      IS27C256  
IS27C256@PLCC32 [(SA015A1T)]      IS27C512  
IS27C512@PLCC32 [(SA015A1T)]      IS27C512@TSOP28 [(SA430T)]  
IS27HC010      IS27HC010@PLCC32 [(SA015A1T)]  
IS27HC010@TSOP32 [(SA410T)]      IS27HC020  
IS27HC020@PLCC32 [(SA015A1T)]      IS27HC020@TSOP32 [(SA410T)]  
IS27HC256      IS27HC256@PLCC32 [(SA015A1T)]  
IS27HC512      IS27HC512@PLCC32 [(SA015A1T)]  
IS27HC512@TSOP28 [(SA430T)]      IS27LV010  
IS27LV010@PLCC32 [(SA015A1T)]      IS27LV010@TSOP32 [(SA410T)]  
IS27LV512      IS27LV512@PLCC32 [(SA015A1T)]  
IS27LV512@TSOP28 [(SA430T)]      IS28F010  
IS28F010@PLCC32 [(SA015A1T)]      IS28F010@TSOP32 [(SA410T)]  
IS28F010A      IS28F010A@PLCC32 [(SA015A1T)]  
IS28F010A@TSOP32 [(SA410T)]      IS28F020  
IS28F020@PLCC32 [(SA015A1T)]      IS28F020@TSOP32 [(SA410T)]  
IS29F010      IS29F010@PLCC32 [(SA015A1T)]  
IS29F010@TSOP32 [(SA410T)]      IS34C02

IS34C02@MSOP8 [(SA666)]            IS34C02@SOIC8 [(SA602A)]  
IS34C02@TSSOP8 [(SA026)]           IS34C02B@DFN8  
IS34C02B@TSSOP8 [(SA026)]  
IS71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]  
IS71V08F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32B04@FBGA56 [(SA642A-B032A-Y096F001)]  
IS71V16F32B04@FBGA59 [(SA642A-B032A-Y096F001)]  
IS71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32T04@FBGA56 [(SA642A-B032A-Y096F001)]  
IS71V16F32T04@FBGA59 [(SA642A-B032A-Y096F001)]  
IS71V16F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]  
IS71V16F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32AS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32BS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF64GS08@FBGA73 [(SA642C-B032A-Y056F001)]  
IS75V16F64GS16@FBGA65 [(SA642C-B032A-Y056F001)]  
IS75V16F64GS32@FBGA65 [(SA642C-B032A-Y056F001)]  
IS93C46                                IS93C46@SOIC8 [(SA602A)]  
IS93C46A(08bit)                        IS93C46A(08bit)@SOIC8 [(SA602A)]  
IS93C46A(08bit)@TSSOP8 [(SA026)]   IS93C46A(16bit)

IS93C46A(16bit)@SOIC8 [(SA602A)] IS93C46A(16bit)@TSSOP8 [(SA026)]  
 IS93C46B IS93C46B@SOIC8 [(SA602A)]  
 IS93C46B@TSSOP8 [(SA026)] IS93C46D(08bit)  
 IS93C46D(08bit)@SOIC8 [(SA602A)] IS93C46D(08bit)@TSSOP8 [(SA026)]  
 IS93C46D(16bit) IS93C46D(16bit)@SOIC8 [(SA602A)]  
 IS93C46D(16bit)@TSSOP8 [(SA026)] IS93C56  
 IS93C56@SOIC8 [(SA602A)] IS93C56A(08bit)  
 IS93C56A(08bit)@SOIC8 [(SA602A)] IS93C56A(08bit)@TSSOP8 [(SA026)]  
 IS93C56A(16bit) IS93C56A(16bit)@SOIC8 [(SA602A)]  
 IS93C56A(16bit)@TSSOP8 [(SA026)] IS93C66  
 IS93C66@SOIC8 [(SA602A)] IS93C66A(08bit)  
 IS93C66A(08bit)@SOIC8 [(SA602A)] IS93C66A(08bit)@TSSOP8 [(SA026)]  
 IS93C66A(16bit) IS93C66A(16bit)@SOIC8 [(SA602A)]  
 IS93C66A(16bit)@TSSOP8 [(SA026)] IS93C76A(08bit)  
 IS93C76A(08bit)@SOIC8 [(SA602A)] IS93C76A(08bit)@TSSOP8 [(SA026)]  
 IS93C76A(16bit) IS93C76A(16bit)@SOIC8 [(SA602A)]  
 IS93C76A(16bit)@TSSOP8 [(SA026)] IS93C86A(08bit)  
 IS93C86A(08bit)@SOIC8 [(SA602A)] IS93C86A(08bit)@TSSOP8 [(SA026)]  
 IS93C86A(16bit) IS93C86A(16bit)@SOIC8 [(SA602A)]  
 IS93C86A(16bit)@TSSOP8 [(SA026)]

## DRAM & SRAM

IS61C1024 IS61C1024(300m)@SOJ32 [(SA646)]  
 IS61C1024(400m)@SOJ32 [(SA661)] IS61C1024@TSOP32 [(SA410T)]  
 IS61C1024L IS61C1024L(300m)@SOJ32 [(SA646)]  
 IS61C1024L(400m)@SOJ32 [(SA661)] IS61C1024L@TSOP32 [(SA410T)]  
 IS61C256AH IS61C256AH@SOJ28 [(SA646)]  
 IS61C256AH@TSOP28 [(SA430T)] IS61C512  
 IS61C512(300m)@SOJ32 [(SA646)] IS61C512(400m)@SOJ32 [(SA661)]  
 IS61C512@TSOP32 [(SA410T)] IS61C64AH  
 IS61C64AH@SOJ28 [(SA646)] IS61C64AH@TSOP28 [(SA430T)]  
 IS61LV256 IS61LV256@SOJ28 [(SA646)]  
 IS61LV256@TSOP28 [(SA430T)] IS61M256  
 IS61M256@SOJ28 [(SA646)] IS61M256@TSOP28 [(SA430T)]  
 IS62C1024 IS62C1024(300m)@SOJ32 [(SA646)]  
 IS62C1024(400m)@SOJ32 [(SA661)] IS62C1024@TSOP32 [(SA410T)]  
 IS62C256 IS62C256@SOJ28 [(SA646)]  
 IS62C256@TSOP28 [(SA430T)] IS62C512  
 IS62C512(300m)@SOJ32 [(SA646)] IS62C512(400m)@SOJ32 [(SA661)]  
 IS62C512@TSOP32 [(SA410T)] IS62C64  
 IS62C64@SOJ28 [(SA646)] IS62C64@TSOP28 [(SA430T)]

IS62LV256                    IS62LV256@SOJ28 [(SA646)]  
IS62LV256@TSOP28 [(SA430T)]

## MICROCONTROLLER

IS89C51A                    IS89C51A@PLCC44 [(SA244)]  
IS89C51A@TQFP44 [(SA245A)]      IS89C52A  
IS89C52A@PLCC44 [(SA244)]      IS89C52A@TQFP44 [(SA245A)]

## ITHINKO

## MICROCONTROLLER

AX5012                    AX5012(5.0V)@SOP24 [(SA404)]  
AX5012(5.5V)@SOP24 [(SA404)]      AX5012(6.0V)@SOP24 [(SA404)]  
AX5012@SOP24 [(SA404)]      AX5012@SOP32

## LATTICE

## PLD

GAL16LV8                    GAL16LV8@PLCC20 [(SA001A)]  
GAL16LV8C                    GAL16LV8C@PLCC20 [(SA001A)]  
GAL16LV8D                    GAL16LV8D@PLCC20 [(SA001A)]  
GAL16LV8Z                    GAL16LV8Z@PLCC20 [(SA001A)]  
GAL16LV8ZD                    GAL16LV8ZD@PLCC20 [(SA001A)]  
GAL16V8                    GAL16V8@PLCC20 [(SA001A)]  
GAL16V8@SOIC20 [(SA404)]      GAL16V8A  
GAL16V8A@PLCC20 [(SA001A)]      GAL16V8A@SOIC20 [(SA404)]  
GAL16V8B                    GAL16V8B@PLCC20 [(SA001A)]  
GAL16V8B@SOIC20 [(SA404)]      GAL16V8C  
GAL16V8C@PLCC20 [(SA001A)]      GAL16V8C@SOIC20 [(SA404)]  
GAL16V8D                    GAL16V8D@PLCC20 [(SA001A)]  
GAL16V8D@SOIC20 [(SA404)]      GAL16V8Z  
GAL16V8Z@PLCC20 [(SA001A)]      GAL16V8Z@SOIC20 [(SA404)]  
GAL18V10                    GAL18V10@PLCC20 [(SA001A)]  
GAL18V10B                    GAL18V10B@PLCC20 [(SA001A)]  
GAL20LV8                    GAL20LV8@PLCC28 [(SA008A)]  
GAL20LV8Z                    GAL20LV8Z@PLCC28 [(SA008A)]

GAL20LV8ZD GAL20LV8ZD@PLCC28 [(SA008A)]  
GAL20RA10 GAL20RA10@PLCC28 [(SA008A)]  
GAL20RA10B GAL20RA10B@PLCC28 [(SA008A)]  
GAL20V8 GAL20V8@PLCC28 [(SA008A)]  
GAL20V8A GAL20V8A@PLCC28 [(SA008A)]  
GAL20V8B GAL20V8B@PLCC28 [(SA008A)]  
GAL20V8C GAL20V8C@PLCC28 [(SA008A)]  
GAL20V8Z GAL20V8Z@PLCC28 [(SA008A)]  
GAL20XV10 GAL20XV10@PLCC28 [(SA008A)]  
GAL20XV10B GAL20XV10B@PLCC28 [(SA008A)]  
GAL22LV10C GAL22LV10C@PLCC28 [(SA008A)]  
GAL22LV10C@SOIC24 [(SA404)] GAL22LV10C@TSOP24 [(SA643)]  
GAL22LV10D GAL22LV10D@PLCC28 [(SA008A)]  
GAL22LV10D@SOIC24 [(SA404)] GAL22LV10D@TSOP24 [(SA643)]  
GAL22LV10Z GAL22LV10Z@PLCC28 [(SA008A)]  
GAL22LV10Z@SOIC24 [(SA404)] GAL22LV10Z@TSOP24 [(SA643)]  
GAL22LV10ZD GAL22LV10ZD@PLCC28 [(SA008A)]  
GAL22LV10ZD@SOIC24 [(SA404)] GAL22LV10ZD@TSOP24 [(SA643)]  
GAL22V10 GAL22V10@PLCC28 [(SA008A)]  
GAL22V10@SOIC24 [(SA404)] GAL22V10A  
GAL22V10A@PLCC28 [(SA008A)] GAL22V10A@SOIC24 [(SA404)]  
GAL22V10B GAL22V10B@PLCC28 [(SA008A)]  
GAL22V10B@SOIC24 [(SA404)] GAL22V10BQ  
GAL22V10BQ@PLCC28 [(SA008A)] GAL22V10BQ@SOIC24 [(SA404)]  
GAL22V10C GAL22V10C@PLCC28 [(SA008A)]  
GAL22V10C@SOIC24 [(SA404)] GAL22V10D  
GAL22V10D@PLCC28 [(SA008A)] GAL22V10D@SOIC24 [(SA404)]  
GAL26CLV12 GAL26CLV12@PLCC28 [(SA008A)]  
GAL26CLV12@SOIC28 [(SA404)] GAL26CLV12@TSOP28 [(SA643)]  
GAL26CLV12B GAL26CLV12B@PLCC28 [(SA008A)]  
GAL26CLV12B@SOIC28 [(SA404)] GAL26CLV12B@TSOP28 [(SA643)]  
GAL26CLV12C GAL26CLV12C@PLCC28 [(SA008A)]  
GAL26CLV12C@SOIC28 [(SA404)] GAL26CLV12C@TSOP28 [(SA643)]  
GAL26CLV12D GAL26CLV12D@PLCC28 [(SA008A)]  
GAL26CLV12D@SOIC28 [(SA404)] GAL26CLV12D@TSOP28 [(SA643)]  
GAL26CLV12Z GAL26CLV12Z@PLCC28 [(SA008A)]  
GAL26CLV12Z@SOIC28 [(SA404)] GAL26CLV12Z@TSOP28 [(SA643)]  
GAL26CLV12ZD GAL26CLV12ZD@PLCC28 [(SA008A)]  
GAL26CLV12ZD@SOIC28 [(SA404)] GAL26CLV12ZD@TSOP28 [(SA643)]  
GAL26CV12 GAL26CV12@PLCC28 [(SA008A)]  
GAL26CV12B GAL26CV12B@PLCC28 [(SA008A)]  
GAL26CV12C GAL26CV12C@PLCC28 [(SA008A)]  
GAL26V12C GAL26V12C@PLCC28 [(SA008A)]

ispGAL22LV10            ispGAL22LV10(ISP) [ISP-HEADER01]  
ispGAL22LV10@PLCC28 [(SA008A)]  
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10@SSOP28 [(SA626A)]  
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10A  
ispGAL22LV10A(ISP) [ISP-HEADER01]  
ispGAL22LV10A@PLCC28 [(SA008A)]  
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10A@SSOP28 [(SA626A)]  
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10B  
ispGAL22LV10B(ISP) [ISP-HEADER01]  
ispGAL22LV10B@PLCC28 [(SA008A)]  
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10B@SSOP28 [(SA626A)]  
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10C  
ispGAL22LV10C(ISP) [ISP-HEADER01]  
ispGAL22LV10C@PLCC28 [(SA008A)]  
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10C@SSOP28 [(SA626A)]  
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10D  
ispGAL22LV10D(ISP) [ISP-HEADER01]  
ispGAL22LV10D@PLCC28 [(SA008A)]  
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10D@SSOP28 [(SA626A)]  
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22V10AB@PLCC28 [(SA008A)]    ispGAL22V10AB@QFN32 [(SA686)]  
ispGAL22V10AC@PLCC28 [(SA008A)]    ispGAL22V10AC@QFN32 [(SA686)]  
ispGAL22V10AV@PLCC28 [(SA008A)]    ispGAL22V10AV@QFN32 [(SA686)]  
ispGAL22V10C(UES)@PLCC28 [(SA008A)]  
ispGAL22V10C@PLCC28 [(SA008A)]    ispLSI1016@PLCC44 [(SA244)]  
ispLSI1016@TQFP44 [(SA245A)]    ispLSI1016E@PLCC44 [(SA244)]  
ispLSI1016E@TQFP44 [(SA245A)]    ispLSI1016EA@PLCC44 [(SA244)]  
ispLSI1016EA@TQFP44 [(SA245A)]    ispLSI2032@PLCC44 [(SA244)]  
ispLSI2032@TQFP44 [(SA245A)]    ispLSI2032A@PLCC44 [(SA244)]  
ispLSI2032A@TQFP44 [(SA245A)]    ispLSI2032A@TQFP48 [(SA248)]  
ispLSI2032E@PLCC44 [(SA244)]    ispLSI2032E@TQFP44 [(SA245A)]  
ispLSI2032E@TQFP48 [(SA248)]    ispLSI2032V@PLCC44 [(SA244)]  
ispLSI2032V@TQFP44 [(SA245A)]    ispLSI2032V@TQFP48 [(SA248)]  
ispLSI2032VE@PLCC44 [(SA244)]    ispLSI2032VE@TQFP44 [(SA245A)]



ispLSI2064A@PLCC44 [(SA244)]      ispLSI2064A@TQFP44 [(SA245A)]  
ispLSI2064V@PLCC44 [(SA244)]      ispLSI2064V@TQFP44 [(SA245A)]  
ispLSI2064VE@PLCC44 [(SA244)]    ispLSI2064VE@TQFP44 [(SA245A)]  
LC4032B@TQFP44 [(SA245A)]  
LC4032B@TQFP44(ISP) [ISP-HEADER01]  
LC4032B@TQFP48 [(SA248)]  
LC4032B@TQFP48(ISP) [ISP-HEADER01]  
LC4032C@TQFP44 [(SA245A)]  
LC4032C@TQFP44(ISP) [ISP-HEADER01]  
LC4032C@TQFP48 [(SA248)]  
LC4032C@TQFP48(ISP) [ISP-HEADER01]  
LC4032V@TQFP44 [(SA245A)]  
LC4032V@TQFP44(ISP) [ISP-HEADER01]  
LC4032V@TQFP48 [(SA248)]  
LC4032V@TQFP48(ISP) [ISP-HEADER01]  
LC4032ZC@csBGA56 [(SA699+B161)]  
LC4032ZC@csBGA56(ISP) [ISP-HEADER01]  
LC4032ZC@TQFP48 [(SA248)]  
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]  
LC4064B@TQFP44 [(SA245A)]  
LC4064B@TQFP44(ISP) [ISP-HEADER01]  
LC4064B@TQFP48 [(SA248)]  
LC4064B@TQFP48(ISP) [ISP-HEADER01]  
LC4064C@TQFP44 [(SA245A)]  
LC4064C@TQFP44(ISP) [ISP-HEADER01]  
LC4064C@TQFP48 [(SA248)]  
LC4064C@TQFP48(ISP) [ISP-HEADER01]  
LC4064V@TQFP44 [(SA245A)]  
LC4064V@TQFP44(ISP) [ISP-HEADER01]  
LC4064V@TQFP48 [(SA248)]  
LC4064V@TQFP48(ISP) [ISP-HEADER01]  
LC4064ZC@TQFP48 [(SA248)]  
LCMXO1200C-FT256(ISP) [ISP-HEADER01]  
LCMXO1200C-FT324(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200C-M100(ISP) [ISP-HEADER01]  
LCMXO1200C-M132(ISP) [ISP-HEADER01]  
LCMXO1200C-MN100(ISP) [ISP-HEADER01]  
LCMXO1200C-MN132(ISP) [ISP-HEADER01]  
LCMXO1200C-T100(ISP) [ISP-HEADER01]  
LCMXO1200C-T144(ISP) [ISP-HEADER01]  
LCMXO1200C-TN100(ISP) [ISP-HEADER01]

LCMXO1200C-TN144(ISP) [ISP-HEADER01]  
LCMXO1200E-FT256(ISP) [ISP-HEADER01]  
LCMXO1200E-FT324(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200E-M100(ISP) [ISP-HEADER01]  
LCMXO1200E-M132(ISP) [ISP-HEADER01]  
LCMXO1200E-MN100(ISP) [ISP-HEADER01]  
LCMXO1200E-MN132(ISP) [ISP-HEADER01]  
LCMXO1200E-T100(ISP) [ISP-HEADER01]  
LCMXO1200E-T144(ISP) [ISP-HEADER01]  
LCMXO1200E-TN100(ISP) [ISP-HEADER01]  
LCMXO1200E-TN144(ISP) [ISP-HEADER01]  
LCMXO2280C-FT256(ISP) [ISP-HEADER01]  
LCMXO2280C-FT324(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]  
LCMXO2280C-M100(ISP) [ISP-HEADER01]  
LCMXO2280C-M132(ISP) [ISP-HEADER01]  
LCMXO2280C-MN100(ISP) [ISP-HEADER01]  
LCMXO2280C-MN132(ISP) [ISP-HEADER01]  
LCMXO2280C-T100(ISP) [ISP-HEADER01]  
LCMXO2280C-T144(ISP) [ISP-HEADER01]  
LCMXO2280C-TN100(ISP) [ISP-HEADER01]  
LCMXO2280C-TN144(ISP) [ISP-HEADER01]  
LCMXO2280E-FT256(ISP) [ISP-HEADER01]  
LCMXO2280E-FT324(ISP) [ISP-HEADER01]  
LCMXO2280E-FTN256(ISP) [ISP-HEADER01]  
LCMXO2280E-FTN324(ISP) [ISP-HEADER01]  
LCMXO2280E-M100(ISP) [ISP-HEADER01]  
LCMXO2280E-M132(ISP) [ISP-HEADER01]  
LCMXO2280E-MN100(ISP) [ISP-HEADER01]  
LCMXO2280E-MN132(ISP) [ISP-HEADER01]  
LCMXO2280E-T100(ISP) [ISP-HEADER01]  
LCMXO2280E-T144(ISP) [ISP-HEADER01]  
LCMXO2280E-TN100(ISP) [ISP-HEADER01]  
LCMXO2280E-TN144(ISP) [ISP-HEADER01]  
LCMXO256C-FT256(ISP) [ISP-HEADER01]  
LCMXO256C-FT324(ISP) [ISP-HEADER01]  
LCMXO256C-FTN256(ISP) [ISP-HEADER01]  
LCMXO256C-FTN324(ISP) [ISP-HEADER01]  
LCMXO256C-M100(ISP) [ISP-HEADER01]  
LCMXO256C-M132(ISP) [ISP-HEADER01]

LCMXO256C-MN100(ISP) [ISP-HEADER01]  
LCMXO256C-MN132(ISP) [ISP-HEADER01]  
LCMXO256C-T100(ISP) [ISP-HEADER01]  
LCMXO256C-T144(ISP) [ISP-HEADER01]  
LCMXO256C-TN100(ISP) [ISP-HEADER01]  
LCMXO256C-TN144(ISP) [ISP-HEADER01]  
LCMXO256E-FT256(ISP) [ISP-HEADER01]  
LCMXO256E-FT324(ISP) [ISP-HEADER01]  
LCMXO256E-FTN256(ISP) [ISP-HEADER01]  
LCMXO256E-FTN324(ISP) [ISP-HEADER01]  
LCMXO256E-M100(ISP) [ISP-HEADER01]  
LCMXO256E-M132(ISP) [ISP-HEADER01]  
LCMXO256E-MN100(ISP) [ISP-HEADER01]  
LCMXO256E-MN132(ISP) [ISP-HEADER01]  
LCMXO256E-T100(ISP) [ISP-HEADER01]  
LCMXO256E-T144(ISP) [ISP-HEADER01]  
LCMXO256E-TN100(ISP) [ISP-HEADER01]  
LCMXO256E-TN144(ISP) [ISP-HEADER01]  
LCMXO640C-FT256(ISP) [ISP-HEADER01]  
LCMXO640C-FT324(ISP) [ISP-HEADER01]  
LCMXO640C-FTN256(ISP) [ISP-HEADER01]  
LCMXO640C-FTN324(ISP) [ISP-HEADER01]  
LCMXO640C-M100(ISP) [ISP-HEADER01]  
LCMXO640C-M132(ISP) [ISP-HEADER01]  
LCMXO640C-MN100(ISP) [ISP-HEADER01]  
LCMXO640C-MN132(ISP) [ISP-HEADER01]  
LCMXO640C-T100(ISP) [ISP-HEADER01]  
LCMXO640C-T144(ISP) [ISP-HEADER01]  
LCMXO640C-TN100(ISP) [ISP-HEADER01]  
LCMXO640C-TN144(ISP) [ISP-HEADER01]  
LCMXO640E-FT256(ISP) [ISP-HEADER01]  
LCMXO640E-FT324(ISP) [ISP-HEADER01]  
LCMXO640E-FTN256(ISP) [ISP-HEADER01]  
LCMXO640E-FTN324(ISP) [ISP-HEADER01]  
LCMXO640E-M100(ISP) [ISP-HEADER01]  
LCMXO640E-M132(ISP) [ISP-HEADER01]  
LCMXO640E-MN100(ISP) [ISP-HEADER01]  
LCMXO640E-MN132(ISP) [ISP-HEADER01]  
LCMXO640E-T100(ISP) [ISP-HEADER01]  
LCMXO640E-T144(ISP) [ISP-HEADER01]  
LCMXO640E-TN100(ISP) [ISP-HEADER01]  
LCMXO640E-TN144(ISP) [ISP-HEADER01]  
LFXP10C-3F256C(ISP) [ISP-HEADER01]

LFXP10C-3F256I(ISP) [ISP-HEADER01]  
LFXP10C-3F388C(ISP) [ISP-HEADER01]  
LFXP10C-3F388I(ISP) [ISP-HEADER01]  
LFXP10C-3FN256C(ISP) [ISP-HEADER01]  
LFXP10C-3FN256I(ISP) [ISP-HEADER01]  
LFXP10C-3FN388C(ISP) [ISP-HEADER01]  
LFXP10C-3FN388I(ISP) [ISP-HEADER01]  
LFXP10C-4F256C(ISP) [ISP-HEADER01]  
LFXP10C-4F256I(ISP) [ISP-HEADER01]  
LFXP10C-4F388C(ISP) [ISP-HEADER01]  
LFXP10C-4F388I(ISP) [ISP-HEADER01]  
LFXP10C-4FN256C(ISP) [ISP-HEADER01]  
LFXP10C-4FN256I(ISP) [ISP-HEADER01]  
LFXP10C-4FN388C(ISP) [ISP-HEADER01]  
LFXP10C-4FN388I(ISP) [ISP-HEADER01]  
LFXP10C-5F256C(ISP) [ISP-HEADER01]  
LFXP10C-5F256I(ISP) [ISP-HEADER01]  
LFXP10C-5F388C(ISP) [ISP-HEADER01]  
LFXP10C-5F388I(ISP) [ISP-HEADER01]  
LFXP10C-5FN256C(ISP) [ISP-HEADER01]  
LFXP10C-5FN256I(ISP) [ISP-HEADER01]  
LFXP10C-5FN388C(ISP) [ISP-HEADER01]  
LFXP10C-5FN388I(ISP) [ISP-HEADER01]  
LFXP10E-3F256C(ISP) [ISP-HEADER01]  
LFXP10E-3F256I(ISP) [ISP-HEADER01]  
LFXP10E-3F388C(ISP) [ISP-HEADER01]  
LFXP10E-3F388I(ISP) [ISP-HEADER01]  
LFXP10E-3FN256C(ISP) [ISP-HEADER01]  
LFXP10E-3FN256I(ISP) [ISP-HEADER01]  
LFXP10E-3FN388C(ISP) [ISP-HEADER01]  
LFXP10E-3FN388I(ISP) [ISP-HEADER01]  
LFXP10E-4F256C(ISP) [ISP-HEADER01]  
LFXP10E-4F256I(ISP) [ISP-HEADER01]  
LFXP10E-4F388C(ISP) [ISP-HEADER01]  
LFXP10E-4F388I(ISP) [ISP-HEADER01]  
LFXP10E-4FN256C(ISP) [ISP-HEADER01]  
LFXP10E-4FN256I(ISP) [ISP-HEADER01]  
LFXP10E-4FN388C(ISP) [ISP-HEADER01]  
LFXP10E-4FN388I(ISP) [ISP-HEADER01]  
LFXP10E-5F256C(ISP) [ISP-HEADER01]  
LFXP10E-5F256I(ISP) [ISP-HEADER01]  
LFXP10E-5F388C(ISP) [ISP-HEADER01]  
LFXP10E-5F388I(ISP) [ISP-HEADER01]

LFXP10E-5FN256C(ISP) [ISP-HEADER01]  
LFXP10E-5FN256I(ISP) [ISP-HEADER01]  
LFXP10E-5FN388C(ISP) [ISP-HEADER01]  
LFXP10E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3F256C(ISP) [ISP-HEADER01]  
LFXP15C-3F256I(ISP) [ISP-HEADER01]  
LFXP15C-3F388C(ISP) [ISP-HEADER01]  
LFXP15C-3F388I(ISP) [ISP-HEADER01]  
LFXP15C-3F484C(ISP) [ISP-HEADER01]  
LFXP15C-3F484I(ISP) [ISP-HEADER01]  
LFXP15C-3FN256C(ISP) [ISP-HEADER01]  
LFXP15C-3FN256I(ISP) [ISP-HEADER01]  
LFXP15C-3FN388C(ISP) [ISP-HEADER01]  
LFXP15C-3FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3FN484C(ISP) [ISP-HEADER01]  
LFXP15C-3FN484I(ISP) [ISP-HEADER01]  
LFXP15C-4F256C(ISP) [ISP-HEADER01]  
LFXP15C-4F256I(ISP) [ISP-HEADER01]  
LFXP15C-4F388C(ISP) [ISP-HEADER01]  
LFXP15C-4F388I(ISP) [ISP-HEADER01]  
LFXP15C-4F484C(ISP) [ISP-HEADER01]  
LFXP15C-4F484I(ISP) [ISP-HEADER01]  
LFXP15C-4FN256C(ISP) [ISP-HEADER01]  
LFXP15C-4FN256I(ISP) [ISP-HEADER01]  
LFXP15C-4FN388C(ISP) [ISP-HEADER01]  
LFXP15C-4FN388I(ISP) [ISP-HEADER01]  
LFXP15C-4FN484C(ISP) [ISP-HEADER01]  
LFXP15C-4FN484I(ISP) [ISP-HEADER01]  
LFXP15C-5F256C(ISP) [ISP-HEADER01]  
LFXP15C-5F256I(ISP) [ISP-HEADER01]  
LFXP15C-5F388C(ISP) [ISP-HEADER01]  
LFXP15C-5F388I(ISP) [ISP-HEADER01]  
LFXP15C-5F484C(ISP) [ISP-HEADER01]  
LFXP15C-5F484I(ISP) [ISP-HEADER01]  
LFXP15C-5FN256C(ISP) [ISP-HEADER01]  
LFXP15C-5FN256I(ISP) [ISP-HEADER01]  
LFXP15C-5FN388C(ISP) [ISP-HEADER01]  
LFXP15C-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-5FN484C(ISP) [ISP-HEADER01]  
LFXP15C-5FN484I(ISP) [ISP-HEADER01]  
LFXP15E-3F256C(ISP) [ISP-HEADER01]  
LFXP15E-3F256I(ISP) [ISP-HEADER01]  
LFXP15E-3F388C(ISP) [ISP-HEADER01]

LFXP15E-3F388I(ISP) [ISP-HEADER01]  
LFXP15E-3F484C(ISP) [ISP-HEADER01]  
LFXP15E-3F484I(ISP) [ISP-HEADER01]  
LFXP15E-3FN256C(ISP) [ISP-HEADER01]  
LFXP15E-3FN256I(ISP) [ISP-HEADER01]  
LFXP15E-3FN388C(ISP) [ISP-HEADER01]  
LFXP15E-3FN388I(ISP) [ISP-HEADER01]  
LFXP15E-3FN484C(ISP) [ISP-HEADER01]  
LFXP15E-3FN484I(ISP) [ISP-HEADER01]  
LFXP15E-4F256C(ISP) [ISP-HEADER01]  
LFXP15E-4F256I(ISP) [ISP-HEADER01]  
LFXP15E-4F388C(ISP) [ISP-HEADER01]  
LFXP15E-4F388I(ISP) [ISP-HEADER01]  
LFXP15E-4F484C(ISP) [ISP-HEADER01]  
LFXP15E-4F484I(ISP) [ISP-HEADER01]  
LFXP15E-4FN256C(ISP) [ISP-HEADER01]  
LFXP15E-4FN256I(ISP) [ISP-HEADER01]  
LFXP15E-4FN388C(ISP) [ISP-HEADER01]  
LFXP15E-4FN388I(ISP) [ISP-HEADER01]  
LFXP15E-4FN484C(ISP) [ISP-HEADER01]  
LFXP15E-4FN484I(ISP) [ISP-HEADER01]  
LFXP15E-5F256C(ISP) [ISP-HEADER01]  
LFXP15E-5F256I(ISP) [ISP-HEADER01]  
LFXP15E-5F388C(ISP) [ISP-HEADER01]  
LFXP15E-5F388I(ISP) [ISP-HEADER01]  
LFXP15E-5F484C(ISP) [ISP-HEADER01]  
LFXP15E-5F484I(ISP) [ISP-HEADER01]  
LFXP15E-5FN256C(ISP) [ISP-HEADER01]  
LFXP15E-5FN256I(ISP) [ISP-HEADER01]  
LFXP15E-5FN388C(ISP) [ISP-HEADER01]  
LFXP15E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15E-5FN484C(ISP) [ISP-HEADER01]  
LFXP15E-5FN484I(ISP) [ISP-HEADER01]  
LFXP20C-3F256C(ISP) [ISP-HEADER01]  
LFXP20C-3F256I(ISP) [ISP-HEADER01]  
LFXP20C-3F388C(ISP) [ISP-HEADER01]  
LFXP20C-3F388I(ISP) [ISP-HEADER01]  
LFXP20C-3F484C(ISP) [ISP-HEADER01]  
LFXP20C-3F484I(ISP) [ISP-HEADER01]  
LFXP20C-3FN256C(ISP) [ISP-HEADER01]  
LFXP20C-3FN256I(ISP) [ISP-HEADER01]  
LFXP20C-3FN388C(ISP) [ISP-HEADER01]  
LFXP20C-3FN388I(ISP) [ISP-HEADER01]

LFXP20C-3FN484C(ISP) [ISP-HEADER01]  
LFXP20C-3FN484I(ISP) [ISP-HEADER01]  
LFXP20C-4F256C(ISP) [ISP-HEADER01]  
LFXP20C-4F256I(ISP) [ISP-HEADER01]  
LFXP20C-4F388C(ISP) [ISP-HEADER01]  
LFXP20C-4F388I(ISP) [ISP-HEADER01]  
LFXP20C-4F484C(ISP) [ISP-HEADER01]  
LFXP20C-4F484I(ISP) [ISP-HEADER01]  
LFXP20C-4FN256C(ISP) [ISP-HEADER01]  
LFXP20C-4FN256I(ISP) [ISP-HEADER01]  
LFXP20C-4FN388C(ISP) [ISP-HEADER01]  
LFXP20C-4FN388I(ISP) [ISP-HEADER01]  
LFXP20C-4FN484C(ISP) [ISP-HEADER01]  
LFXP20C-4FN484I(ISP) [ISP-HEADER01]  
LFXP20C-5F256C(ISP) [ISP-HEADER01]  
LFXP20C-5F256I(ISP) [ISP-HEADER01]  
LFXP20C-5F388C(ISP) [ISP-HEADER01]  
LFXP20C-5F388I(ISP) [ISP-HEADER01]  
LFXP20C-5F484C(ISP) [ISP-HEADER01]  
LFXP20C-5F484I(ISP) [ISP-HEADER01]  
LFXP20C-5FN256C(ISP) [ISP-HEADER01]  
LFXP20C-5FN256I(ISP) [ISP-HEADER01]  
LFXP20C-5FN388C(ISP) [ISP-HEADER01]  
LFXP20C-5FN388I(ISP) [ISP-HEADER01]  
LFXP20C-5FN484C(ISP) [ISP-HEADER01]  
LFXP20C-5FN484I(ISP) [ISP-HEADER01]  
LFXP20E-3F256C(ISP) [ISP-HEADER01]  
LFXP20E-3F256I(ISP) [ISP-HEADER01]  
LFXP20E-3F388C(ISP) [ISP-HEADER01]  
LFXP20E-3F388I(ISP) [ISP-HEADER01]  
LFXP20E-3F484C(ISP) [ISP-HEADER01]  
LFXP20E-3F484I(ISP) [ISP-HEADER01]  
LFXP20E-3FN256C(ISP) [ISP-HEADER01]  
LFXP20E-3FN256I(ISP) [ISP-HEADER01]  
LFXP20E-3FN388C(ISP) [ISP-HEADER01]  
LFXP20E-3FN388I(ISP) [ISP-HEADER01]  
LFXP20E-3FN484C(ISP) [ISP-HEADER01]  
LFXP20E-3FN484I(ISP) [ISP-HEADER01]  
LFXP20E-4F256C(ISP) [ISP-HEADER01]  
LFXP20E-4F256I(ISP) [ISP-HEADER01]  
LFXP20E-4F388C(ISP) [ISP-HEADER01]  
LFXP20E-4F388I(ISP) [ISP-HEADER01]  
LFXP20E-4F484C(ISP) [ISP-HEADER01]

LFXP20E-4F484I(ISP) [ISP-HEADER01]  
LFXP20E-4FN256C(ISP) [ISP-HEADER01]  
LFXP20E-4FN256I(ISP) [ISP-HEADER01]  
LFXP20E-4FN388C(ISP) [ISP-HEADER01]  
LFXP20E-4FN388I(ISP) [ISP-HEADER01]  
LFXP20E-4FN484C(ISP) [ISP-HEADER01]  
LFXP20E-4FN484I(ISP) [ISP-HEADER01]  
LFXP20E-5F256C(ISP) [ISP-HEADER01]  
LFXP20E-5F256I(ISP) [ISP-HEADER01]  
LFXP20E-5F388C(ISP) [ISP-HEADER01]  
LFXP20E-5F388I(ISP) [ISP-HEADER01]  
LFXP20E-5F484C(ISP) [ISP-HEADER01]  
LFXP20E-5F484I(ISP) [ISP-HEADER01]  
LFXP20E-5FN256C(ISP) [ISP-HEADER01]  
LFXP20E-5FN256I(ISP) [ISP-HEADER01]  
LFXP20E-5FN388C(ISP) [ISP-HEADER01]  
LFXP20E-5FN388I(ISP) [ISP-HEADER01]  
LFXP20E-5FN484C(ISP) [ISP-HEADER01]  
LFXP20E-5FN484I(ISP) [ISP-HEADER01]  
LFXP3C-3Q208C(ISP) [ISP-HEADER01]  
LFXP3C-3Q208I(ISP) [ISP-HEADER01]  
LFXP3C-3QN208C(ISP) [ISP-HEADER01]  
LFXP3C-3QN208I(ISP) [ISP-HEADER01]  
LFXP3C-3T100C(ISP) [ISP-HEADER01]  
LFXP3C-3T100I(ISP) [ISP-HEADER01]  
LFXP3C-3T144C(ISP) [ISP-HEADER01]  
LFXP3C-3T144I(ISP) [ISP-HEADER01]  
LFXP3C-3TN100C(ISP) [ISP-HEADER01]  
LFXP3C-3TN100I(ISP) [ISP-HEADER01]  
LFXP3C-3TN144C(ISP) [ISP-HEADER01]  
LFXP3C-3TN144I(ISP) [ISP-HEADER01]  
LFXP3C-4Q208C(ISP) [ISP-HEADER01]  
LFXP3C-4Q208I(ISP) [ISP-HEADER01]  
LFXP3C-4QN208C(ISP) [ISP-HEADER01]  
LFXP3C-4QN208I(ISP) [ISP-HEADER01]  
LFXP3C-4T100C(ISP) [ISP-HEADER01]  
LFXP3C-4T100I(ISP) [ISP-HEADER01]  
LFXP3C-4T144C(ISP) [ISP-HEADER01]  
LFXP3C-4T144I(ISP) [ISP-HEADER01]  
LFXP3C-4TN100C(ISP) [ISP-HEADER01]  
LFXP3C-4TN100I(ISP) [ISP-HEADER01]  
LFXP3C-4TN144C(ISP) [ISP-HEADER01]  
LFXP3C-4TN144I(ISP) [ISP-HEADER01]



LFXP3C-5Q208C(ISP) [ISP-HEADER01]  
LFXP3C-5Q208I(ISP) [ISP-HEADER01]  
LFXP3C-5QN208C(ISP) [ISP-HEADER01]  
LFXP3C-5QN208I(ISP) [ISP-HEADER01]  
LFXP3C-5T100C(ISP) [ISP-HEADER01]  
LFXP3C-5T100I(ISP) [ISP-HEADER01]  
LFXP3C-5T144C(ISP) [ISP-HEADER01]  
LFXP3C-5T144I(ISP) [ISP-HEADER01]  
LFXP3C-5TN100C(ISP) [ISP-HEADER01]  
LFXP3C-5TN100I(ISP) [ISP-HEADER01]  
LFXP3C-5TN144C(ISP) [ISP-HEADER01]  
LFXP3C-5TN144I(ISP) [ISP-HEADER01]  
LFXP3E-3Q208C(ISP) [ISP-HEADER01]  
LFXP3E-3Q208I(ISP) [ISP-HEADER01]  
LFXP3E-3QN208C(ISP) [ISP-HEADER01]  
LFXP3E-3QN208I(ISP) [ISP-HEADER01]  
LFXP3E-3T100C(ISP) [ISP-HEADER01]  
LFXP3E-3T100I(ISP) [ISP-HEADER01]  
LFXP3E-3T144C(ISP) [ISP-HEADER01]  
LFXP3E-3T144I(ISP) [ISP-HEADER01]  
LFXP3E-3TN100C(ISP) [ISP-HEADER01]  
LFXP3E-3TN100I(ISP) [ISP-HEADER01]  
LFXP3E-3TN144C(ISP) [ISP-HEADER01]  
LFXP3E-3TN144I(ISP) [ISP-HEADER01]  
LFXP3E-4Q208C(ISP) [ISP-HEADER01]  
LFXP3E-4Q208I(ISP) [ISP-HEADER01]  
LFXP3E-4QN208C(ISP) [ISP-HEADER01]  
LFXP3E-4QN208I(ISP) [ISP-HEADER01]  
LFXP3E-4T100C(ISP) [ISP-HEADER01]  
LFXP3E-4T100I(ISP) [ISP-HEADER01]  
LFXP3E-4T144C(ISP) [ISP-HEADER01]  
LFXP3E-4T144I(ISP) [ISP-HEADER01]  
LFXP3E-4TN100C(ISP) [ISP-HEADER01]  
LFXP3E-4TN100I(ISP) [ISP-HEADER01]  
LFXP3E-4TN144C(ISP) [ISP-HEADER01]  
LFXP3E-4TN144I(ISP) [ISP-HEADER01]  
LFXP3E-5Q208C(ISP) [ISP-HEADER01]  
LFXP3E-5Q208I(ISP) [ISP-HEADER01]  
LFXP3E-5QN208C(ISP) [ISP-HEADER01]  
LFXP3E-5QN208I(ISP) [ISP-HEADER01]  
LFXP3E-5T100C(ISP) [ISP-HEADER01]  
LFXP3E-5T100I(ISP) [ISP-HEADER01]  
LFXP3E-5T144C(ISP) [ISP-HEADER01]

LFXP3E-5T144I(ISP) [ISP-HEADER01]  
LFXP3E-5TN100C(ISP) [ISP-HEADER01]  
LFXP3E-5TN100I(ISP) [ISP-HEADER01]  
LFXP3E-5TN144C(ISP) [ISP-HEADER01]  
LFXP3E-5TN144I(ISP) [ISP-HEADER01]  
LFXP6C-3F256C(ISP) [ISP-HEADER01]  
LFXP6C-3F256I(ISP) [ISP-HEADER01]  
LFXP6C-3FN256C(ISP) [ISP-HEADER01]  
LFXP6C-3FN256I(ISP) [ISP-HEADER01]  
LFXP6C-3Q208C(ISP) [ISP-HEADER01]  
LFXP6C-3Q208I(ISP) [ISP-HEADER01]  
LFXP6C-3QN208C(ISP) [ISP-HEADER01]  
LFXP6C-3QN208I(ISP) [ISP-HEADER01]  
LFXP6C-3T144C(ISP) [ISP-HEADER01]  
LFXP6C-3T144I(ISP) [ISP-HEADER01]  
LFXP6C-3TN144C(ISP) [ISP-HEADER01]  
LFXP6C-3TN144I(ISP) [ISP-HEADER01]  
LFXP6C-4F256C(ISP) [ISP-HEADER01]  
LFXP6C-4F256I(ISP) [ISP-HEADER01]  
LFXP6C-4FN256C(ISP) [ISP-HEADER01]  
LFXP6C-4FN256I(ISP) [ISP-HEADER01]  
LFXP6C-4Q208C(ISP) [ISP-HEADER01]  
LFXP6C-4Q208I(ISP) [ISP-HEADER01]  
LFXP6C-4QN208C(ISP) [ISP-HEADER01]  
LFXP6C-4QN208I(ISP) [ISP-HEADER01]  
LFXP6C-4T144C(ISP) [ISP-HEADER01]  
LFXP6C-4T144I(ISP) [ISP-HEADER01]  
LFXP6C-4TN144C(ISP) [ISP-HEADER01]  
LFXP6C-4TN144I(ISP) [ISP-HEADER01]  
LFXP6C-5F256C(ISP) [ISP-HEADER01]  
LFXP6C-5F256I(ISP) [ISP-HEADER01]  
LFXP6C-5FN256C(ISP) [ISP-HEADER01]  
LFXP6C-5FN256I(ISP) [ISP-HEADER01]  
LFXP6C-5Q208C(ISP) [ISP-HEADER01]  
LFXP6C-5Q208I(ISP) [ISP-HEADER01]  
LFXP6C-5QN208C(ISP) [ISP-HEADER01]  
LFXP6C-5QN208I(ISP) [ISP-HEADER01]  
LFXP6C-5T144C(ISP) [ISP-HEADER01]  
LFXP6C-5T144I(ISP) [ISP-HEADER01]  
LFXP6C-5TN144C(ISP) [ISP-HEADER01]  
LFXP6C-5TN144I(ISP) [ISP-HEADER01]  
LFXP6E-3F256C(ISP) [ISP-HEADER01]  
LFXP6E-3F256I(ISP) [ISP-HEADER01]

LFXP6E-3FN256C(ISP) [ISP-HEADER01]  
LFXP6E-3FN256I(ISP) [ISP-HEADER01]  
LFXP6E-3Q208C(ISP) [ISP-HEADER01]  
LFXP6E-3Q208I(ISP) [ISP-HEADER01]  
LFXP6E-3QN208C(ISP) [ISP-HEADER01]  
LFXP6E-3QN208I(ISP) [ISP-HEADER01]  
LFXP6E-3T144C(ISP) [ISP-HEADER01]  
LFXP6E-3T144I(ISP) [ISP-HEADER01]  
LFXP6E-3TN144C(ISP) [ISP-HEADER01]  
LFXP6E-3TN144I(ISP) [ISP-HEADER01]  
LFXP6E-4F256C(ISP) [ISP-HEADER01]  
LFXP6E-4F256I(ISP) [ISP-HEADER01]  
LFXP6E-4FN256C(ISP) [ISP-HEADER01]  
LFXP6E-4FN256I(ISP) [ISP-HEADER01]  
LFXP6E-4Q208C(ISP) [ISP-HEADER01]  
LFXP6E-4Q208I(ISP) [ISP-HEADER01]  
LFXP6E-4QN208C(ISP) [ISP-HEADER01]  
LFXP6E-4QN208I(ISP) [ISP-HEADER01]  
LFXP6E-4T144C(ISP) [ISP-HEADER01]  
LFXP6E-4T144I(ISP) [ISP-HEADER01]  
LFXP6E-4TN144C(ISP) [ISP-HEADER01]  
LFXP6E-4TN144I(ISP) [ISP-HEADER01]  
LFXP6E-5F256C(ISP) [ISP-HEADER01]  
LFXP6E-5F256I(ISP) [ISP-HEADER01]  
LFXP6E-5FN256C(ISP) [ISP-HEADER01]  
LFXP6E-5FN256I(ISP) [ISP-HEADER01]  
LFXP6E-5Q208C(ISP) [ISP-HEADER01]  
LFXP6E-5Q208I(ISP) [ISP-HEADER01]  
LFXP6E-5QN208C(ISP) [ISP-HEADER01]  
LFXP6E-5QN208I(ISP) [ISP-HEADER01]  
LFXP6E-5T144C(ISP) [ISP-HEADER01]  
LFXP6E-5T144I(ISP) [ISP-HEADER01]  
LFXP6E-5TN144C(ISP) [ISP-HEADER01]  
LFXP6E-5TN144I(ISP) [ISP-HEADER01]  
M4A3-32/32@PLCC44 [(SA244)]      M4A3-32/32@TQFP44 [(SA245A)]  
M4A3-32/32@TQFP48 [(SA248)]      M4A3-64/32@PLCC44 [(SA244)]  
M4A3-64/32@TQFP44 [(SA245A)]      M4A3-64/32@TQFP48 [(SA248)]  
M4A5-32/32@PLCC44 [(SA244)]      M4A5-32/32@TQFP44 [(SA245A)]  
M4A5-32/32@TQFP48 [(SA248)]      M4A5-64/32@PLCC44 [(SA244)]  
M4A5-64/32@TQFP44 [(SA245A)]      M4A5-64/32@TQFP48 [(SA248)]  
MACH110@PLCC44 [(SA244)]      PALCE20RA10  
PALCE20RA10@PLCC28 [(SA008A)]      PALCE20RA10@SOIC24 [(SA404)]  
PALCE20RA10H      PALCE20RA10H@PLCC28 [(SA008A)]

PALCE20RA10H@SOIC24 [(SA404)] PALCE20RA10Q  
 PALCE20RA10Q@PLCC28 [(SA008A)] PALCE20RA10Q@SOIC24 [(SA404)]  
 PALCE22V10H PALCE22V10H@PLCC28 [(SA008A)]  
 PALCE22V10H@SOIC24 [(SA404)] PALCE22V10Q  
 PALCE22V10Q@PLCC28 [(SA008A)] PALCE22V10Q@SOIC24 [(SA404)]  
 PALCE22V10Z PALCE22V10Z@PLCC28 [(SA008A)]  
 PALCE22V10Z@SOIC24 [(SA404)]

LG Semicon

## DRAM & SRAM

GM76C256CL GM76C256CL@SSOP28 [(SA430T)]  
 GM76C256CL@TSOP28 [(SA630)] GM76C256CLL  
 GM76C256CLL@SSOP28 [(SA430T)] GM76C256CLL@TSOP28 [(SA630)]  
 GM76C8128CL GM76C8128CL@SSOP32 [(SA438T)]  
 GM76C8128CL@TSOP32 [(SA410T)] GM76C8128CL@VSOP32 [(SA620)]  
 GM76C8128CLL GM76C8128CLL@SSOP32 [(SA438T)]  
 GM76C8128CLL@TSOP32 [(SA410T)] GM76C8128CLL@VSOP32 [(SA620)]  
 GM76C88AL GM76C88AL@SSOP28 [(SA430T)]  
 GM76C88AL@TSOP28 [(SA643)] GM76U256CL  
 GM76U256CL@SSOP28 [(SA430T)] GM76U256CL@TSOP28 [(SA643)]  
 GM76U256CLL GM76U256CLL@SSOP28 [(SA430T)]  
 GM76U256CLL@TSOP28 [(SA643)] GM76U8128CL  
 GM76U8128CL@SSOP32 [(SA438T)] GM76U8128CL@TSOP32 [(SA410T)]  
 GM76U8128CL@VSOP32 [(SA620)] GM76U8128CLL  
 GM76U8128CLL@SSOP32 [(SA438T)] GM76U8128CLL@TSOP32 [(SA410T)]  
 GM76U8128CLL@VSOP32 [(SA620)] GM76U8128DL  
 GM76U8128DL@SSOP32 [(SA438T)] GM76U8128DL@TSOP32 [(SA410T)]  
 GM76U8128DL@VSOP32 [(SA620)] GM76U8128DLL  
 GM76U8128DLL@SSOP32 [(SA438T)] GM76U8128DLL@TSOP32 [(SA410T)]  
 GM76U8128DLL@VSOP32 [(SA620)] GM76U8512L  
 GM76U8512L@SSOP32 [(SA438T)] GM76U8512L@TSOP32 [(SA410T)]  
 GM76U8512L@VSOP32 [(SA620)] GM76U8512LL  
 GM76U8512LL@SSOP32 [(SA438T)] GM76U8512LL@TSOP32 [(SA410T)]  
 GM76U8512LL@VSOP32 [(SA620)] GM76V256CL  
 GM76V256CL@SSOP28 [(SA430T)] GM76V256CL@TSOP28 [(SA630)]  
 GM76V256CLL GM76V256CLL@SSOP28 [(SA430T)]  
 GM76V256CLL@TSOP28 [(SA630)] GM76V8128CL  
 GM76V8128CL@SSOP32 [(SA438T)] GM76V8128CL@TSOP32 [(SA410T)]  
 GM76V8128CL@VSOP32 [(SA620)] GM76V8128CLL  
 GM76V8128CLL@SSOP32 [(SA438T)] GM76V8128CLL@TSOP32 [(SA410T)]

GM76V8128CLL@VSOP32 [(SA620)]	GM76V8128DL
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32 [(SA410T)]
GM76V8128DL@VSOP32 [(SA620)]	GM76V8128DLL
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32 [(SA410T)]
GM76V8128DLL@VSOP32 [(SA620)]	GM76V8512L
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32 [(SA410T)]
GM76V8512L@VSOP32 [(SA620)]	GM76V8512LL
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32 [(SA410T)]
GM76V8512LL@VSOP32 [(SA620)]	GM77C8128A
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32 [(SA410T)]
GM77C8128A@VSOP32 [(SA620)]	

## MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20 [(SA404)]
GMS97C2051	GMS97C2051@SOIC20 [(SA404)]
GMS97C51	GMS97C51@PLCC44 [(SA244)]
GMS97C51@TQFP44 [(SA245A)]	GMS97C52
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44 [(SA245A)]
GMS97C54	GMS97C54@PLCC44 [(SA244)]
GMS97C54@TQFP44 [(SA245A)]	GMS97C56
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44 [(SA245A)]
GMS97C58	GMS97C58@PLCC44 [(SA244)]
GMS97C58@TQFP44 [(SA245A)]	GMS97L1051
GMS97L1051@SOIC20 [(SA404)]	GMS97L2051
GMS97L2051@SOIC20 [(SA404)]	GMS97L51
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44 [(SA245A)]
GMS97L52	GMS97L52@PLCC44 [(SA244)]
GMS97L52@TQFP44 [(SA245A)]	GMS97L54
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44 [(SA245A)]
GMS97L56	GMS97L56@PLCC44 [(SA244)]
GMS97L56@TQFP44 [(SA245A)]	GMS97L58
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44 [(SA245A)]
GMS99C52	GMS99C52@PLCC44 [(SA244)]
GMS99C52@TQFP44 [(SA245A)]	GMS99C58
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44 [(SA245A)]

## LINKSMART

## E(E)PROM/FRAM/NVRAM

L24C02 L24C02@SSOP8 [(SA602A)]  
L24C02@TSOP8 [(SA026)] L24C04  
L24C04@SSOP8 [(SA602A)] L24C04@TSOP8 [(SA026)]  
L29004C L29004C@PLCC32 [(SA015A1T)]  
L29004C@TSOP32 [(SA620)] L29S160F@TSOP48 [(SA247-B005)]  
L29S160F-B@TSOP48 [(SA247-B005)] L29S400F@PSOP44 [(SA638)]  
L29S400F@TSOP48 [(SA247-B005)] L29S400F-B@PSOP44 [(SA638)]  
L29S400F-B@TSOP48 [(SA247-B005)] L29S800F@TSOP48 [(SA247-B005)]  
L29S800F-B@TSOP48 [(SA247-B005)] L29W800E@TSOP48 [(SA247-B005)]  
L29W800E-B@TSOP48 [(SA247-B005)] LST28001  
LST28001@PLCC32 [(SA015A1T)] LST28001@TSOP32 [(SA620)]  
LST28002 LST28002@PLCC32 [(SA015A1T)]  
LST28002@TSOP32 [(SA620)] LST28004  
LST28004@PLCC32 [(SA015A1T)] LST28004@TSOP32 [(SA620)]

## MACRONIX

### E(E)PROM/FRAM/NVRAM

KH25L1005 KH25L1005(ISP) [ISP-HEADER01]  
KH25L1005@SON8 [(SA683)]  
KH25L1005@SON8(ISP) [ISP-HEADER01]  
KH25L1005@SOP8 [(SA602A)]  
KH25L1005@SOP8(ISP) [ISP-HEADER01]  
KH25L1005A KH25L1005A@SON8 [(SA683)]  
KH25L1005A@SOP8 [(SA602A)]  
KH25L12805D@SON8(Fast Mode) [(SA684)]  
KH25L12805D@SOP16(Fast Mode) [(SA404)]  
KH25L12805N@SOP16 [(SA404)]  
KH25L12805N@SOP16(Fast Mode) [(SA404)]  
KH25L1602@SOP28 [(SA630)] KH25L1605@SON8 [(SA684)]  
KH25L1605@SON8(Fast Mode) [(SA684)]  
KH25L1605@SOP16 [(SA404)]  
KH25L1605@SOP16(Fast Mode) [(SA404)]  
KH25L1605A@SON8 [(SA684)]  
KH25L1605A@SON8(Fast Mode) [(SA684)]  
KH25L1605A@SOP16 [(SA404)]  
KH25L1605A@SOP16(Fast Mode) [(SA404)]  
KH25L1605A@SOP8 [(SA023A)]  
KH25L1605A@SOP8(Fast Mode) [(SA023A)]  
KH25L1605D@SON8 [(SA684)]  
KH25L1605D@SON8(Fast Mode) [(SA683)]

KH25L1605D@SOP16 [(SA404)]  
KH25L1605D@SOP16(Fast Mode) [(SA404)]  
KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8 [(SA605B)]  
KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8 [(SA683)]  
KH25L2005 KH25L2005(ISP) [ISP-HEADER01]  
KH25L2005@SON8 [(SA683)]  
KH25L2005@SON8(ISP) [ISP-HEADER01]  
KH25L2005@SOP8 [(SA602A)]  
KH25L2005@SOP8(ISP) [ISP-HEADER01]  
KH25L2025 KH25L2025@SON8 [(SA683)]  
KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32 [(SA438T)]  
KH25L3205@SOP16 [(SA404)]  
KH25L3205@SOP16(Fast Mode) [(SA404)]  
KH25L3205@SOP8 [(SA023A)]  
KH25L3205@SOP8(Fast Mode) [(SA023A)]  
KH25L3205A@SON8 [(SA684)]  
KH25L3205A@SON8(Fast Mode) [(SA684)]  
KH25L3205A@SOP16 [(SA404)]  
KH25L3205A@SOP16(Fast Mode) [(SA404)]  
KH25L3205A@SOP8 [(SA023A)]  
KH25L3205A@SOP8(Fast Mode) [(SA023A)]  
KH25L3205D@SON8(Fast Mode) [(SA683)]  
KH25L3205D@SOP16 [(SA404)]  
KH25L3205D@SOP16(Fast Mode) [(SA404)]  
KH25L3205D@SOP8 [(SA023A)]  
KH25L3205D@SOP8(Fast Mode) [(SA605B)]  
KH25L3236DM2I@SOP8 [(SA605B)] KH25L3236DMI@SOP16 [(SA404)]  
KH25L3236DZNI@WSON8 [(SA683)] KH25L4005  
KH25L4005(150mil)@SOP8 [(SA602A)]  
KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005(209mil)@SOP8 [(SA023A)]  
KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005(ISP) [ISP-HEADER01] KH25L4005@SON8 [(SA683)]  
KH25L4005@SON8(ISP) [ISP-HEADER01]  
KH25L4005A  
KH25L4005A(150mil)@SOP8 [(SA602A)]  
KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005A(209mil)@SOP8 [(SA023A)]  
KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005A(ISP) [ISP-HEADER01] KH25L4005A@SON8 [(SA683)]  
KH25L4005A@SON8(ISP) [ISP-HEADER01]

KH25L4025A  
KH25L4025A(150mil)@SOP8 [(SA602A)]  
KH25L4025A(209mil)@SOP8 [(SA023A)]  
KH25L4025A@SON8 [(SA683)]      KH25L512@SON8 [(SA683)]  
KH25L512@SOP8 [(SA602A)]      KH25L512A  
KH25L512A@SON8 [(SA683)]      KH25L512A@SOP8 [(SA602A)]  
KH25L6402@SOP32 [(SA438T)]      KH25L6402A@SOP28 [(SA630)]  
KH25L6405@SOP16 [(SA404)]  
KH25L6405@SOP16(Fast Mode) [(SA404)]  
KH25L6405@SOP8 [(SA023A)]  
KH25L6405@SOP8(Fast Mode) [(SA023A)]  
KH25L6405D@SON8(Fast Mode) [(SA684)]  
KH25L6405D@SOP16 [(SA404)]  
KH25L6405D@SOP16(Fast Mode) [(SA404)]  
KH25L6405D@SOP8 [(SA023A)]      KH25L8005  
KH25L8005(150mil)@SOP8 [(SA602A)]  
KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(209mil)@SOP8 [(SA023A)]  
KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(ISP) [ISP-HEADER01]      KH25L8005@SON8 [(SA683)]  
KH25L8005@SON8(ISP) [ISP-HEADER01]  
KH25L802@SOP28 [(SA630)]      KH25L8025  
KH25L8025(150mil)@SOP8 [(SA602A)]  
KH25L8025(209mil)@SOP8 [(SA023A)]  
KH25L8025@SON8 [(SA683)]      KH25L8036D  
KH25L8036D@SOP16 [(SA404)]  
KH25L8036D@SOP8[150 mil] [(SA602A)]  
KH25L8036D@SOP8[200 mil] [(SA023A)]  
KH25L8036D@WSON8 [(SA683)]      KH29LV004CB@PLCC32 [(SA015A1T)]  
KH29LV004CB@TSOP40 [(SA409T)]      KH29LV004CT@PLCC32 [(SA015A1T)]  
KH29LV004CT@TSOP40 [(SA409T)]      KH29LV008CB@TSOP40 [(SA409T)]  
KH29LV008CT@TSOP40 [(SA409T)]      KH29LV040C  
KH29LV040C@PLCC32 [(SA015A1T)]  
KH29LV160CBT@TSOP48 [(SA247-B005)]  
KH29LV160CTT@TSOP48 [(SA247-B005)]  
KH29LV320CBT@TSOP48 [(SA247-B005)]  
KH29LV320CTT@TSOP48 [(SA247-B005)]  
KH29LV320DBT@TSOP48 [(SA247-B005)]  
KH29LV320DTT@TSOP48 [(SA247-B005)]  
KH29LV400CBT@TSOP48 [(SA247-B005)]  
KH29LV400CTT@TSOP48 [(SA247-B005)]  
KH29LV640DBT@TSOP48 [(SA247-B005)]  
KH29LV640DTT@TSOP48 [(SA247-B005)]



KH29LV800CBT@TSOP48 [(SA247-B005)]  
KH29LV800CTT@TSOP48 [(SA247-B005)]  
MX25L1005                   MX25L1005(ISP) [ISP-HEADER01]  
MX25L1005@SON8 [(SA683)]  
MX25L1005@SON8(ISP) [ISP-HEADER01]  
MX25L1005@SOP8 [(SA602A)]  
MX25L1005@SOP8(ISP) [ISP-HEADER01]  
MX25L1005A                   MX25L1005A@SON8 [(SA683)]  
MX25L1005A@SOP8 [(SA602A)]  
MX25L12805D@SON8(Fast Mode) [(SA684)]  
MX25L12805D@SOP16(Fast Mode) [(SA404)]  
MX25L12805N@SOP16 [(SA404)]  
MX25L12805N@SOP16(Fast Mode) [(SA404)]  
MX25L1602@SOP28 [(SA630)]       MX25L1605@SON8 [(SA684)]  
MX25L1605@SON8(Fast Mode) [(SA684)]  
MX25L1605@SOP16 [(SA404)]  
MX25L1605@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SON8 [(SA684)]  
MX25L1605A@SON8(Fast Mode) [(SA684)]  
MX25L1605A@SOP16 [(SA404)]  
MX25L1605A@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SOP8 [(SA023A)]  
MX25L1605A@SOP8(Fast Mode) [(SA023A)]  
MX25L1605D@SON8 [(SA684)]  
MX25L1605D@SON8(Fast Mode) [(SA683)]  
MX25L1605D@SOP16 [(SA404)]  
MX25L1605D@SOP16(Fast Mode) [(SA404)]  
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
MX25L1615D@SOP16 [(SA404)]       MX25L1615D@SOP8 [(SA023A)]  
MX25L1635DM1I@SOP8 [(SA602A)]    MX25L1635DM2I@SOP8 [(SA605B)]  
MX25L1635DMI@SOP16 [(SA404)]    MX25L1635DZNI@WSON8 [(SA683)]  
MX25L1636DM1I@SOP8 [(SA602A)]    MX25L1636DM2I@SOP8 [(SA605B)]  
MX25L1636DMI@SOP16 [(SA404)]    MX25L1636DZNI@WSON8 [(SA683)]  
MX25L2005                   MX25L2005(ISP) [ISP-HEADER01]  
MX25L2005@SON8 [(SA683)]  
MX25L2005@SON8(ISP) [ISP-HEADER01]  
MX25L2005@SOP8 [(SA602A)]  
MX25L2005@SOP8(ISP) [ISP-HEADER01]  
MX25L2025                   MX25L2025@SON8 [(SA683)]  
MX25L2025@SOP8 [(SA602A)]       MX25L3202@SOP32 [(SA438T)]  
MX25L3205@SOP16 [(SA404)]  
MX25L3205@SOP16(Fast Mode) [(SA404)]

MX25L3205@SOP8 [(SA023A)]  
MX25L3205@SOP8(Fast Mode) [(SA023A)]  
MX25L3205A@SON8 [(SA684)]  
MX25L3205A@SON8(Fast Mode) [(SA684)]  
MX25L3205A@SOP16 [(SA404)]  
MX25L3205A@SOP16(Fast Mode) [(SA404)]  
MX25L3205A@SOP16(Parallel Mode) [(SA404)]  
MX25L3205A@SOP8 [(SA023A)]  
MX25L3205A@SOP8(Fast Mode) [(SA023A)]  
MX25L3205D@SON8(Fast Mode) [(SA683)]  
MX25L3205D@SOP16 [(SA404)]  
MX25L3205D@SOP16(Fast Mode) [(SA404)]  
MX25L3205D@SOP8 [(SA023A)]  
MX25L3205D@SOP8(Fast Mode) [(SA605B)]  
MX25L3215D@SOP16 [(SA404)]      MX25L3215D@SOP8 [(SA023A)]  
MX25L3235DM2I@SOP8 [(SA605B)]      MX25L3235DMI@SOP16 [(SA404)]  
MX25L3235DZNI@WSON8 [(SA683)]      MX25L3236DM2I@SOP8 [(SA605B)]  
MX25L3236DMI@SOP16 [(SA404)]      MX25L3236DZNI@WSON8 [(SA683)]  
MX25L3237D@SOP16 [(SA404)]      MX25L3237D@WSON8 [(SA683)]  
MX25L4005  
MX25L4005(150mil)@SOP8 [(SA602A)]  
MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(209mil)@SOP8 [(SA023A)]  
MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(ISP) [ISP-HEADER01]      MX25L4005@SON8 [(SA683)]  
MX25L4005@SON8(ISP) [ISP-HEADER01]  
MX25L4005A  
MX25L4005A(150mil)@SOP8 [(SA602A)]  
MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(209mil)@SOP8 [(SA023A)]  
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(ISP) [ISP-HEADER01]      MX25L4005A@SON8 [(SA683)]  
MX25L4005A@SON8(ISP) [ISP-HEADER01]  
MX25L4025A  
MX25L4025A(150mil)@SOP8 [(SA602A)]  
MX25L4025A(209mil)@SOP8 [(SA023A)]  
MX25L4025A@SON8 [(SA683)]      MX25L512@SON8 [(SA683)]  
MX25L512@SOP8 [(SA602A)]      MX25L512A  
MX25L512A@SON8 [(SA683)]      MX25L512A@SOP8 [(SA602A)]  
MX25L6402@SOP32 [(SA438T)]      MX25L6402A@SOP28 [(SA630)]  
MX25L6405@SOP16 [(SA404)]  
MX25L6405@SOP16(Fast Mode) [(SA404)]  
MX25L6405@SOP8 [(SA023A)]

MX25L6405@SOP8(Fast Mode) [(SA023A)]  
MX25L6405D@SON8(Fast Mode) [(SA684)]  
MX25L6405D@SOP16 [(SA404)]  
MX25L6405D@SOP16(Fast Mode) [(SA404)]  
MX25L6405D@SOP8 [(SA023A)]      MX25L6415D@SOP16 [(SA404)]  
MX25L6415D@SOP8 [(SA023A)]      MX25L8005  
MX25L8005(150mil)@SOP8 [(SA602A)]  
MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(209mil)@SOP8 [(SA023A)]  
MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(ISP) [ISP-HEADER01]      MX25L8005@SON8 [(SA683)]  
MX25L8005@SON8(ISP) [ISP-HEADER01]  
MX25L802@SOP28 [(SA630)]      MX25L8025  
MX25L8025(150mil)@SOP8 [(SA602A)]  
MX25L8025(209mil)@SOP8 [(SA023A)]  
MX25L8025@SON8 [(SA683)]      MX25L8036D  
MX25L8036D@SOP16 [(SA602A)]  
MX25L8036D@SOP8[150 mil] [(SA602A)]  
MX25L8036D@SOP8[200 mil] [(SA023A)]  
MX25L8036D@WSON8 [(SA683)]      MX26C1000B  
MX26C1000B@PLCC32 [(SA015A1T)]      MX26C1000B@SOIC32 [(SA603)]  
MX26C1000B@TSOP32 [(SA410T)]      MX26C2000B  
MX26C2000B@PLCC32 [(SA015A1T)]      MX26C2000B@SOIC32 [(SA603)]  
MX26C2000B@TSOP32 [(SA410T)]      MX26C512A  
MX26C512A@PLCC32 [(SA015A1T)]      MX26C512A@SOIC28 [(SA630)]  
MX26C512A@TSOP28 [(SA430T)]  
MX26F128J3TC@TSOP56 [(SA628-B018)]  
MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26F640J3TC@TSOP56 [(SA628-B018)]  
MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26L12711MC@PSOP44 [(SA638)]      MX26L12811MC@PSOP44 [(SA638)]  
MX26L6419T@TSOP48 [(SA247-B005)]      MX26L6420@PSOP44 [(SA638)]  
MX26L6420@TSOP48 [(SA247-B005)]      MX26LV004B@PLCC32 [(SA015A1T)]  
MX26LV004B@TSOP40 [(SA409T)]      MX26LV004T@PLCC32 [(SA015A1T)]  
MX26LV004T@TSOP40 [(SA409T)]      MX26LV008B@TSOP40 [(SA409T)]  
MX26LV008T@TSOP40 [(SA409T)]  
MX26LV040(QC)@PLCC32 [(SA015A1T)]  
MX26LV040(TC)@TSOP32 [(SA410T)]  
MX26LV160BT@TSOP48 [(SA247-B005)]  
MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160TT@TSOP48 [(SA247-B005)]  
MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]

MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BT@TSOP48 [(SA247-B005)]  
MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TT@TSOP48 [(SA247-B005)]  
MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV800BM@PSOP44 [(SA638)]  
MX26LV800BT@TSOP48 [(SA247-B005)]  
MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TM@PSOP44 [(SA638)]  
MX26LV800TT@TSOP48 [(SA247-B005)]  
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX27C1000                   MX27C1000@PLCC32 [(SA015A1T)]  
MX27C1000@SOIC32 [(SA603)]    MX27C1000@TSOP32 [(SA410T)]  
MX27C1000A                   MX27C1000A@PLCC32 [(SA015A1T)]  
MX27C1000A@SOIC32 [(SA603)]    MX27C1000A@TSOP32 [(SA410T)]  
MX27C1001                   MX27C1001@PLCC32 [(SA015A1T)]  
MX27C1001@SOIC32 [(SA603)]    MX27C1001@TSOP32 [(SA410T)]  
MX27C1024                   MX27C1024@PLCC44 [(SA244)]  
MX27C1024@TSOP40 [(SA409T)]    MX27C1024A  
MX27C1024A@PLCC44 [(SA244)]    MX27C1024A@TSOP40 [(SA409T)]  
MX27C1024B                   MX27C1024B@PLCC44 [(SA244)]  
MX27C1024B@TSOP40 [(SA409T)]    MX27C1100  
MX27C2000                   MX27C2000@PLCC32 [(SA015A1T)]  
MX27C2000@SOIC32 [(SA603)]    MX27C2000@TSOP32 [(SA410T)]  
MX27C2000A                   MX27C2000A@PLCC32 [(SA015A1T)]  
MX27C2000A@SOIC32 [(SA603)]    MX27C2000A@TSOP32 [(SA410T)]  
MX27C2048                   MX27C2048@PLCC44 [(SA244)]  
MX27C2048@TSOP40 [(SA409T)]    MX27C2100  
MX27C256                    MX27C256@PLCC32 [(SA015A1T)]  
MX27C4000                    MX27C4000@PLCC32 [(SA015A1T)]  
MX27C4000@SOIC32 [(SA603)]    MX27C4000@TSOP32 [(SA410T)]  
MX27C4000A                   MX27C4000A@PLCC32 [(SA015A1T)]  
MX27C4000A@SOIC32 [(SA603)]    MX27C4000A@TSOP32 [(SA410T)]  
MX27C4096                    MX27C4096@PLCC44 [(SA244)]  
MX27C4100                    MX27C4111  
MX27C512                    MX27C512@PLCC32 [(SA015A1T)]  
MX27C516                    MX27C516@PLCC44 [(SA244)]  
MX27C516@TSOP40 [(SA409T)]    MX27C8000  
MX27C8000@PLCC32 [(SA015A1T)]    MX27C8000@SOIC32 [(SA603)]

MX27C8000@TSOP32 [(SA410T)]      MX27C8000A  
MX27C8000A@PLCC32 [(SA015A1T)]      MX27C8000A@SOIC32 [(SA603)]  
MX27C8000A@TSOP32 [(SA410T)]      MX27C8100  
MX27C8100@PSOP44 [(SA638)]      MX27C8111  
MX27C8111@PSOP44 [(SA638)]      MX27L1000  
MX27L1000@PLCC32 [(SA015A1T)]      MX27L1000@TSOP32 [(SA410T)]  
MX27L2000      MX27L2000@PLCC32 [(SA015A1T)]  
MX27L2000@TSOP32 [(SA410T)]      MX27L256  
MX27L256@PLCC32 [(SA015A1T)]      MX27L256@TSOP32 [(SA430T)]  
MX27L4000      MX27L4000@PLCC32 [(SA015A1T)]  
MX27L4000@TSOP32 [(SA410T)]      MX27L4096  
MX27L4096@PLCC44 [(SA244)]      MX27L512  
MX27L512@PLCC32 [(SA015A1T)]      MX27L512@TSOP28 [(SA430T)]  
MX28F002B@TSOP40 [(SA409T)]      MX28F002T@TSOP40 [(SA409T)]  
MX28F1000      MX28F1000@PLCC32 [(SA015A1T)]  
MX28F1000@SOP32 [(SA603)]      MX28F1000@TSOP32 [(SA410T)]  
MX28F1000P      MX28F1000P@PLCC32 [(SA015A1T)]  
MX28F1000P@TSOP32 [(SA410T)]  
MX28F160C3BT@TSOP48 [(SA247-B005)]  
MX28F160C3BX@uBGA48 [(SA634A-B005A-Y048F001)]  
MX28F160C3TT@TSOP48 [(SA247-B005)]  
MX28F160C3TX@uBGA48 [(SA634A-B005A-Y048F001)]  
MX28F2000      MX28F2000@PLCC32 [(SA015A1T)]  
MX28F2000@TSOP32 [(SA410T)]      MX28F2000P  
MX28F2000P@PLCC32 [(SA015A1T)]      MX28F2000P@TSOP32 [(SA410T)]  
MX28F2100B@PSOP44 [(SA638)]      MX28F2100B@TSOP48 [(SA247-B005)]  
MX28F2100T@PSOP44 [(SA638)]      MX28F2100T@TSOP48 [(SA247-B005)]  
MX28F4000      MX28F4000@PLCC32 [(SA015A1T)]  
MX28F4000@TSOP32 [(SA410T)]  
MX28F640C3BT@TSOP48 [(SA247-B005)]  
MX28F640C3BX@uBGA48 [(SA634A-B005A-Y048F001)]  
MX28F640C3TT@TSOP48 [(SA247-B005)]  
MX28F640C3TX@uBGA48 [(SA634A-B005A-Y048F001)]  
MX29F001B      MX29F001B@PLCC32 [(SA015A1T)]  
MX29F001B@TSOP32 [(SA410T)]      MX29F001T  
MX29F001T@PLCC32 [(SA015A1T)]      MX29F001T@TSOP32 [(SA410T)]  
MX29F002B      MX29F002B@PLCC32 [(SA015A1T)]  
MX29F002B@TSOP32 [(SA410T)]      MX29F002NB  
MX29F002NB@PLCC32 [(SA015A1T)]      MX29F002NB@TSOP32 [(SA410T)]  
MX29F002NT      MX29F002NT@PLCC32 [(SA015A1T)]  
MX29F002NT@TSOP32 [(SA410T)]      MX29F002T  
MX29F002T@PLCC32 [(SA015A1T)]      MX29F002T@TSOP32 [(SA410T)]  
MX29F004B      MX29F004B@PLCC32 [(SA015A1T)]

MX29F004B@TSOP32 [(SA410T)]      MX29F004T  
MX29F004T@PLCC32 [(SA015A1T)]      MX29F004T@TSOP32 [(SA410T)]  
MX29F016@PSOP44 [(SA638)]      MX29F016@TSOP40 [(SA409T)]  
MX29F016@TSOP48 [(SA247-B005)]      MX29F022B  
MX29F022B@PLCC32 [(SA015A1T)]      MX29F022B@TSOP32 [(SA410T)]  
MX29F022NB      MX29F022NB@PLCC32 [(SA015A1T)]  
MX29F022NB@TSOP32 [(SA410T)]      MX29F022NT  
MX29F022NT@PLCC32 [(SA015A1T)]      MX29F022NT@TSOP32 [(SA410T)]  
MX29F022T      MX29F022T@PLCC32 [(SA015A1T)]  
MX29F022T@TSOP32 [(SA410T)]      MX29F040  
MX29F040@PLCC32 [(SA015A1T)]      MX29F040@TSOP32 [(SA410T)]  
MX29F040C      MX29F040C@PLCC32 [(SA015A1T)]  
MX29F040C@TSOP32 [(SA410T)]      MX29F080@PSOP44 [(SA638)]  
MX29F080@TSOP40 [(SA409T)]      MX29F100B@PSOP44 [(SA638-B006)]  
MX29F100B@TSOP48 [(SA247-B005)]      MX29F100T@PSOP44 [(SA638-B006)]  
MX29F100T@TSOP48 [(SA247-B005)]      MX29F1610@PSOP44 [(SA638)]  
MX29F1610@TSOP48 [(SA247-B005)]      MX29F1610A@PSOP44 [(SA638)]  
MX29F1610A@TSOP48 [(SA247-B005)]      MX29F1610B@TSOP48 [(SA247-B005)]  
MX29F1611@PSOP44 [(SA638)]      MX29F1615  
MX29F200B@PSOP44 [(SA638-B006)]      MX29F200B@TSOP48 [(SA247-B005)]  
MX29F200CB@PSOP44 [(SA638)]      MX29F200CB@TSOP48 [(SA247-B005)]  
MX29F200CT@PSOP44 [(SA638)]      MX29F200CT@TSOP48 [(SA247-B005)]  
MX29F200T@PSOP44 [(SA638-B006)]      MX29F200T@TSOP48 [(SA247-B005)]  
MX29F4000      MX29F400B@PSOP44 [(SA638-B006)]  
MX29F400B@TSOP48 [(SA247-B005)]      MX29F400CB@PSOP44 [(SA638)]  
MX29F400CB@TSOP48 [(SA247-B005)]      MX29F400CT@PSOP44 [(SA638)]  
MX29F400CT@TSOP48 [(SA247-B005)]      MX29F400T@PSOP44 [(SA638-B006)]  
MX29F400T@TSOP48 [(SA247-B005)]      MX29F800B@PSOP44 [(SA638-B006)]  
MX29F800B@TSOP48 [(SA247-B005)]      MX29F800T@PSOP44 [(SA638-B006)]  
MX29F800T@TSOP48 [(SA247-B005)]      MX29L1611@PSOP44 [(SA638)]  
MX29L1611@TSOP48 [(SA247-B005)]      MX29L1611G  
MX29L3211@PSOP44 [(SA638)]      MX29L3211@TSOP48 [(SA247-B005)]  
MX29LA128MB@TSOP56 [(SA628-B102)]  
MX29LA128MT@TSOP56 [(SA628-B102)]  
MX29LA129MH@TSOP56 [(SA628-B018)]  
MX29LA129ML@TSOP56 [(SA628-B018)]  
MX29LA320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MB@TSOP48 [(SA247-B005)]  
MX29LA320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MT@TSOP48 [(SA247-B005)]  
MX29LA321MB@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MB@TSOP56 [(SA628-B018)]  
MX29LA321MH@FBGA64 [(SA655A-B054A-T064F001Y)]

MX29LA321MH@TSOP56 [(SA628-B018)]  
MX29LA321ML@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321ML@TSOP56 [(SA628-B018)]  
MX29LA321MT@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MT@TSOP56 [(SA628-B018)]  
MX29LV002CB@PLCC32 [(SA015A1T)] MX29LV002CB@TSOP32 [(SA410T)]  
MX29LV002CT@PLCC32 [(SA015A1T)] MX29LV002CT@TSOP32 [(SA410T)]  
MX29LV002NCB@PLCC32 [(SA015A1T)] MX29LV002NCB@TSOP32 [(SA410T)]  
MX29LV002NCT@PLCC32 [(SA015A1T)] MX29LV002NCT@TSOP32 [(SA410T)]  
MX29LV004B@PLCC32 [(SA015A1T)] MX29LV004B@TSOP40 [(SA409T)]  
MX29LV004CB@PLCC32 [(SA015A1T)] MX29LV004CB@TSOP40 [(SA409T)]  
MX29LV004CT@PLCC32 [(SA015A1T)] MX29LV004CT@TSOP40 [(SA409T)]  
MX29LV004T@PLCC32 [(SA015A1T)] MX29LV004T@TSOP40 [(SA409T)]  
MX29LV008B@TSOP40 [(SA409T)] MX29LV008BB@TSOP40 [(SA409T)]  
MX29LV008BT@TSOP40 [(SA409T)] MX29LV008CB@TSOP40 [(SA409T)]  
MX29LV008CT@TSOP40 [(SA409T)] MX29LV008T@TSOP40 [(SA409T)]  
MX29LV017AT@TSOP40 [(SA409T)]  
MX29LV017AX@CSP48 [(SA642G-B026A-T048F001)]  
MX29LV017BT@TSOP40 [(SA409T)]  
MX29LV017BX@CSP48 [(SA642G-B026A-T048F001)]  
MX29LV033T@TSOP40 [(SA409T)] MX29LV040@PLCC32 [(SA015A1T)]  
MX29LV040@TSOP32 [(SA410T)] MX29LV040C@PLCC32 [(SA015A1T)]  
MX29LV040C@TSOP32 [(SA410T)]  
MX29LV065BT@TSOP48 [(SA247-B005)]  
MX29LV065BxB@FBGA63 [(SA642M-B026A-W048F001)]  
MX29LV065M@TSOP48 [(SA247-B005)] MX29LV081@TSOP40 [(SA409T)]  
MX29LV128DB@TSOP48 [(SA247-B005)]  
MX29LV128DB@TSOP56 [(SA628-B102)]  
MX29LV128DT@TSOP48 [(SA247-B005)]  
MX29LV128DT@TSOP56 [(SA628-B102)]  
MX29LV128MB@TSOP56 [(SA628-B102)]  
MX29LV128MH@TSOP56 [(SA628-B102)]  
MX29LV128ML@TSOP56 [(SA628-B102)]  
MX29LV128MT@TSOP56 [(SA628-B102)]  
MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB@PSOP44 [(SA638)]  
MX29LV160AB@TSOP48 [(SA247-B005)]  
MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT@PSOP44 [(SA638)]  
MX29LV160AT@TSOP48 [(SA247-B005)]  
MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]

MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B@PSOP44 [(SA638)]      MX29LV160B@TSOP48 [(SA247-B005)]  
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB@PSOP44 [(SA638)]  
MX29LV160BB@TSOP48 [(SA247-B005)]  
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT@PSOP44 [(SA638)]  
MX29LV160BT@TSOP48 [(SA247-B005)]  
MX29LV160CBM@PSOP44 [(SA638)]  
MX29LV160CBT@TSOP48 [(SA247-B005)]  
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTM@PSOP44 [(SA638)]  
MX29LV160CTT@TSOP48 [(SA247-B005)]  
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DBT@TSOP48 [(SA247-B005)]  
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DTT@TSOP48 [(SA247-B005)]  
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T@PSOP44 [(SA638)]      MX29LV160T@TSOP48 [(SA247-B005)]  
MX29LV320ABT@TSOP48 [(SA247-B005)]  
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATT@TSOP48 [(SA247-B005)]  
MX29LV320ATXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BT@TSOP48 [(SA247-B005)]  
MX29LV320BXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBT@TSOP48 [(SA247-B005)]  
MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CTT@TSOP48 [(SA247-B005)]  
MX29LV320DBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320DBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320DBT@TSOP48 [(SA247-B005)]



MX29LV320DTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320DTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320DTT@TSOP48 [(SA247-B005)]  
MX29LV320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320MB@PSOP44 [(SA638)]  
MX29LV320MB@TSOP48 [(SA247-B005)]  
MX29LV320MH@TSOP56 [(SA628-B067)]  
MX29LV320ML@TSOP56 [(SA628-B067)]  
MX29LV320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320MT@PSOP44 [(SA638)]  
MX29LV320MT@TSOP48 [(SA247-B005)]  
MX29LV320TT@TSOP48 [(SA247-B005)]  
MX29LV320TXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320TXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV321DBT@TSOP48 [(SA247-B005)]  
MX29LV321DBXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV321DTT@TSOP48 [(SA247-B005)]  
MX29LV321DTXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV400B@PSOP44 [(SA638)]      MX29LV400B@TSOP48 [(SA247-B005)]  
MX29LV400BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV400BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV400CBM@PSOP44 [(SA638)]  
MX29LV400CBT@TSOP48 [(SA247-B005)]  
MX29LV400CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400CTM@PSOP44 [(SA638)]  
MX29LV400CTT@TSOP48 [(SA247-B005)]  
MX29LV400CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400T@PSOP44 [(SA638)]      MX29LV400T@TSOP48 [(SA247-B005)]  
MX29LV400TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV400TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV640BBT@TSOP48 [(SA247-B005)]  
MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BT@TSOP48 [(SA247-B005)]  
MX29LV640BTT@TSOP48 [(SA247-B005)]  
MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BUT@TSOP48 [(SA247-B005)]  
MX29LV640BUXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV640DBT@TSOP48 [(SA247-B005)]  
MX29LV640DBX@FBGA48 [(SA642G-B026A-T048F001Y)]

MX29LV640DTT@TSOP48 [(SA247-B005)]  
MX29LV640DTX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640EBT@TSOP48 [(SA247-B005)]  
MX29LV640EBX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640ETT@TSOP48 [(SA247-B005)]  
MX29LV640ETX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MB@TSOP48 [(SA247-B005)]  
MX29LV640MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640MH@TSOP56 [(SA628-B067)]  
MX29LV640ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640ML@TSOP56 [(SA628-B067)]  
MX29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MT@TSOP48 [(SA247-B005)]  
MX29LV640TT@TSOP48 [(SA247-B005)]  
MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV641MH@TSOP48 [(SA247-B005)]  
MX29LV641ML@TSOP48 [(SA247-B005)]  
MX29LV800AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB@PSOP44 [(SA638)]  
MX29LV800AB@TSOP48 [(SA247-B005)]  
MX29LV800AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT@PSOP44 [(SA638)]  
MX29LV800AT@TSOP48 [(SA247-B005)]  
MX29LV800B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B@PSOP44 [(SA638)]      MX29LV800B@TSOP48 [(SA247-B005)]  
MX29LV800CBM@PSOP44 [(SA638)]  
MX29LV800CBT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CBT@TSOP48 [(SA247-B005)]  
MX29LV800CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTM@PSOP44 [(SA638)]  
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CTT@TSOP48 [(SA247-B005)]  
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)]      MX29LV800T@TSOP48 [(SA247-B005)]

MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX29SL800CT@TSOP48 [(SA247-B005)]  
MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69LW162BXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW162TXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW164BXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW164TXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW322BXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW322TXB@CSP69 [(SA642A-B032A-Y096F001)]  
MX69LW324BXB@CSP69 [(SA642A-B032A-Y096F001)]

MX69LW324TXB@CSP69 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

MX10E8050I                    MX10E8050I@PLCC44 [(SA244)]  
MX10E8050I@TQFP44 [(SA245A)]    MX10EXA@PLCC44 [(SA244)]  
MX10EXA@TQFP44 [(SA245A)]  
MX10F201FC@TQFP100(\*) [(TA010-B006)]  
MX10F202FC@TQFP100(\*) [(TA010-B006)]  
MX10FLCD                    MX10FMAXD  
MX10FMAXD@PLCC44 [(SA244)]    MX10FMAXD@TQFP44 [(SA245A)]

## MAXIM

### E(E)PROM/FRAM/NVRAM

DS1220AB                    DS1220AD  
DS1220Y                    DS1225AB  
DS1225AD                    DS1225D  
DS1225E                    DS1225Y  
DS1230AB                    DS1230W  
DS1230Y                    DS1235AB  
DS1235Y                    DS1243Y  
DS1244                    DS1244Y  
DS1245AB                    DS1245EE  
DS1245P                    DS1245W  
DS1245Y                    DS1248P  
DS1248W                    DS1248Y  
DS1249AB                    DS1249W  
DS1249Y                    DS1250AB  
DS1250W                    DS1250Y  
DS1251AB                    DS1251W  
DS1251Y                    DS1256P  
DS1256W                    DS1256Y  
DS1258AB                    DS1258W  
DS1258Y                    DS1265AB  
DS1265W                    DS1265Y  
DS1270AB                    DS1270W  
DS1270Y                    DS1284  
DS1284N                    DS1284Q@PLCC28 [(SA008A)]  
DS1284QN@PLCC28 [(SA008A)]    DS1286

DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1386(32K)
DS1386(8K)	DS1485
DS1485@SOIC28 [(SA630)]	DS1488
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1642
DS1643	DS1644
DS1644P [ordering number is marked above]	
DS1644PS [(PEP+S414T)]	DS1645AB
DS1645EE	DS1645Y
DS1646	DS1647
DS1647LPM	DS1650AB
DS1650Y	DS1687-3
DS1687-5	DS17287-3
DS17287-5	DS1742
DS1742W	DS1743
DS1743P	DS1743W
DS1743WP	DS1744
DS1744P	DS1744W
DS1744WP	DS1746
DS1747	
DS1747P [ordering number is marked above]	
DS1747PS [(PEP+S414T)]	DS1747W
DS1747WP [ordering number is marked above]	
DS1747WPS [(PEP+S414T)]	DS17487-3
DS17487-5	DS17887-3
DS17887-5	DS2430A@TO-92
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-92
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6 [(SA602A)]
DS2433@PR-35	DS2433S(3.9)@SOIC8 [(SA602A)]
DS2433S(5.5)@SOIC8 [(SA605A)]	DS2502
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8 [(SA602A)]
DS2502UNW	DS2502UNW@SOIC8 [(SA602A)]
DS2502UNW@TSOC6 [(SA602A)]	DS2506
DS2506S@SOIC8 [(SA023A)]	DS4510@uSOP10
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20 [(SA026)]

## MICROCONTROLLER

DS87C520 DS87C520@PLCC44 [(SA244)]  
DS87C520@TQFP44 [(SA245A)] DS89C420(rev.A)  
DS89C420(rev.A)@PLCC44 [(SA244)]  
DS89C420(rev.A)@TQFP44 [(SA245A)]

## MAXWELL

### E(E)PROM/FRAM/NVRAM

27C010T@LDFP32 [(SA438T)] 28C010  
28C010@PLCC32 [(SA015A1T)] 28C010@TSOP32 [(SA438T)]  
28C010T 28C010T@PLCC32 [(SA015A1T)]  
28C010T@TSOP32 [(SA438T)] 28C011  
28C011@PLCC32 [(SA015A1T)] 28C011@TSOP32 [(SA438T)]  
28C011T 28C011T@PLCC32 [(SA015A1T)]  
28C011T@TSOP32 [(SA438T)]

## MEGAWIN

### E(E)PROM/FRAM/NVRAM

MM25SB512@SOIC8 [(SA602A)] MM29F040  
MM29F040@PLCC32 [(SA015A1T)] MM29F040@TSOP32 [(SA410T)]  
MM29LF040 MM29LF040@PLCC32 [(SA015A1T)]  
MM29LF040@TSOP32 [(SA410T)]

### MICROCONTROLLER

MPC89L516X2 MPC89L516X2@PLCC44 [(SA244)]  
MPC89L516X2@TQFP44 [(SA245A)] MPC89L556X2  
MPC89L556X2@PLCC44 [(SA244)] MPC89L556X2@TQFP44 [(SA245A)]

## MEMOCOM

### E(E)PROM/FRAM/NVRAM

KI01602AB(Ga1)@FBGA66 [(SA642R-B023A-T096F001Y)]  
KI01602AB(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]

KI01602AT(Ga1)@FBGA66 [(SA642R-B023A-T096F001Y)]  
KI01602AT(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]  
KI01604AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI01604AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI01604AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI01604AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI01608AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI01608AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI01608AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI01608AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03204AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03204AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03204AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03204AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03208AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03208AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204CB@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204CT@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208BB@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208BT@FBGA56 [(SA642P-B207A-W056F001Y)]

## MICON

### MICROCONTROLLER

MDT10P21(dip18)                    MDT10P21(dip20)  
MDT10P21(dip22)                    MDT10P21@SOP18 [(SA404A)]  
MDT10P21@SOP20 [(SA404A)]        MDT10P21@SOP24 [(SA404A)]  
MDT10P22(dip18)                    MDT10P22(dip20)  
MDT10P22(dip22)                    MDT10P22@SOP18 [(SA404A)]  
MDT10P22@SOP20 [(SA404A)]        MDT10P22@SOP24 [(SA404A)]  
MDT10P23(dip18)                    MDT10P23(dip20)

MDT10P23(dip22) MDT10P23@SOP18 [(SA404A)]  
MDT10P23@SOP20 [(SA404A)] MDT10P23@SOP24 [(SA404A)]  
MDT10P61 MDT10P61@SOP18 [(SA404A)]  
MDT10P61@SSOP20 [(SA626A)] MDT2005  
MDT2005@SOP18 [(SA404A)] MDT2005@SSOP20 [(SA626A)]  
MDT2010 MDT2010@SOP18 [(SA404A)]  
MDT2010@SSOP20 [(SA626A)] MDT2020  
MDT2020@SOP28 [(SA404A)] MDT2020@SSOP28 [(SA626A)]  
MDT2030 MDT2030@SOP18 [(SA404A)]  
MDT2030@SSOP20 [(SA626A)] MDT2050  
MDT2050@SOP18 [(SA404A)] MDT2050@SSOP20 [(SA626A)]  
MDT2051 MDT2051@SOP18 [(SA404A)]  
MDT2051@SSOP20 [(SA626A)] MDT2060  
MDT2060@SOP18 [(SA404A)] MDT2060@SSOP20 [(SA626A)]

## MICROCHIP

### E(E)PROM/FRAM/NVRAM

24AA00 24AA00@SOIC8 [(SA602A)]  
24AA00@SOT-23 [(SA717)] 24AA00@TSSOP8 [(SA026)]  
24AA01 24AA01@SOIC8 [(SA602A)]  
24AA01@TSSOP8 [(SA026)] 24AA014  
24AA014@SOIC8 [(SA602A)] 24AA014@TSSOP8 [(SA026)]  
24AA02 24AA02@DFN8 [(SA694)]  
24AA02@MSOP8 [(SA666)] 24AA02@SOIC8 [(SA602A)]  
24AA02@SOT-23-5 [(SA717)] 24AA02@TSSOP8 [(SA026)]  
24AA024 24AA024@DFN8 [(SA694)]  
24AA024@MSOP8 [(SA666)] 24AA024@SOIC8 [(SA602A)]  
24AA024@TSSOP8 [(SA026)] 24AA025  
24AA025@DFN8 [(SA694)] 24AA025@MSOP8 [(SA666)]  
24AA025@SOIC8 [(SA602A)] 24AA025@TSSOP8 [(SA026)]  
24AA04 24AA04@SOIC8 [(SA602A)]  
24AA04@TSSOP8 [(SA026)] 24AA08  
24AA08@SOIC8 [(SA602A)] 24AA08@TSSOP8 [(SA026)]  
24AA1025 24AA1025@SOIC8 [(SA602A)]  
24AA1025@TSSOP8 [(SA026)] 24AA128  
24AA128@MSOP8 [(SA666)] 24AA128@SOIC8 [(SA602A)]  
24AA128@TSSOP14 [(SA026)] 24AA128@TSSOP8 [(SA026)]  
24AA16 24AA16@SOIC8 [(SA602A)]  
24AA16@TSSOP8 [(SA026)] 24AA164  
24AA164@SOIC8 [(SA602A)] 24AA164@TSSOP8 [(SA026)]



24AA174	24AA174@SOIC8 [(SA602A)]
24AA174@TSSOP8 [(SA026)]	24AA256
24AA256@MSOP8 [(SA666)]	24AA256@SOIC8 [(SA605A)]
24AA256@TSSOP14 [(SA026)]	24AA256@TSSOP8 [(SA026)]
24AA32	24AA32(Rotated)@TSSOP8 [(SA026)]
24AA32@MSOP8 [(SA666)]	24AA32@SOIC8 [(SA602A)]
24AA32@TSSOP8 [(SA026)]	24AA32A
24AA32A(Rotated)@TSSOP8 [(SA026)]	
24AA32A@MSOP8 [(SA666)]	24AA32A@SOIC8 [(SA602A)]
24AA32A@TSSOP8 [(SA026)]	24AA512
24AA512@DFN8 [(SA683)]	24AA512@SOIC8 [(SA605A)]
24AA512@TSSOP14 [(SA602)]	24AA515
24AA515@SOIC8 [(SA605A)]	24AA52
24AA52@DFN8 [(SA694)]	24AA52@MSOP8 [(SA666)]
24AA52@SOIC8 [(SA602A)]	24AA52@TSSOP8 [(SA026)]
24AA64	24AA64(Rotated)@TSSOP8 [(SA026)]
24AA64@MSOP8 [(SA666)]	24AA64@SOIC8 [(SA602A)]
24AA64@TSSOP8 [(SA026)]	24AA65
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8 [(SA026)]
24C00	24C00@SOIC8 [(SA602A)]
24C00@SOT-23 [(SA717)]	24C00@TSSOP8 [(SA026)]
24C01	24C01A
24C01A@SOIC8 [(SA602A)]	24C01C
24C01C@SOIC8 [(SA602A)]	24C01C@TSSOP8 [(SA026)]
24C02	24C02A
24C02A@SOIC8 [(SA602A)]	24C02C
24C02C@SOIC8 [(SA602A)]	24C02C@TSSOP8 [(SA026)]
24C04	24C04A
24C04A@SOIC8 [(SA602A)]	24C04A@TSSOP8 [(SA026)]
24C08	24C08@SOIC8 [(SA602A)]
24C08B	24C08B@SOIC8 [(SA602A)]
24C16	24C16@SOIC8 [(SA602A)]
24C16B	24C16B@SOIC8 [(SA602A)]
24C32	24C32@SOIC8 [(SA602A)]
24C64	24C64@SOIC8 [(SA602A)]
24C64@TSSOP8 [(SA026)]	24C65
24C65@SOIC8 [(SA602A)]	24FC1025
24FC1025@SOIC8 [(SA602A)]	24FC1025@TSSOP8 [(SA026)]
24FC128	24FC128@MSOP8 [(SA666)]
24FC128@SOIC8 [(SA602A)]	24FC128@TSSOP14 [(SA026)]
24FC128@TSSOP8 [(SA026)]	24FC256
24FC256@MSOP8 [(SA666)]	24FC256@SOIC8 [(SA605A)]
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8 [(SA026)]

24FC32 24FC32@SOIC8 [(SA602A)]  
24FC512 24FC512@DFN8 [(SA683)]  
24FC512@SOIC8 [(SA605A)] 24FC512@TSSOP14 [(SA602)]  
24FC515 24FC515@SOIC8 [(SA605A)]  
24FC65 24FC65@SOIC8 [(SA605A)]  
24LC00 24LC00@SOIC8 [(SA602A)]  
24LC00@SOT-23 [(SA717)] 24LC00@TSSOP8 [(SA026)]  
24LC01 24LC014  
24LC014@SOIC8 [(SA602A)] 24LC014@TSSOP8 [(SA026)]  
24LC01B 24LC01B@SOIC8 [(SA602A)]  
24LC01B@TSSOP8 [(SA026)] 24LC02  
24LC024 24LC024@SOIC8 [(SA602A)]  
24LC024@TSSOP8 [(SA026)] 24LC025  
24LC025@SOIC8 [(SA602A)] 24LC025@TSSOP8 [(SA026)]  
24LC02B 24LC02B@DFN8 [(SA694)]  
24LC02B@MSOP8 [(SA666)] 24LC02B@SOIC8 [(SA602A)]  
24LC02B@SOT-23-5 [(SA717)] 24LC02B@TSSOP8 [(SA026)]  
24LC04 24LC04B  
24LC04B@SOIC8 [(SA602A)] 24LC04B@TSSOP8 [(SA026)]  
24LC08 24LC08B  
24LC08B@SOIC8 [(SA602A)] 24LC08B@TSSOP8 [(SA026)]  
24LC1025 24LC1025@SOIC8 [(SA602A)]  
24LC1025@TSSOP8 [(SA026)] 24LC128  
24LC128@MSOP8 [(SA666)] 24LC128@SOIC8 [(SA605A)]  
24LC128@TSSOP14 [(SA026)] 24LC128@TSSOP8 [(SA026)]  
24LC16 24LC16@MSOP8 [(SA605A)]  
24LC16@SOIC8 [(SA602A)] 24LC164  
24LC164@SOIC8 [(SA602A)] 24LC16B  
24LC16B@SOIC8 [(SA602A)] 24LC16B@TSSOP8 [(SA026)]  
24LC174 24LC174@SOIC8 [(SA602A)]  
24LC21 24LC21@SOIC8 [(SA602A)]  
24LC21A 24LC21A@SOIC8 [(SA602A)]  
24LC22A 24LC22A@SOIC8 [(SA602A)]  
24LC256 24LC256@MSOP8 [(SA666)]  
24LC256@SOIC8 [(SA605A)] 24LC256@TSSOP14 [(SA026)]  
24LC256@TSSOP8 [(SA026)] 24LC32  
24LC32@SOIC8 [(SA602A)] 24LC32A  
24LC32A@SOIC8 [(SA602A)] 24LC32A@TSSOP8 [(SA026)]  
24LC512 24LC512@DFN8 [(SA683)]  
24LC512@SOIC8 [(SA605A)] 24LC512@TSSOP14 [(SA602)]  
24LC515 24LC515@SOIC8 [(SA605A)]  
24LC64 24LC64(Rotated)@TSSOP8 [(SA026)]  
24LC64@MSOP8 [(SA605A)] 24LC64@SOIC8 [(SA602A)]

24LC64@TSSOP8 [(SA026)]      24LC65  
 24LC65@SOIC8 [(SA602A)]      24LCS21  
 24LCS21@SOIC8 [(SA602A)]      24LCS21A  
 24LCS21A@SOIC8 [(SA602A)]      24LCS22  
 24LCS22@SOIC8 [(SA602A)]      24LCS22A  
 24LCS22A@SOIC8 [(SA602A)]      24LCS52  
 24LCS52@DFN8 [(SA694)]      24LCS52@MSOP8 [(SA666)]  
 24LCS52@SOIC8 [(SA602A)]      24LCS52@TSSOP8 [(SA026)]  
 25AA010A      25AA010A@DFN8 [(SA683)]  
 25AA010A@MSOP8 [(SA605A)]      25AA010A@SOIC8 [(SA602A)]  
 25AA010A@SOT-23 [(SA698)]      25AA010A@TSSOP8 [(SA026)]  
 25AA010A[X-Rotated]@TSSOP8 [(SA026)]  
 25AA020A      25AA020A@DFN8 [(SA683)]  
 25AA020A@MSOP8 [(SA605A)]      25AA020A@SOIC8 [(SA602A)]  
 25AA020A@SOT-23 [(SA698)]      25AA020A@TSSOP8 [(SA026)]  
 25AA020A[X-Rotated]@TSSOP8 [(SA026)]  
 25AA040      25AA040@SOIC8 [(SA602A)]  
 25AA040@TSSOP8 [(SA026)]      25AA040A  
 25AA040A@DFN8 [(SA683)]      25AA040A@MSOP8 [(SA605A)]  
 25AA040A@SOIC8 [(SA602A)]      25AA040A@SOT-23 [(SA698)]  
 25AA040A@TSSOP8 [(SA026)]  
 25AA040A[X-Rotated]@TSSOP8 [(SA026)]  
 25AA080      25AA080@SOIC8 [(SA602A)]  
 25AA080A      25AA080A@MSOP8 [(SA605A)]  
 25AA080A@SOIC8 [(SA602A)]      25AA080A@TSSOP8 [(SA026)]  
 25AA080B      25AA080B@MSOP8 [(SA605A)]  
 25AA080B@SOIC8 [(SA602A)]      25AA080B@TSSOP8 [(SA026)]  
 25AA1024      25AA1024@DFN8 [(SA683)]  
 25AA1024@SOIC8 [(SA602A)]      25AA1024@SOIJ8 [(SA605)]  
 25AA160      25AA160@SOIC8 [(SA602A)]  
 25AA160A      25AA160A@MSOP8 [(SA605A)]  
 25AA160A@SOIC8 [(SA602A)]      25AA160A@TSSOP8 [(SA026)]  
 25AA160B      25AA160B@MSOP8 [(SA605A)]  
 25AA160B@SOIC8 [(SA602A)]      25AA160B@TSSOP8 [(SA026)]  
 25AA256      25AA256@DFN8 [(SA683)]  
 25AA256@SOIC8(4.0) [(SA602A)]      25AA256@SOIC8(5.4) [(SA605A)]  
 25AA256@TSSOP8 [(SA026)]  
 25AA256[X-Rotated]@TSSOP8 [(SA026)]  
 25AA320      25AA320@SOIC8 [(SA602A)]  
 25AA320@TSSOP14 [(SA026)]      25AA320@TSSOP8 [(SA026)]  
 25AA512      25AA512@DFN8 [(SA683)]  
 25AA512@SOIC8 [(SA602A)]      25AA512@SOIJ8 [(SA605)]  
 25AA640      25AA640@SOIC8 [(SA602A)]

25AA640@TSSOP8 [(SA026)]      25C040  
 25C040@SOIC8 [(SA602A)]      25C040@TSSOP8 [(SA026)]  
 25C080      25C080@SOIC8 [(SA602A)]  
 25C160      25C160@SOIC8 [(SA602A)]  
 25C320      25C320@SOIC8 [(SA602A)]  
 25C320@TSSOP14 [(SA026)]      25C320@TSSOP8 [(SA026)]  
 25C640      25C640@SOIC8 [(SA602A)]  
 25C640@TSSOP8 [(SA026)]      25LC010A  
 25LC010A@DFN8 [(SA683)]      25LC010A@MSOP8 [(SA605A)]  
 25LC010A@SOIC8 [(SA602A)]      25LC010A@SOT-23 [(SA698)]  
 25LC010A@TSSOP8 [(SA026)]  
 25LC010A[X-Rotated]@TSSOP8 [(SA026)]  
 25LC020A      25LC020A@DFN8 [(SA683)]  
 25LC020A@MSOP8 [(SA605A)]      25LC020A@SOIC8 [(SA602A)]  
 25LC020A@SOT-23 [(SA698)]      25LC020A@TSSOP8 [(SA026)]  
 25LC020A[X-Rotated]@TSSOP8 [(SA026)]  
 25LC040      25LC040@SOIC8 [(SA602A)]  
 25LC040@TSSOP8 [(SA026)]      25LC040A  
 25LC040A@DFN8 [(SA683)]      25LC040A@MSOP8 [(SA605A)]  
 25LC040A@SOIC8 [(SA602A)]      25LC040A@SOT-23 [(SA698)]  
 25LC040A@TSSOP8 [(SA026)]  
 25LC040A[X-Rotated]@TSSOP8 [(SA026)]  
 25LC080      25LC080@SOIC8 [(SA602A)]  
 25LC080A      25LC080A@MSOP8 [(SA605A)]  
 25LC080A@SOIC8 [(SA602A)]      25LC080A@TSSOP8 [(SA026)]  
 25LC080B      25LC080B@MSOP8 [(SA605A)]  
 25LC080B@SOIC8 [(SA602A)]      25LC080B@TSSOP8 [(SA026)]  
 25LC1024      25LC1024@DFN8 [(SA683)]  
 25LC1024@SOIC8 [(SA602A)]      25LC1024@SOI18 [(SA605)]  
 25LC160      25LC160@SOIC8 [(SA602A)]  
 25LC160A      25LC160A@MSOP8 [(SA605A)]  
 25LC160A@SOIC8 [(SA602A)]      25LC160A@TSSOP8 [(SA026)]  
 25LC160B      25LC160B@MSOP8 [(SA605A)]  
 25LC160B@SOIC8 [(SA602A)]      25LC160B@TSSOP8 [(SA026)]  
 25LC256      25LC256@DFN8 [(SA683)]  
 25LC256@SOIC8(4.0) [(SA602A)]      25LC256@SOIC8(5.4) [(SA605A)]  
 25LC256@TSSOP8 [(SA026)]  
 25LC256[X-Rotated]@TSSOP8 [(SA026)]  
 25LC320      25LC320(SN)@SOIC8 [(SA602A)]  
 25LC320@TSSOP14 [(SA026)]      25LC320@TSSOP8 [(SA026)]  
 25LC512      25LC512@DFN8 [(SA683)]  
 25LC512@SOIC8 [(SA602A)]      25LC512@SOI18 [(SA605)]  
 25LC640      25LC640@SOIC8 [(SA602A)]

25LC640@TSSOP8 [(SA026)] 27256  
 27256@PLCC32 [(SA015A1T)] 27C128  
 27C128@PLCC32 [(SA015A1T)] 27C128A  
 27C128A@PLCC32 [(SA015A1T)] 27C256  
 27C256@PLCC32 [(SA015A1T)] 27C32A  
 27C512 27C512@PLCC32 [(SA015A1T)]  
 27C512A 27C512A@PLCC32 [(SA015A1T)]  
 27C513 27C64  
 27C64@PLCC32 [(SA015A1T)] 27C64@SOIC28 [(SA404)]  
 27HC1616 27HC1616@PLCC44 [(SA244)]  
 27HC1616L 27HC1616L@PLCC44 [(SA244)]  
 27HC191 27HC191@PLCC28 [(SA008A)]  
 27HC191@SOIC24 [(SA404)] 27HC256  
 27HC256@PLCC32 [(SA015A1T)] 27HC256L  
 27HC256L@PLCC32 [(SA015A1T)] 27HC291  
 27HC291@PLCC28 [(SA008A)] 27HC291@SOIC24 [(SA404)]  
 27HC416 27HC64  
 27HC64@PLCC32 [(SA015A1T)] 27HC64@SOIC28 [(SA404)]  
 27HC641 27HC641@PLCC28 [(SA008A)]  
 27HC641@SOIC24 [(SA404)] 27HC641L  
 27HC641L@PLCC28 [(SA008A)] 27HC641L@SOIC24 [(SA404)]  
 27HC64L 27HC64L@PLCC32 [(SA015A1T)]  
 27HC64L@SOIC28 [(SA404)] 27LV256  
 27LV256@PLCC32 [(SA015A1T)] 27LV64  
 2817 2864  
 2864@PLCC32 [(SA015A1T)] 28C04  
 28C04@PLCC32 [(SA015A1T)] 28C04@SOIC24 [(SA404)]  
 28C04A 28C04A@PLCC32 [(SA015A1T)]  
 28C04A@SOIC24 [(SA404)] 28C04AF  
 28C04AF@PLCC32 [(SA015A1T)] 28C04AF@SOIC24 [(SA404)]  
 28C04F 28C04F@PLCC32 [(SA015A1T)]  
 28C04F@SOIC24 [(SA404)] 28C16  
 28C16@PLCC32 [(SA015A1T)] 28C16@SOIC24 [(SA404)]  
 28C16A 28C16A@PLCC32 [(SA015A1T)]  
 28C16A@SOIC24 [(SA404)] 28C16AF  
 28C16AF@PLCC32 [(SA015A1T)] 28C16AF@SOIC24 [(SA404)]  
 28C16F 28C16F@PLCC32 [(SA015A1T)]  
 28C16F@SOIC24 [(SA404)] 28C17  
 28C17@PLCC32 [(SA015A1T)] 28C17@SOIC28 [(SA404)]  
 28C17A 28C17A@PLCC32 [(SA015A1T)]  
 28C17A@SOIC28 [(SA404)] 28C17AF  
 28C17AF@PLCC32 [(SA015A1T)] 28C17AF@SOIC28 [(SA404)]  
 28C17F 28C17F@PLCC32 [(SA015A1T)]

28C17F@SOIC28 [(SA404)]	28C256
28C256@PLCC32 [(SA015A1T)]	28C256F
28C256F@PLCC32 [(SA015A1T)]	28C64A
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28 [(SA404)]
28C64A@TSOP32 [(SA410T)]	28C64AF
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28 [(SA404)]
28LV64A	28LV64A@PLCC32 [(SA015A1T)]
28LV64A@SOIC28 [(SA404)]	28PC64
28PC64@PLCC32 [(SA015A1T)]	59C11
59C11@SOIC8 [(SA602A)]	85C72
85C72@SOIC8 [(SA602A)]	85C82
85C82@SOIC8 [(SA602A)]	85C92
85C92@SOIC8 [(SA602A)]	93AA46(08bit)
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46(16bit)
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A(08bit)
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8 [(SA666)]
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23 [(SA717)]
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B(16bit)
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8 [(SA666)]
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23 [(SA717)]
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C(08bit)
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8 [(SA666)]
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8 [(SA026)]
93AA46C(16bit)	93AA46C(16bit)@DFN8 [(BBBB)]
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8 [(SA602A)]
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56(08bit)
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56(16bit)
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A(08bit)
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@MSOP8 [(SA666)]
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@SOT-23 [(SA717)]
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B(16bit)
93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@MSOP8 [(SA666)]
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56B(16bit)@SOT-23 [(SA717)]
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C(08bit)
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8 [(SA666)]
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8 [(SA026)]
93AA56C(16bit)	93AA56C(16bit)@DFN8 [(BBBB)]
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8 [(SA602A)]
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66(08bit)
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66(16bit)
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A(08bit)
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8 [(SA666)]
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23 [(SA717)]

93AA66A(08bit)@TSSOP8 [(SA026)] 93AA66B(16bit)  
 93AA66B(16bit)@DFN8 [(BBBB)] 93AA66B(16bit)@MSOP8 [(SA666)]  
 93AA66B(16bit)@SOIC8 [(SA602A)] 93AA66B(16bit)@SOT-23 [(SA717)]  
 93AA66B(16bit)@TSSOP8 [(SA026)] 93AA66C(08bit)  
 93AA66C(08bit)@DFN8 [(BBBB)] 93AA66C(08bit)@MSOP8 [(SA666)]  
 93AA66C(08bit)@SOIC8 [(SA602A)] 93AA66C(08bit)@TSSOP8 [(SA026)]  
 93AA66C(16bit) 93AA66C(16bit)@DFN8 [(BBBB)]  
 93AA66C(16bit)@MSOP8 [(SA666)] 93AA66C(16bit)@SOIC8 [(SA602A)]  
 93AA66C(16bit)@TSSOP8 [(SA026)] 93AA76(08bit)  
 93AA76(08bit)@SOIC8 [(SA602A)] 93AA76(16bit)  
 93AA76(16bit)@SOIC8 [(SA602A)] 93AA76A(08bit)  
 93AA76A(08bit)@DFN8 [(BBBB)] 93AA76A(08bit)@MSOP8 [(SA666)]  
 93AA76A(08bit)@SOIC8 [(SA602A)] 93AA76A(08bit)@SOT-23 [(SA717)]  
 93AA76A(08bit)@TSSOP8 [(SA026)] 93AA76B(16bit)  
 93AA76B(16bit)@DFN8 [(BBBB)] 93AA76B(16bit)@MSOP8 [(SA666)]  
 93AA76B(16bit)@SOIC8 [(SA602A)] 93AA76B(16bit)@SOT-23 [(SA717)]  
 93AA76B(16bit)@TSSOP8 [(SA026)] 93AA76C(08bit)  
 93AA76C(08bit)@DFN8 [(BBBB)] 93AA76C(08bit)@MSOP8 [(SA666)]  
 93AA76C(08bit)@SOIC8 [(SA602A)] 93AA76C(08bit)@TSSOP8 [(SA026)]  
 93AA76C(16bit) 93AA76C(16bit)@DFN8 [(BBBB)]  
 93AA76C(16bit)@MSOP8 [(SA666)] 93AA76C(16bit)@SOIC8 [(SA602A)]  
 93AA76C(16bit)@TSSOP8 [(SA026)] 93AA86(08bit)  
 93AA86(08bit)@SOIC8 [(SA602A)] 93AA86(16bit)  
 93AA86(16bit)@SOIC8 [(SA602A)] 93AA86A(08bit)  
 93AA86A(08bit)@DFN8 [(BBBB)] 93AA86A(08bit)@MSOP8 [(SSA666)]  
 93AA86A(08bit)@SOIC8 [(SA602A)] 93AA86A(08bit)@SOT-23 [(SA717)]  
 93AA86A(08bit)@TSSOP8 [(SA026)] 93AA86B(16bit)  
 93AA86B(16bit)@DFN8 [(BBBB)] 93AA86B(16bit)@MSOP8 [(SA666)]  
 93AA86B(16bit)@SOIC8 [(SA602A)] 93AA86B(16bit)@SOT-23 [(SA717)]  
 93AA86B(16bit)@TSSOP8 [(SA026)] 93AA86C(08bit)  
 93AA86C(08bit)@DFN8 [(BBBB)] 93AA86C(08bit)@MSOP8 [(SA666)]  
 93AA86C(08bit)@SOIC8 [(SA602A)] 93AA86C(08bit)@TSSOP8 [(SA026)]  
 93AA86C(16bit) 93AA86C(16bit)@DFN8 [(BBBB)]  
 93AA86C(16bit)@MSOP8 [(SA666)] 93AA86C(16bit)@SOIC8 [(SA602A)]  
 93AA86C(16bit)@TSSOP8 [(SA026)] 93C06(08bit)  
 93C06(08bit)@SOIC8 [(SA602A)] 93C06(16bit)  
 93C06(16bit)@SOIC8 [(SA602A)] 93C46(08bit)  
 93C46(08bit)@SOIC8 [(SA602A)] 93C46(16bit)  
 93C46(16bit)@SOIC8 [(SA602A)] 93C46A(08bit)  
 93C46A(08bit)@DFN8 [(BBBB)] 93C46A(08bit)@MSOP8 [(SA666)]  
 93C46A(08bit)@SOIC8 [(SA602A)] 93C46A(08bit)@SOT-23 [(SA717)]  
 93C46A(08bit)@TSSOP8 [(SA026)] 93C46B(16bit)  
 93C46B(16bit)@DFN8 [(BBBB)] 93C46B(16bit)@MSOP8 [(SA666)]

93C46B(16bit)@SOIC8 [(SA602A)]	93C46B(16bit)@SOT-23 [(SA717)]
93C46B(16bit)@TSSOP8 [(SA026)]	93C46C(08bit)
93C46C(08bit)@DFN8 [(BBBB)]	93C46C(08bit)@MSOP8 [(SA666)]
93C46C(08bit)@SOIC8 [(SA602A)]	93C46C(08bit)@TSSOP8 [(SA026)]
93C46C(16bit)	93C46C(16bit)@DFN8 [(BBBB)]
93C46C(16bit)@MSOP8 [(SA666)]	93C46C(16bit)@SOIC8 [(SA602A)]
93C46C(16bit)@TSSOP8 [(SA026)]	93C56(08bit)
93C56(08bit)@SOIC8 [(SA602A)]	93C56(16bit)
93C56(16bit)@SOIC8 [(SA602A)]	93C56A(08bit)
93C56A(08bit)@DFN8 [(BBBB)]	93C56A(08bit)@MSOP8 [(SA666)]
93C56A(08bit)@SOIC8 [(SA602A)]	93C56A(08bit)@SOT-23 [(SA717)]
93C56A(08bit)@TSSOP8 [(SA026)]	93C56B(16bit)
93C56B(16bit)@DFN8 [(BBBB)]	93C56B(16bit)@MSOP8 [(SA666)]
93C56B(16bit)@SOIC8 [(SA602A)]	93C56B(16bit)@SOT-23 [(SA717)]
93C56B(16bit)@TSSOP8 [(SA026)]	93C56C(08bit)
93C56C(08bit)@DFN8 [(BBBB)]	93C56C(08bit)@MSOP8 [(SA666)]
93C56C(08bit)@SOIC8 [(SA602A)]	93C56C(08bit)@TSSOP8 [(SA026)]
93C56C(16bit)	93C56C(16bit)@DFN8 [(BBBB)]
93C56C(16bit)@MSOP8 [(SA666)]	93C56C(16bit)@SOIC8 [(SA602A)]
93C56C(16bit)@TSSOP8 [(SA026)]	93C66(08bit)
93C66(08bit)@SOIC8 [(SA602A)]	93C66(16bit)
93C66(16bit)@SOIC8 [(SA602A)]	93C66A(08bit)
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8 [(SA666)]
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23 [(SA717)]
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B(16bit)
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8 [(SA666)]
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23 [(SA717)]
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C(08bit)
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8 [(SA666)]
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8 [(SA026)]
93C66C(16bit)	93C66C(16bit)@DFN8 [(BBBB)]
93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8 [(SA602A)]
93C66C(16bit)@TSSOP8 [(SA026)]	93C76(08bit)
93C76(08bit)@SOIC8 [(SA602A)]	93C76(16bit)
93C76(16bit)@SOIC8 [(SA602A)]	93C76A(08bit)
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8 [(SA666)]
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23 [(SA717)]
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B(16bit)
93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8 [(SA666)]
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23 [(SA717)]
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C(08bit)
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8 [(SA666)]
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8 [(SA026)]



93C76C(16bit)                    93C76C(16bit)@DFN8 [(BBBB)]  
 93C76C(16bit)@MSOP8 [(SA666)]    93C76C(16bit)@SOIC8 [(SA602A)]  
 93C76C(16bit)@TSSOP8 [(SA026)]    93C86(08bit)  
 93C86(08bit)@SOIC8 [(SA602A)]    93C86(16bit)  
 93C86(16bit)@SOIC8 [(SA602A)]    93C86A(08bit)  
 93C86A(08bit)@DFN8 [(BBBB)]    93C86A(08bit)@MSOP8 [(SSA666)]  
 93C86A(08bit)@SOIC8 [(SA602A)]    93C86A(08bit)@SOT-23 [(SA717)]  
 93C86A(08bit)@TSSOP8 [(SA026)]    93C86B(16bit)  
 93C86B(16bit)@DFN8 [(BBBB)]    93C86B(16bit)@MSOP8 [(SA666)]  
 93C86B(16bit)@SOIC8 [(SA602A)]    93C86B(16bit)@SOT-23 [(SA717)]  
 93C86B(16bit)@TSSOP8 [(SA026)]    93C86C(08bit)  
 93C86C(08bit)@DFN8 [(BBBB)]    93C86C(08bit)@MSOP8 [(SA666)]  
 93C86C(08bit)@SOIC8 [(SA602A)]    93C86C(08bit)@TSSOP8 [(SA026)]  
 93C86C(16bit)                    93C86C(16bit)@DFN8 [(BBBB)]  
 93C86C(16bit)@MSOP8 [(SA666)]    93C86C(16bit)@SOIC8 [(SA602A)]  
 93C86C(16bit)@TSSOP8 [(SA026)]    93LC46(08bit)  
 93LC46(08bit)@SOIC8 [(SA602A)]    93LC46(16bit)  
 93LC46(16bit)@SOIC8 [(SA602A)]    93LC46A(08bit)  
 93LC46A(08bit)@DFN8 [(BBBB)]    93LC46A(08bit)@MSOP8 [(SA666)]  
 93LC46A(08bit)@SOIC8 [(SA602A)]    93LC46A(08bit)@SOT-23 [(SA717)]  
 93LC46A(08bit)@TSSOP8 [(SA026)]    93LC46B(16bit)  
 93LC46B(16bit)@DFN8 [(BBBB)]    93LC46B(16bit)@MSOP8 [(SA666)]  
 93LC46B(16bit)@SOIC8 [(SA602A)]    93LC46B(16bit)@SOT-23 [(SA717)]  
 93LC46B(16bit)@TSSOP8 [(SA026)]    93LC46BX  
 93LC46BX@SOIC8 [(SA602A)]    93LC46C(08bit)  
 93LC46C(08bit)@DFN8 [(BBBB)]    93LC46C(08bit)@MSOP8 [(SA666)]  
 93LC46C(08bit)@SOIC8 [(SA602A)]    93LC46C(08bit)@TSSOP8 [(SA026)]  
 93LC46C(16bit)                    93LC46C(16bit)@DFN8 [(BBBB)]  
 93LC46C(16bit)@MSOP8 [(SA666)]    93LC46C(16bit)@SOIC8 [(SA602A)]  
 93LC46C(16bit)@TSSOP8 [(SA026)]    93LC56(08bit)  
 93LC56(08bit)@SOIC8 [(SA602A)]    93LC56(16bit)  
 93LC56(16bit)@SOIC8 [(SA602A)]    93LC56A(08bit)  
 93LC56A(08bit)@DFN8 [(BBBB)]    93LC56A(08bit)@MSOP8 [(SA666)]  
 93LC56A(08bit)@SOIC8 [(SA602A)]    93LC56A(08bit)@SOT-23 [(SA717)]  
 93LC56A(08bit)@TSSOP8 [(SA026)]    93LC56B(16bit)  
 93LC56B(16bit)@DFN8 [(BBBB)]    93LC56B(16bit)@MSOP8 [(SA666)]  
 93LC56B(16bit)@SOIC8 [(SA602A)]    93LC56B(16bit)@SOT-23 [(SA717)]  
 93LC56B(16bit)@TSSOP8 [(SA026)]    93LC56BX  
 93LC56BX@SOIC8 [(SA602A)]    93LC56C(08bit)  
 93LC56C(08bit)@DFN8 [(BBBB)]    93LC56C(08bit)@MSOP8 [(SA666)]  
 93LC56C(08bit)@SOIC8 [(SA602A)]    93LC56C(08bit)@TSSOP8 [(SA026)]  
 93LC56C(16bit)                    93LC56C(16bit)@DFN8 [(BBBB)]  
 93LC56C(16bit)@MSOP8 [(SA666)]    93LC56C(16bit)@SOIC8 [(SA602A)]

93LC56C(16bit)@TSSOP8 [(SA026)]	93LC66(08bit)
93LC66(08bit)@SOIC8 [(SA602A)]	93LC66(16bit)
93LC66(16bit)@SOIC8 [(SA602A)]	93LC66A(08bit)
93LC66A(08bit)@DFN8 [(BBBB)]	93LC66A(08bit)@MSOP8 [(SA666)]
93LC66A(08bit)@SOIC8 [(SA602A)]	93LC66A(08bit)@SOT-23 [(SA717)]
93LC66A(08bit)@TSSOP8 [(SA026)]	93LC66B(16bit)
93LC66B(16bit)@DFN8 [(BBBB)]	93LC66B(16bit)@MSOP8 [(SA666)]
93LC66B(16bit)@SOIC8 [(SA602A)]	93LC66B(16bit)@SOT-23 [(SA717)]
93LC66B(16bit)@TSSOP8 [(SA026)]	93LC66BX
93LC66BX@SOIC8 [(SA602A)]	93LC66C(08bit)
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8 [(SA666)]
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8 [(SA026)]
93LC66C(16bit)	93LC66C(16bit)@DFN8 [(BBBB)]
93LC66C(16bit)@MSOP8 [(SA666)]	93LC66C(16bit)@SOIC8 [(SA602A)]
93LC66C(16bit)@TSSOP8 [(SA026)]	93LC76(08bit)
93LC76(08bit)@SOIC8 [(SA602A)]	93LC76(16bit)
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A(08bit)
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8 [(SA666)]
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23 [(SA717)]
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B(16bit)
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8 [(SA666)]
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23 [(SA717)]
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C(08bit)
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8 [(SA666)]
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8 [(SA026)]
93LC76C(16bit)	93LC76C(16bit)@DFN8 [(BBBB)]
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8 [(SA602A)]
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86(08bit)
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86(16bit)
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A(08bit)
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8 [(SSA666)]
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23 [(SA717)]
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B(16bit)
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8 [(SA666)]
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23 [(SA717)]
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C(08bit)
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8 [(SA666)]
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8 [(SA026)]
93LC86C(16bit)	93LC86C(16bit)@DFN8 [(BBBB)]
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8 [(SA602A)]
93LC86C(16bit)@TSSOP8 [(SA026)]	93LCS46
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8 [(SA602A)]
93LCS56	93LCS56@SOIC14 [(SA026)]

93LCS56@SOIC8 [(SA602A)]	93LCS66
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8 [(SA602A)]
ER5911	ER5911@SOIC8 [(SA602A)]
HCS101	HCS101SN@SOIC8 [(SA602A)]
HCS200	HCS200SN@SOIC8 [(SA602A)]
HCS300	HCS300SN@SOIC8 [(SA602A)]
HCS301	HCS301SN@SOIC8 [(SA602A)]
HCS320	HCS320SN@SOIC8 [(SA602A)]
HCS360	HCS360SN@SOIC8 [(SA602A)]
HCS361	HCS361SN@SOIC8 [(SA602A)]

## MICROCONTROLLER

MCP25020  
MCP25020(150mil)@SOIC14 [(SA602)]  
MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(208mil)@SOIC14 [(SA404)]  
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(ISP) [ISP-HEADER01] MCP25025  
MCP25025(150mil)@SOIC14 [(SA602)]  
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25025(208mil)@SOIC14 [(SA404)]  
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25025(ISP) [ISP-HEADER01] MCP25050  
MCP25050(150mil)@SOIC14 [(SA602)]  
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(208mil)@SOIC14 [(SA404)]  
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(ISP) [ISP-HEADER01] MCP25055  
MCP25055(150mil)@SOIC14 [(SA602)]  
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25055(208mil)@SOIC14 [(SA404)]  
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25055(ISP) [ISP-HEADER01] PIC10F200  
PIC10F200(ISP) [ISP-HEADER01] PIC10F200@SOT6 [(SA717)]  
PIC10F200@SOT6(ISP) [ISP-HEADER01]  
PIC10F202 PIC10F202(ISP) [ISP-HEADER01]  
PIC10F202@SOT6 [(SA717)]  
PIC10F202@SOT6(ISP) [ISP-HEADER01]  
PIC10F204 PIC10F204(ISP) [ISP-HEADER01]  
PIC10F204@SOT6 [(SA717)]  
PIC10F204@SOT6(ISP) [ISP-HEADER01]

PIC10F206 PIC10F206(ISP) [ISP-HEADER01]  
PIC10F206@SOT6 [(SA717)]  
PIC10F206@SOT6(ISP) [ISP-HEADER01]  
PIC10F220 PIC10F220(ISP) [ISP-HEADER01]  
PIC10F220@SOT6 [(SA717)]  
PIC10F220@SOT6(ISP) [ISP-HEADER01]  
PIC10F222 PIC10F222(ISP) [ISP-HEADER01]  
PIC10F222@SOT6 [(SA717)]  
PIC10F222@SOT6(ISP) [ISP-HEADER01]  
PIC12C508 PIC12C508(ISP) [ISP-HEADER01]  
PIC12C508@SOIC8 [(SA605A)]  
PIC12C508@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A PIC12C508A(ISP) [ISP-HEADER01]  
PIC12C508A(SM)@SOIC8 [(SA605A)]  
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A(SN)@SOIC8 [(SA602A)]  
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509 PIC12C509(ISP) [ISP-HEADER01]  
PIC12C509(SM)@SOIC8 [(SA605A)]  
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509(SN)@SOIC8 [(SA602A)]  
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A PIC12C509A(ISP) [ISP-HEADER01]  
PIC12C509A(SM)@SOIC8 [(SA605A)]  
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A(SN)@SOIC8 [(SA602A)]  
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A@DFN8 [(SA683)]  
PIC12C509A@DFN8(ISP) [ISP-HEADER01]  
PIC12C671 PIC12C671(ISP) [ISP-HEADER01]  
PIC12C671@DFN8 [(SA683)]  
PIC12C671@DFN8(ISP) [ISP-HEADER01]  
PIC12C671@SOIC8 [(SA605A)]  
PIC12C671@SOIC8(ISP) [ISP-HEADER01]  
PIC12C672 PIC12C672(ISP) [ISP-HEADER01]  
PIC12C672@DFN8 [(SA683)]  
PIC12C672@DFN8(ISP) [ISP-HEADER01]  
PIC12C672@SOIC8 [(SA605A)]  
PIC12C672@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE518 PIC12CE518(ISP) [ISP-HEADER01]  
PIC12CE518@SOIC8 [(SA605A)]  
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519 PIC12CE519(ISP) [ISP-HEADER01]

PIC12CE519(SM)@SOIC8 [(SA605A)]  
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519(SN)@SOIC8 [(SA602A)]  
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE673 PIC12CE673(ISP) [ISP-HEADER01]  
PIC12CE673@SOIC8 [(SA605A)]  
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE674 PIC12CE674(ISP) [ISP-HEADER01]  
PIC12CE674@SOIC8 [(SA605A)]  
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]  
PIC12F508 PIC12F508(ISP) [ISP-HEADER01]  
PIC12F508@MSOP8 [(SA666)]  
PIC12F508@MSOP8(ISP) [ISP-HEADER01]  
PIC12F508@SOIC8 [(SA602)]  
PIC12F508@SOIC8(ISP) [ISP-HEADER01]  
PIC12F509 PIC12F509(ISP) [ISP-HEADER01]  
PIC12F509@MSOP8 [(SA666)]  
PIC12F509@MSOP8(ISP) [ISP-HEADER01]  
PIC12F509@SOIC8 [(SA602)]  
PIC12F509@SOIC8(ISP) [ISP-HEADER01]  
PIC12F510 PIC12F510(ISP) [ISP-HEADER01]  
PIC12F510@MSOP8 [(SA666)]  
PIC12F510@MSOP8(ISP) [ISP-HEADER01]  
PIC12F510@SOIC8 [(SA605A)]  
PIC12F510@SOIC8(ISP) [ISP-HEADER01]  
PIC12F609 PIC12F609(ISP) [ISP-HEADER01]  
PIC12F609@DFN8 [(BBBB)]  
PIC12F609@DFN8(ISP) [ISP-HEADER01]  
PIC12F609@SOIC8 [(SA602A)]  
PIC12F609@SOIC8(ISP) [ISP-HEADER01]  
PIC12F615 PIC12F615(ISP) [ISP-HEADER01]  
PIC12F615@DFN8 [(BBBB)]  
PIC12F615@DFN8(ISP) [ISP-HEADER01]  
PIC12F615@SOIC8 [(SA602A)]  
PIC12F615@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629 PIC12F629(ISP) [ISP-HEADER01]  
PIC12F629(SM)@SOIC8 [(SA605A)]  
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629(SN)@SOIC8 [(SA602A)]  
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629@DFN8 [(SA683)]  
PIC12F629@DFN8(ISP) [ISP-HEADER01]  
PIC12F635 PIC12F635(ISP) [ISP-HEADER01]

PIC12F635(MD)@DFN8 [(SA744)]  
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(MF)@DFN8 [(SA683)]  
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(SM)@SOIC8 [(SA605A)]  
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F635(SN)@SOIC8 [(SA602A)]  
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675 PIC12F675(ISP) [ISP-HEADER01]  
PIC12F675(SM)@SOIC8 [(SA605A)]  
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675(SN)@SOIC8 [(SA602A)]  
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675@DFN8 [(SA683)]  
PIC12F675@DFN8(ISP) [ISP-HEADER01]  
PIC12F675@SSOP20 [(SA626A)]  
PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
PIC12F683 PIC12F683(ISP) [ISP-HEADER01]  
PIC12F683(MD)@DFN8 [(SA744)]  
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(MF)@DFN8 [(SA683)]  
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(SM)@SOIC8 [(SA605A)]  
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F683(SN)@SOIC8 [(SA602A)]  
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV609 PIC12HV609(ISP) [ISP-HEADER01]  
PIC12HV609@DFN8 [(BBBB)]  
PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
PIC12HV609@SOIC8 [(SA602A)]  
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV615 PIC12HV615(ISP) [ISP-HEADER01]  
PIC12HV615@DFN8 [(BBBB)]  
PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
PIC12HV615@SOIC8 [(SA602A)]  
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508 PIC12LC508(ISP) [ISP-HEADER01]  
PIC12LC508@SOIC8 [(SA605A)]  
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A PIC12LC508A(ISP) [ISP-HEADER01]  
PIC12LC508A(SM)@SOIC8 [(SA605A)]  
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A(SN)@SOIC8 [(SA602A)]

PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509 PIC12LC509(ISP) [ISP-HEADER01]  
PIC12LC509(SM)@SOIC8 [(SA605A)]  
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509(SN)@SOIC8 [(SA602A)]  
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A PIC12LC509A(ISP) [ISP-HEADER01]  
PIC12LC509A(SM)@SOIC8 [(SA605A)]  
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A(SN)@SOIC8 [(SA602A)]  
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC671 PIC12LC671(ISP) [ISP-HEADER01]  
PIC12LC671@DFN8 [(SA683)]  
PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
PIC12LC671@SOIC8 [(SA605A)]  
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC672 PIC12LC672(ISP) [ISP-HEADER01]  
PIC12LC672@DFN8 [(SA683)]  
PIC12LC672@DFN8(ISP) [ISP-HEADER01]  
PIC12LC672@SOIC8 [(SA605A)]  
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF508 PIC12LF508(ISP) [ISP-HEADER01]  
PIC12LF508@MSOP8 [(SA666)]  
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF508@SOIC8 [(SA602)]  
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF509 PIC12LF509(ISP) [ISP-HEADER01]  
PIC12LF509@MSOP8 [(SA666)]  
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF509@SOIC8 [(SA602)]  
PIC12LF509@SOIC8(ISP) [ISP-HEADER01]  
PIC14000 PIC14000(ISP) [ISP-HEADER01]  
PIC14000@SOIC28 [(SA404)]  
PIC14000@SOIC28(ISP) [ISP-HEADER01]  
PIC14000@SSOP28 [(SA626A)]  
PIC14000@SSOP28(ISP) [ISP-HEADER01]  
PIC16C432 PIC16C432(ISP) [ISP-HEADER01]  
PIC16C432@SSOP20 [(SA626A)]  
PIC16C432@SSOP20(ISP) [ISP-HEADER01]  
PIC16C433 PIC16C433(ISP) [ISP-HEADER01]  
PIC16C433@SOIC18 [(SA404)]  
PIC16C433@SOIC18(ISP) [ISP-HEADER01]  
PIC16C505 PIC16C505@SOIC14 [(SA602)]

PIC16C52 PIC16C52@SOIC18 [(SA404)]  
PIC16C54 PIC16C54@SOIC18 [(SA404)]  
PIC16C54A PIC16C54A@SOIC18 [(SA404)]  
PIC16C54A@SSOP20 [(SA626A)] PIC16C54B  
PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20 [(SA626A)]  
PIC16C54C PIC16C54C@SOIC18 [(SA404)]  
PIC16C54C@SSOP20 [(SA626A)] PIC16C55  
PIC16C55@SOIC28 [(SA404)] PIC16C554  
PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18 [(SA404)]  
PIC16C554@SOIC18(ISP) [ISP-HEADER01]  
PIC16C554@SSOP20 [(SA626A)]  
PIC16C554@SSOP20(ISP) [ISP-HEADER01]  
PIC16C556 PIC16C556(ISP) [ISP-HEADER01]  
PIC16C556@SOIC18 [(SA404)]  
PIC16C556@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558 PIC16C558(ISP) [ISP-HEADER01]  
PIC16C558@SOIC18 [(SA404)]  
PIC16C558@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558@SSOP20 [(SA626A)]  
PIC16C558@SSOP20(ISP) [ISP-HEADER01]  
PIC16C55A PIC16C55A@SOIC28 [(SA404)]  
PIC16C55A@SSOP28 [(SA626A)] PIC16C56  
PIC16C56@SOIC18 [(SA404)] PIC16C56A  
PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20 [(SA626A)]  
PIC16C57 PIC16C57@SOIC28 [(SA404)]  
PIC16C57@SSOP28 [(SA626A)] PIC16C57C  
PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28 [(SA626A)]  
PIC16C58 PIC16C58@SOIC18 [(SA404)]  
PIC16C58A PIC16C58A@SOIC18 [(SA404)]  
PIC16C58A@SSOP20 [(SA626A)] PIC16C58B  
PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20 [(SA626A)]  
PIC16C61 PIC16C61(ISP) [ISP-HEADER01]  
PIC16C61@SOIC18 [(SA404)]  
PIC16C61@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62 PIC16C62(ISP) [ISP-HEADER01]  
PIC16C62@SOIC28 [(SA404)]  
PIC16C62@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62@SSOP28 [(SA626A)]  
PIC16C62@SSOP28(ISP) [ISP-HEADER01]  
PIC16C620 PIC16C620(ISP) [ISP-HEADER01]  
PIC16C620@SOIC18 [(SA404)]  
PIC16C620@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A PIC16C620A(ISP) [ISP-HEADER01]



PIC16C620A@SOIC18 [(SA404)]  
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A@SSOP20 [(SA626A)]  
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C621 PIC16C621(ISP) [ISP-HEADER01]  
PIC16C621@SOIC18 [(SA404)]  
PIC16C621@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A PIC16C621A(ISP) [ISP-HEADER01]  
PIC16C621A@SOIC18 [(SA404)]  
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A@SSOP20 [(SA626A)]  
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C622 PIC16C622(ISP) [ISP-HEADER01]  
PIC16C622@SOIC18 [(SA404)]  
PIC16C622@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A PIC16C622A(ISP) [ISP-HEADER01]  
PIC16C622A@SOIC18 [(SA404)]  
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A@SSOP20 [(SA626A)]  
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C625 PIC16C625(ISP) [ISP-HEADER01]  
PIC16C625@SOIC18 [(SA404)]  
PIC16C625@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62A PIC16C62A(ISP) [ISP-HEADER01]  
PIC16C62A@SOIC28 [(SA404)]  
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62A@SSOP28 [(SA626A)]  
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C62B PIC16C62B(ISP) [ISP-HEADER01]  
PIC16C62B@SOIC28 [(SA404)]  
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62B@SSOP28 [(SA626A)]  
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C63 PIC16C63(ISP) [ISP-HEADER01]  
PIC16C63@SOIC28 [(SA404)]  
PIC16C63@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A PIC16C63A(ISP) [ISP-HEADER01]  
PIC16C63A@SOIC28 [(SA404)]  
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A@SSOP28 [(SA626A)]  
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C64 PIC16C64(ISP) [ISP-HEADER01]  
PIC16C64@PLCC44 [(SA244)]

PIC16C64@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64@TQFP44 [(SA245A)]  
PIC16C64@TQFP44(ISP) [ISP-HEADER01]  
PIC16C641 PIC16C641@SOIC28 [(SA404)]  
PIC16C641@SSOP28 [(SA626A)] PIC16C642  
PIC16C642@SOIC28 [(SA404)] PIC16C642@SSOP28 [(SA626A)]  
PIC16C64A PIC16C64A(ISP) [ISP-HEADER01]  
PIC16C64A@PLCC44 [(SA244)]  
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64A@TQFP44 [(SA245A)]  
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65 PIC16C65(ISP) [ISP-HEADER01]  
PIC16C65@PLCC44 [(SA244)]  
PIC16C65@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65@TQFP44 [(SA245A)]  
PIC16C65@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65A PIC16C65A(ISP) [ISP-HEADER01]  
PIC16C65A@PLCC44 [(SA244)]  
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65A@TQFP44 [(SA245A)]  
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65B PIC16C65B(ISP) [ISP-HEADER01]  
PIC16C65B@PLCC44 [(SA244)]  
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65B@TQFP44 [(SA245A)]  
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C66 PIC16C66(ISP) [ISP-HEADER01]  
PIC16C66@SOIC28 [(SA404)]  
PIC16C66@SOIC28(ISP) [ISP-HEADER01]  
PIC16C661 PIC16C661@PLCC44 [(SA244)]  
PIC16C661@TQFP44 [(SA245A)] PIC16C662  
PIC16C662@PLCC44 [(SA244)] PIC16C662@TQFP44 [(SA245A)]  
PIC16C67 PIC16C67(ISP) [ISP-HEADER01]  
PIC16C67@PLCC44 [(SA244)]  
PIC16C67@PLCC44(ISP) [ISP-HEADER01]  
PIC16C67@TQFP44 [(SA245A)]  
PIC16C67@TQFP44(ISP) [ISP-HEADER01]  
PIC16C70 PIC16C70(ISP) [ISP-HEADER01]  
PIC16C70@SOIC18 [(SA404)]  
PIC16C70@SOIC18(ISP) [ISP-HEADER01]  
PIC16C71 PIC16C71(ISP) [ISP-HEADER01]  
PIC16C71@SOIC18 [(SA404)]  
PIC16C71@SOIC18(ISP) [ISP-HEADER01]

PIC16C710 PIC16C710(ISP) [ISP-HEADER01]  
PIC16C710@SOIC18 [(SA404)]  
PIC16C710@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710@SSOP20 [(SA626A)]  
PIC16C710@SSOP20(ISP) [ISP-HEADER01]  
PIC16C711 PIC16C711(ISP) [ISP-HEADER01]  
PIC16C711@SOIC18 [(SA404)]  
PIC16C711@SOIC18(ISP) [ISP-HEADER01]  
PIC16C711@SSOP20 [(SA626A)]  
PIC16C711@SSOP20(ISP) [ISP-HEADER01]  
PIC16C712 PIC16C712(ISP) [ISP-HEADER01]  
PIC16C712@SOIC18 [(SA404)]  
PIC16C712@SOIC18(ISP) [ISP-HEADER01]  
PIC16C712@SSOP20 [(SA626A)]  
PIC16C712@SSOP20(ISP) [ISP-HEADER01]  
PIC16C715 PIC16C715@SOIC18 [(SA404)]  
PIC16C715@SSOP20 [(SA626A)] PIC16C716  
PIC16C716(ISP) [ISP-HEADER01] PIC16C716@SOIC18 [(SA404)]  
PIC16C716@SOIC18(ISP) [ISP-HEADER01]  
PIC16C716@SSOP20 [(SA626A)]  
PIC16C716@SSOP20(ISP) [ISP-HEADER01]  
PIC16C717 PIC16C717(ISP) [ISP-HEADER01]  
PIC16C717@SOIC18 [(SA404)]  
PIC16C717@SOIC18(ISP) [ISP-HEADER01]  
PIC16C717@SSOP20 [(SA626A)]  
PIC16C717@SSOP20(ISP) [ISP-HEADER01]  
PIC16C71A PIC16C71A(ISP) [ISP-HEADER01]  
PIC16C71A@SOIC18 [(SA404)]  
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C72 PIC16C72(ISP) [ISP-HEADER01]  
PIC16C72@SOIC28 [(SA404)]  
PIC16C72@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72@SSOP28 [(SA626A)]  
PIC16C72@SSOP28(ISP) [ISP-HEADER01]  
PIC16C72A PIC16C72A(ISP) [ISP-HEADER01]  
PIC16C72A@SOIC28 [(SA404)]  
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72A@SSOP28 [(SA626A)]  
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C73 PIC16C73(ISP) [ISP-HEADER01]  
PIC16C73@SOIC28 [(SA404)]  
PIC16C73@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73A PIC16C73A(ISP) [ISP-HEADER01]

PIC16C73A@SOIC28 [(SA404)]  
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B PIC16C73B(ISP) [ISP-HEADER01]  
PIC16C73B@SOIC28 [(SA404)]  
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B@SSOP28 [(SA626A)]  
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C74 PIC16C74(ISP) [ISP-HEADER01]  
PIC16C74@PLCC44 [(SA244)]  
PIC16C74@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74@TQFP44 [(SA245A)]  
PIC16C74@TQFP44(ISP) [ISP-HEADER01]  
PIC16C745 PIC16C745(ISP) [ISP-HEADER01]  
PIC16C745@SOIC28 [(SA404)]  
PIC16C745@SOIC28(ISP) [ISP-HEADER01]  
PIC16C74A PIC16C74A(ISP) [ISP-HEADER01]  
PIC16C74A@PLCC44 [(SA244)]  
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74A@TQFP44 [(SA245A)]  
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C74B PIC16C74B(ISP) [ISP-HEADER01]  
PIC16C74B@MQFP44 [(SA675)]  
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16C74B@PLCC44 [(SA244)]  
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74B@TQFP44 [(SA245A)]  
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C76 PIC16C76(ISP) [ISP-HEADER01]  
PIC16C76@SOIC28 [(SA404)]  
PIC16C76@SOIC28(ISP) [ISP-HEADER01]  
PIC16C765 PIC16C765(ISP) [ISP-HEADER01]  
PIC16C765@PLCC44 [(SA244)]  
PIC16C765@PLCC44(ISP) [ISP-HEADER01]  
PIC16C765@TQFP44 [(SA245A)]  
PIC16C765@TQFP44(ISP) [ISP-HEADER01]  
PIC16C77 PIC16C77(ISP) [ISP-HEADER01]  
PIC16C77@PLCC44 [(SA244)]  
PIC16C77@PLCC44(ISP) [ISP-HEADER01]  
PIC16C77@TQFP44 [(SA245A)]  
PIC16C77@TQFP44(ISP) [ISP-HEADER01]  
PIC16C770 PIC16C770(ISP) [ISP-HEADER01]  
PIC16C770@SOIC20 [(SA404)]  
PIC16C770@SOIC20(ISP) [ISP-HEADER01]

PIC16C770@SSOP20 [(SA626A)]  
PIC16C770@SSOP20(ISP) [ISP-HEADER01]  
PIC16C771 PIC16C771(ISP) [ISP-HEADER01]  
PIC16C771@SOIC20 [(SA404)]  
PIC16C771@SOIC20(ISP) [ISP-HEADER01]  
PIC16C771@SSOP20 [(SA626A)]  
PIC16C771@SSOP20(ISP) [ISP-HEADER01]  
PIC16C773 PIC16C773(ISP) [ISP-HEADER01]  
PIC16C773@SOIC28 [(SA404)]  
PIC16C773@SOIC28(ISP) [ISP-HEADER01]  
PIC16C773@SSOP28 [(SA626A)]  
PIC16C773@SSOP28(ISP) [ISP-HEADER01]  
PIC16C774 PIC16C774(ISP) [ISP-HEADER01]  
PIC16C774@PLCC44 [(SA244)]  
PIC16C774@PLCC44(ISP) [ISP-HEADER01]  
PIC16C774@TQFP44 [(SA675)]  
PIC16C774@TQFP44(ISP) [ISP-HEADER01]  
PIC16C781 PIC16C781(ISP) [ISP-HEADER01]  
PIC16C781@SOIC20 [(SA404)]  
PIC16C781@SOIC20(ISP) [ISP-HEADER01]  
PIC16C781@SSOP20 [(SA626A)]  
PIC16C781@SSOP20(ISP) [ISP-HEADER01]  
PIC16C782 PIC16C782(ISP) [ISP-HEADER01]  
PIC16C782@SOIC20 [(SA404)]  
PIC16C782@SOIC20(ISP) [ISP-HEADER01]  
PIC16C782@SSOP20 [(SA626A)]  
PIC16C782@SSOP20(ISP) [ISP-HEADER01]  
PIC16C84 PIC16C84(ISP) [ISP-HEADER01]  
PIC16C84@SOIC18 [(SA404)]  
PIC16C84@SOIC18(ISP) [ISP-HEADER01]  
PIC16C923@PLCC68(\*) [(SA648-B6807)]  
PIC16C923@PLCC68(ISP) [ISP-HEADER01]  
PIC16C923@SDIP64(ISP) [ISP-HEADER01]  
PIC16C923@TQFP64(ISP) [ISP-HEADER01]  
PIC16C924@PLCC68(\*) [(SA648-B6807)]  
PIC16C924@PLCC68(ISP) [ISP-HEADER01]  
PIC16C924@SDIP64(ISP) [ISP-HEADER01]  
PIC16C924@TQFP64(ISP) [ISP-HEADER01]  
PIC16C925@PLCC68(\*) [(SA648-B6807)]  
PIC16C925@PLCC68(ISP) [ISP-HEADER01]  
PIC16C925@TQFP64(ISP) [ISP-HEADER01]  
PIC16C926@PLCC68(\*) [(SA648-B6807)]  
PIC16C926@PLCC68(ISP) [ISP-HEADER01]

PIC16C926@TQFP64(ISP) [ISP-HEADER01]  
PIC16CE623 PIC16CE623(ISP) [ISP-HEADER01]  
PIC16CE623@SOIC18 [(SA404)]  
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE624 PIC16CE624(ISP) [ISP-HEADER01]  
PIC16CE624@SOIC18 [(SA404)]  
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625 PIC16CE625(ISP) [ISP-HEADER01]  
PIC16CE625@SOIC18 [(SA404)]  
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625@SSOP20 [(SA626A)]  
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]  
PIC16CR83 PIC16CR83(ISP) [ISP-HEADER01]  
PIC16CR83@SOIC18 [(SA404)]  
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]  
PIC16CR84 PIC16CR84(ISP) [ISP-HEADER01]  
PIC16CR84@SOIC18 [(SA404)]  
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F505 PIC16F505(ISP) [ISP-HEADER01]  
PIC16F505@SOIC14 [(SA602)]  
PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
PIC16F505@TSSOP14 [(SA026)]  
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F506 PIC16F506(ISP) [ISP-HEADER01]  
PIC16F506@SOIC14 [(SA602)]  
PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
PIC16F506@TSSOP14 [(SA026)]  
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F526 PIC16F526@SOIC14 [(SA602)]  
PIC16F526@TSSOP14 [(SA026)] PIC16F54  
PIC16F54(ISP) [ISP-HEADER01] PIC16F54@SOIC18 [(SA404)]  
PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
PIC16F54@SSOP20 [(SA626A)]  
PIC16F54@SSOP20(ISP) [ISP-HEADER01]  
PIC16F57 PIC16F57(ISP) [ISP-HEADER01]  
PIC16F57@SOIC28 [(SA404)]  
PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
PIC16F57@SSOP28 [(SA626A)]  
PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
PIC16F59 PIC16F59(ISP) [ISP-HEADER01]  
PIC16F59@PLCC44 [(SA244)]  
PIC16F59@PLCC44(ISP) [ISP-HEADER01]  
PIC16F59@TQFP44 [(SA245A)]

PIC16F59@TQFP44(ISP) [ISP-HEADER01]  
PIC16F610 PIC16F610(ISP) [ISP-HEADER01]  
PIC16F610@QFN16 [(SA727)]  
PIC16F610@QFN16(ISP) [ISP-HEADER01]  
PIC16F610@SOIC14 [(SA602)]  
PIC16F610@SOIC14(ISP) [ISP-HEADER01]  
PIC16F610@TSSOP14 [(SA026)]  
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F616 PIC16F616(ISP) [ISP-HEADER01]  
PIC16F616@QFN16 [(SA727)]  
PIC16F616@QFN16(ISP) [ISP-HEADER01]  
PIC16F616@SOIC14 [(SA602)]  
PIC16F616@SOIC14(ISP) [ISP-HEADER01]  
PIC16F616@TSSOP14 [(SA026)]  
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F627 PIC16F627(ISP) [ISP-HEADER01]  
PIC16F627@SOIC18 [(SA404)]  
PIC16F627@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627@SSOP20 [(SA626A)]  
PIC16F627@SSOP20(ISP) [ISP-HEADER01]  
PIC16F627A PIC16F627A(ISP) [ISP-HEADER01]  
PIC16F627A@SOIC18 [(SA404)]  
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627A@SSOP20 [(SA626A)]  
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628 PIC16F628(ISP) [ISP-HEADER01]  
PIC16F628@SOIC18 [(SA404)]  
PIC16F628@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628@SSOP20 [(SA626A)]  
PIC16F628@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628A PIC16F628A(ISP) [ISP-HEADER01]  
PIC16F628A@SOIC18 [(SA404)]  
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628A@SSOP20 [(SA626A)]  
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F630 PIC16F630(ISP) [ISP-HEADER01]  
PIC16F630@SOIC14 [(SA602)]  
PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
PIC16F630@TSSOP14 [(SA026)]  
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F631 PIC16F631(ISP) [ISP-HEADER01]  
PIC16F631@QFN20 [(SA692)]  
PIC16F631@QFN20(ISP) [ISP-HEADER01]

PIC16F631@SOIC20 [(SA404)]  
PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
PIC16F631@SSOP20 [(SA626A)]  
PIC16F631@SSOP20(ISP) [ISP-HEADER01]  
PIC16F636 PIC16F636(ISP) [ISP-HEADER01]  
PIC16F636@QFN16 [(SA727)]  
PIC16F636@QFN16(ISP) [ISP-HEADER01]  
PIC16F636@SOIC14 [(SA602)]  
PIC16F636@SOIC14(ISP) [ISP-HEADER01]  
PIC16F636@TSSOP14 [(SA026)]  
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F639 PIC16F639(ISP) [ISP-HEADER01]  
PIC16F639@QFN20 [(SA692)]  
PIC16F639@QFN20(ISP) [ISP-HEADER01]  
PIC16F639@SOIC20 [(SA404)]  
PIC16F639@SOIC20(ISP) [ISP-HEADER01]  
PIC16F639@SSOP20 [(SA626A)]  
PIC16F639@SSOP20(ISP) [ISP-HEADER01]  
PIC16F648A PIC16F648A(ISP) [ISP-HEADER01]  
PIC16F648A@SOIC18 [(SA404)]  
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F648A@SSOP20 [(SA626A)]  
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F676 PIC16F676(ISP) [ISP-HEADER01]  
PIC16F676@SOIC14 [(SA602)]  
PIC16F676@SOIC14(ISP) [ISP-HEADER01]  
PIC16F676@TSSOP14 [(SA026)]  
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F677 PIC16F677(ISP) [ISP-HEADER01]  
PIC16F677@QFN20 [(SA692)]  
PIC16F677@QFN20(ISP) [ISP-HEADER01]  
PIC16F677@SOIC20 [(SA404)]  
PIC16F677@SOIC20(ISP) [ISP-HEADER01]  
PIC16F677@SSOP20 [(SA626A)]  
PIC16F677@SSOP20(ISP) [ISP-HEADER01]  
PIC16F684 PIC16F684(ISP) [ISP-HEADER01]  
PIC16F684@QFN16 [(SA727)]  
PIC16F684@QFN16(ISP) [ISP-HEADER01]  
PIC16F684@SOIC14 [(SA602)]  
PIC16F684@SOIC14(ISP) [ISP-HEADER01]  
PIC16F684@TSSOP14 [(SA026)]  
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F685 PIC16F685(ISP) [ISP-HEADER01]



PIC16F685@QFN20 [(SA692)]  
PIC16F685@QFN20(ISP) [ISP-HEADER01]  
PIC16F685@SOIC20 [(SA404)]  
PIC16F685@SOIC20(ISP) [ISP-HEADER01]  
PIC16F685@SSOP20 [(SA626A)]  
PIC16F685@SSOP20(ISP) [ISP-HEADER01]  
PIC16F687 PIC16F687(ISP) [ISP-HEADER01]  
PIC16F687@QFN20 [(SA692)]  
PIC16F687@QFN20(ISP) [ISP-HEADER01]  
PIC16F687@SOIC20 [(SA404)]  
PIC16F687@SOIC20(ISP) [ISP-HEADER01]  
PIC16F687@SSOP20 [(SA626A)]  
PIC16F687@SSOP20(ISP) [ISP-HEADER01]  
PIC16F688 PIC16F688(ISP) [ISP-HEADER01]  
PIC16F688@QFN16 [(SA727)]  
PIC16F688@QFN16(ISP) [ISP-HEADER01]  
PIC16F688@SOIC14 [(SA602)]  
PIC16F688@SOIC14(ISP) [ISP-HEADER01]  
PIC16F688@TSSOP14 [(SA026)]  
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F689 PIC16F689(ISP) [ISP-HEADER01]  
PIC16F689@QFN20 [(SA692)]  
PIC16F689@QFN20(ISP) [ISP-HEADER01]  
PIC16F689@SOIC20 [(SA404)]  
PIC16F689@SOIC20(ISP) [ISP-HEADER01]  
PIC16F689@SSOP20 [(SA626A)]  
PIC16F689@SSOP20(ISP) [ISP-HEADER01]  
PIC16F690 PIC16F690(ISP) [ISP-HEADER01]  
PIC16F690@QFN20 [(SA692)]  
PIC16F690@QFN20(ISP) [ISP-HEADER01]  
PIC16F690@SOIC20 [(SA404)]  
PIC16F690@SOIC20(ISP) [ISP-HEADER01]  
PIC16F690@SSOP20 [(SA626A)]  
PIC16F690@SSOP20(ISP) [ISP-HEADER01]  
PIC16F716 PIC16F716(ISP) [ISP-HEADER01]  
PIC16F716@SOIC18 [(SA404)]  
PIC16F716@SOIC18(ISP) [ISP-HEADER01]  
PIC16F716@SSOP20 [(SA626A)]  
PIC16F716@SSOP20(ISP) [ISP-HEADER01]  
PIC16F72 PIC16F72(ISP) [ISP-HEADER01]  
PIC16F72@QFN28 [(SA685-B006)]  
PIC16F72@QFN28(ISP) [ISP-HEADER01]  
PIC16F72@SOIC28 [(SA404)]

PIC16F72@SOIC28(ISP) [ISP-HEADER01]  
PIC16F72@SSOP28 [(SA626A)]  
PIC16F72@SSOP28(ISP) [ISP-HEADER01]  
PIC16F722 PIC16F722@QFN28 [(SA685-B006)]  
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28 [(SA626A)]  
PIC16F723 PIC16F723@QFN28 [(SA685-B006)]  
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28 [(SA626A)]  
PIC16F724 PIC16F724@QFN44 [(SA737)]  
PIC16F724@TQFP44 [(SA245A)] PIC16F726  
PIC16F726@QFN28 [(SA685-B006)] PIC16F726@SOIC28 [(SA404)]  
PIC16F726@SSOP28 [(SA626A)] PIC16F727  
PIC16F727@QFN44 [(SA737)] PIC16F727@TQFP44 [(SA245A)]  
PIC16F73 PIC16F73(ISP) [ISP-HEADER01]  
PIC16F73@SOIC28 [(SA404)]  
PIC16F73@SOIC28(ISP) [ISP-HEADER01]  
PIC16F73@SSOP28 [(SA626A)]  
PIC16F73@SSOP28(ISP) [ISP-HEADER01]  
PIC16F737 PIC16F737(ISP) [ISP-HEADER01]  
PIC16F737@SOIC28 [(SA404)]  
PIC16F737@SOIC28(ISP) [ISP-HEADER01]  
PIC16F737@SSOP28 [(SA626A)]  
PIC16F737@SSOP28(ISP) [ISP-HEADER01]  
PIC16F74 PIC16F74(ISP) [ISP-HEADER01]  
PIC16F74@PLCC44 [(SA244)]  
PIC16F74@PLCC44(ISP) [ISP-HEADER01]  
PIC16F74@TQFP44 [(SA245A)]  
PIC16F74@TQFP44(ISP) [ISP-HEADER01]  
PIC16F747 PIC16F747(ISP) [ISP-HEADER01]  
PIC16F747@TQFP44 [(SA245A)]  
PIC16F747@TQFP44(ISP) [ISP-HEADER01]  
PIC16F76 PIC16F76(ISP) [ISP-HEADER01]  
PIC16F76@SOIC28 [(SA404)]  
PIC16F76@SOIC28(ISP) [ISP-HEADER01]  
PIC16F76@SSOP28 [(SA626A)]  
PIC16F76@SSOP28(ISP) [ISP-HEADER01]  
PIC16F767 PIC16F767(ISP) [ISP-HEADER01]  
PIC16F767@SOIC28 [(SA404)]  
PIC16F767@SOIC28(ISP) [ISP-HEADER01]  
PIC16F767@SSOP28 [(SA626A)]  
PIC16F767@SSOP28(ISP) [ISP-HEADER01]  
PIC16F77 PIC16F77(ISP) [ISP-HEADER01]  
PIC16F77@PLCC44 [(SA244)]  
PIC16F77@PLCC44(ISP) [ISP-HEADER01]

PIC16F77@TQFP44 [(SA245A)]  
PIC16F77@TQFP44(ISP) [ISP-HEADER01]  
PIC16F777 PIC16F777(ISP) [ISP-HEADER01]  
PIC16F777@TQFP44 [(SA245A)]  
PIC16F777@TQFP44(ISP) [ISP-HEADER01]  
PIC16F785 PIC16F785(ISP) [ISP-HEADER01]  
PIC16F785@QFN20 [(SA692)]  
PIC16F785@QFN20(ISP) [ISP-HEADER01]  
PIC16F785@SOIC20 [(SA404)]  
PIC16F785@SOIC20(ISP) [ISP-HEADER01]  
PIC16F785@SSOP20 [(SA626A)]  
PIC16F785@SSOP20(ISP) [ISP-HEADER01]  
PIC16F818 PIC16F818(ISP) [ISP-HEADER01]  
PIC16F818@QFN28 [(SA685-B006)]  
PIC16F818@QFN28(ISP) [ISP-HEADER01]  
PIC16F818@SOIC18 [(SA404)]  
PIC16F818@SOIC18(ISP) [ISP-HEADER01]  
PIC16F818@SSOP20 [(SA626A)]  
PIC16F818@SSOP20(ISP) [ISP-HEADER01]  
PIC16F819 PIC16F819(ISP) [ISP-HEADER01]  
PIC16F819@QFN28 [(SA685-B006)]  
PIC16F819@QFN28(ISP) [ISP-HEADER01]  
PIC16F819@SOIC18 [(SA404)]  
PIC16F819@SOIC18(ISP) [ISP-HEADER01]  
PIC16F819@SSOP20 [(SA626A)]  
PIC16F819@SSOP20(ISP) [ISP-HEADER01]  
PIC16F83 PIC16F83(ISP) [ISP-HEADER01]  
PIC16F83@SOIC18 [(SA404)]  
PIC16F83@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84 PIC16F84(ISP) [ISP-HEADER01]  
PIC16F84@SOIC18 [(SA404)]  
PIC16F84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A PIC16F84A(ISP) [ISP-HEADER01]  
PIC16F84A@SOIC18 [(SA404)]  
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A@SSOP20 [(SA626A)]  
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F87 PIC16F87(ISP) [ISP-HEADER01]  
PIC16F87@QFN28 [(SA685-B006)]  
PIC16F87@QFN28(ISP) [ISP-HEADER01]  
PIC16F87@SOIC18 [(SA404)]  
PIC16F87@SOIC18(ISP) [ISP-HEADER01]  
PIC16F87@SSOP20 [(SA626A)]

PIC16F87@SSOP20(ISP) [ISP-HEADER01]  
PIC16F870 PIC16F870(ISP) [ISP-HEADER01]  
PIC16F870@SOIC28 [(SA404)]  
PIC16F870@SOIC28(ISP) [ISP-HEADER01]  
PIC16F870@SSOP28 [(SA626A)]  
PIC16F870@SSOP28(ISP) [ISP-HEADER01]  
PIC16F871 PIC16F871(ISP) [ISP-HEADER01]  
PIC16F871@PLCC44 [(SA244)]  
PIC16F871@PLCC44(ISP) [ISP-HEADER01]  
PIC16F871@TQFP44 [(SA245A)]  
PIC16F871@TQFP44(ISP) [ISP-HEADER01]  
PIC16F872 PIC16F872(ISP) [ISP-HEADER01]  
PIC16F872@SOIC28 [(SA404)]  
PIC16F872@SOIC28(ISP) [ISP-HEADER01]  
PIC16F872@SSOP28 [(SA626A)]  
PIC16F872@SSOP28(ISP) [ISP-HEADER01]  
PIC16F873 PIC16F873(ISP) [ISP-HEADER01]  
PIC16F873@SOIC28 [(SA404)]  
PIC16F873@SOIC28(ISP) [ISP-HEADER01]  
PIC16F873A  
PIC16F873A(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@QFN28 [(SA697-B006)]  
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SOIC28 [(SA404)]  
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SSOP28 [(SA626A)]  
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874 PIC16F874(ISP) [ISP-HEADER01]  
PIC16F874@PLCC44 [(SA244)]  
PIC16F874@PLCC44(ISP) [ISP-HEADER01]  
PIC16F874@TQFP44 [(SA245A)]

PIC16F874@TQFP44(ISP) [ISP-HEADER01]  
PIC16F874A  
PIC16F874A(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@PLCC44 [(SA244)]  
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@TQFP44 [(SA245A)]  
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876                    PIC16F876(ISP) [ISP-HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28(ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877                    PIC16F877(ISP) [ISP-HEADER01]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]

PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F88                    PIC16F88(ISP) [ISP-HEADER01]  
PIC16F88@QFN28 [(SA685-B006)]  
PIC16F88@QFN28(ISP) [ISP-HEADER01]  
PIC16F88@SOIC18 [(SA404)]  
PIC16F88@SOIC18(ISP) [ISP-HEADER01]  
PIC16F88@SSOP20 [(SA626A)]  
PIC16F88@SSOP20(ISP) [ISP-HEADER01]  
PIC16F882  
PIC16F882(ISP)(High-V) [ISP-HEADER01]  
PIC16F882(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@QFN28 [(SA697-B005)]  
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SOIC28 [(SA404)]  
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SSOP28 [(SA626A)]  
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883  
PIC16F883(ISP)(High-V) [ISP-HEADER01]  
PIC16F883(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@QFN28 [(SA697-B005)]  
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SOIC28 [(SA404)]  
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SSOP28 [(SA626A)]  
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884  
PIC16F884(ISP)(High-V) [ISP-HEADER01]  
PIC16F884(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44 [(SA712)]  
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML) [(SA737)]  
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@TQFP44 [(SA245A)]  
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886  
PIC16F886(ISP)(High-V) [ISP-HEADER01]  
PIC16F886(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@QFN28 [(SA697-B005)]  
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SOIC28 [(SA404)]  
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SSOP28 [(SA626A)]  
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887  
PIC16F887(ISP)(High-V) [ISP-HEADER01]  
PIC16F887(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44 [(SA712)]  
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML) [(SA737)]  
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@TQFP44 [(SA245A)]  
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F913                    PIC16F913(ISP) [ISP-HEADER01]  
PIC16F913@QFN28 [(SA697-B006)]  
PIC16F913@QFN28(ISP) [ISP-HEADER01]

PIC16F913@SOIC28 [(SA404)]  
PIC16F913@SOIC28(ISP) [ISP-HEADER01]  
PIC16F913@SSOP28 [(SA626A)]  
PIC16F913@SSOP28(ISP) [ISP-HEADER01]  
PIC16F914 PIC16F914(ISP) [ISP-HEADER01]  
PIC16F914@QFN44 [(SA712)]  
PIC16F914@QFN44(ISP) [ISP-HEADER01]  
PIC16F914@QFN44(ML) [(SA737)]  
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F914@TQFP44 [(SA245A)]  
PIC16F914@TQFP44(ISP) [ISP-HEADER01]  
PIC16F916 PIC16F916(ISP) [ISP-HEADER01]  
PIC16F916@QFN28 [(SA697-B006)]  
PIC16F916@QFN28(ISP) [ISP-HEADER01]  
PIC16F916@SOIC28 [(SA404)]  
PIC16F916@SOIC28(ISP) [ISP-HEADER01]  
PIC16F916@SSOP28 [(SA626A)]  
PIC16F916@SSOP28(ISP) [ISP-HEADER01]  
PIC16F917 PIC16F917(ISP) [ISP-HEADER01]  
PIC16F917@QFN44 [(SA712)]  
PIC16F917@QFN44(ISP) [ISP-HEADER01]  
PIC16F917@QFN44(ML) [(SA737)]  
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F917@TQFP44 [(SA245A)]  
PIC16F917@TQFP44(ISP) [ISP-HEADER01]  
PIC16F946@TQFP64(ISP) [ISP-HEADER01]  
PIC16HV540 PIC16HV540@SOIC18 [(SA404)]  
PIC16HV540@SSOP20 [(SA626A)] PIC16HV610  
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16 [(SA727)]  
PIC16HV610@QFN16(ISP) [ISP-HEADER01]  
PIC16HV610@SOIC14 [(SA602)]  
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV610@TSSOP14 [(SA026)]  
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV616 PIC16HV616(ISP) [ISP-HEADER01]  
PIC16HV616@QFN16 [(SA727)]  
PIC16HV616@QFN16(ISP) [ISP-HEADER01]  
PIC16HV616@SOIC14 [(SA602)]  
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV616@TSSOP14 [(SA026)]  
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV785 PIC16HV785(ISP) [ISP-HEADER01]  
PIC16HV785@QFN20 [(SA692)]



PIC16HV785@QFN20(ISP) [ISP-HEADER01]  
PIC16HV785@SOIC20 [(SA404)]  
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]  
PIC16HV785@SSOP20 [(SA626A)]  
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC505 PIC16LC505@SOIC14 [(SA602)]  
PIC16LC54A PIC16LC54A@SOIC18 [(SA404)]  
PIC16LC54A@SSOP20 [(SA626A)] PIC16LC54C  
PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20 [(SA626A)]  
PIC16LC554 PIC16LC554(ISP) [ISP-HEADER01]  
PIC16LC554@SOIC18 [(SA404)]  
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC558 PIC16LC558(ISP) [ISP-HEADER01]  
PIC16LC558@SOIC18 [(SA404)]  
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC56A PIC16LC56A@SOIC18 [(SA404)]  
PIC16LC56A@SSOP20 [(SA626A)] PIC16LC58A  
PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20 [(SA626A)]  
PIC16LC58B PIC16LC58B@SOIC18 [(SA404)]  
PIC16LC58B@SSOP20 [(SA626A)] PIC16LC620  
PIC16LC620(ISP) [ISP-HEADER01] PIC16LC620@SOIC18 [(SA404)]  
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A PIC16LC620A(ISP) [ISP-HEADER01]  
PIC16LC620A@SOIC18 [(SA404)]  
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A@SSOP20 [(SA626A)]  
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC621A PIC16LC621A(ISP) [ISP-HEADER01]  
PIC16LC621A@SOIC18 [(SA404)]  
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC621A@SSOP20 [(SA626A)]  
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC622 PIC16LC622(ISP) [ISP-HEADER01]  
PIC16LC622@SOIC18 [(SA404)]  
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC62A PIC16LC62A(ISP) [ISP-HEADER01]  
PIC16LC62A@SOIC28 [(SA404)]  
PIC16LC62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC62A@SSOP28 [(SA626A)]  
PIC16LC62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC62B PIC16LC62B(ISP) [ISP-HEADER01]  
PIC16LC62B@SOIC28 [(SA404)]  
PIC16LC62B@SOIC28(ISP) [ISP-HEADER01]

PIC16LC62B@SSOP28 [(SA626A)]  
PIC16LC62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC63 PIC16LC63(ISP) [ISP-HEADER01]  
PIC16LC63@SOIC28 [(SA404)]  
PIC16LC63@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC63A PIC16LC63A(ISP) [ISP-HEADER01]  
PIC16LC63A@SOIC28 [(SA404)]  
PIC16LC63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC63A@SSOP28 [(SA626A)]  
PIC16LC63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC64A PIC16LC64A(ISP) [ISP-HEADER01]  
PIC16LC64A@PLCC44 [(SA244)]  
PIC16LC64A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC64A@TQFP44 [(SA245A)]  
PIC16LC64A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC65A PIC16LC65A(ISP) [ISP-HEADER01]  
PIC16LC65A@PLCC44 [(SA244)]  
PIC16LC65A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC65A@TQFP44 [(SA245A)]  
PIC16LC65A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC65B PIC16LC65B(ISP) [ISP-HEADER01]  
PIC16LC65B@PLCC44 [(SA244)]  
PIC16LC65B@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC65B@TQFP44 [(SA245A)]  
PIC16LC65B@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC66 PIC16LC66(ISP) [ISP-HEADER01]  
PIC16LC66@SOIC28 [(SA404)]  
PIC16LC66@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC67 PIC16LC67(ISP) [ISP-HEADER01]  
PIC16LC67@PLCC44 [(SA244)]  
PIC16LC67@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC67@TQFP44 [(SA245A)]  
PIC16LC67@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC71 PIC16LC71(ISP) [ISP-HEADER01]  
PIC16LC71@SOIC18 [(SA404)]  
PIC16LC71@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710 PIC16LC710(ISP) [ISP-HEADER01]  
PIC16LC710@SOIC18 [(SA404)]  
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710@SSOP20 [(SA626A)]  
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC711 PIC16LC711(ISP) [ISP-HEADER01]  
PIC16LC711@SOIC18 [(SA404)]

PIC16LC711@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC711@SSOP20 [(SA626A)]  
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC712                    PIC16LC712(ISP) [ISP-HEADER01]  
PIC16LC712@SOIC18 [(SA404)]  
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC712@SSOP20 [(SA626A)]  
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC715                    PIC16LC715@SOIC18 [(SA404)]  
PIC16LC716                    PIC16LC716(ISP) [ISP-HEADER01]  
PIC16LC716@SOIC18 [(SA404)]  
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717                    PIC16LC717(ISP) [ISP-HEADER01]  
PIC16LC717@SOIC18 [(SA404)]  
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC717@SSOP20 [(SA626A)]  
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC72                    PIC16LC72(ISP) [ISP-HEADER01]  
PIC16LC72@SOIC28 [(SA404)]  
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72@SSOP28 [(SA626A)]  
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC72A                    PIC16LC72A(ISP) [ISP-HEADER01]  
PIC16LC72A@SOIC28 [(SA404)]  
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72A@SSOP28 [(SA626A)]  
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC73A                    PIC16LC73A(ISP) [ISP-HEADER01]  
PIC16LC73A@SOIC28 [(SA404)]  
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B                    PIC16LC73B(ISP) [ISP-HEADER01]  
PIC16LC73B@SOIC28 [(SA404)]  
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B@SSOP28 [(SA626A)]  
PIC16LC73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC74                    PIC16LC74(ISP) [ISP-HEADER01]  
PIC16LC74@PLCC44 [(SA244)]  
PIC16LC74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74@TQFP44 [(SA245A)]  
PIC16LC74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74A                    PIC16LC74A(ISP) [ISP-HEADER01]

PIC16LC74A@PLCC44 [(SA244)]  
PIC16LC74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74A@TQFP44 [(SA245A)]  
PIC16LC74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74B PIC16LC74B(ISP) [ISP-HEADER01]  
PIC16LC74B@MQFP44 [(SA675)]  
PIC16LC74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16LC74B@PLCC44 [(SA244)]  
PIC16LC74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74B@TQFP44 [(SA245A)]  
PIC16LC74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC76 PIC16LC76(ISP) [ISP-HEADER01]  
PIC16LC76@SOIC28 [(SA404)]  
PIC16LC76@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC77 PIC16LC77(ISP) [ISP-HEADER01]  
PIC16LC77@PLCC44 [(SA244)]  
PIC16LC77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC773 PIC16LC773(ISP) [ISP-HEADER01]  
PIC16LC773@SOIC28 [(SA404)]  
PIC16LC773@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC773@SSOP28 [(SA626A)]  
PIC16LC773@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC774 PIC16LC774(ISP) [ISP-HEADER01]  
PIC16LC774@PLCC44 [(SA244)]  
PIC16LC774@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC774@TQFP44 [(SA675)]  
PIC16LC774@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC84 PIC16LC84(ISP) [ISP-HEADER01]  
PIC16LC84@SOIC18 [(SA404)]  
PIC16LC84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC923@PLCC68(\*) [(SA648-B6807)]  
PIC16LC923@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC923@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC923@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC924@PLCC68(\*) [(SA648-B6807)]  
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC925@PLCC68(\*) [(SA648-B6807)]  
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC926@PLCC68(\*) [(SA648-B6807)]  
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]

PIC16LC926@TQFP64(ISP) [ISP-HEADER01]  
PIC16LCE623@SOIC18 [(SA404)]  
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16LCE623@SSOP20 [(SA626A)]  
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF505 PIC16LF505(ISP) [ISP-HEADER01]  
PIC16LF505@SOIC14 [(SA602)]  
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF505@TSSOP14 [(SA026)]  
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF506 PIC16LF506(ISP) [ISP-HEADER01]  
PIC16LF506@SOIC14 [(SA602)]  
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF506@TSSOP14 [(SA026)]  
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF526 PIC16LF526@SOIC14 [(SA602)]  
PIC16LF526@TSSOP14 [(SA026)] PIC16LF54  
PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54@SOIC18 [(SA404)]  
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF54@SSOP20 [(SA626A)]  
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF57 PIC16LF57(ISP) [ISP-HEADER01]  
PIC16LF57@SOIC28 [(SA404)]  
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF57@SSOP28 [(SA626A)]  
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF59 PIC16LF59(ISP) [ISP-HEADER01]  
PIC16LF59@PLCC44 [(SA244)]  
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF59@TQFP44 [(SA245A)]  
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF627 PIC16LF627(ISP) [ISP-HEADER01]  
PIC16LF627@SOIC18 [(SA404)]  
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627@SSOP20 [(SA626A)]  
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF627A PIC16LF627A(ISP) [ISP-HEADER01]  
PIC16LF627A@SOIC18 [(SA404)]  
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627A@SSOP20 [(SA626A)]  
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628 PIC16LF628(ISP) [ISP-HEADER01]  
PIC16LF628@SOIC18 [(SA404)]

PIC16LF628@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628@SSOP20 [(SA626A)]  
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628A PIC16LF628A(ISP) [ISP-HEADER01]  
PIC16LF628A@SOIC18 [(SA404)]  
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628A@SSOP20 [(SA626A)]  
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF631 PIC16LF631(ISP) [ISP-HEADER01]  
PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-HEADER01]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]  
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-HEADER01]  
PIC16LF687@QFN20 [(SA692)]

PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF687@SSOP20 [(SA626A)]  
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]  
PIC16LF72@SOIC28 [(SA404)]  
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF72@SSOP28 [(SA626A)]  
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF722 PIC16LF722@QFN28 [(SA685-B006)]  
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28 [(SA626A)]  
PIC16LF723 PIC16LF723@QFN28 [(SA685-B006)]  
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28 [(SA626A)]  
PIC16LF724 PIC16LF724@QFN44 [(SA737)]  
PIC16LF724@TQFP44 [(SA245A)] PIC16LF726  
PIC16LF726@QFN28 [(SA685-B006)] PIC16LF726@SOIC28 [(SA404)]  
PIC16LF726@SSOP28 [(SA626A)] PIC16LF727  
PIC16LF727@QFN44 [(SA737)] PIC16LF727@TQFP44 [(SA245A)]  
PIC16LF73 PIC16LF73(ISP) [ISP-HEADER01]  
PIC16LF73@SOIC28 [(SA404)]  
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]

PIC16LF73@SSOP28 [(SA626A)]  
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF737 PIC16LF737(ISP) [ISP-HEADER01]  
PIC16LF737@SOIC28 [(SA404)]  
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF737@SSOP28 [(SA626A)]  
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF74 PIC16LF74(ISP) [ISP-HEADER01]  
PIC16LF74@PLCC44 [(SA244)]  
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF74@TQFP44 [(SA245A)]  
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF747 PIC16LF747(ISP) [ISP-HEADER01]  
PIC16LF747@TQFP44 [(SA245A)]  
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF76 PIC16LF76(ISP) [ISP-HEADER01]  
PIC16LF76@SOIC28 [(SA404)]  
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF76@SSOP28 [(SA626A)]  
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF767 PIC16LF767(ISP) [ISP-HEADER01]  
PIC16LF767@SOIC28 [(SA404)]  
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF767@SSOP28 [(SA626A)]  
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF77 PIC16LF77(ISP) [ISP-HEADER01]  
PIC16LF77@PLCC44 [(SA244)]  
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF77@TQFP44 [(SA245A)]  
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF777 PIC16LF777(ISP) [ISP-HEADER01]  
PIC16LF777@TQFP44 [(SA245A)]  
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF818 PIC16LF818(ISP) [ISP-HEADER01]  
PIC16LF818@QFN28 [(SA685-B006)]  
PIC16LF818@QFN28(ISP) [ISP-HEADER01]  
PIC16LF818@SOIC18 [(SA404)]  
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF818@SSOP20 [(SA626A)]  
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF819 PIC16LF819(ISP) [ISP-HEADER01]  
PIC16LF819@QFN28 [(SA685-B006)]  
PIC16LF819@QFN28(ISP) [ISP-HEADER01]



PIC16LF819@SOIC18 [(SA404)]  
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF819@SSOP20 [(SA626A)]  
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF83 PIC16LF83(ISP) [ISP-HEADER01]  
PIC16LF83@SOIC18 [(SA404)]  
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84 PIC16LF84(ISP) [ISP-HEADER01]  
PIC16LF84@SOIC18 [(SA404)]  
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A PIC16LF84A(ISP) [ISP-HEADER01]  
PIC16LF84A@SOIC18 [(SA404)]  
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A@SSOP20 [(SA626A)]  
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF87 PIC16LF87(ISP) [ISP-HEADER01]  
PIC16LF87@QFN28 [(SA685-B006)]  
PIC16LF87@QFN28(ISP) [ISP-HEADER01]  
PIC16LF87@SOIC18 [(SA404)]  
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF87@SSOP20 [(SA626A)]  
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF870 PIC16LF870(ISP) [ISP-HEADER01]  
PIC16LF870@SOIC28 [(SA404)]  
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF870@SSOP28 [(SA626A)]  
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF871 PIC16LF871(ISP) [ISP-HEADER01]  
PIC16LF871@PLCC44 [(SA244)]  
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF871@TQFP44 [(SA245A)]  
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF872 PIC16LF872(ISP) [ISP-HEADER01]  
PIC16LF872@SOIC28 [(SA404)]  
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF872@SSOP28 [(SA626A)]  
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF873 PIC16LF873(ISP) [ISP-HEADER01]  
PIC16LF873@SOIC28 [(SA404)]  
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF873A  
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]

PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@QFN28 [(SA697-B006)]  
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SOIC28 [(SA404)]  
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SSOP28 [(SA626A)]  
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874 PIC16LF874(ISP) [ISP-HEADER01]  
PIC16LF874@PLCC44 [(SA244)]  
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF874@TQFP44 [(SA245A)]  
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF874A  
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@PLCC44 [(SA244)]  
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@TQFP44 [(SA245A)]  
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876 PIC16LF876(ISP) [ISP-HEADER01]  
PIC16LF876@SOIC28 [(SA404)]  
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF876A  
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]

PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@QFN28 [(SA697-B006)]  
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SOIC28 [(SA404)]  
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SSOP28 [(SA626A)]  
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877 PIC16LF877(ISP) [ISP-HEADER01]  
PIC16LF877@PLCC44 [(SA244)]  
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF877@TQFP44 [(SA245A)]  
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF877A  
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@PLCC44 [(SA244)]  
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@TQFP44 [(SA245A)]  
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF88 PIC16LF88(ISP) [ISP-HEADER01]  
PIC16LF88@QFN28 [(SA685-B006)]  
PIC16LF88@QFN28(ISP) [ISP-HEADER01]  
PIC16LF88@SOIC18 [(SA404)]  
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF88@SSOP20 [(SA626A)]

PIC16LF88@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF913 PIC16LF913(ISP) [ISP-HEADER01]  
PIC16LF913@QFN28 [(SA697-B006)]  
PIC16LF913@QFN28(ISP) [ISP-HEADER01]  
PIC16LF913@SOIC28 [(SA404)]  
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF913@SSOP28 [(SA626A)]  
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF914 PIC16LF914(ISP) [ISP-HEADER01]  
PIC16LF914@QFN44 [(SA712)]  
PIC16LF914@QFN44(ISP) [ISP-HEADER01]  
PIC16LF914@QFN44(ML) [(SA737)]  
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF914@TQFP44 [(SA245A)]  
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF916 PIC16LF916(ISP) [ISP-HEADER01]  
PIC16LF916@QFN28 [(SA697-B006)]  
PIC16LF916@QFN28(ISP) [ISP-HEADER01]  
PIC16LF916@SOIC28 [(SA404)]  
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF916@SSOP28 [(SA626A)]  
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF917 PIC16LF917(ISP) [ISP-HEADER01]  
PIC16LF917@QFN44 [(SA712)]  
PIC16LF917@QFN44(ISP) [ISP-HEADER01]  
PIC16LF917@QFN44(ML) [(SA737)]  
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF917@TQFP44 [(SA245A)]  
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]  
PIC16LV54A PIC16LV54A@SOIC18 [(SA404)]  
PIC16LV54A@SSOP20 [(SA626A)] PIC16LV58A  
PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20 [(SA626A)]  
PIC17C42 PIC17C42@PLCC44 [(SA244)]  
PIC17C42@TQFP44 [(SA245A)] PIC17C42A  
PIC17C42A@PLCC44 [(SA244)] PIC17C42A@TQFP44 [(SA245A)]  
PIC17C43 PIC17C43@PLCC44 [(SA244)]  
PIC17C43@TQFP44 [(SA245A)] PIC17C44  
PIC17C44@PLCC44 [(SA244)] PIC17C44@TQFP44 [(SA245A)]  
PIC17LC42 PIC17LC42@PLCC44 [(SA244)]  
PIC17LC42@TQFP44 [(SA245A)] PIC17LC42A  
PIC17LC42A@PLCC44 [(SA244)] PIC17LC42A@TQFP44 [(SA245A)]  
PIC17LC43 PIC17LC43@PLCC44 [(SA244)]

PIC17LC43@TQFP44 [(SA245A)] PIC17LC44  
PIC17LC44@PLCC44 [(SA244)] PIC17LC44@TQFP44 [(SA245A)]  
PIC18C242 PIC18C242@SOIC28 [(SA404)]  
PIC18C252 PIC18C252@SOIC28 [(SA404)]  
PIC18C442 PIC18C442@PLCC44 [(SA244)]  
PIC18C442@TQFP44 [(SA245A)] PIC18C452  
PIC18C452@PLCC44 [(SA244)] PIC18C452@TQFP44 [(SA245A)]  
PIC18F1220 PIC18F1220(ISP) [ISP-HEADER01]  
PIC18F1220@SOIC18 [(SA404)]  
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1220@SSOP20 [(SA626A)]  
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1230 PIC18F1230(ISP) [ISP-HEADER01]  
PIC18F1230@QFN28 [(SA685-B006)]  
PIC18F1230@QFN28(ISP) [ISP-HEADER01]  
PIC18F1230@SOIC18 [(SA404)]  
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1230@SSOP20 [(SA626A)]  
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1320 PIC18F1320(ISP) [ISP-HEADER01]  
PIC18F1320@SOIC18 [(SA404)]  
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1320@SSOP20 [(SA626A)]  
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330 PIC18F1330(ISP) [ISP-HEADER01]  
PIC18F1330@QFN28 [(SA685-B006)]  
PIC18F1330@QFN28(ISP) [ISP-HEADER01]  
PIC18F1330@SOIC18 [(SA404)]  
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1330@SSOP20 [(SA626A)]  
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330-ICD@QFN28 [(SA685-B006)]  
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]  
PIC18F2220 PIC18F2220(ISP) [ISP-HEADER01]  
PIC18F2220@SOIC28 [(SA404)]  
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2221  
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@QFN28 [(SA685-B006)]  
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@SOIC28 [(SA404)]  
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2320 PIC18F2320(ISP) [ISP-HEADER01]

PIC18F2320@SOIC28 [(SA404)]  
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2321  
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@QFN28 [(SA685-B006)]  
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@SOIC28 [(SA404)]  
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2331                    PIC18F2331(ISP) [ISP-HEADER01]  
PIC18F2331@SOIC28 [(SA404)]  
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18F23K20  
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@QFN28 [(SA685-B006)]  
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28 [(SA404)]  
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28 [(SA626A)]  
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410  
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@QFN28 [(SA685-B006)]  
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@SOIC28 [(SA404)]  
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F242                    PIC18F242(ISP) [ISP-HEADER01]  
PIC18F242@SOIC28 [(SA404)]  
PIC18F242@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2420  
PIC18F2420(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2420@SOIC28 [(SA404)]  
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423  
PIC18F2423(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@QFN28 [(SA685-B006)]  
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]

PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@SOIC28 [(SA404)]  
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2431 PIC18F2431(ISP) [ISP-HEADER01]  
PIC18F2431@SOIC28 [(SA404)]  
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2439 PIC18F2439(ISP) [ISP-HEADER01]  
PIC18F2439@SOIC28 [(SA404)]  
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2450  
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@QFN28 [(SA685-B006)]  
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@SOIC28 [(SA404)]  
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455  
PIC18F2455(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455@SOIC28 [(SA404)]  
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458  
PIC18F2458(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SOIC28 [(SA404)]  
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SSOP28 [(SA626A)]  
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F248 PIC18F248(ISP) [ISP-HEADER01]  
PIC18F248@SOIC28 [(SA404)]  
PIC18F248@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2480  
PIC18F2480(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@QFN28 [(SA685-B006)]  
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@SOIC28 [(SA404)]  
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18F24J10 PIC18F24J10(ISP) [ISP-HEADER01]  
PIC18F24J10@QFN28 [(SA685-B006)]  
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F24J10@SOIC28 [(SA404)]  
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F24J10@SSOP28 [(SA626A)]  
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F24K20  
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@QFN28 [(SA685-B006)]  
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28 [(SA404)]  
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28 [(SA626A)]  
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2510 PIC18F2510(ISP) [ISP-HEADER01]  
PIC18F2510@QFN28 [(SA685-B006)]  
PIC18F2510@QFN28(ISP) [ISP-HEADER01]  
PIC18F2510@SOIC28 [(SA404)]  
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2515  
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2515@SOIC28 [(SA404)]  
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F252 PIC18F252(ISP) [ISP-HEADER01]  
PIC18F252@SOIC28 [(SA404)]  
PIC18F252@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2520  
PIC18F2520(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2520@SOIC28 [(SA404)]  
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523  
PIC18F2523(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@QFN28 [(SA685-B006)]  
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]



PIC18F2523@SOIC28 [(SA404)]  
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525  
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525@SOIC28 [(SA404)]  
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2539 PIC18F2539(ISP) [ISP-HEADER01]  
PIC18F2539@SOIC28 [(SA404)]  
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2550  
PIC18F2550(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2550@SOIC28 [(SA404)]  
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553  
PIC18F2553(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SOIC28 [(SA404)]  
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SSOP28 [(SA626A)]  
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F258 PIC18F258(ISP) [ISP-HEADER01]  
PIC18F258@SOIC28 [(SA404)]  
PIC18F258@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2580  
PIC18F2580(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@QFN28 [(SA685-B006)]  
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@SOIC28 [(SA404)]  
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585  
PIC18F2585(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SDIP28 [(SA022A)]  
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2585@SOIC28 [(SA404)]  
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25J10 PIC18F25J10(ISP) [ISP-HEADER01]  
PIC18F25J10@QFN28 [(SA685-B006)]  
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F25J10@SOIC28 [(SA404)]  
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F25J10@SSOP28 [(SA626A)]  
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F25K20  
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@QFN28 [(SA685-B006)]  
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28 [(SA404)]  
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28 [(SA626A)]  
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610  
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610@SOIC28 [(SA404)]  
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620  
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620@SOIC28 [(SA404)]  
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680  
PIC18F2680(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SDIP28 [(SA022A)]  
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SOIC28 [(SA404)]  
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682  
PIC18F2682(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@QFN28 [(SA685)]

PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@SOIC28 [(SA404)]  
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685  
PIC18F2685(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@QFN28 [(SA685)]  
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@SOIC28 [(SA404)]  
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4220                    PIC18F4220(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44 [(SA712)]  
PIC18F4220@QFN44(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44(ML) [(SA737)]  
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4220@TQFP44 [(SA245A)]  
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4221  
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44 [(SA712)]  
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44(ML) [(SA737)]  
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@TQFP44 [(SA245A)]  
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4320                    PIC18F4320(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44 [(SA712)]  
PIC18F4320@QFN44(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44(ML) [(SA737)]  
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4320@TQFP44 [(SA245A)]  
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4321  
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44 [(SA712)]  
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44(ML) [(SA737)]  
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@TQFP44 [(SA245A)]

PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4331 PIC18F4331(ISP) [ISP-HEADER01]  
PIC18F4331@TQFP44 [(SA245A)]  
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18F43K20  
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44 [(SA712)]  
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML) [(SA737)]  
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44 [(SA245A)]  
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410  
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44 [(SA712)]  
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44(ML) [(SA737)]  
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@TQFP44 [(SA245A)]  
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F442 PIC18F442(ISP) [ISP-HEADER01]  
PIC18F442@PLCC44 [(SA244)]  
PIC18F442@PLCC44(ISP) [ISP-HEADER01]  
PIC18F442@TQFP44 [(SA245A)]  
PIC18F442@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4420  
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44 [(SA712)]  
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44(ML) [(SA737)]  
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@TQFP44 [(SA245A)]  
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423  
PIC18F4423(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44 [(SA712)]  
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18F4423@QFN44(ML) [(SA737)]  
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@TQFP44 [(SA245A)]  
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4431 PIC18F4431(ISP) [ISP-HEADER01]  
PIC18F4431@TQFP44 [(SA245A)]  
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4439 PIC18F4439(ISP) [ISP-HEADER01]  
PIC18F4439@TQFP44 [(SA245A)]  
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4450  
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44 [(SA712)]  
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44(ML) [(SA737)]  
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@TQFP44 [(SA245A)]  
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455  
PIC18F4455(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44 [(SA712)]  
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML) [(SA737)]  
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@TQFP44 [(SA245A)]  
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458  
PIC18F4458(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@QFN44 [(SA737)]  
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@TQFP44 [(SA245A)]  
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F448 PIC18F448(ISP) [ISP-HEADER01]  
PIC18F448@PLCC44 [(SA244)]

PIC18F448@PLCC44(ISP) [ISP-HEADER01]  
PIC18F448@TQFP44 [(SA245A)]  
PIC18F448@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4480  
PIC18F4480(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44 [(SA712)]  
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML) [(SA737)]  
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@TQFP44 [(SA245A)]  
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44J10                    PIC18F44J10(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44 [(SA712)]  
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44(ML) [(SA709)]  
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F44J10@TQFP44 [(SA245A)]  
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F44K20  
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44 [(SA712)]  
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML) [(SA737)]  
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44 [(SA245A)]  
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4510                    PIC18F4510(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44 [(SA712)]  
PIC18F4510@QFN44(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44(ML) [(SA737)]  
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4510@TQFP44 [(SA245A)]  
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4515  
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]

PIC18F4515@QFN44 [(SA712)]  
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44(ML) [(SA737)]  
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@TQFP44 [(SA245A)]  
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F452                    PIC18F452(ISP) [ISP-HEADER01]  
PIC18F452@PLCC44 [(SA244)]  
PIC18F452@PLCC44(ISP) [ISP-HEADER01]  
PIC18F452@TQFP44 [(SA245A)]  
PIC18F452@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4520                  PIC18F4520(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44 [(SA712)]  
PIC18F4520@QFN44(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44(ML) [(SA737)]  
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4520@TQFP44 [(SA245A)]  
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4523  
PIC18F4523(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44 [(SA712)]  
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML) [(SA737)]  
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@TQFP44 [(SA245A)]  
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525  
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44 [(SA712)]  
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44(ML) [(SA737)]  
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@TQFP44 [(SA245A)]  
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4539                  PIC18F4539(ISP) [ISP-HEADER01]  
PIC18F4539@TQFP44 [(SA245A)]  
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4550  
PIC18F4550(ISP)(High-V) [ISP-HEADER01]

PIC18F4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44 [(SA712)]  
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML) [(SA737)]  
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@TQFP44 [(SA245A)]  
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553  
PIC18F4553(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@QFN44 [(SA737)]  
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@TQFP44 [(SA245A)]  
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F458                    PIC18F458(ISP) [ISP-HEADER01]  
PIC18F458@PLCC44 [(SA244)]  
PIC18F458@PLCC44(ISP) [ISP-HEADER01]  
PIC18F458@TQFP44 [(SA245A)]  
PIC18F458@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4580  
PIC18F4580(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44 [(SA712)]  
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML) [(SA737)]  
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@TQFP44 [(SA245A)]  
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585  
PIC18F4585(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44 [(SA712)]  
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML) [(SA737)]



PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@TQFP44 [(SA245A)]  
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45J10 PIC18F45J10(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44 [(SA712)]  
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44(ML) [(SA709)]  
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F45J10@TQFP44 [(SA245A)]  
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F45K20  
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44 [(SA712)]  
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML) [(SA737)]  
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44 [(SA245A)]  
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610  
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44 [(SA712)]  
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44(ML) [(SA737)]  
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@TQFP44 [(SA245A)]  
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620  
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44 [(SA712)]  
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44(ML) [(SA737)]  
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@TQFP44 [(SA245A)]  
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680  
PIC18F4680(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]

PIC18F4680@QFN44 [(SA712)]  
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML) [(SA737)]  
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@TQFP44 [(SA245A)]  
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682  
PIC18F4682(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44 [(SA712)]  
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML) [(SA737)]  
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@TQFP44 [(SA245A)]  
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685  
PIC18F4685(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44 [(SA712)]  
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML) [(SA737)]  
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@TQFP44 [(SA245A)]  
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]

PIC18F6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]

PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]

PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]  
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18LC452 PIC18LC452@PLCC44 [(SA244)]  
PIC18LC452@TQFP44 [(SA245A)] PIC18LF1220  
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18 [(SA404)]  
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1220@SSOP20 [(SA626A)]  
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF1320 PIC18LF1320(ISP) [ISP-HEADER01]  
PIC18LF1320@SOIC18 [(SA404)]  
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1320@SSOP20 [(SA626A)]  
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF2220 PIC18LF2220(ISP) [ISP-HEADER01]  
PIC18LF2220@SOIC28 [(SA404)]  
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2221  
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@QFN28 [(SA685-B006)]  
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@SOIC28 [(SA404)]  
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2320 PIC18LF2320(ISP) [ISP-HEADER01]  
PIC18LF2320@SOIC28 [(SA404)]  
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2321  
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@QFN28 [(SA685-B006)]  
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@SOIC28 [(SA404)]  
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2331 PIC18LF2331(ISP) [ISP-HEADER01]  
PIC18LF2331@SOIC28 [(SA404)]  
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2410  
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@QFN28 [(SA685-B006)]  
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@SOIC28 [(SA404)]  
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF242 PIC18LF242(ISP) [ISP-HEADER01]  
PIC18LF242@SOIC28 [(SA404)]

PIC18LF242@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2420  
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 [(SA404)]  
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2431 PIC18LF2431(ISP) [ISP-HEADER01]  
PIC18LF2431@SOIC28 [(SA404)]  
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2439 PIC18LF2439(ISP) [ISP-HEADER01]  
PIC18LF2439@SOIC28 [(SA404)]  
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2450  
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@QFN28 [(SA685-B006)]  
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@SOIC28 [(SA404)]  
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455  
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 [(SA404)]  
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF248 PIC18LF248(ISP) [ISP-HEADER01]  
PIC18LF248@SOIC28 [(SA404)]  
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2480  
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@QFN28 [(SA685-B006)]  
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28 [(SA404)]  
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-HEADER01]  
PIC18LF24J10@QFN28 [(SA685-B006)]  
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SOIC28 [(SA404)]  
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SSOP28 [(SA626A)]

PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2510 PIC18LF2510(ISP) [ISP-HEADER01]  
PIC18LF2510@QFN28 [(SA685-B006)]  
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]  
PIC18LF2510@SOIC28 [(SA404)]  
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2515  
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2515@SOIC28 [(SA404)]  
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF252 PIC18LF252(ISP) [ISP-HEADER01]  
PIC18LF252@SOIC28 [(SA404)]  
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2520  
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28 [(SA404)]  
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525  
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525@SOIC28 [(SA404)]  
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2539 PIC18LF2539(ISP) [ISP-HEADER01]  
PIC18LF2539@SOIC28 [(SA404)]  
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2550  
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28 [(SA404)]  
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF258 PIC18LF258(ISP) [ISP-HEADER01]  
PIC18LF258@SOIC28 [(SA404)]  
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2580  
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@QFN28 [(SA685-B006)]  
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28 [(SA404)]  
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10                    PIC18LF25J10(ISP) [ISP-HEADER01]  
PIC18LF25J10@QFN28 [(SA685-B006)]  
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SOIC28 [(SA404)]  
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SSOP28 [(SA626A)]  
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2610  
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2610@SOIC28 [(SA404)]  
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620  
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620@SOIC28 [(SA404)]  
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680  
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28 [(SA022A)]  
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28 [(SA404)]  
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682  
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@QFN28 [(SA685)]  
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28 [(SA404)]  
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]



PIC18LF2685  
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@QFN28 [(SA685)]  
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28 [(SA404)]  
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4220 PIC18LF4220(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44 [(SA712)]  
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44(ML) [(SA737)]  
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4220@TQFP44 [(SA245A)]  
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4221  
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44 [(SA712)]  
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44(ML) [(SA737)]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4221@TQFP44 [(SA245A)]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4320 PIC18LF4320(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44 [(SA712)]  
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44(ML) [(SA737)]  
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4320@TQFP44 [(SA245A)]  
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44 [(SA712)]  
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44(ML) [(SA737)]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4321@TQFP44 [(SA245A)]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4331 PIC18LF4331(ISP) [ISP-HEADER01]  
PIC18LF4331@TQFP44 [(SA245A)]  
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4410

PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44 [(SA712)]  
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44(ML) [(SA737)]  
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4410@TQFP44 [(SA245A)]  
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF442 PIC18LF442(ISP) [ISP-HEADER01]  
PIC18LF442@PLCC44 [(SA244)]  
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF442@TQFP44 [(SA245A)]  
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4420  
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44 [(SA712)]  
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44(ML) [(SA737)]  
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4420@TQFP44 [(SA245A)]  
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4431 PIC18LF4431(ISP) [ISP-HEADER01]  
PIC18LF4431@TQFP44 [(SA245A)]  
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4439 PIC18LF4439(ISP) [ISP-HEADER01]  
PIC18LF4439@TQFP44 [(SA245A)]  
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4450  
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 [(SA712)]  
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44(ML) [(SA737)]  
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4450@TQFP44 [(SA245A)]  
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455  
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 [(SA712)]  
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML) [(SA737)]  
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]

PIC18LF4455@TQFP44 [(SA245A)]  
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF448 PIC18LF448(ISP) [ISP-HEADER01]  
PIC18LF448@PLCC44 [(SA244)]  
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF448@TQFP44 [(SA245A)]  
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4480  
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44 [(SA712)]  
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML) [(SA737)]  
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44 [(SA245A)]  
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-HEADER01]  
PIC18LF44J10@QFN44 [(SA712)]  
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF44J10@QFN44(ML) [(SA709)]  
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF44J10@TQFP44 [(SA245A)]  
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4510 PIC18LF4510(ISP) [ISP-HEADER01]  
PIC18LF4510@QFN44 [(SA712)]  
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4510@QFN44(ML) [(SA737)]  
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4510@TQFP44 [(SA245A)]  
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4515  
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44 [(SA712)]  
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44(ML) [(SA737)]  
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4515@TQFP44 [(SA245A)]  
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF452 PIC18LF452(ISP) [ISP-HEADER01]

PIC18LF452@PLCC44 [(SA244)]  
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF452@TQFP44 [(SA245A)]  
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4520 PIC18LF4520(ISP) [ISP-HEADER01]  
PIC18LF4520@QFN44 [(SA712)]  
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4520@QFN44(ML) [(SA737)]  
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4520@TQFP44 [(SA245A)]  
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4525  
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44 [(SA712)]  
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44(ML) [(SA737)]  
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4525@TQFP44 [(SA245A)]  
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4539 PIC18LF4539(ISP) [ISP-HEADER01]  
PIC18LF4539@TQFP44 [(SA245A)]  
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4550  
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44 [(SA712)]  
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML) [(SA737)]  
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44 [(SA245A)]  
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF458 PIC18LF458(ISP) [ISP-HEADER01]  
PIC18LF458@PLCC44 [(SA244)]  
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF458@TQFP44 [(SA245A)]  
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4580  
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44 [(SA712)]

PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML) [(SA737)]  
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44 [(SA245A)]  
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585  
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44 [(SA712)]  
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML) [(SA737)]  
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44 [(SA245A)]  
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF45J10                    PIC18LF45J10(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44 [(SA712)]  
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44(ML) [(SA709)]  
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF45J10@TQFP44 [(SA245A)]  
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4610  
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44 [(SA712)]  
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44(ML) [(SA737)]  
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4610@TQFP44 [(SA245A)]  
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620  
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44 [(SA712)]  
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44(ML) [(SA737)]  
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4620@TQFP44 [(SA245A)]  
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4680  
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44 [(SA712)]  
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML) [(SA737)]  
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44 [(SA245A)]  
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682  
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44 [(SA712)]  
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML) [(SA737)]  
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44 [(SA245A)]  
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685  
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44 [(SA712)]  
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML) [(SA737)]  
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44 [(SA245A)]  
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]

PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]

PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC30F2010 PIC30F2010(ISP) [ISP-HEADER01]  
PIC30F2010@SDIP28 [(SA022A)]  
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2010@SOIC28 [(SA404)]  
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F2011(ISP) [ISP-HEADER01]  
PIC30F2011@QFN28(ISP) [ISP-HEADER01]  
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]  
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]  
PIC30F2012(ISP) [ISP-HEADER01]  
PIC30F2012@QFN28(ISP) [ISP-HEADER01]  
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3010(ISP) [ISP-HEADER01]  
PIC30F3010@QFN44(ISP) [ISP-HEADER01]  
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3011(ISP) [ISP-HEADER01]  
PIC30F3011@QFN44(ISP) [ISP-HEADER01]  
PIC30F3011@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012(ISP) [ISP-HEADER01]  
PIC30F3012@QFN44(ISP) [ISP-HEADER01]  
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]  
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]  
PIC30F3013(ISP) [ISP-HEADER01]  
PIC30F3013@QFN44(ISP) [ISP-HEADER01]  
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3014(ISP) [ISP-HEADER01]  
PIC30F3014@QFN44(ISP) [ISP-HEADER01]  
PIC30F3014@QFP44(ISP) [ISP-HEADER01]  
PIC30F4011(ISP) [ISP-HEADER01]  
PIC30F4011@QFN44(ISP) [ISP-HEADER01]  
PIC30F4011@QFP44(ISP) [ISP-HEADER01]  
PIC30F4012(ISP) [ISP-HEADER01]  
PIC30F4012@QFN44(ISP) [ISP-HEADER01]  
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]



PIC30F4012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F4013(ISP) [ISP-HEADER01]  
PIC30F4013@QFN44(ISP) [ISP-HEADER01]  
PIC30F4013@QFP44(ISP) [ISP-HEADER01]  
PIC30F5011@QFP64(ISP) [ISP-HEADER01]  
PIC30F5013@QFP80(ISP) [ISP-HEADER01]  
PIC30F5015@QFP64(ISP) [ISP-HEADER01]  
PIC30F5016@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6010A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6011@QFP64(ISP) [ISP-HEADER01]  
PIC30F6011A@QFP64(ISP) [ISP-HEADER01]  
PIC30F6012@QFP64(ISP) [ISP-HEADER01]  
PIC30F6012A@QFP64(ISP) [ISP-HEADER01]  
PIC30F6013@QFP80(ISP) [ISP-HEADER01]  
PIC30F6013A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6014A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6015@QFP64(ISP) [ISP-HEADER01]  
PS200 PS200(ISP) [ISP-HEADER01]  
PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-HEADER01]  
PS200@SSOP20 [(SA626A)] PS200@SSOP20(ISP) [ISP-HEADER01]  
rfPIC12C509AF@SSOP20 [(SA626A)]  
rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]  
rfPIC12C509AG@SOIC18 [(SA404)]  
rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]  
rfPIC12LC509AF@SSOP20 [(SA626A)]  
rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]  
rfPIC12LC509AG@SOIC18 [(SA404)]  
rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

## MICRON

### E(E)PROM/FRAM/NVRAM

MT28F002B1VG-B@TSOP40 [(SA409T)] MT28F002B1VG-T@TSOP40 [(SA409T)]  
MT28F002B3VG-B@TSOP40 [(SA409T)] MT28F002B3VG-T@TSOP40 [(SA409T)]  
MT28F002B5VG-B@TSOP40 [(SA409T)] MT28F002B5VG-T@TSOP40 [(SA409T)]

MT28F002C1VG-T@TSOP40 [(SA409T)] MT28F002C5VG-T@TSOP40 [(SA409T)]  
MT28F002VG-B@TSOP40 [(SA409T)] MT28F002VG-T@TSOP40 [(SA409T)]  
MT28F004B1VG-B@TSOP40 [(SA409T)] MT28F004B1VG-T@TSOP40 [(SA409T)]  
MT28F004B3VG-B@TSOP40 [(SA409T)] MT28F004B3VG-T@TSOP40 [(SA409T)]  
MT28F004B5VG-B@TSOP40 [(SA409T)] MT28F004B5VG-T@TSOP40 [(SA409T)]  
MT28F004VG-B@TSOP40 [(SA409T)] MT28F004VG-T@TSOP40 [(SA409T)]  
MT28F008B1VG-B@TSOP40 [(SA409T)] MT28F008B1VG-T@TSOP40 [(SA409T)]  
MT28F008B3VG-B@TSOP40 [(SA409T)] MT28F008B3VG-T@TSOP40 [(SA409T)]  
MT28F008B5VG-B@TSOP40 [(SA409T)] MT28F008B5VG-T@TSOP40 [(SA409T)]  
MT28F016S3VG@TSOP40 [(SA409T)] MT28F016S5VG@TSOP40 [(SA409T)]  
MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F200B1SGB@PSOP44 [(SA638)] MT28F200B1SGT@PSOP44 [(SA638)]  
MT28F200B1WGB@TSOP48 [(SA247-B005)]  
MT28F200B1WGT@TSOP48 [(SA247-B005)]  
MT28F200B3SGB@PSOP44 [(SA638)] MT28F200B3SGT@PSOP44 [(SA638)]  
MT28F200B3WGB@TSOP48 [(SA247-B005)]  
MT28F200B3WGT@TSOP48 [(SA247-B005)]  
MT28F200B5SGB@PSOP44 [(SA638)] MT28F200B5SGT@PSOP44 [(SA638)]  
MT28F200B5WGB@TSOP48 [(SA247-B005)]  
MT28F200B5WGT@TSOP48 [(SA247-B005)]  
MT28F320J3A(FW201)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW204)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44 [(SA638)]  
MT28F400B1WGB@TSOP48 [(SA247-B005)]  
MT28F400B1WGT@TSOP48 [(SA247-B005)]  
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44 [(SA638)]  
MT28F400B3WGB@TSOP48 [(SA247-B005)]  
MT28F400B3WGT@TSOP48 [(SA247-B005)]  
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44 [(SA638)]  
MT28F400B5WGB@TSOP48 [(SA247-B005)]  
MT28F400B5WGT@TSOP48 [(SA247-B005)]  
MT28F640J3A(FW202)(I.)@FBGA64 [(SA655A-B054A-T064F001)]

MT28F640J3A(FW205)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW206)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW209)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW505)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW506)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F640J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44 [(SA638)]  
MT28F800B1WGB@TSOP48 [(SA247-B005)]  
MT28F800B1WGT@TSOP48 [(SA247-B005)]  
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44 [(SA638)]  
MT28F800B3WGB@TSOP48 [(SA247-B005)]  
MT28F800B3WGT@TSOP48 [(SA247-B005)]  
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44 [(SA638)]  
MT28F800B5WGB@TSOP48 [(SA247-B005)]  
MT28F800B5WGT@TSOP48 [(SA247-B005)]  
MT29F1G08ABAWP@TSOP48 [(SA247-B005)]  
MT29F2G08AAAWG@TSOP48 [(SA247-B005)]  
MT29F2G08AABWP@TSOP48 [(SA247-B005)]  
MT29F2G08AACWP@TSOP48 [(SA247-B005)]  
MT29F4G08AAAWP@TSOP48 [(SA247-B005)]  
MT29F4G08BAB@TSOP48 [(SA247-B005)]  
MT29F8G08DAA@TSOP48 [(SA247-B005)]

## DRAM & SRAM

MTSRAM@FBGA48 [(SA634A-B005A-Y048F001)]

## MICRONAS

## MICROCONTROLLER

SDA555XFL@SDIP52(\*) [(SA627-B5603)]

## MICRON-CUSTOMER

## E(E)PROM/FRAM/NVRAM

MT29F4G08AAAWP(sony)@TSOP48 [(SA247+B005)]

# mitsubishi

## E(E)PROM/FRAM/NVRAM

M5L27128K	M5L2716
M5L27256K	M5L2732
M5L2732A	M5L27512
M5L27512K	M5L2764K
M5L27C512A	M5M27128P
M5M27256P	M5M27512P
M5M2764P	M5M27C100K
M5M27C100K@PLCC32 [(SA015A1T)]	M5M27C100K@TSOP32 [(SA410T)]
M5M27C100P	M5M27C100P@PLCC32 [(SA015A1T)]
M5M27C100P@TSOP32 [(SA410T)]	M5M27C101JK
M5M27C101JK@PLCC32 [(SA015A1T)]	M5M27C101JK@TSOP32 [(SA410T)]
M5M27C101K	M5M27C101K@PLCC32 [(SA015A1T)]
M5M27C101K@TSOP32 [(SA410T)]	M5M27C101P
M5M27C101P@PLCC32 [(SA015A1T)]	M5M27C101P@TSOP32 [(SA410T)]
M5M27C102K	M5M27C102K@PLCC44 [(SA244)]
M5M27C102P	M5M27C102P@PLCC44 [(SA244)]
M5M27C128K	M5M27C201K
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32 [(SA410T)]
M5M27C202K	M5M27C202K@PLCC44 [(SA244)]
M5M27C256(K)	M5M27C256(P)
M5M27C256A(FP)	M5M27C256A(K)
M5M27C256A(P)	M5M27C401K
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32 [(SA410T)]
M5M27C402K	M5M27C512(FP)
M5M27C512A(FP)	M5M27C512A(K)
M5M27C512A(P)	M5M28F101
M5M28F101@PLCC32 [(SA015A1T)]	M5M28F101@SOP32 [(SA438T)]
M5M28F101@TSOP32 [(SA410T)]	M5M28F101A
M5M28F101A@PLCC32 [(SA015A1T)]	M5M28F101A@SOIC32 [(SA438T)]
M5M28F101A@TSOP32 [(SA410T)]	
M5M29FB160A@TSOP48 [(SA247-B005)]	
M5M29FB800(FP)@PSOP44 [(SA638)]	
M5M29FB800(VP)@TSOP48 [(SA247-B005)]	
M5M29FT160A@TSOP48 [(SA247-B005)]	
M5M29FT800(FP)@PSOP44 [(SA638)]	
M5M29FT800(VP)@TSOP48 [(SA247-B005)]	
M5M29GB160B(VP)@TSOP48 [(SA247-B005)]	

M5M29GB320(VP)@TSOP48 [(SA247-B005)]  
M5M29GB320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29GT160B(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29JB160A@TSOP48 [(SA247-B005)]  
M5M29JT160A@TSOP48 [(SA247-B005)]  
M6M80011A M6M80011A@SOIC10 [(SA023A)]  
M6M80011A@SOIC16 [(SA023A)] M6M80021  
M6M80021@SOIC10 [(SA023A)] M6M80021@SOIC16 [(SA023A)]  
M6M80041 M6M80041@SOIC10 [(SA023A)]  
M6MG3B641S16TP@TSOP52 [(SA657-B036)]  
M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
M6MGB321S4TP@TSOP52 [(SA657-B036)]  
M6MGB321S8TP@TSOP52 [(SA657-B036)]  
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB331S8KT@TSOP52 [(SA657-B036)]  
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB641S16TP@TSOP52 [(SA657-B036)]  
M6MGB641S4TP@TSOP52 [(SA657-B036)]  
M6MGB641S8TP@TSOP52 [(SA657-B036)]  
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
M6MGE157S4KT@TSOP52 [(SA657-B055)]  
M6MGT321S4TP@TSOP52 [(SA657-B036)]  
M6MGT321S8TP@TSOP52 [(SA657-B036)]  
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT331S8KT@TSOP52 [(SA657-B036)]  
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT641S16TP@TSOP52 [(SA657-B036)]  
M6MGT641S4TP@TSOP52 [(SA657-B036)]  
M6MGT641S8TP@TSOP52 [(SA657-B036)]  
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

## MICROCONTROLLER

M30240EFCP@QFP80(Renesas) [(PCA7302E1F-80)]  
M30620EFCP@QFP100(Renesas) [(PCA7412F-100)]

M30620ECFS@QFN100(Renesas) [(PCA7412L-100)]  
M30620ECGP@LQFP100(Renesas) [(PCA7412G-100)]  
M30621ECGP@QFP80(Renesas) [(PCA7413F-80)]  
M30622ECTFP@QFP100(Renesas) [(PCA7412F-100)]  
M30623ECTGP@QFP80(Renesas) [(PCA7413F-80)]  
M306V0EEFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V0EEFS@QFN100(Renesas) [(PCA7412L-100)]  
M306V2EEFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V2EEFS@QFN100(Renesas) [(PCA7412L-100)]  
M34282E2GP [(SA026)]            M34283G2GP [(SA026)]  
M34283G2GP(ISP) [ISP-HEADER01]  
M34513E4FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34513E4SP@SDIP32(Renesas) [(PCA7442SP)]  
M34513E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34514E8FP@SSOP42(Renesas) [(PCA7441)]  
M34518E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34518E8SP@SDIP32(Renesas) [(PCA7442SP)]  
M34519E8FP@SSOP42(Renesas) [(PCA7441)]  
M34524EDFP@QFP64(Renesas) [(PCA7448)]  
M34551E8FP@QFP48(Renesas) [(PCA7414)]  
M34554EDFP@QFP64(Renesas) [(PCA7448)]  
M34570E8FP@SSOP36(Renesas) [(PCA7425)]  
M34570EDFP@SSOP36(Renesas) [(PCA7425)]  
M34583EDFP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34584EDFP@SSOP42(Renesas) [(PCA7441)]  
M37150EFFP@SSOP42(Renesas) [(PCA7450FP)]  
M37151EFFP@SSOP42(Renesas) [(PCA7450FP)]  
M37160EFFP@SSOP42(Renesas) [(PCA7450FP)]  
M37161EFFP@SSOP42(Renesas) [(PCA7450FP)]  
M37516E6HKP@QFN44(Renesas) [(PCA7446)]  
M37516E6HP@LQFP48(Renesas) [(PCA7419)]  
M37540E2FP@SSOP36(Renesas) [(PCA7435FPG02)]  
M37540E2GP@LQFP32(Renesas) [(PCA7435GPG03)]  
M37540E2SP@SDIP32(Renesas) [(PCA7435SPG02)]  
M37540E8FP@SSOP36(Renesas) [(PCA7435FPG02)]  
M37540E8GP@LQFP32(Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32(Renesas) [(PCA7435SPG02)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)]    M37545G6(GP)@LQFP32 [(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)]    M37546G2(FP)@SSOP36 [(SA645)]

M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20 [(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24 [(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24 [(SA653)]  
M37560EFDFF@QFP100(Renesas) [(PCA4738F-100A)]  
M37560EFFP@QFN100(Renesas) [(PCA4738L-100A)]  
M37560EFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M37560EFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M37630E4FP@QFP44(Renesas) [(PCA7430)]  
M37630E4FS@QFN80(Renesas) [(PCA7431)]  
M37640E8FP@QFP80(Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80(Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]  
M37751F6CFP@QFP80(Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8DXXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64(Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]

M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]  
M38223E4GP@QFP80(Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38227EFCFP@QFP80(Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38227ECHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]  
M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]  
M38C89EFP@LQFP144(Renesas) [(PCA7447FP)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]



R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725-B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725-B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]

R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026-B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026-B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725-B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725-B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026-B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697-B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697-B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026-B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725-B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]

R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]

R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]

R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]

R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]

R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]

R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]



R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]

R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]  
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226KFP@TQFP48 [(SA248-B005)]  
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227JFP@TQFP48 [(SA248-B005)]  
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227KFP@TQFP48 [(SA248-B005)]  
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228JFP@TQFP48 [(SA248-B005)]  
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228KFP@TQFP48 [(SA248-B005)]  
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AJFP@TQFP48 [(SA248-B005)]  
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AKFP@TQFP48 [(SA248-B005)]  
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CJFP@TQFP48 [(SA248-B005)]  
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CKFP@TQFP48 [(SA248-B005)]  
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236JFP@TQFP48 [(SA248-B005)]

R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236KFP@TQFP48 [(SA248-B005)]  
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237JFP@TQFP48 [(SA248-B005)]  
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237KFP@TQFP48 [(SA248-B005)]  
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238JFP@TQFP48 [(SA248-B005)]  
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238KFP@TQFP48 [(SA248-B005)]  
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AJFP@TQFP48 [(SA248-B005)]  
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AKFP@TQFP48 [(SA248-B005)]  
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CJFP@TQFP48 [(SA248-B005)]  
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CKFP@TQFP48 [(SA248-B005)]  
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]

R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]

R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]

R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]

R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP ) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]



R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]

R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]

R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]

R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]

R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]

R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]



R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]

R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026-B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H1SNSP@TSSOP20 [(SA026-B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SDSP@TSSOP20 [(SA725-B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SNSP@TSSOP20 [(SA725-B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SDSP@TSSOP20 [(SA026-B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SNSP@TSSOP20 [(SA026-B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SDSP@TSSOP20 [(SA026-B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SNSP@TSSOP20 [(SA026-B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212K2SDFP@QFP32 [(SA663-B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K2SNFP@QFP32 [(SA663-B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]

R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]  
 R5F212K4SDFP@QFP32 [(SA663-B005)]  
 R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]  
 R5F212K4SNFP@QFP32 [(SA663-B005)]  
 R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]  
 R5F212L2SDFP@QFP32 [(SA663-B005)]  
 R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L2SNFP@QFP32 [(SA663-B005)]  
 R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L4SDFP@QFP32 [(SA663-B005)]  
 R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L4SNFP@QFP32 [(SA663-B005)]  
 R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

## MOSEL-VITELIC

### E(E)PROM/FRAM/NVRAM

V29C31004B            V29C31004B@PLCC32 [(SA015A1T)]  
 V29C31004B@TSOP32 [(SA410T)]    V29C31004T  
 V29C31004T@PLCC32 [(SA015A1T)]    V29C31004T@TSOP32 [(SA410T)]  
 V29C51000B            V29C51000B@PLCC32 [(SA015A1T)]  
 V29C51000T            V29C51000T@PLCC32 [(SA015A1T)]  
 V29C51001B            V29C51001B@PLCC32 [(SA015A1T)]  
 V29C51001B@TSOP32 [(SA410T)]    V29C51001T  
 V29C51001T@PLCC32 [(SA015A1T)]    V29C51001T@TSOP32 [(SA410T)]  
 V29C51002B            V29C51002B@PLCC32 [(SA015A1T)]  
 V29C51002B@TSOP32 [(SA410T)]    V29C51002T  
 V29C51002T@PLCC32 [(SA015A1T)]    V29C51002T@TSOP32 [(SA410T)]  
 V29C51004B            V29C51004B@PLCC32 [(SA015A1T)]  
 V29C51004B@TSOP32 [(SA410T)]    V29C51004T  
 V29C51004T@PLCC32 [(SA015A1T)]    V29C51004T@TSOP32 [(SA410T)]  
 V29LC51000            V29LC51000@PLCC32 [(SA015A1T)]  
 V29LC51001            V29LC51001@PLCC32 [(SA015A1T)]  
 V29LC51002            V29LC51002@PLCC32 [(SA015A1T)]

## MICROCONTROLLER

MSU1958	MSU1958@PLCC44 [(SA244)]
MSU1958@TQFP44 [(SA245A)]	MSU2952
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44 [(SA245A)]
MSU2958	MSU2958@PLCC44 [(SA244)]
MSU2958@TQFP44 [(SA245A)]	MSU2964
MSU2964@PLCC44 [(SA244)]	MSU2964@TQFP44 [(SA245A)]

## MOSTEK

### E(E)PROM/FRAM/NVRAM

ET2716	ETC2716
ETC2732	MK2716
MK2764	MK48C02
MK48C12	MK48T02
MK48T08	MK48T12
MK48T12B	MK48T18
MK48Z02	MK48Z08
MK48Z12	MK48Z12B
MK48Z18	

## MOTOROLA

### E(E)PROM/FRAM/NVRAM

MC68764	MC68766
MCM2716	

### DRAM & SRAM

MCM2018A	MCM2018A@PLCC32 [(SA015A1T)]
MCM60256A	MCM60256A@SOIC28 [(SA630)]
MCM60256AC	MCM60256AC@SOIC28 [(SA630)]
MCM60256AV	MCM60256AV@SOIC28 [(SA630)]
MCM60L256A	MCM60L256A@SOIC28 [(SA630)]
MCM60L256AC	MCM60L256AC@SOIC28 [(SA630)]

MCM60L256AV	MCM60L256AV@SOIC28 [(SA630)]
MCM6206	MCM6206@SOIC28 [(SA630)]
MCM6206C	MCM6206C@SOIC28 [(SA630)]
MCM6207	MCM6207@SOJ24 [(SA646)]
MCM6207C	MCM6207C@SOJ24 [(SA646)]
MCM6208	MCM6208@SOJ24 [(SA646)]
MCM6208C	MCM6208C@SOJ24 [(SA646)]
MCM6209	MCM6209@SOJ28 [(SA646)]
MCM6209C	MCM6209C@SOJ28 [(SA646)]
MCM6229	MCM6229(300m)@SOJ28 [(SA646)]
MCM6229(400m)@SOJ28 [(SA661)]	MCM6229A
MCM6229A(300m)@SOJ28 [(SA646)]	MCM6229A(400m)@SOJ28 [(SA661)]
MCM6264	MCM6264@SOIC28 [(SA630)]
MCM6264C	MCM6264C@SOIC28 [(SA630)]
MCM6268	MCM6269
MCM6287	MCM6287@SOJ24 [(SA646)]
MCM6288	MCM6288@SOJ22 [(SA646)]
MCM6288B	MCM6288B@SOJ22 [(SA646)]
MCM6288C	MCM6288C@SOJ22 [(SA646)]
MCM6290	MCM6290@SOJ24 [(SA646)]
MCM6290B	MCM6290B@SOJ24 [(SA646)]
MCM6290C	MCM6290C@SOJ24 [(SA646)]
MCM62L07	MCM62L07@SOJ24 [(SA646)]
MCM62L08	MCM62L08@SOJ24 [(SA646)]
MCM62L09	MCM62L09@SOJ28 [(SA646)]
MCM6706	MCM6706@SOIC28 [(SA630)]
MCM6706A	MCM6706A@SOJ28 [(SA646)]
MCM6708A	MCM6708A@SOJ24 [(SA646)]
MCM6709A	MCM6709A@SOJ28 [(SA646)]

## MICROCONTROLLER

MC56F8011VFAE@QFP32 [(SA663+B005)]  
 MC56F8013VFAE@QFP32 [(SA663+B005)]  
 MC56F8014VFAE@QFP32 [(SA663+B005)]  
 MC56F8023MFAE@QFP32 [(SA663+B005)]  
 MC56F8023VFAE@QFP32 [(SA663+B005)]  
 MC56F8025VLD@QFP44 [(SA245A+B005)]  
 MC56F8036MFAE@QFP48 [(SA248+B005)]  
 MC56F8036VFAE@QFP48 [(SA248+B005)]  
 MC56F8037VLH@QFP64 [(PEP+S616)]  
 MC68HC908AP16CB(S)@SDIP42 [(SA028)]

MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP8CFA@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32 [(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)] MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44 [(SA675)]  
MC68HC908GR16CFA@TQFP48 [(SA248)]  
MC68HC908GR16CFJ@TQFP32 [(SA663)]  
MC68HC908GR16MFA@TQFP48 [(SA248)]  
MC68HC908GR16MFJ@TQFP32 [(SA663)]  
MC68HC908GR16VFA@TQFP48 [(SA248)]  
MC68HC908GR16VFJ@TQFP32 [(SA663)]  
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32 [(SA663)]  
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28 [(SA404)]  
MC68HC908GR4MFA@TQFP32 [(SA663)] MC68HC908GR4MP  
MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32 [(SA663)]  
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28 [(SA404)]  
MC68HC908GR8CFA@TQFP32 [(SA663)] MC68HC908GR8CP  
MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32 [(SA663)]  
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28 [(SA404)]  
MC68HC908GR8VFA@TQFP32 [(SA663)] MC68HC908GR8VP  
MC68HC908JK1CDW@SOIC20 [(SA404)] MC68HC908JK1CP  
MC68HC908JK1ECDW@SOIC20 [(SA404)]

MC68HC908JK1ECP  
MC68HC908JK1EMDW@SOIC20 [(SA404)]  
MC68HC908JK1EMP                   MC68HC908JK1MDW@SOIC20 [(SA404)]  
MC68HC908JK1MP                    MC68HC908JK3CDW@SOIC20 [(SA404)]  
MC68HC908JK3CP  
MC68HC908JK3ECDW@SOIC20 [(SA404)]  
MC68HC908JK3ECP  
MC68HC908JK3EMDW@SOIC20 [(SA404)]  
MC68HC908JK3EMP                   MC68HC908JK3MDW@SOIC20 [(SA404)]  
MC68HC908JK3MP                    MC68HC908JL3CDW@SOIC28 [(SA404)]  
MC68HC908JL3CFA@TQFP48 [(SA248)]   MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [(SA404)]  
MC68HC908JL3ECFA@TQFP48 [(SA248)]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [(SA404)]  
MC68HC908JL3EMFA@TQFP48 [(SA248)]  
MC68HC908JL3EMP                    MC68HC908JL3MDW@SOIC28 [(SA404)]  
MC68HC908JL3MFA@TQFP48 [(SA248)]   MC68HC908JL3MP  
MC68HC908LB8CDWE(S)@SOIC20       MC68HC908LB8CPE(S)  
MC68HC908LB8MDWE(S)@SOIC20       MC68HC908LB8MPE(S)  
MC68HC908LB8VDWE(S)@SOIC20       MC68HC908LB8VPE(S)  
MC68HC908QT1ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]  
MC68HC908QT1CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1CP                    MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1MP                    MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT1VP  
MC68HC908QT2ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AMFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2CP                    MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2MP                    MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT2VP  
MC68HC908QT4ACFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4AMFQE@DFN8 [(SA744-B006)]

MC68HC908QT4AVFQE@DFN8 [(SA744-B006)]  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4CP MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4MP MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VFQ@DFN8 [(SA744-B006)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)] MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)] MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)] MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)] MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)] MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)] MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]  
MC68HC908QY4CDW@SOIC16 [(SA404)] MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)] MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)] MC68HC908QY4VP  
MC68HRC908JK1CDW@SOIC20 [(SA404)]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [(SA404)]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [(SA404)]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [(SA404)]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [(SA404)]  
MC68HRC908JK3MP  
MC68HRC908JL3CDW@SOIC28 [(SA404)]



MC68HRC908JL3CFA@TQFP48 [(SA248)]  
MC68HRC908JL3CP  
MC68HRC908JL3ECDW@SOIC28 [(SA404)]  
MC68HRC908JL3ECFA@TQFP48 [(SA248)]  
MC68HRC908JL3ECP  
MC68HRC908JL3EMDW@SOIC28 [(SA404)]  
MC68HRC908JL3EMFA@TQFP48 [(SA248)]  
MC68HRC908JL3EMP  
MC68HRC908JL3MDW@SOIC28 [(SA404)]  
MC68HRC908JL3MFA@TQFP48 [(SA248)]  
MC68HRC908JL3MP                    MC908AP16CBE@SDIP42 [(SA028)]  
MC908AP16CFAE@LQFP48 [(SA248)]    MC908AP16CFBE@TQFP44 [(SA675)]  
MC908AP32CBE@SDIP42 [(SA028)]    MC908AP32CFAE@LQFP48 [(SA248)]  
MC908AP32CFBE@TQFP44 [(SA675)]    MC908AP64CBE@SDIP42 [(SA028)]  
MC908AP64CFAE@LQFP48 [(SA248)]    MC908AP64CFBE@TQFP44 [(SA675)]  
MC908AP8CBE@SDIP42 [(SA028)]    MC908AP8CFAE@@LQFP48 [(SA248)]  
MC908AP8CFBE@TQFP44 [(SA675)]    MC908EY16ACFJE@TQFP32 [(SA663)]  
MC908EY16AKFJE@TQFP32 [(SA663)]    MC908EY16AMFJE@TQFP32 [(SA663)]  
MC908EY16AVFJE@TQFP32 [(SA663)]    MC908EY8ACFJE@TQFP32 [(SA663)]  
MC908EY8AKFJE@TQFP32 [(SA663)]    MC908EY8AMFJE@TQFP32 [(SA663)]  
MC908EY8AVFJE@TQFP32 [(SA663)]    MC908JL16CDWE@SOIC28 [(SA404)]  
MC908JL16CFJE@LQFP32 [(SA663)]    MC908JL16CPE  
MC908JL16CSPE@SDIP32 [(SA653)]    MC908QT1ACDWE@SOIC8 [(SA605A)]  
MC908QT1ACPE                    MC908QT1AMDWE@SOIC8 [(SA605A)]  
MC908QT1AMPE                    MC908QT1AVDWE@SOIC8 [(SA605A)]  
MC908QT1AVPE                    MC908QT2ACDWE@SOIC8 [(SA605A)]  
MC908QT2ACPE                    MC908QT2AMDWE@SOIC8 [(SA605A)]  
MC908QT2AMPE                    MC908QT2AVDWE@SOIC8 [(SA605A)]  
MC908QT2AVPE                    MC908QT4ACDWE@SOIC8 [(SA605A)]  
MC908QT4ACPE                    MC908QT4AMDWE@SOIC8 [(SA605A)]  
MC908QT4AMPE                    MC908QT4AVDWE@SOIC8 [(SA605A)]  
MC908QT4AVPE                    MC908QY1ACDTE@TSSOP16 [(SA026)]  
MC908QY1ACDWE@SOIC16 [(SA404)]    MC908QY1ACPE  
MC908QY1AMDTE@TSSOP16 [(SA026)]    MC908QY1AMDWE@SOIC16 [(SA404)]  
MC908QY1AMPE                    MC908QY1AVDTE@TSSOP16 [(SA026)]  
MC908QY1AVDWE@SOIC16 [(SA404)]    MC908QY1AVPE  
MC908QY2ACDTE@TSSOP16 [(SA026)]    MC908QY2ACDWE@SOIC16 [(SA404)]  
MC908QY2ACPE                    MC908QY2AMDTE@TSSOP16 [(SA026)]  
MC908QY2AMDWE@SOIC16 [(SA404)]    MC908QY2AMPE  
MC908QY2AVDTE@TSSOP16 [(SA026)]    MC908QY2AVDWE@SOIC16 [(SA404)]  
MC908QY2AVPE                    MC908QY4ACDTE@TSSOP16 [(SA026)]  
MC908QY4ACDWE@SOIC16 [(SA404)]    MC908QY4ACPE  
MC908QY4AMDTE@TSSOP16 [(SA026)]    MC908QY4AMDWE@SOIC16 [(SA404)]

MC908QY4AMPE                    MC908QY4AVDTE@TSSOP16 [(SA026)]  
MC908QY4AVDWE@SOIC16 [(SA404)]    MC908QY4AVPE  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
PC56F8011VFAE@QFP32 [(SA663+B005)]  
PC56F8013VFAE@QFP32 [(SA663+B005)]  
PC56F8014VFAE@QFP32 [(SA663+B005)]

## MYSON

### MICROCONTROLLER

MTV212MN32                    MTV212MN64I  
MTV212MS32@SDIP42 [(SA028)]    MTV212MS64I@SDIP42 [(SA028)]  
MTV212MV32@PLCC44 [(SA244)]    MTV212MV64I@PLCC44 [(SA244)]

## NEC

## E(E)PROM/FRAM/NVRAM

D2716D                    uPD271000  
 uPD271000@PLCC32 [(SA015A1T)]    uPD271000@TSOP32 [(SA410T)]  
 uPD27128                    uPD27128(C)  
 uPD27128(D)                uPD2716  
 uPD27256                    uPD27256(C)  
 uPD27256(D)                uPD27256A  
 uPD27256A(C)                uPD27256A(D)  
 uPD2732                    uPD2732A  
 uPD27512                    uPD27512ACT  
 uPD27512AD                uPD2764  
 uPD2764C                    uPD2764D  
 uPD27C1000                uPD27C1000@PLCC32 [(SA015A1T)]  
 uPD27C1000@TSOP32 [(SA410T)]    uPD27C1000A  
 uPD27C1000A@PLCC32 [(SA015A1T)]    uPD27C1000A@TSOP32 [(SA410T)]  
 uPD27C1000AD                uPD27C1000AD@PLCC32 [(SA015A1T)]  
 uPD27C1000AD@TSOP32 [(SA410T)]    uPD27C1001  
 uPD27C1001@PLCC32 [(SA015A1T)]    uPD27C1001@TSOP32 [(SA410T)]  
 uPD27C1001A                uPD27C1001A@PLCC32 [(SA015A1T)]  
 uPD27C1001A@TSOP32 [(SA410T)]    uPD27C1001D  
 uPD27C1001D@PLCC32 [(SA015A1T)]    uPD27C1001D@TSOP32 [(SA410T)]  
 uPD27C1024                uPD27C1024A  
 uPD27C2001                uPD27C2001@PLCC32 [(SA015A1T)]  
 uPD27C2001@TSOP32 [(SA410T)]    uPD27C2001D  
 uPD27C2001D@PLCC32 [(SA015A1T)]    uPD27C2001D@TSOP32 [(SA410T)]  
 uPD27C210                uPD27C256  
 uPD27C256A                uPD27C400  
 uPD27C4001                uPD27C4001@PLCC32 [(SA015A1T)]  
 uPD27C4001@TSOP32 [(SA410T)]    uPD27C4096  
 uPD27C512                uPD27C64(C)  
 uPD27C64(D)                uPD27C8000  
 uPD27C8001                uPD27C8001@PLCC32 [(SA015A1T)]  
 uPD27C8001@TSOP32 [(SA410T)]    uPD28C04  
 uPD28C04@SOIC24 [(SA404)]    uPD28C05  
 uPD28C05@SOIC24 [(SA404)]    uPD28C256  
 uPD28C64                uPD28C64@SOIC28 [(SA404)]  
 uPD29F008CB@TSOP40 [(SA409T)]    uPD29F008CT@TSOP40 [(SA409T)]

## DRAM & SRAM

PD4361B PD4361B@SOJ24 [(SA646)]

## NEXFLASH

### E(E)PROM/FRAM/NVRAM

NX25B40(Bottom Boot)@MLP8 [(SA683)]  
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]  
NX25B40(Top Boot)@MLP8 [(SA683)]  
NX25B40(Top Boot)@SOIC8 [(SA602A)]  
NX25P10@MLP8 [(SA683)] NX25P10@SOIC8 [(SA602A)]  
NX25P16@MLP8 [(SA683)] NX25P16@MLP8(ISP) [ISP-HEADER01]  
NX25P16@SOIC16 [(SA404)]  
NX25P16@SOIC16(ISP) [ISP-HEADER01]  
NX25P16@SOIC8 [(SA023A)]  
NX25P16@SOIC8(ISP) [ISP-HEADER01]  
NX25P20@MLP8 [(SA683)] NX25P20@SOIC8 [(SA602A)]  
NX25P32@MLP8 [(SA683)] NX25P32@MLP8(ISP) [ISP-HEADER01]  
NX25P32@SOIC16 [(SA404)]  
NX25P32@SOIC16(ISP) [ISP-HEADER01]  
NX25P40@MLP8 [(SA683)] NX25P40@SOIC8 [(SA602A)]  
NX25P64@MLP8 [(SA683)] NX25P64@MLP8(ISP) [ISP-HEADER01]  
NX25P64@SOIC16 [(SA404)]  
NX25P64@SOIC16(ISP) [ISP-HEADER01]  
NX25P80@MLP8 [(SA683)] NX25P80@SOIC8 [(SA602A)]  
NX29F010 NX29F010@PLCC32 [(SA015A1T)]  
NX29F010@TSOP32 [(SA410T)]

## NJRC

### E(E)PROM/FRAM/NVRAM

NJU26040V NJU26040V@SSOP32 [(SA626A)]

## NOVATEK

### MICROCONTROLLER

NT68F631@PLCC44 [(SA244)]	NT68F631@SDIP42 [(SA028)]
NT68F631ALG@PLCC44 [(SA244)]	NT68F631AUG@SDIP42 [(SA028)]
NT68F631L@PLCC44 [(SA244)]	NT68F631LG@PLCC44 [(SA244)]
NT68F631U@SDIP42 [(SA028)]	NT68F631UG@SDIP42 [(SA028)]
NT68F632@PLCC44 [(SA244)]	NT68F632@SDIP42 [(SA028)]
NT68F632ALG@PLCC44 [(SA244)]	NT68F632AUG@SDIP42 [(SA028)]
NT68F632L@PLCC44 [(SA244)]	NT68F632LG@PLCC44 [(SA244)]
NT68F632U@SDIP42 [(SA028)]	NT68F632UG@SDIP42 [(SA028)]
NT68F633@PLCC44 [(SA244)]	NT68F633@SDIP42 [(SA028)]
NT68F633L@PLCC44 [(SA244)]	NT68F633LG@PLCC44 [(SA244)]
NT68F633U@SDIP42 [(SA028)]	NT68F633UG@SDIP42 [(SA028)]
NT68F636@PLCC44 [(SA244)]	NT68F636@SDIP42 [(SA028)]
NT68F636L@PLCC44 [(SA244)]	NT68F636LG@PLCC44 [(SA244)]
NT68F636U@SDIP42 [(SA028)]	NT68F636UG@SDIP42 [(SA028)]
NT68F63L(0444)@PLCC44 [(SA244)]	NT68F63L(0444)@SDIP42 [(SA028)]
NT68F63L(0448)@PLCC44 [(SA244)]	NT68F63L(0448)@SDIP42 [(SA028)]
NT68F63L(0523)@PLCC44 [(SA244)]	NT68F63L(0523)@SDIP42 [(SA028)]
NT68F63L@PLCC44 [(SA244)]	NT68F63LA@PLCC44 [(SA244)]
NT68F63LG@PLCC44 [(SA244)]	NT68F63LGG@PLCC44 [(SA244)]
NT68F63U@SDIP42 [(SA028)]	NT68F63UA@SDIP42 [(SA028)]
NT68F63UG@SDIP42 [(SA028)]	NT68F63UGG@SDIP42 [(SA028)]

## NSC

### E(E)PROM/FRAM/NVRAM

2864	MM2716
MM2716E	NM24C02
NM24C02@SOIC8 [(SA602A)]	NM24C02@TSOP8 [(SA026)]
NM24C02L	NM24C02L@SOIC8 [(SA602A)]
NM24C02L@TSOP8 [(SA026)]	NM24C03
NM24C03@SOIC8 [(SA602A)]	NM24C03@TSOP8 [(SA026)]
NM24C04	NM24C04@SOIC8 [(SA602A)]
NM24C04@TSOP8 [(SA026)]	NM24C05
NM24C05@SOIC8 [(SA602A)]	NM24C05@TSOP8 [(SA026)]
NM24C08	NM24C08@SOIC8 [(SA602A)]
NM24C09	NM24C09@SOIC8 [(SA602A)]
NM24C16	NM24C16@SOIC8 [(SA602A)]
NM24C17	NM24C17@SOIC8 [(SA602A)]
NM25C04	NM25C04@SOIC16 [(SA602)]
NM25C04@SOIC8 [(SA602A)]	NM25C04@TSSOP14 [(SA026)]

NM25C04@TSSOP8 [(SA026)]      NM27C010  
NM27C010@PLCC32 [(SA015A1T)]      NM27C010@TSOP32 [(SA410T)]  
NM27C010Q      NM27C010Q@PLCC32 [(SA015A1T)]  
NM27C010Q@TSOP32 [(SA410T)]      NM27C020  
NM27C020@PLCC32 [(SA015A1T)]      NM27C020@TSOP32 [(SA410T)]  
NM27C020Q      NM27C020Q@PLCC32 [(SA015A1T)]  
NM27C020Q@TSOP32 [(SA410T)]      NM27C040  
NM27C040@PLCC32 [(SA015A1T)]      NM27C040@TSOP32 [(SA410T)]  
NM27C1023      NM27C128  
NM27C128@PLCC32 [(SA015A1T)]      NM27C210  
NM27C210@PLCC44 [(SA244)]      NM27C210Q  
NM27C210Q@PLCC44 [(SA244)]      NM27C240  
NM27C240@PLCC44 [(SA244)]      NM27C256  
NM27C256@PLCC32 [(SA015A1T)]      NM27C400  
NM27C512      NM27C512@PLCC32 [(SA015A1T)]  
NM27C512Q      NM27C512Q@PLCC32 [(SA015A1T)]  
NM27C64Q      NM27C64Q@PLCC32 [(SA015A1T)]  
NM27CP256      NM27CP256@PLCC32 [(SA015A1T)]  
NM27LC010      NM27LC010@PLCC32 [(SA015A1T)]  
NM27LC010@TSOP32 [(SA410T)]      NM27LC256  
NM27LC256@PLCC32 [(SA015A1T)]      NM27LC512  
NM27LC512@PLCC32 [(SA015A1T)]      NM27LC64  
NM27LC64@PLCC32 [(SA015A1T)]      NM27LV010  
NM27LV010@PLCC32 [(SA015A1T)]      NM27LV010@TSOP32 [(SA410T)]  
NM27LV210      NM27LV210@PLCC44 [(SA244)]  
NM27LV512      NM27LV512@PLCC32 [(SA015A1T)]  
NM27LV512@TSOP32 [(SA410T)]      NM27P040  
NM27P040@PLCC32 [(SA015A1T)]      NM27P040@TSOP32 [(SA410T)]  
NM27P210      NM27P210@PLCC44 [(SA244)]  
NM27P512      NM27P512@PLCC32 [(SA015A1T)]  
NM59C11      NM59C11@SOIC8 [(SA602A)]  
NM93C06(08bit)      NM93C06(08bit)@SOIC8 [(SA602A)]  
NM93C06(16bit)      NM93C06(16bit)@SOIC8 [(SA602A)]  
NM93C46      NM93C46@SOIC8 [(SA602A)]  
NM93C46A(08bit)      NM93C46A(08bit)@SOIC8 [(SA602A)]  
NM93C46A(16bit)      NM93C46A(16bit)@SOIC8 [(SA602A)]  
NM93C46AL(08bit)  
NM93C46AL(08bit)@SOIC8 [(SA602A)]  
NM93C46AL(16bit)  
NM93C46AL(16bit)@SOIC8 [(SA602A)]  
NM93C46ALZ(08bit)  
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]  
NM93C46ALZ(16bit)

NM93C46ALZ(16bit)@SOIC8 [(SA602A)]  
NM93C46L NM93C46L@SOIC8 [(SA602A)]  
NM93C46LZ NM93C46LZ@SOIC8 [(SA602A)]  
NM93C56 NM93C56@SOIC8 [(SA602A)]  
NM93C56A(08bit) NM93C56A(08bit)@SOIC8 [(SA602A)]  
NM93C56A(16bit) NM93C56A(16bit)@SOIC8 [(SA602A)]  
NM93C56AL(08bit)  
NM93C56AL(08bit)@SOIC8 [(SA602A)]  
NM93C56AL(16bit)  
NM93C56AL(16bit)@SOIC8 [(SA602A)]  
NM93C56ALZ(08bit)  
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]  
NM93C56ALZ(16bit)  
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]  
NM93C56L NM93C56L@SOIC8 [(SA602A)]  
NM93C56LZ NM93C56LZ@SOIC8 [(SA602A)]  
NM93C66 NM93C66@SOIC8 [(SA602A)]  
NM93C66A NM93C66A(08bit)  
NM93C66A(08bit)@SOIC8 [(SA602A)] NM93C66A@SOIC8 [(SA602A)]  
NM93C66AL(08bit)  
NM93C66AL(08bit)@SOIC8 [(SA602A)]  
NM93C66AL(16bit)  
NM93C66AL(16bit)@SOIC8 [(SA602A)]  
NM93C66ALZ(08bit)  
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]  
NM93C66ALZ(16bit)  
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]  
NM93C66L NM93C66L@SOIC8 [(SA602A)]  
NM93C66LZ NM93C66LZ@SOIC8 [(SA602A)]  
NM93C86(16bit) NM93C86(16bit)@SOIC8 [(SA602A)]  
NM93C86A NM93C86A(08bit)  
NM93C86A(08bit)@SOIC8 [(SA602A)] NM93C86A@SOIC8 [(SA602A)]  
NM93C86AL(08bit)  
NM93C86AL(08bit)@SOIC8 [(SA602A)]  
NM93C86AL(16bit)  
NM93C86AL(16bit)@SOIC8 [(SA602A)]  
NM93C86ALZ(08bit)  
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]  
NM93C86ALZ(16bit)  
NM93C86ALZ(16bit)@SOIC8 [(SA602A)]  
NM93C86L NM93C86L@SOIC8 [(SA602A)]  
NM93C86LZ NM93C86LZ@SOIC8 [(SA602A)]  
NM93CS06(M8)@SOIC8 [(SA602A)] NM93CS06(MT8)@TSSOP8 [(SA026)]

NM93CS06(N) NM93CS46(M8)@SOIC8 [(SA602A)]  
NM93CS46(MT8)@TSSOP8 [(SA026)] NM93CS46(N)  
NM93CS56(M8)@SOIC8 [(SA602A)] NM93CS56(MT8)@TSSOP8 [(SA026)]  
NM93CS56(N) NM93CS66(M8)@SOIC8 [(SA602A)]  
NM93CS66(MT8)@TSSOP8 [(SA026)] NM93CS66(N)  
NMC2732 NMC2732B  
NMC2732H NMC27C010  
NMC27C010@PLCC32 [(SA015A1T)] NMC27C010@TSOP32 [(SA410T)]  
NMC27C1024 NMC27C1024@PLCC44 [(SA244)]  
NMC27C128B NMC27C128B@PLCC32 [(SA015A1T)]  
NMC27C128BN NMC27C128BN@PLCC32 [(SA015A1T)]  
NMC27C128BQ NMC27C128BQ@PLCC32 [(SA015A1T)]  
NMC27C128CQ NMC27C128Q  
NMC27C16 NMC27C16BQ  
NMC27C16BQE NMC27C16H  
NMC27C16HQ NMC27C16Q  
NMC27C210 NMC27C210@PLCC44 [(SA244)]  
NMC27C210Q NMC27C210Q@PLCC44 [(SA244)]  
NMC27C256B NMC27C256B@PLCC32 [(SA015A1T)]  
NMC27C256BN NMC27C256BQE  
NMC27C256BQM NMC27C256Q  
NMC27C256Q@PLCC32 [(SA015A1T)] NMC27C32  
NMC27C32B NMC27C32BQ  
NMC27C32E NMC27C32EH  
NMC27C32H NMC27C512  
NMC27C512@PLCC32 [(SA015A1T)] NMC27C512A  
NMC27C512A@PLCC32 [(SA015A1T)] NMC27C512AN  
NMC27C512AN@PLCC32 [(SA015A1T)] NMC27C64  
NMC27C64@PLCC32 [(SA015A1T)] NMC27C64BN  
NMC27C64N NMC27CP128  
NMC27CP256 NMC27CP64  
NMC59C11 NMC59C11@SOIC8 [(SA602A)]  
NMC87C257Q NMC87C257Q@PLCC32  
NMC87C257V NMC87C257V@PLCC32  
NMC9306 NMC9306@SOIC8 [(SA602A)]  
NMC9307 NMC9307@SOIC8 [(SA602A)]  
NMC9346 NMC9346@SOIC8 [(SA602A)]  
NMC93C56 NMC93C56@SOIC14 [(SA602)]  
NMC93C56@SOIC8 [(SA602A)] NMC93C66  
NMC93C66@SOIC14 [(SA602)] NMC93C86A  
NMC93C86A@SOIC14 [(SA602)] NMC93C86A@SOIC8 [(SA602A)]  
NMC93CS06(M14)@SOIC14 [(SA602)] NMC93CS06(N)  
NMC93CS46(M14)@SOIC14 [(SA602)] NMC93CS46(N)



NMC93CS56(M14)@SOIC14 [(SA602)] NMC93CS56(N)  
NMC93CS66(M14)@SOIC14 [(SA602)] NMC93CS66(N)  
NMC93S06(M14)@SOIC14 [(SA602)] NMC93S06(N)  
NMC9817 NMC9817A  
NS2816A NS9816A

## PLD

GAL16V8 GAL16V8@PLCC20 [(SA001A)]  
GAL16V8A GAL16V8A@PLCC20 [(SA001A)]  
GAL20V8 GAL20V8@PLCC28 [(SA008A)]  
GAL20V8A GAL20V8A@PLCC28 [(SA008A)]  
GAL20V8QS GAL20V8QS@PLCC28 [(SA008A)]

## NTE

### E(E)PROM/FRAM/NVRAM

NTE2532 NTE2532A  
NTE25L32

## NUMONYX

### E(E)PROM/FRAM/NVRAM

M25PX32@SOIC16 [(SA404)] M25PX32@SOIC8 [(SA023A)]  
M25PX32@VFQFPN8 [(SA683)] M25PX64@SOIC16 [(SA404)]  
M25PX64@VDFPN8 [(SA684)]

## NUVOTON

### MICROCONTROLLER

W78E051DDG W78E051DFG@TQFP44 [(SA245A)]  
W78E051DLG@TQFP48 [(SA248A-B005)]  
W78E051DPG@PLCC44 [(SA244)] W78E052DDG  
W78E052DFG@TQFP44 [(SA245A)]  
W78E052DLG@TQFP48 [(SA248A-B005)]

W78E052DPG@PLCC44 [(SA244)]      W78E054DDG  
W78E054DFG@TQFP44 [(SA245A)]  
W78E054DLG@TQFP48 [(SA248A-B005)]  
W78E054DPG@PLCC44 [(SA244)]      W78E058DDG  
W78E058DFG@TQFP44 [(SA245A)]  
W78E058DLG@TQFP48 [(SA248A-B005)]  
W78E058DPG@PLCC44 [(SA244)]      W78E516DDG  
W78E516DFG@TQFP44 [(SA245A)]  
W78E516DLG@TQFP48 [(SA248A-B005)]  
W78E516DPG@PLCC44 [(SA244)]      W78I051DDG  
W78I051DFG@TQFP44 [(SA245A)]  
W78I051DLG@TQFP48 [(SA248A-B005)]  
W78I051DPG@PLCC44 [(SA244)]      W78I052DDG  
W78I052DFG@TQFP44 [(SA245A)]  
W78I052DLG@TQFP48 [(SA248A-B005)]  
W78I052DPG@PLCC44 [(SA244)]      W78I054DDG  
W78I054DFG@TQFP44 [(SA245A)]  
W78I054DLG@TQFP48 [(SA248A-B005)]  
W78I054DPG@PLCC44 [(SA244)]

## NXP

### MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]      P83C660X2@TQFP44 [(SA245A)]  
P83C661X2@PLCC44 [(SA244)]      P83C661X2@TQFP44 [(SA245A)]  
P87C51      P87C51@PLCC44 [(SA244)]  
P87C51@TQFP44 [(SA245A)]      P87C51FA  
P87C51FA@PLCC44 [(SA244)]      P87C51FA@TQFP44 [(SA245A)]  
P87C51FB      P87C51FB@PLCC44 [(SA244)]  
P87C51FB@TQFP44 [(SA245A)]      P87C51FC  
P87C51FC@PLCC44 [(SA244)]      P87C51FC@TQFP44 [(SA245A)]  
P87C51MA2@PLCC44 [(SA244)]      P87C51MB2@PLCC44 [(SA244)]  
P87C51MC2@PLCC44 [(SA244)]      P87C51RA+  
P87C51RA+@PLCC44 [(SA244)]      P87C51RA+@TQFP44 [(SA245A)]  
P87C51RA2      P87C51RA2@PLCC44 [(SA244)]  
P87C51RA2@TQFP44 [(SA245A)]      P87C51RB+  
P87C51RB+@PLCC44 [(SA244)]      P87C51RB+@TQFP44 [(SA245A)]  
P87C51RB2      P87C51RB2@PLCC44 [(SA244)]  
P87C51RB2@TQFP44 [(SA245A)]      P87C51RC+  
P87C51RC+@PLCC44 [(SA244)]      P87C51RC+@TQFP44 [(SA245A)]  
P87C51RC2      P87C51RC2@PLCC44 [(SA244)]

P87C51RC2@TQFP44 [(SA245A)] P87C51RD+  
P87C51RD+@PLCC44 [(SA244)] P87C51RD+@TQFP44 [(SA245A)]  
P87C51RD2 P87C51RD2@PLCC44 [(SA244)]  
P87C51RD2@TQFP44 [(SA245A)] P87C51SB  
P87C51SB@PLCC44 [(SA244)] P87C51SB@TQFP44 [(SA245A)]  
P87C51SF P87C51SF@PLCC44 [(SA244)]  
P87C51SF@TQFP44 [(SA245A)] P87C51UB  
P87C51UB@PLCC44 [(SA244)] P87C51UB@TQFP44 [(SA245A)]  
P87C51UF P87C51UF@PLCC44 [(SA244)]  
P87C51UF@TQFP44 [(SA245A)] P87C51X2  
P87C51X2@PLCC44 [(SA244)] P87C51X2@TQFP44 [(SA245A)]  
P87C52 P87C52@PLCC44 [(SA244)]  
P87C52@TQFP44 [(SA245A)] P87C524  
P87C524@PLCC44 [(SA244)] P87C524@TQFP44 [(SA245A)]  
P87C528 P87C528@PLCC44 [(SA244)]  
P87C528@TQFP44 [(SA245A)] P87C52SB  
P87C52SB@PLCC44 [(SA244)] P87C52SB@TQFP44 [(SA245A)]  
P87C52SF P87C52SF@PLCC44 [(SA244)]  
P87C52SF@TQFP44 [(SA675)] P87C52UB  
P87C52UB@PLCC44 [(SA244)] P87C52UB@TQFP44 [(SA245A)]  
P87C52UF P87C52UF@PLCC44 [(SA244)]  
P87C52UF@TQFP44 [(SA245A)] P87C52X2  
P87C52X2@PLCC44 [(SA244)] P87C52X2@TQFP44 [(SA245A)]  
P87C54 P87C54@PLCC44 [(SA244)]  
P87C54@TQFP44 [(SA245A)] P87C54SB  
P87C54SB@PLCC44 [(SA244)] P87C54SB@TQFP44 [(SA245A)]  
P87C54SF P87C54SF@PLCC44 [(SA244)]  
P87C54SF@TQFP44 [(SA245A)] P87C54UB  
P87C54UB@PLCC44 [(SA244)] P87C54UB@TQFP44 [(SA245A)]  
P87C54UF P87C54UF@PLCC44 [(SA244)]  
P87C54UF@TQFP44 [(SA245A)] P87C54X2  
P87C54X2@PLCC44 [(SA244)] P87C54X2@TQFP44 [(SA245A)]  
P87C550 P87C550@PLCC44 [(SA244)]  
P87C552@PLCC68(\*) [(SA648-B6806)]  
P87C554@PLCC68(\*) [(SA648-B6806)]  
P87C575 P87C575@PLCC44 [(SA244)]  
P87C575@TQFP44 [(SA245A)] P87C576  
P87C576@PLCC44 [(SA244)] P87C576@TQFP44 [(SA245A)]  
P87C58 P87C58@PLCC44 [(SA244)]  
P87C58@TQFP44 [(SA245A)] P87C58SB  
P87C58SB@PLCC44 [(SA244)] P87C58SB@TQFP44 [(SA245A)]  
P87C58UB P87C58UB@PLCC44 [(SA244)]  
P87C58UB@TQFP44 [(SA245A)] P87C58X2

P87C58X2@PLCC44 [(SA244)] P87C58X2@TQFP44 [(SA245A)]  
P87C591@PLCC44 [(SA244)] P87C591@TQFP44 [(SA245A)]  
P87C652 P87C652@PLCC44 [(SA244)]  
P87C652@TQFP44 [(SA245A)] P87C654  
P87C654@PLCC44 [(SA244)] P87C654@TQFP44 [(SA245A)]  
P87C660X2@PLCC44 [(SA244)] P87C660X2@TQFP44 [(SA245A)]  
P87C661X2@PLCC44 [(SA244)] P87C661X2@TQFP44 [(SA245A)]  
P87C748 P87C748@PLCC28 [(SA008A)]  
P87C749 P87C749@PLCC28 [(SA008A)]  
P87C750 P87C750@PLCC28 [(SA008A)]  
P87C750@SSOP24 [(SA626A)] P87C751  
P87C751@PLCC28 [(SA008A)] P87C751@SSOP24 [(SA626A)]  
P87C752 P87C752@PLCC28 [(SA008A)]  
P87C752@SSOP28 [(SA626A)] P87C754  
P87C754@PLCC28 [(SA008A)] P87C754@SSOP28 [(SA626A)]  
P87CL52X2 P87CL52X2@PLCC44 [(SA244)]  
P87CL52X2@TQFP44 [(SA245A)] P87CL54X2  
P87CL54X2@PLCC44 [(SA244)] P87CL54X2@TQFP44 [(SA245A)]  
P87L51FA P87L51FA@PLCC44 [(SA244)]  
P87L51FA@TQFP44 [(SA245A)] P87L51FB  
P87L51FB@PLCC44 [(SA244)] P87L51FB@TQFP44 [(SA245A)]  
P87LPC759 P87LPC759(ISP) [ISP-HEADER01]  
P87LPC760 P87LPC760(ISP) [ISP-HEADER01]  
P87LPC760@TSSOP14 [(SA026)]  
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]  
P87LPC761 P87LPC761(ISP) [ISP-HEADER01]  
P87LPC762 P87LPC762(ISP) [ISP-HEADER01]  
P87LPC762@PLCC44 [(SA244)]  
P87LPC762@PLCC44(ISP) [ISP-HEADER01]  
P87LPC762@SOIC20 [(SA404)]  
P87LPC762@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764 P87LPC764(ISP) [ISP-HEADER01]  
P87LPC764@PLCC44 [(SA244)]  
P87LPC764@PLCC44(ISP) [ISP-HEADER01]  
P87LPC764@SOIC20 [(SA404)]  
P87LPC764@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764@TSSOP20 [(SA643)]  
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC767 P87LPC767(ISP) [ISP-HEADER01]  
P87LPC767@PLCC44 [(SA244)]  
P87LPC767@PLCC44(ISP) [ISP-HEADER01]  
P87LPC767@SOIC20 [(SA404)]  
P87LPC767@SOIC20(ISP) [ISP-HEADER01]

P87LPC768 P87LPC768(ISP) [ISP-HEADER01]  
P87LPC768@SOIC20 [(SA404)]  
P87LPC768@SOIC20(ISP) [ISP-HEADER01]  
P87LPC769 P87LPC769(ISP) [ISP-HEADER01]  
P87LPC769@PLCC44 [(SA244)]  
P87LPC769@PLCC44(ISP) [ISP-HEADER01]  
P87LPC769@SOIC20 [(SA404)]  
P87LPC769@SOIC20(ISP) [ISP-HEADER01]  
P87LPC778 P87LPC778(ISP) [ISP-HEADER01]  
P87LPC778@TSSOP20 [(SA026)]  
P87LPC778@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC779 P87LPC779(ISP) [ISP-HEADER01]  
P87LPC779@TSSOP20 [(SA643)]  
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]  
P89C138 P89C138@PLCC44 [(SA244)]  
P89C138@TQFP44 [(SA245A)] P89C238  
P89C238@PLCC44 [(SA244)] P89C238@TQFP44 [(SA245A)]  
P89C51B P89C51B@PLCC44 [(SA244)]  
P89C51B@TQFP44 [(SA245A)] P89C51RA+  
P89C51RA+@PLCC44 [(SA244)] P89C51RA+@TQFP44 [(SA245A)]  
P89C51RA2B P89C51RA2B@PLCC44 [(SA244)]  
P89C51RA2B@TQFP44 [(SA245A)] P89C51RB+  
P89C51RB+@PLCC44 [(SA244)] P89C51RB+@TQFP44 [(SA245A)]  
P89C51RB2B P89C51RB2B@PLCC44 [(SA244)]  
P89C51RB2B@TQFP44 [(SA245A)] P89C51RB2H  
P89C51RB2H@PLCC44 [(SA244)] P89C51RB2H@TQFP44 [(SA245A)]  
P89C51RC+ P89C51RC+@PLCC44 [(SA244)]  
P89C51RC+@TQFP44 [(SA245A)] P89C51RC2B  
P89C51RC2B@PLCC44 [(SA244)] P89C51RC2B@TQFP44 [(SA245A)]  
P89C51RC2H P89C51RC2H@PLCC44 [(SA244)]  
P89C51RC2H@TQFP44 [(SA245A)] P89C51RD+  
P89C51RD+@PLCC44 [(SA244)] P89C51RD+@TQFP44 [(SA245A)]  
P89C51RD2B P89C51RD2B@PLCC44 [(SA244)]  
P89C51RD2B@TQFP44 [(SA245A)] P89C51RD2H  
P89C51RD2H@PLCC44 [(SA244)] P89C51RD2H@TQFP44 [(SA245A)]  
P89C51UB P89C51UB@PLCC44 [(SA244)]  
P89C51UB@TQFP44 [(SA245A)] P89C51UF  
P89C51UF@PLCC44 [(SA244)] P89C51UF@TQFP44 [(SA245A)]  
P89C51X2 P89C51X2@PLCC44 [(SA244)]  
P89C51X2@TQFP44 [(SA245A)] P89C51X2B  
P89C51X2B@PLCC44 [(SA244)] P89C51X2B@TQFP44 [(SA245A)]  
P89C51X2F P89C51X2F@PLCC44 [(SA244)]  
P89C51X2F@TQFP44 [(SA245A)] P89C52

P89C52@PLCC44 [(SA244)] P89C52@TQFP44 [(SA245A)]  
P89C52B P89C52B@PLCC44 [(SA244)]  
P89C52B@TQFP44 [(SA245A)] P89C52UB  
P89C52UB@PLCC44 [(SA244)] P89C52UB@TQFP44 [(SA245A)]  
P89C52UF P89C52UF@PLCC44 [(SA244)]  
P89C52UF@TQFP44 [(SA245A)] P89C52X2  
P89C52X2@PLCC44 [(SA244)] P89C52X2@TQFP44 [(SA245A)]  
P89C52X2B P89C52X2B@PLCC44 [(SA244)]  
P89C52X2B@TQFP44 [(SA245A)] P89C52X2F  
P89C52X2F@PLCC44 [(SA244)] P89C52X2F@TQFP44 [(SA245A)]  
P89C536@PLCC44 [(SA244)] P89C538@PLCC44 [(SA244)]  
P89C54 P89C54@PLCC44 [(SA244)]  
P89C54@TQFP44 [(SA245A)] P89C54B  
P89C54B@PLCC44 [(SA244)] P89C54B@TQFP44 [(SA245A)]  
P89C54UB P89C54UB@PLCC44 [(SA244)]  
P89C54UB@TQFP44 [(SA245A)] P89C54UF  
P89C54UF@PLCC44 [(SA244)] P89C54UF@TQFP44 [(SA245A)]  
P89C54X2 P89C54X2@PLCC44 [(SA244)]  
P89C54X2@TQFP44 [(SA245A)] P89C54X2B  
P89C54X2B@PLCC44 [(SA244)] P89C54X2B@TQFP44 [(SA245A)]  
P89C54X2F P89C54X2F@PLCC44 [(SA244)]  
P89C54X2F@TQFP44 [(SA245A)] P89C58  
P89C58@PLCC44 [(SA244)] P89C58@TQFP44 [(SA245A)]  
P89C58B P89C58B@PLCC44 [(SA244)]  
P89C58B@TQFP44 [(SA245A)] P89C58UB  
P89C58UB@PLCC44 [(SA244)] P89C58UB@TQFP44 [(SA245A)]  
P89C58UF P89C58UF@PLCC44 [(SA244)]  
P89C58UF@TQFP44 [(SA245A)] P89C58X2  
P89C58X2@PLCC44 [(SA244)] P89C58X2@TQFP44 [(SA245A)]  
P89C58X2B P89C58X2B@PLCC44 [(SA244)]  
P89C58X2B@TQFP44 [(SA245A)] P89C58X2F  
P89C58X2F@PLCC44 [(SA244)] P89C58X2F@TQFP44 [(SA245A)]  
P89C60X2 P89C60X2@PLCC44 [(SA244)]  
P89C60X2@TQFP44 [(SA245A)] P89C61X2  
P89C61X2@PLCC44 [(SA244)] P89C61X2@TQFP44 [(SA245A)]  
P89C660 P89C660@PLCC44 [(SA244)]  
P89C660@TQFP44 [(SA245A)] P89C662  
P89C662@PLCC44 [(SA244)] P89C662@TQFP44 [(SA245A)]  
P89C664 P89C664@PLCC44 [(SA244)]  
P89C664@TQFP44 [(SA245A)] P89C668  
P89C668@PLCC44 [(SA244)] P89C668@TQFP44 [(SA245A)]  
P89C669 P89C669@LQFP44 [(SA245A)]  
P89C669@PLCC44 [(SA244)] P89C738

P89C738@PLCC44 [(SA244)] P89C738@TQFP44 [(SA245A)]  
P89C838 P89C838@PLCC44 [(SA244)]  
P89C838@TQFP44 [(SA245A)] P89CV51RB2@PLCC44 [(SA244)]  
P89CV51RB2@TQFP44 [(SA245A)] P89CV51RC2@PLCC44 [(SA244)]  
P89CV51RC2@TQFP44 [(SA245A)] P89CV51RD2@PLCC44 [(SA244)]  
P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD) [(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]  
P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]

P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(BA)@PLCC28 [(SA008A)]  
P89LPC93201(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(FA)@PLCC28 [(SA008A)]  
P89LPC93201(FDH)@TSSOP28 [(SA643)]  
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9321(BA)@PLCC28 [(SA008A)]  
P89LPC9321(BDH)@TSSOP28 [(SA643)]  
P89LPC9321(FA)@PLCC28 [(SA008A)]



P89LPC9321(FDH)@TSSOP28 [(SA643)]  
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC93401(FDH)@TSSOP28 [(SA643)]  
P89LPC93401V  
P89LPC9341(FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]

P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
P89LV51RB2                    P89LV51RB2@PLCC44 [(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)]    P89LV51RC2  
P89LV51RC2@PLCC44 [(SA244)]    P89LV51RC2@TQFP44 [(SA245A)]  
P89LV51RD2                    P89LV51RD2(new)  
P89LV51RD2(new)@PLCC44 [(SA244)]  
P89LV51RD2(new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)]    P89LV51RD2@TQFP44 [(SA245A)]  
P89LV51RD2BA(new)@PLCC44 [(SA244)]  
P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2BBC@TQFP44 [(SA245A)]    P89LV51RD2BN

P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)] P89LV51RD2FN  
P89LV51RD2FN(new) P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44 [(SA245A)]  
P89V51RC2 P89V51RC2@PLCC44 [(SA244)]  
P89V51RC2@TQFP44 [(SA245A)] P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44 [(SA244)]  
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44 [(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)] P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)] P89V51RD2FN  
P89V51RD2FN(new) P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44 [(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44 [(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44 [(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44 [(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44 [(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44 [(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44 [(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44 [(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44 [(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44 [(SA245A)]

OKI

## E(E)PROM/FRAM/NVRAM

MR27C1602B MR27C1602B@PSOP44 [(SA638)]  
MR27V1602D MR27V1602D@PSOP44 [(SA638)]

MR27V1602D@TSOP44 [(SA645)] MR27V1602D@TSOP48 [(SA247-B005)]  
MR27V1602E MR27V1602E@PSOP44 [(SA638)]  
MR27V1602E@TSOP44 [(SA645)] MR27V1602E@TSOP48 [(SA247-B005)]  
MR27V1602F MR27V1602F@PSOP44 [(SA638)]  
MR27V1602F@TSOP44 [(SA645)] MR27V1602F@TSOP48 [(SA247-B005)]  
MR27V1652D MR27V1652D@PSOP44 [(SA638)]  
MR27V1652D@TSOP44 [(SA645)] MR27V1652D@TSOP48 [(SA247-B005)]  
MR27V3202F@TSOP44 [(SA645)] MR27V3202F@TSOP48 [(SA247-B005)]  
MR27V401D MR27V401D@PSOP32 [(SA638)]  
MR27V401D@TSOP32 [(SA620)] MR27V401E  
MR27V401E@PSOP32 [(SA638)] MR27V401E@TSOP32 [(SA620)]  
MR27V402D MR27V402D@PSOP40 [(SA661)]  
MR27V402D@TSOP44 [(SA645)] MR27V402E  
MR27V402E@PSOP40 [(SA661)] MR27V402E@TSOP44 [(SA645)]  
MR27V6402D@PSOP44 [(SA638)] MR27V6402D@TSOP44 [(SA645)]  
MR27V6402D@TSOP48 [(SA247-B005)] MR27V6402G@PSOP44 [(SA638)]  
MR27V6402G@TSOP44 [(SA645)] MR27V6402G@TSOP48 [(SA247-B005)]  
MR27V802D MR27V802D@PSOP44 [(SA638)]  
MR27V802D@TSOP44 [(SA645)] MR27V802F@PSOP44 [(SA638)]  
MR27V802F@TSOP44 [(SA645)] MR27V802F@TSOP48 [(SA247-B005)]  
MR27V852D MR27V852D@PSOP44 [(SA638)]  
MR27V852D@TSOP44 [(SA645)] MR27V852E  
MR27V852E@SOJ42 [(SA661)] MSM16812(08bit)  
MSM16812(08bit)@SOIC8 [(SA602A)] MSM271000  
MSM271000@PLCC32 [(SA015A1T)] MSM271000@TSOP32 [(SA410T)]  
MSM27128 MSM27128A  
MSM27128AS MSM27128AZB-RS  
MSM2716 MSM27256  
MSM27256AS MSM27256ZB-RS  
MSM2732 MSM2732A  
MSM27512 MSM27512AS  
MSM27512ZB-RS MSM2764  
MSM2764A MSM2764AS  
MSM2764AZB-RS MSM2764RS  
MSM27C1024 MSM27C1024AS  
MSM27C128 MSM27C128AZB-RS  
MSM27C1602CZ MSM27C1602CZ@PSOP44 [(SA638)]  
MSM27C1602CZ@TSOP48 [(SA247-B005)]  
MSM27C1652CZ MSM27C1652CZ@PSOP44 [(SA638)]  
MSM27C1652CZ@TSOP48 [(SA247-B005)]  
MSM27C256 MSM27C256A  
MSM27C256H MSM27C256HZB  
MSM27C256ZB MSM27C64AS

MSM27C802CZ                    MSM27C802CZ@PSOP44 [(SA638)]  
MSM27C802CZ@TSOP44 [(SA645)]    MSM27C852CZ  
MSM27C852CZ@PSOP44 [(SA638)]    MSM27C852CZ@TSOP44 [(SA645)]  
MSM2816A(RS)                    MSM28C16A

## DRAM & SRAM

MSM51256                    MSM51256@SOIC28 [(SA630)]  
MSM51257AL                    MSM51257AL@SOIC28 [(SA630)]  
MSM51257ALL                    MSM51257ALL@SOIC28 [(SA630)]  
MSM5165AL                    MSM5165AL@SOIC28 [(SA630)]  
MSM5188                    MSM5188@SOJ22 [(SA646)]

## PARALLAX

## MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)]    SX20AC/SS@SSOP20 [(SA626A)]  
SX28AC/DP                    SX28AC/DP/G  
SX28AC/SS/G@SSOP28 [(SA626A)]    SX28AC/SS@SSOP28 [(SA626A)]  
SX48BD/G@TQFP48 [(SA248)]    SX48BD@TQFP48 [(SA248)]

## PFLASH(MSTAR)

## E(E)PROM/FRAM/NVRAM

PS25LV010A@SOIC8 [(SA602A)]    PS25LV010A@WSON8 [(SA683)]  
PS25LV020@SOIC8 [(SA602A)]    PS25LV020@WSON8 [(SA683)]  
PS25LV040@SOIC8 [(SA605A)]    PS25LV040@WSON8 [(SA683)]  
PS25LV080@SOIC8 [(SA605A)]    PS25LV080@WSON8 [(SA683)]

## PHILIPS

## E(E)PROM/FRAM/NVRAM

27C010                    27C010@PLCC32 [(SA015A1T)]  
27C010@TSOP32 [(SA410T)]    27C040  
27C040@PLCC32 [(SA015A1T)]    27C040@TSOP32 [(SA410T)]

27C210 27C210@PLCC44 [(SA244)]  
 27C240 27C240@PLCC44 [(SA244)]  
 27C256 27C256@PLCC32 [(SA015A1T)]  
 27C32 27C512  
 27C512@PLCC32 [(SA015A1T)] 27C64  
 27C64@PLCC32 [(SA015A1T)] 27C64A  
 27C64A@PLCC32 [(SA015A1T)] 27C64AF  
 27C64AF@PLCC32 [(SA015A1T)] 27HC641  
 27HC641@PLCC28 [(SA008A)] 27PC32  
 PCA24S08@SOIC8 [(SA602A)] PCA24S08@TSSOP8 [(SA026)]  
 PCA8574(P) PCA8574(T)@SOIC16 [(SA404)]  
 PCA8574(TS)@SSOP20 [(SA026)] PCA8574A(P)  
 PCA8574A(T)@SOIC16 [(SA404)] PCA8574A(TS)@SSOP20 [(SA026)]  
 PCA8581 PCA8581@SOIC8 [(SA602A)]  
 PCA8581C PCA8581C@SOIC8 [(SA602A)]  
 PCA8582A PCA8582A@SOIC8 [(SA602A)]  
 PCA8582B PCA8582B@SOIC8 [(SA602A)]  
 PCA8582C PCA8582C@SOIC8 [(SA602A)]  
 PCA8582D PCA8582D@SOIC8 [(SA602A)]  
 PCA8582E PCA8582E@SOIC8 [(SA602A)]  
 PCA9500@HQVFN16 PCA9500@SOIC16 [(SA404)]  
 PCA9500@TSSOP16 [(SA026)] PCA9501@HQVFN20  
 PCA9501@SOIC20 [(SA404)] PCA9501@TSSOP20 [(SA026)]  
 PCA9561D@SOP20 [(SA404)] PCA9561W@TSSOP20 [(SA026)]  
 PCD8581 PCD8581@SOIC8 [(SA602A)]  
 PCD8581C PCD8581C@SOIC8 [(SA602A)]  
 PCD8582A PCD8582A@SOIC8 [(SA602A)]  
 PCD8582B PCD8582B@SOIC8 [(SA602A)]  
 PCD8582C PCD8582C@SOIC8 [(SA602A)]  
 PCD8582D PCD8582D@SOIC8 [(SA602A)]  
 PCD8582E PCD8582E@SOIC8 [(SA602A)]  
 PCF85102C PCF85102C@SOIC8 [(SA602A)]  
 PCF85103C PCF85103C@SOIC8 [(SA602A)]  
 PCF85116 PCF85116@SOIC8 [(SA602A)]  
 PCF8581 PCF8581@SOIC8 [(SA602A)]  
 PCF8581C PCF8581C@SOIC8 [(SA602A)]  
 PCF8582A PCF8582A@SOIC8 [(SA602A)]  
 PCF8582B PCF8582B@SOIC8 [(SA602A)]  
 PCF8582C PCF8582C@SOIC8 [(SA602A)]  
 PCF8582D PCF8582D@SOIC8 [(SA602A)]  
 PCF8582E PCF8582E@SOIC8 [(SA602A)]  
 PCF8594 PCF8594@SOIC8 [(SA626A)]  
 PCF8594C PCF8594C@SOIC8 [(SA626A)]

PCF8594D	PCF8594D@SOIC8 [(SA626A)]
PCF8594E	PCF8594E@SOIC8 [(SA626A)]
PCF8598	PCF8598@SOIC8 [(SA626A)]
PCF8598C	PCF8598C@SOIC8 [(SA626A)]
PCF8598D	PCF8598D@SOIC8 [(SA626A)]
PCF8598E	PCF8598E@SOIC8 [(SA626A)]

## MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44 [(SA245A)]
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44 [(SA245A)]
P87C51	P87C51@PLCC44 [(SA244)]
P87C51@TQFP44 [(SA245A)]	P87C51FA
P87C51FA@PLCC44 [(SA244)]	P87C51FA@TQFP44 [(SA245A)]
P87C51FB	P87C51FB@PLCC44 [(SA244)]
P87C51FB@TQFP44 [(SA245A)]	P87C51FC
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44 [(SA245A)]
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44 [(SA244)]
P87C51MC2@PLCC44 [(SA244)]	P87C51RA+
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44 [(SA245A)]
P87C51RA2	P87C51RA2@PLCC44 [(SA244)]
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB+
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44 [(SA245A)]
P87C51RB2	P87C51RB2@PLCC44 [(SA244)]
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC+
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44 [(SA245A)]
P87C51RC2	P87C51RC2@PLCC44 [(SA244)]
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD+
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44 [(SA245A)]
P87C51RD2	P87C51RD2@PLCC44 [(SA244)]
P87C51RD2@TQFP44 [(SA245A)]	P87C51SB
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44 [(SA245A)]
P87C51SF	P87C51SF@PLCC44 [(SA244)]
P87C51SF@TQFP44 [(SA245A)]	P87C51UB
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44 [(SA245A)]
P87C51UF	P87C51UF@PLCC44 [(SA244)]
P87C51UF@TQFP44 [(SA245A)]	P87C51X2
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44 [(SA245A)]
P87C52	P87C52@PLCC44 [(SA244)]
P87C52@TQFP44 [(SA245A)]	P87C524
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44 [(SA245A)]
P87C528	P87C528@PLCC44 [(SA244)]

P87C528@TQFP44 [(SA245A)] P87C52SB  
P87C52SB@PLCC44 [(SA244)] P87C52SB@TQFP44 [(SA245A)]  
P87C52SF P87C52SF@PLCC44 [(SA244)]  
P87C52SF@TQFP44 [(SA675)] P87C52UB  
P87C52UB@PLCC44 [(SA244)] P87C52UB@TQFP44 [(SA245A)]  
P87C52UF P87C52UF@PLCC44 [(SA244)]  
P87C52UF@TQFP44 [(SA245A)] P87C52X2  
P87C52X2@PLCC44 [(SA244)] P87C52X2@TQFP44 [(SA245A)]  
P87C54 P87C54@PLCC44 [(SA244)]  
P87C54@TQFP44 [(SA245A)] P87C54SB  
P87C54SB@PLCC44 [(SA244)] P87C54SB@TQFP44 [(SA245A)]  
P87C54SF P87C54SF@PLCC44 [(SA244)]  
P87C54SF@TQFP44 [(SA245A)] P87C54UB  
P87C54UB@PLCC44 [(SA244)] P87C54UB@TQFP44 [(SA245A)]  
P87C54UF P87C54UF@PLCC44 [(SA244)]  
P87C54UF@TQFP44 [(SA245A)] P87C54X2  
P87C54X2@PLCC44 [(SA244)] P87C54X2@TQFP44 [(SA245A)]  
P87C550 P87C550@PLCC44 [(SA244)]  
P87C552@PLCC68(\*) [(SA648-B6806)]  
P87C554@PLCC68(\*) [(SA648-B6806)]  
P87C575 P87C575@PLCC44 [(SA244)]  
P87C575@TQFP44 [(SA245A)] P87C576  
P87C576@PLCC44 [(SA244)] P87C576@TQFP44 [(SA245A)]  
P87C58 P87C58@PLCC44 [(SA244)]  
P87C58@TQFP44 [(SA245A)] P87C58SB  
P87C58SB@PLCC44 [(SA244)] P87C58SB@TQFP44 [(SA245A)]  
P87C58UB P87C58UB@PLCC44 [(SA244)]  
P87C58UB@TQFP44 [(SA245A)] P87C58X2  
P87C58X2@PLCC44 [(SA244)] P87C58X2@TQFP44 [(SA245A)]  
P87C591@PLCC44 [(SA244)] P87C591@TQFP44 [(SA245A)]  
P87C652 P87C652@PLCC44 [(SA244)]  
P87C652@TQFP44 [(SA245A)] P87C654  
P87C654@PLCC44 [(SA244)] P87C654@TQFP44 [(SA245A)]  
P87C660X2@PLCC44 [(SA244)] P87C660X2@TQFP44 [(SA245A)]  
P87C661X2@PLCC44 [(SA244)] P87C661X2@TQFP44 [(SA245A)]  
P87C748 P87C748@PLCC28 [(SA008A)]  
P87C749 P87C749@PLCC28 [(SA008A)]  
P87C750 P87C750@PLCC28 [(SA008A)]  
P87C750@SSOP24 [(SA626A)] P87C751  
P87C751@PLCC28 [(SA008A)] P87C751@SSOP24 [(SA626A)]  
P87C752 P87C752@PLCC28 [(SA008A)]  
P87C752@SSOP28 [(SA626A)] P87C754  
P87C754@PLCC28 [(SA008A)] P87C754@SSOP28 [(SA626A)]



P87CL52X2 P87CL52X2@PLCC44 [(SA244)]  
P87CL52X2@TQFP44 [(SA245A)] P87CL54X2  
P87CL54X2@PLCC44 [(SA244)] P87CL54X2@TQFP44 [(SA245A)]  
P87L51FA P87L51FA@PLCC44 [(SA244)]  
P87L51FA@TQFP44 [(SA245A)] P87L51FB  
P87L51FB@PLCC44 [(SA244)] P87L51FB@TQFP44 [(SA245A)]  
P87LPC759 P87LPC759(ISP) [ISP-HEADER01]  
P87LPC760 P87LPC760(ISP) [ISP-HEADER01]  
P87LPC760@TSSOP14 [(SA026)]  
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]  
P87LPC761 P87LPC761(ISP) [ISP-HEADER01]  
P87LPC762 P87LPC762(ISP) [ISP-HEADER01]  
P87LPC762@PLCC44 [(SA244)]  
P87LPC762@PLCC44(ISP) [ISP-HEADER01]  
P87LPC762@SOIC20 [(SA404)]  
P87LPC762@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764 P87LPC764(ISP) [ISP-HEADER01]  
P87LPC764@PLCC44 [(SA244)]  
P87LPC764@PLCC44(ISP) [ISP-HEADER01]  
P87LPC764@SOIC20 [(SA404)]  
P87LPC764@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764@TSSOP20 [(SA643)]  
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC767 P87LPC767(ISP) [ISP-HEADER01]  
P87LPC767@PLCC44 [(SA244)]  
P87LPC767@PLCC44(ISP) [ISP-HEADER01]  
P87LPC767@SOIC20 [(SA404)]  
P87LPC767@SOIC20(ISP) [ISP-HEADER01]  
P87LPC768 P87LPC768(ISP) [ISP-HEADER01]  
P87LPC768@SOIC20 [(SA404)]  
P87LPC768@SOIC20(ISP) [ISP-HEADER01]  
P87LPC769 P87LPC769(ISP) [ISP-HEADER01]  
P87LPC769@PLCC44 [(SA244)]  
P87LPC769@PLCC44(ISP) [ISP-HEADER01]  
P87LPC769@SOIC20 [(SA404)]  
P87LPC769@SOIC20(ISP) [ISP-HEADER01]  
P87LPC778 P87LPC778(ISP) [ISP-HEADER01]  
P87LPC778@TSSOP20 [(SA026)]  
P87LPC778@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC779 P87LPC779(ISP) [ISP-HEADER01]  
P87LPC779@TSSOP20 [(SA643)]  
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]  
P89C138 P89C138@PLCC44 [(SA244)]

P89C138@TQFP44 [(SA245A)] P89C238  
P89C238@PLCC44 [(SA244)] P89C238@TQFP44 [(SA245A)]  
P89C51B P89C51B@PLCC44 [(SA244)]  
P89C51B@TQFP44 [(SA245A)] P89C51RA+  
P89C51RA+@PLCC44 [(SA244)] P89C51RA+@TQFP44 [(SA245A)]  
P89C51RA2B P89C51RA2B@PLCC44 [(SA244)]  
P89C51RA2B@TQFP44 [(SA245A)] P89C51RB+  
P89C51RB+@PLCC44 [(SA244)] P89C51RB+@TQFP44 [(SA245A)]  
P89C51RB2B P89C51RB2B@PLCC44 [(SA244)]  
P89C51RB2B@TQFP44 [(SA245A)] P89C51RB2H  
P89C51RB2H@PLCC44 [(SA244)] P89C51RB2H@TQFP44 [(SA245A)]  
P89C51RC+ P89C51RC+@PLCC44 [(SA244)]  
P89C51RC+@TQFP44 [(SA245A)] P89C51RC2B  
P89C51RC2B@PLCC44 [(SA244)] P89C51RC2B@TQFP44 [(SA245A)]  
P89C51RC2H P89C51RC2H@PLCC44 [(SA244)]  
P89C51RC2H@TQFP44 [(SA245A)] P89C51RD+  
P89C51RD+@PLCC44 [(SA244)] P89C51RD+@TQFP44 [(SA245A)]  
P89C51RD2B P89C51RD2B@PLCC44 [(SA244)]  
P89C51RD2B@TQFP44 [(SA245A)] P89C51RD2H  
P89C51RD2H@PLCC44 [(SA244)] P89C51RD2H@TQFP44 [(SA245A)]  
P89C51UB P89C51UB@PLCC44 [(SA244)]  
P89C51UB@TQFP44 [(SA245A)] P89C51UF  
P89C51UF@PLCC44 [(SA244)] P89C51UF@TQFP44 [(SA245A)]  
P89C51X2 P89C51X2@PLCC44 [(SA244)]  
P89C51X2@TQFP44 [(SA245A)] P89C51X2B  
P89C51X2B@PLCC44 [(SA244)] P89C51X2B@TQFP44 [(SA245A)]  
P89C51X2F P89C51X2F@PLCC44 [(SA244)]  
P89C51X2F@TQFP44 [(SA245A)] P89C52  
P89C52@PLCC44 [(SA244)] P89C52@TQFP44 [(SA245A)]  
P89C52B P89C52B@PLCC44 [(SA244)]  
P89C52B@TQFP44 [(SA245A)] P89C52UB  
P89C52UB@PLCC44 [(SA244)] P89C52UB@TQFP44 [(SA245A)]  
P89C52UF P89C52UF@PLCC44 [(SA244)]  
P89C52UF@TQFP44 [(SA245A)] P89C52X2  
P89C52X2@PLCC44 [(SA244)] P89C52X2@TQFP44 [(SA245A)]  
P89C52X2B P89C52X2B@PLCC44 [(SA244)]  
P89C52X2B@TQFP44 [(SA245A)] P89C52X2F  
P89C52X2F@PLCC44 [(SA244)] P89C52X2F@TQFP44 [(SA245A)]  
P89C536@PLCC44 [(SA244)] P89C538@PLCC44 [(SA244)]  
P89C54 P89C54@PLCC44 [(SA244)]  
P89C54@TQFP44 [(SA245A)] P89C54B  
P89C54B@PLCC44 [(SA244)] P89C54B@TQFP44 [(SA245A)]  
P89C54UB P89C54UB@PLCC44 [(SA244)]

P89C54UB@TQFP44 [(SA245A)] P89C54UF  
P89C54UF@PLCC44 [(SA244)] P89C54UF@TQFP44 [(SA245A)]  
P89C54X2 P89C54X2@PLCC44 [(SA244)]  
P89C54X2@TQFP44 [(SA245A)] P89C54X2B  
P89C54X2B@PLCC44 [(SA244)] P89C54X2B@TQFP44 [(SA245A)]  
P89C54X2F P89C54X2F@PLCC44 [(SA244)]  
P89C54X2F@TQFP44 [(SA245A)] P89C58  
P89C58@PLCC44 [(SA244)] P89C58@TQFP44 [(SA245A)]  
P89C58B P89C58B@PLCC44 [(SA244)]  
P89C58B@TQFP44 [(SA245A)] P89C58UB  
P89C58UB@PLCC44 [(SA244)] P89C58UB@TQFP44 [(SA245A)]  
P89C58UF P89C58UF@PLCC44 [(SA244)]  
P89C58UF@TQFP44 [(SA245A)] P89C58X2  
P89C58X2@PLCC44 [(SA244)] P89C58X2@TQFP44 [(SA245A)]  
P89C58X2B P89C58X2B@PLCC44 [(SA244)]  
P89C58X2B@TQFP44 [(SA245A)] P89C58X2F  
P89C58X2F@PLCC44 [(SA244)] P89C58X2F@TQFP44 [(SA245A)]  
P89C60X2 P89C60X2@PLCC44 [(SA244)]  
P89C60X2@TQFP44 [(SA245A)] P89C61X2  
P89C61X2@PLCC44 [(SA244)] P89C61X2@TQFP44 [(SA245A)]  
P89C660 P89C660@PLCC44 [(SA244)]  
P89C660@TQFP44 [(SA245A)] P89C662  
P89C662@PLCC44 [(SA244)] P89C662@TQFP44 [(SA245A)]  
P89C664 P89C664@PLCC44 [(SA244)]  
P89C664@TQFP44 [(SA245A)] P89C668  
P89C668@PLCC44 [(SA244)] P89C668@TQFP44 [(SA245A)]  
P89C669 P89C669@LQFP44 [(SA245A)]  
P89C669@PLCC44 [(SA244)] P89C738  
P89C738@PLCC44 [(SA244)] P89C738@TQFP44 [(SA245A)]  
P89C838 P89C838@PLCC44 [(SA244)]  
P89C838@TQFP44 [(SA245A)] P89CV51RB2@PLCC44 [(SA244)]  
P89CV51RB2@TQFP44 [(SA245A)] P89CV51RC2@PLCC44 [(SA244)]  
P89CV51RC2@TQFP44 [(SA245A)] P89CV51RD2@PLCC44 [(SA244)]  
P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD) [(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]  
P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]

P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]

P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(BA)@PLCC28 [(SA008A)]  
P89LPC93201(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(FA)@PLCC28 [(SA008A)]  
P89LPC93201(FDH)@TSSOP28 [(SA643)]  
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9321(BA)@PLCC28 [(SA008A)]  
P89LPC9321(BDH)@TSSOP28 [(SA643)]  
P89LPC9321(FA)@PLCC28 [(SA008A)]  
P89LPC9321(FDH)@TSSOP28 [(SA643)]  
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]

P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC93401(FDH)@TSSOP28 [(SA643)]  
P89LPC93401V  
P89LPC9341(FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]

P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
P89LV51RB2 P89LV51RB2@PLCC44 [(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)] P89LV51RC2  
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44 [(SA245A)]  
P89LV51RD2 P89LV51RD2(new)  
P89LV51RD2(new)@PLCC44 [(SA244)]  
P89LV51RD2(new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44 [(SA245A)]  
P89LV51RD2BA(new)@PLCC44 [(SA244)]  
P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2BBC@TQFP44 [(SA245A)] P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)] P89LV51RD2FN  
P89LV51RD2FN(new) P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44 [(SA245A)]  
P89V51RC2 P89V51RC2@PLCC44 [(SA244)]  
P89V51RC2@TQFP44 [(SA245A)] P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44 [(SA244)]  
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44 [(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]

P89V51RD2BBC@TQFP44 [(SA245A)] P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)] P89V51RD2FN  
P89V51RD2FN(new) P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44 [(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44 [(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44 [(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44 [(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44 [(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44 [(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44 [(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44 [(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44 [(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44 [(SA245A)]

PJ

## E(E)PROM/FRAM/NVRAM

PJ24C02 PJ24C02@SOIC8 [(SA602A)]  
PJ24C02@TSSOP8 [(SA026)]

PMC

## E(E)PROM/FRAM/NVRAM

PM24C64 PM24C64@SOIC8 [(SA602A)]  
PM24C64@TSOP8 [(SA026)] PM25LV010(B)@SOIC8 [(SA023A)]  
PM25LV010(Q)@WSON8 [(SA683)] PM25LV010(S)@SOIC8 [(SA602A)]  
PM25LV010A@SOIC8 [(SA602A)] PM25LV010A@WSON8 [(SA683)]  
PM25LV016@SOIC8 [(SA605A)] PM25LV016@WSON8 [(SA683)]  
PM25LV016A@SOIC8 [(SA605A)] PM25LV016A@WSON8 [(SA683)]  
PM25LV020(B)@SOIC8 [(SA023A)] PM25LV020(Q)@WSON8 [(SA683)]  
PM25LV020(S)@SOIC8 [(SA602A)] PM25LV040(B)@SOIC8 [(SA023A)]



PM25LV040(Q)@WSON8 [(SA683)]	PM25LV040(S)@SOIC8 [(SA602A)]
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8 [(SA683)]
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8 [(SA683)]
PM25LV512(B)@SOIC8 [(SA023A)]	PM25LV512(Q)@WSON8 [(SA683)]
PM25LV512(S)@SOIC8 [(SA602A)]	PM29F002B
PM29F002B@PLCC32 [(SA015A1T)]	PM29F002T
PM29F002T@PLCC32 [(SA015A1T)]	PM29F004B
PM29F004B@PLCC32 [(SA015A1T)]	PM29F004T
PM29F004T@PLCC32 [(SA015A1T)]	PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32 [(SA620)]
PM29LV002T	PM29LV002T@PLCC32 [(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32 [(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32 [(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32 [(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32 [(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)]	PM37LV512
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32 [(SA620)]
PM39F010	PM39F010@PLCC32 [(SA015A1T)]
PM39F010@VSOP32 [(SA620)]	PM39F020
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32 [(SA620)]
PM39F040	PM39F040@PLCC32 [(SA015A1T)]
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32 [(SA015A1T)]
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32 [(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32 [(SA015A1T)]
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32 [(SA015A1T)]
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32 [(SA015A1T)]
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32 [(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32 [(SA015A1T)]
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32 [(SA620)]
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32 [(SA620)]
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32 [(SA620)]

PSS

## E(E)PROM/FRAM/NVRAM

PS24C256	PS24C256@SOIC8 [(SA602A)]
PS29FS001	PS29FS001@PLCC32 [(SA015A1T)]
PS29FS001@TSOP32 [(SA410T)]	PS29FS001@VSOP32 [(SA620)]

PS29LP001                    PS29LP001@PLCC32 [(SA015A1T)]  
PS29LP001@VSOP32 [(SA620)]

## PTC

### E(E)PROM/FRAM/NVRAM

PT28C020                    PT28C020@PLCC32 [(SA015A1T)]  
PT28C040                    PT28C040@PLCC32 [(SA015A1T)]  
PT29C020                    PT29C020@PLCC32 [(SA015A1T)]  
PT29C040                    PT29C040@PLCC32 [(SA015A1T)]

### MICROCONTROLLER

PT89316                    PT89316@PLCC44 [(SA244)]  
PT89316@TQFP44 [(SA245A)]            PT8932  
PT8932@PLCC44 [(SA244)]            PT8932@TQFP44 [(SA245)]  
PT8936                    PT8936@PLCC44 [(SA244)]  
PT8936@TQFP44 [(SA245A)]            PT8956  
PT8956@PLCC44 [(SA244)]            PT8956@TQFP44 [(SA245A)]

## QIXIN

### MICROCONTROLLER

LS2051                    LS2051@SOIC20 [(SA404)]

## Quick Pulse

### E(E)PROM/FRAM/NVRAM

27010                    27011  
27040                    27128A  
27210                    27256  
27512                    2764A

## RAMTRON

## E(E)PROM/FRAM/NVRAM

FM1208	FM1208@SOIC24 [(SA404)]
FM1608	FM1608@SOIC28 [(SA404)]
FM1808	FM1808@SOIC28 [(SA404)]
FM18L08	FM18L08@SOIC28 [(SA404)]
FM24164	FM24164@SOIC8 [(SA602A)]
FM24C04(P)	FM24C04(S)@SOP8 [(SA602A)]
FM24C04A(P)	FM24C04A(S)@SOP8 [(SA602A)]
FM24C16(P)	FM24C16(S)@SOP8 [(SA602A)]
FM24C16A(P)	FM24C16A(S)@SOP8 [(SA602A)]
FM24C256@SOIC8 [(SA605A)]	FM24C512@SOIC8 [(SA602A)]
FM24C64	FM24C64@SOIC8 [(SA602A)]
FM24CL04	FM24CL04@SOIC8 [(SA602A)]
FM24CL16	FM24CL16@SOIC8 [(SA602A)]
FM24CL64@SOIC8 [(SA602A)]	FM25040
FM25040@SOIC8 [(SA602A)]	FM25160
FM25160@SOIC8 [(SA602A)]	FM25640
FM25640@SOIC8 [(SA602A)]	FM25C160
FM25C160@SOIC8 [(SA602A)]	FM25CL04@SOIC8 [(SA602A)]
FM25CL64	FM25CL64@SOIC8 [(SA602A)]
FM25L16	FM25L16@SOIC8 [(SA602A)]
FM25L256	FM25L256@SOIC8 [(SA602A)]
FM25L256@TDFN8 [(BBBB)]	FM25L512
FM25L512@SOIC8 [(SA602A)]	FM25W256@SOIC8 [(SA602A)]
FM30C256@SOIC20 [(SA404)]	FM3104@SOIC14 [(SA602)]
FM3116@SOIC14 [(SA602)]	FM31256@SOIC14 [(SA602)]
FM3164@SOIC14 [(SA602)]	FM32256G@SOIC14 [(SA602)]
FM32256S@SOIC14 [(SA602)]	FM3264G@SOIC14 [(SA602)]
FM3264S@SOIC14 [(SA602)]	FM3808
FM3808@TSOP32 [(SA620)]	

## MICROCONTROLLER

VMX51C900	VMX51C900@PLCC44 [(SA244)]
VMX51C900@TQFP44 [(SA245A)]	VRS1000
VRS1000@PLCC44 [(SA244)]	VRS1000@TQFP44 [(SA245A)]
VRS1100	VRS1100@PLCC44 [(SA244)]
VRS1100@TQFP44 [(SA245A)]	VRS51C1000
VRS51C1000@PLCC44 [(SA244)]	VRS51C1000@TQFP44 [(SA245A)]
VRS51C1100	VRS51C1100@PLCC44 [(SA244)]

VRS51C1100@TQFP44 [(SA245A)]      VRS51C540  
VRS51C540@PLCC44 [(SA244)]      VRS51C540@TQFP44 [(SA245A)]  
VRS51C550      VRS51C550@PLCC44 [(SA244)]  
VRS51C550@TQFP44 [(SA245A)]      VRS51C560  
VRS51C560@PLCC44 [(SA244)]      VRS51C560@TQFP44 [(SA245A)]  
VRS51C570      VRS51C570@PLCC44 [(SA244)]  
VRS51C570@TQFP44 [(SA245A)]      VRS51C580  
VRS51C580@PLCC44 [(SA244)]      VRS51C580@TQFP44 [(SA245A)]  
VRS51C700      VRS51C700@PLCC44 [(SA244)]  
VRS51C700@TQFP44 [(SA245A)]      VRS51L1050  
VRS51L1050@PLCC44 [(SA244)]      VRS51L1050@TQFP44 [(SA245A)]  
VRS51L540      VRS51L540@PLCC44 [(SA244)]  
VRS51L540@TQFP44 [(SA245A)]      VRS51L550  
VRS51L550@PLCC44 [(SA244)]      VRS51L550@TQFP44 [(SA245A)]  
VRS51L560      VRS51L560@PLCC44 [(SA244)]  
VRS51L560@TQFP44 [(SA245A)]      VRS51L570  
VRS51L570@PLCC44 [(SA244)]      VRS51L570@TQFP44 [(SA245A)]  
VRS51L580      VRS51L580@PLCC44 [(SA244)]  
VRS51L580@TQFP44 [(SA245A)]      VRS51X540  
VRS51X540@PLCC44 [(SA244)]      VRS51X540@TQFP44 [(SA245A)]  
VRS51X550      VRS51X550@PLCC44 [(SA244)]  
VRS51X550@TQFP44 [(SA245A)]      VRS51X560  
VRS51X560@PLCC44 [(SA244)]      VRS51X560@TQFP44 [(SA245A)]  
VRS51X570      VRS51X570@PLCC44 [(SA244)]  
VRS51X570@TQFP44 [(SA245A)]      VRS51X580  
VRS51X580@PLCC44 [(SA244)]      VRS51X580@TQFP44 [(SA245A)]  
VRS540      VRS540@PLCC44 [(SA244)]  
VRS540@TQFP44 [(SA245A)]      VRS550  
VRS550@PLCC44 [(SA244)]      VRS550@TQFP44 [(SA245A)]  
VRS560      VRS560@PLCC44 [(SA244)]  
VRS560@TQFP44 [(SA245A)]      VRS570  
VRS570@PLCC44 [(SA244)]      VRS570@TQFP44 [(SA245A)]  
VRS580      VRS580@PLCC44 [(SA244)]  
VRS580@TQFP44 [(SA245A)]      VRS700  
VRS700@PLCC44 [(SA244)]      VRS700@TQFP44 [(SA245A)]  
VRS900      VRS900@PLCC44 [(SA244)]  
VRS900@TQFP44 [(SA245A)]

RATO

E(E)PROM/FRAM/NVRAM

RT24A02 RT24A02@SOIC8 [(SA602A)]  
RT24A02@TSSOP8 [(SA026)] RT24A04  
RT24A04@SOIC8 [(SA602A)] RT24A04@TSSOP8 [(SA026)]  
RT24A08 RT24A08@SOIC8 [(SA602A)]  
RT24A08@TSSOP8 [(SA026)] RT24A16  
RT24A16@SOIC8 [(SA602A)] RT24A16@TSSOP8 [(SA026)]  
RT93C46B(16bit) RT93C46B(16bit)@SOIC8 [(SA602A)]  
RT93C46B(16bit)@TSSOP8 [(SA026)] RT93LC46(08bit)  
RT93LC46(08bit)@SOIC8 [(SA602A)] RT93LC46(08bit)@TSSOP8 [(SA026)]  
RT93LC46(16bit) RT93LC46(16bit)@SOIC8 [(SA602A)]  
RT93LC46(16bit)@TSSOP8 [(SA026)]

## RAYDIUM

### E(E)PROM/FRAM/NVRAM

RM24C02@SOP8 [(SA602A)] RM24C04@SOP8 [(SA602A)]  
RM24C08@SOP8 [(SA602A)] RM24C128@SOP8 [(SA602A)]  
RM24C16@SOP8 [(SA602A)] RM24C32@SOP8 [(SA602A)]  
RM24C64@SOP8 [(SA602A)]

## RENESAS

### E(E)PROM/FRAM/NVRAM

HN58C256A(FP)@SOP28 [(SA630)] HN58C256A(P)  
HN58C256A(T)@TSOP28 [(SA643)] HN58C257A(T)@TSOP32 [(SA620)]  
HN58V24256 HN58V24256@SOIC8 [(SA602A)]  
HN58V24256@TSSOP14 [(SA026)] HN58V24512  
HN58V24512@SOIC8 [(SA602A)] HN58W241000  
HN58W241000@SOIC8 [(SA602A)] HN58X2402  
HN58X2402@SOIC8 [(SA602A)] HN58X2402@TSSOP8 [(SA026)]  
HN58X2404 HN58X2404@SOIC8 [(SA602A)]  
HN58X2404@TSSOP8 [(SA026)] HN58X2408  
HN58X2408@SOIC8 [(SA602A)] HN58X2408@TSSOP8 [(SA026)]  
HN58X24128 HN58X24128@SOIC8 [(SA602A)]  
HN58X2416 HN58X2416@SOIC8 [(SA602A)]  
HN58X2416@TSSOP8 [(SA026)] HN58X24256  
HN58X24256@SOIC8 [(SA602A)] HN58X2432  
HN58X2432@SOIC8 [(SA602A)] HN58X2432@TSSOP8 [(SA026)]

HN58X24512                   HN58X24512@SOIC8 [(SA602A)]  
HN58X2464                   HN58X2464@SOIC8 [(SA602A)]  
HN58X2464@TSSOP8 [(SA026)]       HN58X2502@SOIC8 [(SA602A)]  
HN58X2502@TSSOP8 [(SA026)]       HN58X2504@SOIC8 [(SA602A)]  
HN58X2504@TSSOP8 [(SA026)]       HN58X25128@SOIC8 [(SA602A)]  
HN58X25128@TSSOP14 [(SA026)]      HN58X25256@SOIC8 [(SA602A)]  
HN58X25256@TSSOP14 [(SA026)]      HN58X2532@SOIC8 [(SA602A)]  
HN58X2532@TSSOP8 [(SA026)]       HN58X2564@SOIC8 [(SA602A)]  
HN58X2564@TSSOP8 [(SA026)]       M5L2732  
M5L2732A  
M5M29KB331(AVP)@TSOP48 [(SA247-B005)]  
M5M29KB641(AVP)@TSOP48 [(SA247-B005)]  
M5M29KE131BTP@TSOP52 [(SA657-B117)]  
M5M29KE131BV@TSOP48 [(SA247-B005)]  
M5M29KT331(AVP)@TSOP48 [(SA247-B005)]  
M5M29KT641(AVP)@TSOP48 [(SA247-B005)]  
M6MG3B641S16TP@TSOP52 [(SA657-B036)]  
M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
M6MGB321S4TP@TSOP52 [(SA657-B036)]  
M6MGB321S8TP@TSOP52 [(SA657-B036)]  
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB331S8KT@TSOP52 [(SA657-B036)]  
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB641S16TP@TSOP52 [(SA657-B036)]  
M6MGB641S4TP@TSOP52 [(SA657-B036)]  
M6MGB641S8TP@TSOP52 [(SA657-B036)]  
M6MGB647M34CKT@TSOP52 [(SA657-B036)]  
M6MGB64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGB64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
M6MGB64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
M6MGD13TW34DWG@CSP72 [(SA642F-B064A-T064F001)]  
M6MGE157S4KT@TSOP52 [(SA657-B055)]  
M6MGT321S4TP@TSOP52 [(SA657-B036)]  
M6MGT321S8TP@TSOP52 [(SA657-B036)]  
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT331S8KT@TSOP52 [(SA657-B036)]  
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT641S16TP@TSOP52 [(SA657-B036)]

M6MGT641S4TP@TSOP52 [(SA657-B036)]  
M6MGT641S8TP@TSOP52 [(SA657-B036)]  
M6MGT647M34CKT@TSOP52 [(SA657-B036)]  
M6MGT64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGT64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
M6MGT64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

## DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)]      R1LV0408C@STSOP32 [(SA620)]  
R1LV0408C@TSOP32 [(SA410T)]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]      HD4074344@SOIC28 [(SA404)]  
HD4074394@SDIP28 [(SA022A)]      HD4074394@SOIC28 [(SA404)]  
HD64F3694FX@TQFP48 [(SA671)]      HD64F3694FY@TQFP48 [(SA248)]  
HD64F3694GFX@TQFP48 [(SA671)]      HD64F3694GFY@TQFP48 [(SA248)]  
M34282E2GP [(SA026)]      M34283G2GP [(SA026)]  
M34283G2GP(ISP) [ISP-HEADER01]      M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)]      M37545G6(GP)@LQFP32 [(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)]      M37546G2(FP)@SSOP36 [(SA645)]  
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]

M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20 [(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24 [(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24 [(SA653)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]



R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725-B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725-B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026-B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026-B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725-B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725-B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026-B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697-B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697-B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026-B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725-B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]

R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]

R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]

R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]

R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]

R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]



R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]  
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226KFP@TQFP48 [(SA248-B005)]  
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227JFP@TQFP48 [(SA248-B005)]  
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227KFP@TQFP48 [(SA248-B005)]  
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228JFP@TQFP48 [(SA248-B005)]  
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228KFP@TQFP48 [(SA248-B005)]  
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]

R5F2122AJFP@TQFP48 [(SA248-B005)]  
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122AKFP@TQFP48 [(SA248-B005)]  
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CJFP@TQFP48 [(SA248-B005)]  
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2122CKFP@TQFP48 [(SA248-B005)]  
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236JFP@TQFP48 [(SA248-B005)]  
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21236KFP@TQFP48 [(SA248-B005)]  
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237JFP@TQFP48 [(SA248-B005)]  
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21237KFP@TQFP48 [(SA248-B005)]  
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238JFP@TQFP48 [(SA248-B005)]  
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21238KFP@TQFP48 [(SA248-B005)]  
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AJFP@TQFP48 [(SA248-B005)]  
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123AKFP@TQFP48 [(SA248-B005)]  
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CJFP@TQFP48 [(SA248-B005)]  
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2123CKFP@TQFP48 [(SA248-B005)]  
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]

R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]

R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]

R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]

R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]

R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]



R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]

R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]

R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]

R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]

R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]



R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026-B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H1SNSP@TSSOP20 [(SA026-B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SDSP@TSSOP20 [(SA725-B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SNSP@TSSOP20 [(SA725-B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SDSP@TSSOP20 [(SA026-B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SNSP@TSSOP20 [(SA026-B001)]

R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J1SDSP@TSSOP20 [(SA026-B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])  
R5F212J1SNSP@TSSOP20 [(SA026-B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])  
R5F212K2SDFP@QFP32 [(SA663-B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire [(SA663-B005)])  
R5F212K2SNFP@QFP32 [(SA663-B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire [(SA663-B005)])  
R5F212K4SDFP@QFP32 [(SA663-B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire [(SA663-B005)])  
R5F212K4SNFP@QFP32 [(SA663-B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire [(SA663-B005)])  
R5F212L2SDFP@QFP32 [(SA663-B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L2SNFP@QFP32 [(SA663-B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SDFP@QFP32 [(SA663-B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SNFP@QFP32 [(SA663-B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire [(SA663+B005)])

## RICOH

### E(E)PROM/FRAM/NVRAM

RD27C256                      RD27C32  
RD27C64

## ROCKWELL

## E(E)PROM/FRAM/NVRAM

R2764	R2764C
R2764P	R27C64
R2816	R5213
R52B13	R52B33

## ROHM

## E(E)PROM/FRAM/NVRAM

BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8 [(SA026)]
BR24C01@TSSOP8(3*3mm) [(SA666)]	BR24C01A
BR24C01A(F) [(SA602A)]	BR24C01A(FJ) [(SA602A)]
BR24C01A(FV) [(SA026)]	BR24C02
BR24C02(F) [(SA602A)]	BR24C02(FJ) [(SA602A)]
BR24C02(FV) [(SA026)]	BR24C02@SOP8 [(SA602A)]
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8(3*3mm) [(SA666)]
BR24C04	BR24C04(F) [(SA602A)]
BR24C04(FJ) [(SA602A)]	BR24C04(FV) [(SA026)]
BR24C04@SOP8 [(SA602A)]	BR24C04@TSSOP8 [(SA026)]
BR24C04@TSSOP8(3*3mm) [(SA666)]	BR24C08
BR24C08(F) [(SA602A)]	BR24C08(FJ) [(SA602A)]
BR24C08(FV) [(SA026)]	BR24C08@SOP8 [(SA602A)]
BR24C08@TSSOP8 [(SA026)]	BR24C08@TSSOP8(3*3mm) [(SA666)]
BR24C16	BR24C16(F) [(SA602A)]
BR24C16(FJ) [(SA602A)]	BR24C16(FV) [(SA026)]
BR24C21	BR24C21(F) [(SA602A)]
BR24C21(FJ) [(SA602A)]	BR24C21(FV) [(SA026)]
BR24C32	BR24C32(F) [(SA602A)]
BR24C64	BR24C64(F) [(SA602A)]
BR24E16	BR24E16(F) [(SA602A)]
BR24E16(FJ) [(SA602A)]	BR24E16(FV) [(SA026)]
BR24L01A	BR24L01A(F) [(SA602A)]
BR24L01A(FJ) [(SA602A)]	BR24L01A(FV) [(SA026)]
BR24L01A(FVM) [(SA666)]	BR24L02
BR24L02(F) [(SA602A)]	BR24L02(FJ) [(SA602A)]
BR24L02(FV) [(SA026)]	BR24L02(FVM) [(SA666)]
BR24L04	BR24L04(F) [(SA602A)]
BR24L04(FJ) [(SA602A)]	BR24L04(FV) [(SA026)]

BR24L04(FVM) [(SA666)]	BR24L08
BR24L08(F) [(SA602A)]	BR24L08(FJ) [(SA602A)]
BR24L08(FV) [(SA026)]	BR24L08(FVM) [(SA666)]
BR24L16	BR24L16(F) [(SA602A)]
BR24L16(FJ) [(SA602A)]	BR24L16(FV) [(SA026)]
BR24L16(FVM) [(SA666)]	BR24L32
BR24L32(F) [(SA602A)]	BR24L32(FJ) [(SA602A)]
BR24L32(FV) [(SA026)]	BR24L64
BR24L64(F) [(SA602A)]	BR24L64(FJ) [(SA602A)]
BR24L64(FV) [(SA026)]	BR25010@SOIC8 [(SA602A)]
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8 [(SA602A)]
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8 [(SA602A)]
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8 [(SA602A)]
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8 [(SA602A)]
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8 [(SA602A)]
BR25L010	BR25L010(F) [(SA602A)]
BR25L010(FJ) [(SA602A)]	BR25L010(FV) [(SA026)]
BR25L010(FVM) [(SA666)]	BR25L020
BR25L020(F) [(SA602A)]	BR25L020(FJ) [(SA602A)]
BR25L020(FV) [(SA026)]	BR25L020(FVM) [(SA666)]
BR25L040	BR25L040(F) [(SA602A)]
BR25L040(FJ) [(SA602A)]	BR25L040(FV) [(SA026)]
BR25L040(FVM) [(SA666)]	BR25L080
BR25L080(F) [(SA602A)]	BR25L080(FJ) [(SA602A)]
BR25L080(FV) [(SA026)]	BR25L160
BR25L160(F) [(SA602A)]	BR25L160(FJ) [(SA602A)]
BR25L160(FV) [(SA026)]	BR25L320
BR25L320(F) [(SA602A)]	BR25L320(FJ) [(SA602A)]
BR25L320(FV) [(SA026)]	BR25L640
BR25L640(F) [(SA602A)]	BR25L640(FJ) [(SA602A)]
BR25L640(FV) [(SA026)]	BR34L02
BR34L02(F) [(SA602A)]	BR34L02(FJ) [(SA602A)]
BR34L02(FV) [(SA026)]	BR34L02(FVM) [(SA666)]
BR9010	BR9010(F) [(SA602A)]
BR9010(FV) [(SA026)]	BR9010(RFV) [(SA026)]
BR9010(RFVM) [(SA666)]	BR9016
BR9016(F) [(SA602A)]	BR9016(RFV) [(SA026)]
BR9016A(F) [(SA602A)]	BR9016A(RFV) [(SA026)]
BR9016A(RFVM) [(SA666)]	BR9020
BR9020(F) [(SA602A)]	BR9020(FV) [(SA026)]
BR9020(RFV) [(SA026)]	BR9020(RFVM) [(SA666)]
BR9040	BR9040(F) [(SA602A)]
BR9040(FV) [(SA026)]	BR9040(RFV) [(SA026)]

BR9040(RFVM) [(SA666)]	BR9080
BR9080(F) [(SA602A)]	BR9080(RFV) [(SA026)]
BR9080A	BR9080A(F) [(SA602A)]
BR9080A(FV) [(SA026)]	BR9080A(RFV) [(SA026)]
BR9080A(RFVM) [(SA666)]	BR93A46(F) [(SA602A)]
BR93A46(FJ) [(SA602A)]	BR93A46(RF) [(SA602A)]
BR93A46(RFJ) [(SA602A)]	BR93A56(F) [(SA602A)]
BR93A56(FJ) [(SA602A)]	BR93A56(RF) [(SA602A)]
BR93A56(RFJ) [(SA602A)]	BR93A66(F) [(SA602A)]
BR93A66(FJ) [(SA602A)]	BR93A66(RF) [(SA602A)]
BR93A66(RFJ) [(SA602A)]	BR93A86(F) [(SA602A)]
BR93A86(FJ) [(SA602A)]	BR93A86(RF) [(SA602A)]
BR93A86(RFJ) [(SA602A)]	BR93C46
BR93C46(F) [(SA602A)]	BR93C46(FJ) [(SA602A)]
BR93C46(FV) [(SA026)]	BR93C46(RF) [(SA602A)]
BR93C46(RFJ) [(SA602A)]	BR93C56
BR93C56(F) [(SA602A)]	BR93C56(FJ) [(SA602A)]
BR93C56(FV) [(SA026)]	BR93C56(RF) [(SA602A)]
BR93C56(RFJ) [(SA602A)]	BR93C66
BR93C66(F) [(SA602A)]	BR93C66(FJ) [(SA602A)]
BR93C66(FV) [(SA026)]	BR93C66(RF) [(SA602A)]
BR93C66(RFJ) [(SA602A)]	BR93H46(RF) [(SA602A)]
BR93H46(RFJ) [(SA602A)]	BR93H56(RF) [(SA602A)]
BR93H56(RFJ) [(SA602A)]	BR93H66(RF) [(SA602A)]
BR93H66(RFJ) [(SA602A)]	BR93H76(RF) [(SA602A)]
BR93H76(RFJ) [(SA602A)]	BR93H86(RF) [(SA602A)]
BR93H86(RFJ) [(SA602A)]	BR93L46
BR93L46(F) [(SA602A)]	BR93L46(FJ) [(SA602A)]
BR93L46(FV) [(SA026)]	BR93L46(RF) [(SA602A)]
BR93L46(RFJ) [(SA602A)]	BR93L56
BR93L56(F) [(SA602A)]	BR93L56(FJ) [(SA602A)]
BR93L56(FV) [(SA026)]	BR93L56(RF) [(SA602A)]
BR93L56(RFJ) [(SA602A)]	BR93L66
BR93L66(F) [(SA602A)]	BR93L66(FJ) [(SA602A)]
BR93L66(FV) [(SA026)]	BR93L66(RF) [(SA602A)]
BR93L66(RFJ) [(SA602A)]	BR93L76(F) [(SA602A)]
BR93L76(FJ) [(SA602A)]	BR93L76(RF) [(SA602A)]
BR93L76(RFJ) [(SA602A)]	BR93L76(RFV) [(SA026A)]
BR93L76(RFVJ) [(SA666A)]	BR93L76(RFVM) [(SA666A)]
BR93L76(RFVT) [(SA026A)]	BR93L86(F) [(SA602A)]
BR93L86(FJ) [(SA602A)]	BR93L86(RF) [(SA602A)]
BR93L86(RFJ) [(SA602A)]	BR93L86(RFV) [(SA026A)]
BR93L86(RFVJ) [(SA666A)]	BR93L86(RFVM) [(SA666A)]

BR93L86(RFVT) [(SA026A)]	BR93LC46
BR93LC46(F) [(SA602A)]	BR93LC46(FJ) [(SA602A)]
BR93LC46(FV) [(SA026)]	BR93LC46(RF) [(SA602A)]
BR93LC46(RFJ) [(SA602A)]	BR93LC56
BR93LC56(F) [(SA602A)]	BR93LC56(FJ) [(SA602A)]
BR93LC56(FV) [(SA026)]	BR93LC56(RF) [(SA602A)]
BR93LC56(RFJ) [(SA602A)]	BR93LC66
BR93LC66(F) [(SA602A)]	BR93LC66(FJ) [(SA602A)]
BR93LC66(FV) [(SA026)]	BR93LC66(RF) [(SA602A)]
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F) [(SA602A)]
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8 [(SA666)]
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8 [(SA026)]
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8 [(SA602A)]
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8 [(SA666)]
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8 [(SA026)]
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8 [(SA026)]
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8 [(SA026)]

## SAIFUN

### E(E)PROM/FRAM/NVRAM

SA24C1024	SA24C1024@SOIC8 [(SA602A)]
SA24C512	SA24C512@SOIC8 [(SA602A)]
SA24C512@TSSOP8 [(SA026)]	SA25C1024(H)
SA25C1024(H)@CSP8 [(SA683)]	SA25C1024(H)@SOIC8 [(SA602A)]
SA25C1024(L)	SA25C1024(L)@CSP8 [(SA683)]
SA25C1024(L)@SOIC8 [(SA602A)]	SA25C512(H)
SA25C512(H)@CSP8 [(SA683)]	SA25C512(H)@SOIC8 [(SA602A)]
SA25C512(L)	SA25C512(L)@CSP8 [(SA683)]
SA25C512(L)@SOIC8 [(SA602A)]	SA25F005
SA25F005@MLF8 [(SA683)]	SA25F005@SOIC8 [(SA602A)]
SA25F010	SA25F010@MLF8 [(SA683)]
SA25F010@SOIC8 [(SA602A)]	SA25F020
SA25F020@MLF8 [(SA683)]	SA25F020@SOIC8 [(SA602A)]
SA25F040	SA25F040@MLF8 [(SA683)]
SA25F040@SOIC8 [(SA602A)]	SA25F080
SA25F080@MLF8 [(SA683)]	SA25F080@SOIC8 [(SA602A)]
SA25F160	SA25F160(ISP) [ISP-HEADER01]
SA25F160@MLF8 [(SA683)]	
SA25F160@MLF8(ISP) [ISP-HEADER01]	
SA25F160@SOIC16 [(SA602)]	

SA25F160@SOIC16(ISP) [ISP-HEADER01]

## SAMSUNG

### E(E)PROM/FRAM/NVRAM

K5A3240CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3240CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3240YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3281CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3281CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3340YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A6317CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A6317CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5D1257DCMD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D5613HCMD075@FBGA137 [(SA700E-B153-M137F001Y)]  
K5D5613VCMD075@FBGA137 [(SA700E-B153-M137F001Y)]  
K5D5629ACCD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D5657ACAD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D5657ACBD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D5657DCAD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5J6316CBM@FBGA69 [(SA642A-B032A-Y096F001)]  
K5J6316CTM@FBGA69 [(SA642A-B032A-Y096F001)]  
K5J6332CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5J6332CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5L2864ABM@FBGA115 [(SA664A-B189A-W115F001Y)]  
K5L2864ATM@FBGA115 [(SA664A-B189A-W115F001Y)]  
K5L3216CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]

K5L3316CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5L6331CAA@FBGA56 [(SA642P-B032A-W056F001Y)]  
K5L6631CAA@FBGA56 [(SA642P-B032A-W056F001Y)]  
K5N3217ABM@FBGA56 [(SA733A-B212A-M056F001Y)]  
K5N3217ATM@FBGA56 [(SA733A-B212A-M056F001Y)]  
K8D1716UBC@FBGA48 [(SA642N-B026A-W048F001N)]  
K8D1716UBC@TSOP48 [(SA247-B005)]  
K8D1716UTC@FBGA48 [(SA642N-B026A-W048F001N)]  
K8D1716UTC@TSOP48 [(SA247-B005)]  
K8D3216UBC@FBGA48 [(SA642B-B026A-Y072F001)]  
K8D3216UBC@TSOP48 [(SA247-B005)]  
K8D3216UTC@FBGA48 [(SA642B-B026A-Y072F001)]  
K8D3216UTC@TSOP48 [(SA247-B005)]  
K8D3316UBC@FBGA48 [(SA642B-B026A-Y072F001)]  
K8D3316UBC@TSOP48 [(SA247-B005)]  
K8D3316UTC@FBGA48 [(SA642B-B026A-Y072F001)]  
K8D3316UTC@TSOP48 [(SA247-B005)]  
K8D6316UBM@FBGA48 [(SA642N-B026A-W048F001Y)]  
K8D6316UBM@TSOP48 [(SA247-B005)]  
K8D6316UTM@FBGA48 [(SA642N-B026A-W048F001Y)]  
K8D6316UTM@TSOP48 [(SA247-B005)]  
K8P3215UQB@FBGA48 [(SA642G-B026A-T048F001Y)]  
K8P3215UQB@FBGA64 [(SA655F-B099A-W064F001Y)]  
K8P3215UQB@TSOP48 [(SA247-B005)]  
K8P6415UQB@FBGA48 [(SA642G-B026A-T048F001Y)]  
K8P6415UQB@FBGA64 [(SA655F-B099A-W064F001Y)]  
K8P6415UQB@TSOP48 [(SA247-B005)] K8Q2815UQB@TSOP56 [(SA628+B102)]  
K9F1208R0C@FBGA63 [(SA642LL-B280-M063F001N)]  
K9F1208U0A@TSOP48 [(SA247-B005)]  
K9F1208U0B@FBGA63 [(SA642LL-B026-M063F001N)]  
K9F1208U0B@TSOP48 [(SA247-B005)]  
K9F1208U0C@FBGA63 [(SA642LL-B026-M063F001N)]  
K9F1208U0C@TSOP48 [(SA247-B005)] K9F1208U0M@TSOP48 [(SA247-B005)]  
K9F1216U0A@TSOP48 [(SA247-B005)] K9F1G08Q0M@TSOP48 [(SA247-B005)]  
K9F1G08U0A@TSOP48 [(SA247-B005)] K9F1G08U0M@TSOP48 [(SA247-B005)]  
K9F1G16D0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]



K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F2808U0C@TSOP48 [(SA247-B005)]  
K9F2G08R0A@FBGA63 [(SA642V-B280A-T096F001)]  
K9F2G08U0A@TSOP48 [(SA247-B005)] K9F2G08U0M@TSOP48 [(SA247-B005)]  
K9F4008W0A@TSOP44 [(SA645)] K9F4G08U0A@TSOP48 [(SA247-B005)]  
K9F4G08U0M@TSOP48 [(SA247-B005)]  
K9F5608R0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0B(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0B@TSOP48 [(SA247-B005)]  
K9F5608U0C(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0C(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0C@TSOP48 [(SA247-B005)]  
K9F5608U0D(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D@TSOP48 [(SA247-B005)] K9F6408U0C@TSOP44 [(SA645-B005)]  
K9F8G08U0A@TSOP48 [(SA247-B005)] K9F8G08U0M@TSOP48 [(SA247-B005)]  
K9G4G08U0A@TSOP48 [(SA247-B005)] K9G8G08U0M@TSOP48 [(SA247-B005)]  
K9GAG08U0M@TSOP48 [(SA247-B005)] K9HBG08U1M@TSOP48 [(SA247-B005)]  
K9K1208D0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9K1208U0A@TSOP48 [(SA247-B005)] K9K1208U0M@TSOP48 [(SA247-B005)]  
K9K1216Q0C@FBGA63 [(SA664A-B114-W115F001)]  
K9K1G08U0M@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M@TSOP48 [(SA247-B005)] K9K4G08Q0M@TSOP48 [(SA247-B005)]  
K9K4G08U0M@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(PCB0)@TSOP48 [(SA247-B005)]

K9K4G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K8G08U0A@TSOP48 [(SA247-B005)] K9L8G08U0M@TSOP48 [(SA247-B005)]  
K9LAG08U0M@TSOP48 [(SA247-B005)] K9LAG08U1M@TSOP48 [(SA247-B005)]  
K9LBG08U0M@TSOP48 [(SA247-B005)] K9T1G08U0M@TSOP48 [(SA247-B005)]  
K9W8G08U1M(PCB0)@TSOP48 [(SA247-B005)]  
K9W8G08U1M(PIB0)@TSOP48 [(SA247-B005)]  
KAD060300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD060300C@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD060700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
KAD070300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD070700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
KAD090300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD100300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KBE00500AM-D437@FBGA137 [(SA700E-B153A-M137F001Y)]  
KBE00F003A-D411@FBGA107 [(SA642V-B133-T096F001Y)]  
KBE00G005M-D411@FBGA137 [(SA700E-B153A-M137F001Y)]  
KBE00S005M-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
KBE00S00AM-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
KFG1216Q2B-DEB8@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2A-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2A-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2B-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2B-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG5616D1M@FBGA63 [(SA642A-B026A-Y096N001)]  
KFG5616Q1M@FBGA63 [(SA642A-B026A-Y096N001)]  
KFG5616U1M@FBGA63 [(SA642A-B026A-Y096N001)]  
KM2816A KM2816AI  
KM2817A KM2817AI  
KM2864A KM2864AH  
KM2865A KM2865AH  
KM28C16 KM28C16@PLCC32 [(SA015A1T)]  
KM28C16I KM28C16I@PLCC32 [(SA015A1T)]  
KM28C17 KM28C17@PLCC32 [(SA015A1T)]  
KM28C17I KM28C17I@PLCC32 [(SA015A1T)]  
KM28C256 KM28C256@PLCC32 [(SA015A1T)]  
KM28C256I KM28C256I@PLCC32 [(SA015A1T)]  
KM28C64 KM28C64@PLCC32 [(SA015A1T)]  
KM28C64A KM28C64A@PLCC32 [(SA015A1T)]  
KM28C64B KM28C64B@PLCC32 [(SA015A1T)]  
KM28C64I KM28C64I@PLCC32 [(SA015A1T)]

KM28C65 KM28C65@PLCC32 [(SA015A1T)]  
KM28C65A KM28C65A@PLCC32 [(SA015A1T)]  
KM28C65I KM28C65I@PLCC32 [(SA015A1T)]  
KM29U128T@TSOP48 [(SA247-B005)] KM29W32000AIT@TSOP44 [(SA645)]  
KM29W32000AT@TSOP44(DWB) [(SA645)]  
KM29W32000AT@TSOP44(ZMQ) [(SA645)]  
KM93C06(08bit) KM93C06(16bit)  
KM93C06(G)(08bit)@SOIC8 [(SA602A)]  
KM93C06(G)(16bit)@SOIC8 [(SA602A)]  
KM93C06(GD)(08bit)@SOIC8 [(SA602A)]  
KM93C06(GD)(16bit)@SOIC8 [(SA602A)]  
KM93C07(08bit) KM93C07(16bit)  
KM93C07(G)(08bit)@SOIC8 [(SA602A)]  
KM93C07(G)(16bit)@SOIC8 [(SA602A)]  
KM93C07(GD)(08bit)@SOIC8 [(SA602A)]  
KM93C07(GD)(16bit)@SOIC8 [(SA602A)]  
KM93C46V KM93C46V(G)@SOIC8 [(SA602A)]  
KM93C46V(GD)@SOIC8 [(SA602A)] KM93C47V  
KM93C47V(G)@SOIC8 [(SA602A)] KM93C47V(GD)@SOIC8 [(SA602A)]  
KM93C56V KM93C56V(G)@SOIC8 [(SA602A)]  
KM93C56V(GD)@SOIC8 [(SA602A)] KM93C57V  
KM93C57V(G)@SOIC8 [(SA602A)] KM93C57V(GD)@SOIC8 [(SA602A)]  
KM93C66V KM93C66V(G)@SOIC8 [(SA602A)]  
KM93C66V(GD)@SOIC8 [(SA602A)] KM93C67V  
KM93C67V(G)@SOIC8 [(SA602A)] KM93C67V(GD)@SOIC8 [(SA602A)]  
KS24C010 KS24C010@SOIC8 [(SA602A)]  
KS24C010@TSSOP8 [(SA026)] KS24C011  
KS24C011@SOIC8 [(SA602A)] KS24C011@TSSOP8 [(SA026)]  
KS24C020 KS24C020@SOIC8 [(SA602A)]  
KS24C020@TSSOP8 [(SA026)] KS24C021  
KS24C021@SOIC8 [(SA602A)] KS24C021@TSSOP8 [(SA026)]  
KS24C040 KS24C040@SOIC8 [(SA602A)]  
KS24C040@TSSOP8 [(SA026)] KS24C041  
KS24C041@SOIC8 [(SA602A)] KS24C041@TSSOP8 [(SA026)]  
KS24C080 KS24C080@SOIC8 [(SA602A)]  
KS24C080@TSSOP8 [(SA026)] KS24C081  
KS24C081@SOIC8 [(SA602A)] KS24C081@TSSOP8 [(SA026)]  
S524A40X10 S524A40X10@SOP8 [(SA602A)]  
S524A40X10@TSSOP8 [(SA026)] S524A40X11  
S524A40X11@SOP8 [(SA602A)] S524A40X11@TSSOP8 [(SA026)]  
S524A40X20 S524A40X20@SOP8 [(SA602A)]  
S524A40X20@TSSOP8 [(SA026)] S524A40X21  
S524A40X21@SOP8 [(SA602A)] S524A40X21@TSSOP8 [(SA026)]

S524A40X40 S524A40X40@SOP8 [(SA602A)]  
 S524A40X40@TSSOP8 [(SA026)] S524A40X41  
 S524A40X41@SOP8 [(SA602A)] S524A40X41@TSSOP8 [(SA026)]  
 S524A60X51 S524A60X51@SOP8 [(SA602A)]  
 S524A60X51@TSSOP8 [(SA026)] S524A60X81  
 S524A60X81@SOP8 [(SA602A)] S524A60X81@TSSOP8 [(SA026)]  
 S524AB0X91 S524AB0X91@SOP8 [(SA602A)]  
 S524AB0X91@TSSOP8 [(SA026)] S524AB0XB1  
 S524AB0XB1@SOP8 [(SA602A)] S524AB0XB1@TSSOP8 [(SA026)]  
 S524AD0XD1 S524AD0XD1@SOP8 [(SA602A)]  
 S524AD0XD1@TSSOP8 [(SA026)] S524AD0XF1  
 S524AD0XF1@SOP8 [(SA602A)] S524AD0XF1@TSSOP8 [(SA026)]  
 S524C20D11 S524C20D11@SOP8 [(SA602A)]  
 S524C20D11@TSSOP8 [(SA026)] S524C20D21  
 S524C20D21@SOP8 [(SA602A)] S524C20D21@TSSOP8 [(SA026)]  
 S524C80D41 S524C80D41@SOP8 [(SA602A)]  
 S524C80D41@TSSOP8 [(SA026)] S524C80D81  
 S524C80D81@SOP8 [(SA602A)] S524C80D81@TSSOP8 [(SA026)]  
 S524L50X51 S524L50X51@SOP8 [(SA602A)]  
 S524L50X51@TSSOP8 [(SA026)] S524LB0X91  
 S524LB0X91@SOP8 [(SA602A)] S524LB0X91@TSSOP8 [(SA026)]  
 S524LB0XB1 S524LB0XB1@SOP8 [(SA602A)]  
 S524LB0XB1@TSSOP8 [(SA026)]

## DRAM & SRAM

KM61257 KM61257@SOJ24 [(SA646)]  
 KM61257L KM61257L@SOJ24 [(SA646)]  
 KM6165 KM6165@SOJ24 [(SA646)]  
 KM6165L KM6165L@SOJ24 [(SA646)]  
 KM62256A KM62256A@SOIC28 [(SA630)]  
 KM62256AL KM62256AL@SOIC28 [(SA630)]  
 KM6264A KM6264A@SOIC28 [(SA630)]  
 KM6264AL KM6264AL@SOIC28 [(SA630)]  
 KM64257 KM64257@SOJ24 [(SA646)]  
 KM64257L KM64257L@SOJ24 [(SA646)]  
 KM6465LP KM6465LP@SOJ22 [(SA646)]  
 KM6465P KM68257LP  
 KM68257LP@SOIC28 [(SA630)] KM68257P  
 KM68257P@SOIC28 [(SA630)] KM6865LP  
 KM6865LP@SOIC28 [(SA630)] KM6865P  
 KM6865P@SOIC28 [(SA630)]

## PLD

CPL16L8	CPL16L8@PLCC20 [(SA001A)]
CPL16L8L	CPL16L8L@PLCC20 [(SA001A)]
CPL16R4	CPL16R4@PLCC20 [(SA001A)]
CPL16R4L	CPL16R4L@PLCC20 [(SA001A)]
CPL16R6	CPL16R6@PLCC20 [(SA001A)]
CPL16R6L	CPL16R6L@PLCC20 [(SA001A)]
CPL16R8	CPL16R8@PLCC20 [(SA001A)]
CPL16R8L	CPL16R8L@PLCC20 [(SA001A)]

## MICROCONTROLLER

S3F84I8@QFP44 [(SA769)]	S3F84I8@SDIP42 [(SA028)]
S3F84I9@QFP44 [(SA769)]	S3F84I9@SDIP42 [(SA028)]
S3F84P4	S3F84P4@SOP8 [(SA602A+B003)]
S3F9444	S3F9444@SOP8 [(SA602A+B003)]
S3F9454(dip16)	S3F9454(dip20)
S3F9454@SOP20 [(SA404+B005)]	S3F9488@QFP44 [(SA245A)]
S3F9488@SDIP32 [(SA653)]	S3F9488@SDIP42 [(SA028)]
S3F9488@SOP32 [(SA630)]	S3F9498@SDIP30 [(SA653)]
S3F9498@SDIP32 [(SA653)]	S3F9498@SOP28 [(SA630)]
S3F9498@SOP32 [(SA630)]	

## SAMSUNG-CUSTOMER

### E(E)PROM/FRAM/NVRAM

K9F1208U0B(LM)@TSOP48 [(SA247-B005)]
K9F1G08U0A(AMLOGIC)@TSOP48 [(SA247-B005)]
K9F1G08U0M(DD5)@TSOP48 [(SA247+B005)]
K9F2G08U0A(YYD)@TSOP48 [(SA247-B005)]
K9F2G08U0A(ZX)@TSOP48 [(SA247-B005)]
K9F2G08U0M(YYD)@TSOP48 [(SA247-B005)]
K9F4G08U0A(WS)@TSOP48 [(SA247-B005)]
K9F4G08U0M(DD5)@TSOP48 [(SA247+B005)]
K9F5608U0B(QJ)@TSOP48 [(SA247-B005)]
K9F5608U0D(RS)@TSOP48 [(SA247-B005)]
K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]

K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9HBG08U1A(CH)@TSOP48 [(SA247-B005)]  
 K9HBG08U1M(CH)@TSOP48 [(SA247-B005)]  
 K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]  
 K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]  
 K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]

## SANYO

### E(E)PROM/FRAM/NVRAM

LE24C041                   LE24C041@MFP8 [(SA654)]  
 LE24C042                   LE24C042@MFP8 [(SA654)]  
 LE24C081                   LE24C081@MFP8 [(SA654)]  
 LE24C082                   LE24C082@MFP8 [(SA654)]  
 LE24C161                   LE24C161@MFP8 [(SA654)]  
 LE24C162                   LE24C162@MFP8 [(SA654)]  
 LE24C322@MFP8 [(SA654)]       LE24C322@WLP6 [(SA698)]  
 LE24L322@MFP8 [(SA654)]       LE25FU106BMA@MFP8 [(SA654)]  
 LE25FU106BTT@MSOP8 [(SA654)]   LE25FU406BMA@MFP8 [(SA602A)]  
 LE25FU406BTT@MSOP8 [(SA654)]   LE25FV055T@MSOP8 [(SA654)]  
 LE25FV101T@MSOP8 [(SA654)]   LE25FV105T@MSOP8 [(SA654)]  
 LE25FV201T@MSOP8 [(SA654)]   LE25FV401T@MSOP8 [(SA654)]  
 LE25FV411T@MSOP8 [(SA654)]   LE25FV451T@VSOP32 [(SA620)]  
 LE25FW056FN@VSON8 [(SA683)]   LE25FW056MA@MFP8 [(SA602A)]  
 LE25FW106M@SOP8 [(SA602A)]   LE25FW106T@MSOP8 [(SA654)]  
 LE25FW1606FN@VSON8 [(SA683)]   LE25FW203ATT@MSOP8 [(SA654)]  
 LE25FW206M@SOP8 [(SA602A)]   LE25FW206T@MSOP8 [(SA654)]  
 LE25FW406BMA@MFP8 [(SA602A)]   LE25FW406BTT@MSOP8 [(SA654)]  
 LE25FW406M@SOP8 [(SA602A)]   LE25FW406T@MSOP8 [(SA654)]  
 LE25FW806M@SOP8 [(SA602A)]   LE25FW806T@MSOP8 [(SA654)]  
 LE26CW006@WLP6 [(SA698)]       LE28BW168T@TSOP48 [(SA247-B005)]  
 LE28C1001AM@SOP32 [(SA687)]   LE28C1001AT@TSOP32 [(SA410T)]  
 LE28C1001ATS@VSOP32 [(SA620)]   LE28C1001DT@TSOP32 [(SA410T)]  
 LE28C1001DTS@VSOP32 [(SA620)]   LE28CV1001AT@TSOP32 [(SA410T)]  
 LE28CV1001ATS@VSOP32 [(SA620)]   LE28CV1001DT@TSOP32 [(SA410T)]  
 LE28CV1001DTS@VSOP32 [(SA620)]   LE28CW1001DT@TSOP32 [(SA410T)]  
 LE28CW1001DTS@VSOP32 [(SA620)]

LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]  
LE28DW1621T@TSOP48 [(SA247-B005)]  
LE28DW8102T@TSOP48 [(SA637)]  
LE28DW8163T@TSOP48 [(SA247-B005)]  
LE28F1101T@TSOP40 [(SA623)] LE28F1601T@TSOP40 [(SA409T)]  
LE28F2001ATS@TSOP32 [(SA410T)] LE28F4001ATS@TSOP32 [(SA410T)]  
LE28F4001M@SSOP32 [(SA438T)] LE28F8001T@TSOP40 [(SA409T)]  
LE28FU4101T@TSOP48 [(SA247-B005)]  
LE28FV1101T@TSOP40 [(SA623)] LE28FV1601T@TSOP40 [(SA409T)]  
LE28FV2001ATS@TSOP32 [(SA410T)] LE28FV4001ATS@TSOP32 [(SA410T)]  
LE28FV4001CTS@TSOP32 [(SA410T)] LE28FV4001M@SSOP32 [(SA438T)]  
LE28FV4001T@TSOP40 [(SA409T)]  
LE28FV4101T@TSOP48 [(SA247-B005)]  
LE28FV8001T@TSOP40 [(SA409T)]  
LE28FW1633FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
LE28FW1633FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
LE28FW1633TB@TSOP48 [(SA247-B005)]  
LE28FW1633TT@TSOP48 [(SA247-B005)]  
LE28FW4101T@TSOP48 [(SA247-B005)]  
LE28FW8201T@TSOP48 [(SA247-B005)]  
LE28FW8203TB@FBGA48 [(SA642B-B026A-Y072F001)]  
LE28FW8203TB@TSOP48 [(SA247-B005)]  
LE28FW8203TT@FBGA48 [(SA642B-B026A-Y072F001)]  
LE28FW8203TT@TSOP48 [(SA247-B005)]

## SCENIX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] SX20AC/SS@SSOP20 [(SA626A)]  
SX28AC/DP SX28AC/DP/G  
SX28AC/SS/G@SSOP28 [(SA626A)] SX28AC/SS@SSOP28 [(SA626A)]  
SX48BD/G@TQFP48 [(SA248)] SX48BD@TQFP48 [(SA248)]

## SEEQ

### E(E)PROM/FRAM/NVRAM

27128 27256  
2764 27C256

2804	2804A	
2816A	2816AH	
5213	52B13	
52B13H	52B23	
52B23H	52B33	
52B33H	5516A	
5516AH	5517A	
5517AH	DE2817A	
DE2817A@PLCC32 [(SA015A1T)]	DE2817AH	
DE2817AH@PLCC32 [(SA015A1T)]	DQ2817A	
DQ2817A@PLCC32 [(SA015A1T)]	DQ2817AH	
DQ2817AH@PLCC32 [(SA015A1T)]	DQ2864	
DQ2864@PLCC32 [(SA015A1T)]	DQ2864H	
DQ2864H@PLCC32 [(SA015A1T)]	DQ28C256	
DQ28C256@PLCC32 [(SA015A1T)]	DQ28C64	
DQ28C64@PLCC32 [(SA015A1T)]	DQ28C64A	
DQ28C64A@PLCC32 [(SA015A1T)]	DQ28C65	
DQ28C65@PLCC32 [(SA015A1T)]	DQ52B13	
DQ52B13H	E28C64	
E28C64@PLCC32 [(SA015A1T)]	E52B13	
E52B13H	E52B23	
E52B23H	E52B33	
E52B33H	M28C64	
M28C64@PLCC32 [(SA015A1T)]	M52B13	
M52B13H	M52B23	
M52B23H	M52B33	
M52B33H	PQ2864	
PQ2864@PLCC32 [(SA015A1T)]	PQ2864H	
PQ2864H@PLCC32 [(SA015A1T)]	PQ28C64	
PQ28C64@PLCC32 [(SA015A1T)]	PQ28C65	
PQ28C65@PLCC32 [(SA015A1T)]		

## SEIKO

### E(E)PROM/FRAM/NVRAM

S-22H10	S-22H10@SOP18 [(SA404)]	
S-22H12	S-22H12@SOP18 [(SA404)]	
S-22S10	S-22S10@SOP18 [(SA404)]	
S-22S12	S-22S12@SOP18 [(SA404)]	
S-24C01A(DP)	S-24C01A(DPA)	
S-24C01A(FJA)@SOIC8 [(SA602A)]	S-24C01B(DP)	



S-24C01B(FJ)@SOIC8 [(SA602A)] S-24C02A(DP)  
S-24C02A(DPA) S-24C02A(FJA)@SOIC8 [(SA602A)]  
S-24C02B(DP) S-24C02B(FJ)@SOIC8 [(SA602A)]  
S-24C04A(DP) S-24C04A(DPA)  
S-24C04A(FJA)@SOIC8 [(SA602A)] S-24C04B(DP)  
S-24C04B(FJ)@SOIC8 [(SA602A)] S-24C08A(DPA)  
S-24C08A(FJA)@SOIC8 [(SA602A)] S-24C16A(DPA)  
S-24C16A(FJA)@SOIC8 [(SA602A)] S-24CS01A(DP)  
S-24CS01A(FJ)@SOIC8 [(SA602A)] S-24CS01A(FT)@TSSOP8 [(SA026)]  
S-24CS02A(DP) S-24CS02A(FJ)@SOIC8 [(SA602A)]  
S-24CS02A(FT)@TSSOP8 [(SA026)] S-24CS04A(DP)  
S-24CS04A(FJ)@SOIC8 [(SA602A)] S-24CS04A(FT)@TSSOP8 [(SA026)]  
S-24CS08A(DP) S-24CS08A(FJ)@SOIC8 [(SA602A)]  
S-24CS08A(FT)@TSSOP8 [(SA026)] S-24CS16A(DP)  
S-24CS16A(FJ)@SOIC8 [(SA602A)] S-24CS16A(FT)@TSSOP8 [(SA026)]  
S-24CS64A(FJ)@SOIC8 [(SA602A)] S-24CS64A(FT)@TSSOP8 [(SA026)]  
S-24H45 S-24H45@SOP8 [(SA605A)]  
S-24S45 S-24S45@SOP8 [(SA605A)]  
S-2817A@SOP28 [(SA630)] S-29130A(DFJA)@SOIC8 [(SA602A)]  
S-29130A(DPA) S-29130A(FJA)@SOIC8 [(SA602A)]  
S-29131A(DPA) S-29131A(FJA)@SOIC8 [(SA602A)]  
S-29190A(DPA) S-29190A(FJA)@SOIC8 [(SA602A)]  
S-29191A(DPA) S-29191A(FJA)@SOIC8 [(SA602A)]  
S-29194A(DPA) S-29194A(FJA)@SOIC8 [(SA602A)]  
S-29220A(DFJA)@SOIC8 [(SA602A)] S-29220A(DPA)  
S-29220A(FJA)@SOIC8 [(SA602A)] S-29221A(DPA)  
S-29221A(FJA)@SOIC8 [(SA602A)] S-29230A(DFJA)@SOIC8 [(SA602A)]  
S-29230A(DPA) S-29230A(FJA)@SOIC8 [(SA602A)]  
S-29231A(DPA) S-29231A(FJA)@SOIC8 [(SA602A)]  
S-29290A(DPA) S-29290A(FJA)@SOIC8 [(SA602A)]  
S-29291A(DPA) S-29291A(FJA)@SOIC8 [(SA602A)]  
S-29294A(DPA) S-29294A(FJA)@SOIC8 [(SA602A)]  
S-29330A(DFJA)@SOIC8 [(SA602A)] S-29330A(DPA)  
S-29330A(FJA)@SOIC8 [(SA602A)] S-29331A(DPA)  
S-29331A(FJA)@SOIC8 [(SA602A)] S-29390A(DPA)  
S-29390A(FJA)@SOIC8 [(SA602A)] S-29391A(DPA)  
S-29391A(FJA)@SOIC8 [(SA602A)] S-29394A(DPA)  
S-29394A(FJA)@SOIC8 [(SA602A)] S-29430A  
S-29430A@SOIC8 [(SA602A)] S-29530A  
S-29530A@SOIC8 [(SA602A)] S-29630A  
S-29630A@SOIC8 [(SA602A)] S-29L130A(DFE)@SOIC8 [(SA602A)]  
S-29L130A(FE)@SOIC8 [(SA602A)] S-29L130A(FS)@SSOP8 [(SA026)]  
S-29L131A(DFE)@SOIC8 [(SA602A)] S-29L131A(FS)@SSOP8 [(SA026)]

S-29L194A(DFE)@SOIC8 [(SA602A)] S-29L194A(FS)@TSSOP8 [(SA026)]  
 S-29L220A(DFE)@SOIC8 [(SA602A)] S-29L220A(FE)@SOIC8 [(SA602A)]  
 S-29L220A(FS)@SSOP8 [(SA026)] S-29L221A(DFE)@SOIC8 [(SA602A)]  
 S-29L221A(FS)@SSOP8 [(SA026)] S-29L294A(DFE)@SOIC8 [(SA602A)]  
 S-29L294A(FS)@TSSOP8 [(SA026)] S-29L330A(DFE)@SOIC8 [(SA602A)]  
 S-29L330A(FE)@SOIC8 [(SA602A)] S-29L330A(FS)@SSOP8 [(SA026)]  
 S-29L331A(DFE)@SOIC8 [(SA602A)] S-29L331A(FS)@SSOP8 [(SA026)]  
 S-29L394A(DFE)@SOIC8 [(SA602A)] S-29L394A(FS)@TSSOP8 [(SA026)]  
 S-29U130A(DFE)@SOIC8 [(SA602A)] S-29U130A(FS)@SSOP8 [(SA026)]  
 S-29U131A(DFE)@SOIC8 [(SA602A)] S-29U131A(FS)@SSOP8 [(SA026)]  
 S-29U194A(DFE)@SOIC8 [(SA602A)] S-29U194A(FS)@TSSOP8 [(SA026)]  
 S-29U220A(DFE)@SOIC8 [(SA602A)] S-29U220A(FS)@SSOP8 [(SA026)]  
 S-29U221A(DFE)@SOIC8 [(SA602A)] S-29U221A(FS)@SSOP8 [(SA026)]  
 S-29U294A(DFE)@SOIC8 [(SA602A)] S-29U294A(FS)@TSSOP8 [(SA026)]  
 S-29U330A(DFE)@SOIC8 [(SA602A)] S-29U330A(FS)@SSOP8 [(SA026)]  
 S-29U331A(DFE)@SOIC8 [(SA602A)] S-29U331A(FS)@SSOP8 [(SA026)]  
 S-29U394A(DFE)@SOIC8 [(SA602A)] S-29U394A(FS)@TSSOP8 [(SA026)]  
 S-29Z330A(DFJA)@SOIC8 [(SA602A)] S-29Z330A(FS)@SSOP8 [(SA026)]  
 S-29Z430A(DFJA)@SOIC8 [(SA602A)] S-29Z430A(FS)@SSOP8 [(SA026)]  
 S-93A46A(D0A)@SOIC8 [(SA602A)] S-93A56A(D0A)@SOIC8 [(SA602A)]  
 S-93A66A(D0A)@SOIC8 [(SA602A)] S-93A66A(FJ)@SOIC8 [(SA602A)]  
 S-93A86A@SOIC8 [(SA602A)] S-93C46A(DFJ)@SOIC8 [(SA602A)]  
 S-93C46A(DP) S-93C46A(FJ)@SOIC8 [(SA602A)]  
 S-93C46A(FT)@TSSOP8 [(SA026)] S-93C46B(DP)  
 S-93C46B(FJ)@SOIC8 [(SA602A)] S-93C46B(FT)@TSSOP8 [(SA026)]  
 S-93C56A(DFJ)@SOIC8 [(SA602A)] S-93C56A(DP)  
 S-93C56A(FJ)@SOIC8 [(SA602A)] S-93C56A(FT)@TSSOP8 [(SA026)]  
 S-93C56B(DP) S-93C56B(FJ)@SOIC8 [(SA602A)]  
 S-93C56B(FT)@TSSOP8 [(SA026)] S-93C66A(DFJ)@SOIC8 [(SA602A)]  
 S-93C66A(DP) S-93C66A(FJ)@SOIC8 [(SA602A)]  
 S-93C66A(FT)@TSSOP8 [(SA026)] S-93C66B(DP)  
 S-93C66B(FJ)@SOIC8 [(SA602A)] S-93C66B(FT)@TSSOP8 [(SA026)]  
 S-93C76A(DP) S-93C76A(FJ)@SOIC8 [(SA602A)]  
 S-93C76A(FT)@TSSOP8 [(SA026)] S-93C86A(DP)  
 S-93C86A(FJ)@SOIC8 [(SA602A)] S-93C86A(FT)@TSSOP8 [(SA026)]  
 S-93C86B@SOIC8 [(SA602A)] S-93C86B@TSSOP8 [(SA026)]  
 S-93L46A(D0I)@SOIC8 [(SA602A)] S-93L56A(D0I)@SOIC8 [(SA602A)]  
 S-93L66A(D0I)@SOIC8 [(SA602A)] S-93L76A(D0I)@SOIC8 [(SA602A)]

## SGS-THOMSON

### E(E)PROM/FRAM/NVRAM

ET2716 ETC2716  
 ETC2732 M24128  
 M24128@SOIC8 [(SA602A)] M24164  
 M24164@SOIC8 [(SA602A)] M24256  
 M24256[3.9]@SOIC8 [(SA602A)] M24256[5.5]@SOIC8 [(SA605A)]  
 M24512 M24512@SOIC8 [(SA605A)]  
 M24512@TSOP8 [(SA026)] M24C04  
 M24C04@SOIC8 [(SA602A)] M24C08  
 M24C08@SOIC8 [(SA602A)] M24C08W  
 M24C08W@SOIC8 [(SA602A)] M24C08W@TSOP8 [(SA026)]  
 M24C64(BN) M24C64(DL)@TSSOP14 [(SA026)]  
 M24C64(DW)@TSSOP8 [(SA602A)] M24C64(MN)@SOIC8 [(SA605A)]  
 M24C64(MW)@SOIC8 [(SA602A)] M27128A  
 M2716 M27256  
 M27256A M2732A  
 M27512 M2764  
 M2764A M27C1000  
 M27C1000@PLCC32 [(SA015A1T)] M27C1000@TSOP32 [(SA410T)]  
 M27C1001 M27C1001@PLCC32 [(SA015A1T)]  
 M27C1001@TSOP32 [(SA410T)] M27C1024  
 M27C1024@PLCC44 [(SA244)] M27C160  
 M27C160@PLCC44 [(SA244)] M27C160@PSOP44 [(SA638)]  
 M27C2001 M27C2001@PLCC32 [(SA015A1T)]  
 M27C2001@TSOP32 [(SA410T)] M27C202  
 M27C202@PLCC44 [(SA244)] M27C202@TSOP40 [(SA409T)]  
 M27C256B M27C256B@PLCC32 [(SA015A1T)]  
 M27C400 M27C4001  
 M27C4001@PLCC32 [(SA015A1T)] M27C4001@TSOP32 [(SA410T)]  
 M27C4002 M27C4002@PLCC44 [(SA244)]  
 M27C405 M27C405@PLCC32 [(SA015A1T)]  
 M27C405@TSOP32 [(SA410T)] M27C512  
 M27C512@PLCC32 [(SA015A1T)] M27C516  
 M27C516@PLCC44 [(SA244)] M27C64A  
 M27C64A@PLCC32 [(SA015A1T)] M27C800  
 M27C800@PLCC44 [(SA244)] M27C800@PSOP44 [(SA638)]  
 M27C801 M27C801@PLCC32 [(SA015A1T)]  
 M27C801@TSOP32 [(SA410T)] M27HC641  
 M27HC641@PLCC28 [(SA008A)] M27HC642  
 M27HC642@PLCC28 [(SA008A)] M27V101  
 M27V101@PLCC32 [(SA015A1T)] M27V101@TSOP32 [(SA410T)]  
 M27V201 M27V201@PLCC32 [(SA015A1T)]  
 M27V201@TSOP32 [(SA410T)] M27V401

M27V401@PLCC32 [(SA015A1T)] M27V401@TSOP32 [(SA410T)]  
M27V402 M27V402@PLCC44 [(SA244)]  
M27V402@TSOP40 [(SA409T)] M27V512  
M27V512@PLCC32 [(SA015A1T)] M27V512@TSOP28 [(SA430T)]  
M27V800 M27V800@PLCC44 [(SA244)]  
M27V801 M27V801@PLCC32 [(SA015A1T)]  
M27V801@TSOP32 [(SA410T)] M27W201  
M27W201@PLCC32 [(SA015A1T)] M27W201@TSOP32 [(SA410T)]  
M28010 M28010@PLCC32 [(SA015A1T)]  
M28010@TSOP32 [(SA410T)] M28C16@PLCC32 [(SA015A1T)]  
M28C64C M28C64C@PLCC32 [(SA015A1T)]  
M28C64C@SOIC28 [(SA404)] M28C64C@TSOP28 [(SA430T)]  
M28F101 M28F101@PLCC32 [(SA015A1T)]  
M28F101@TSOP32 [(SA410T)] M28F102  
M28F102@PLCC44 [(SA244)] M28F102@TSOP40 [(SA409T)]  
M28F201 M28F201@PLCC32 [(SA015A1T)]  
M28F201@TSOP32 [(SA410T)] M28F211@TSOP40 [(SA409T)]  
M28F220@PSOP44 [(SA638)] M28F220@TSOP48 [(SA247-B005)]  
M28F256 M28F256@PLCC32 [(SA015A1T)]  
M28F256@TSOP32 [(SA410T)] M28F411@TSOP40 [(SA409T)]  
M28F512 M28F512@PLCC32 [(SA015A1T)]  
M28F512@TSOP32 [(SA410T)] M29F002B  
M29F002B@PLCC32 [(SA015A1T)] M29F002B@TSOP32 [(SA410T)]  
M29F002T M29F002T@PLCC32 [(SA015A1T)]  
M29F002T@TSOP32 [(SA410T)] M29F040  
M29F040@PLCC32 [(SA015A1T)] M29F040@TSOP32 [(SA410T)]  
M29F040B M29F040B@PLCC32 [(SA015A1T)]  
M29F040B@TSOP32 [(SA410T)] M29F100B@PSOP44 [(SA638-B006)]  
M29F100B@TSOP48 [(SA247-B005)] M29F100T@PSOP44 [(SA638-B006)]  
M29F100T@TSOP48 [(SA247-B005)] M29F102B@PLCC44 [(SA244)]  
M29F102B@TSOP40 [(SA623)] M29F102BB@PLCC44 [(SA244)]  
M29F102BB@TSOP40 [(SA623)] M29F200B@PSOP44 [(SA638-B006)]  
M29F200B@TSOP48 [(SA247-B005)] M29F200T@PSOP44 [(SA638-B006)]  
M29F200T@TSOP48 [(SA247-B005)] M29F400B@PSOP44 [(SA638-B006)]  
M29F400B@TSOP48 [(SA247-B005)] M29F400T@PSOP44 [(SA638-B006)]  
M29F400T@TSOP48 [(SA247-B005)] M29V040@PLCC32 [(SA015A1T)]  
M29V040@TSOP32 [(SA410T)] M29W008B@TSOP40 [(SA409T)]  
M29W008T@TSOP40 [(SA409T)] M29W040@PLCC32 [(SA015A1T)]  
M29W040@TSOP32 [(SA410T)] M29W400B@PSOP44 [(SA638)]  
M29W400B@TSOP48 [(SA247-B005)] M29W400T@PLCC44 [(SA638)]  
M29W400T@TSOP48 [(SA247-B005)] M29W512B@PLCC32 [(SA015A1T)]  
M29W512B@TSOP32 [(SA620)] M29W800B@PSOP44 [(SA638)]  
M29W800B@TSOP48 [(SA247-B005)] M29W800T@PSOP44 [(SA638)]

M29W800T@TSOP48 [(SA247-B005)] M48T35  
M48T35@SOIC28 [(SA404)] M48T35Y  
M48T35Y@SOIC28 [(SA404)] M48T59  
M48T59@SOIC28 [(SA404)] M48T59Y  
M48T59Y@SOIC28 [(SA404)] M48Z128  
M48Z128Y M48Z30  
M48Z30Y M48Z32  
M48Z32Y M50FW080@PLCC32 [(SA015A1T)]  
M50FW080@TSOP40 [(SA409T)] M50FW080@VSOP32 [(SA620)]  
M87C257 M87C257@PLCC32 [(SA015A1T)]  
M93C06(08bit) M93C06(08bit)@SOIC8 [(SA602A)]  
M93C06(16bit) M93C06(16bit)@SOIC8 [(SA602A)]  
M93S46 M93S46@SOIC8 [(SA602A)]  
M93S46@TSSOP8 [(SA026)] M95P02  
M95P02@SOIC8 [(SA602A)] M95P04  
M95P04@SOIC8 [(SA602A)] M95P08  
M95P08@SOIC8 [(SA602A)] MK48C02  
MK48C02B MK48C12  
MK48C12B MK48T02  
MK48T02B MK48T08  
MK48T12 MK48T12B  
MK48T18 MK48Z02  
MK48Z02B MK48Z08  
MK48Z12 MK48Z12B  
MK48Z18 MKI48Z02  
MKI48Z02B MKI48Z12  
MKI48Z12B MKI48Z18  
ST24C01 ST24C01@SOIC8 [(SA602A)]  
ST24C02A ST24C02A@SOIC8 [(SA602A)]  
ST24C16 ST24C16@SOIC8 [(SA602A)]  
ST24W01 ST24W01@SOIC8 [(SA602A)]  
ST24W02 ST24W02@SOIC8 [(SA602A)]  
ST24W04C ST24W04C@SOIC8 [(SA602A)]  
ST27128A ST27256  
ST2764A ST27C256  
ST93C06(08bit) ST93C06(08bit)@SOIC8 [(SA602A)]  
ST93C06(16bit) ST93C06(16bit)@SOIC8 [(SA602A)]  
ST93CS46 ST93CS46@SOIC8 [(SA602A)]  
TS27C256 TS27C64  
TS27C64@PLCC32 [(SA015A1T)] TS27C64A  
TS27C64A@PLCC32 [(SA015A1T)] TS28C16A  
TS28C17A

## PLD

GAL16V8                    GAL16V8A  
GAL20V8                    GAL20V8A

## SHARP

## E(E)PROM/FRAM/NVRAM

LH28F002SCHN@PSOP44 [(SA638)]    LH28F002SCHT@TSOP40 [(SA409T)]  
LH28F002SCN@PSOP44 [(SA638)]    LH28F002SCT@TSOP40 [(SA409T)]  
LH28F004BVE(BT)@TSOP40 [(SA409T)]  
LH28F004BVE(TT)@TSOP40 [(SA409T)]  
LH28F004BVHS(BT)@VSOP40 [(SA623)]  
LH28F004BVHS(TT)@VSOP40 [(SA623)]  
LH28F004BVT(BT)@TSOP40 [(SA409T)]  
LH28F004BVT(TT)@TSOP40 [(SA409T)]  
LH28F004SCHN@PSOP44 [(SA638)]    LH28F004SCHS@VSOP40 [(SA623)]  
LH28F004SCHT@TSOP40 [(SA409T)]    LH28F004SCN@PSOP44 [(SA638)]  
LH28F004SCS@VSOP40 [(SA623)]    LH28F004SCT@TSOP40 [(SA409T)]  
LH28F008BJT(BTLZ1)@TSOP40 [(SA409T)]  
LH28F008BJT(TB)@TSOP40 [(SA409T)]  
LH28F008BJT(TT)@TSOP40 [(SA409T)]  
LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]  
LH28F008BVT(BT)@TSOP40 [(SA409T)]  
LH28F008BVT(TT)@TSOP40 [(SA409T)]  
LH28F008SAN@PSOP44 [(SA638)]    LH28F008SAR@RTSOP40 [(SA409T)]  
LH28F008SAT@TSOP40 [(SA409T)]  
LH28F008SCH(L85)@RTSOP40 [(SA409T)]  
LH28F008SCH-L@TSOP40 [(SA409T)]    LH28F008SCHN@PSOP44 [(SA638)]  
LH28F008SCH-V@TSOP40 [(SA409T)]  
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]  
LH28F008SCN@PSOP44 [(SA638)]    LH28F008SCN-L@PSOP44 [(SA638)]  
LH28F008SCT@TSOP40 [(SA409T)]    LH28F008SCT-L@TSOP40 [(SA409T)]  
LH28F008SCT-V@TSOP40 [(SA409T)]    LH28F008SCV@TSOP40 [(SA409T)]  
LH28F016SA@TSOP56 [(SA628-B011)]    LH28F016SC@PSOP44 [(SA638)]  
LH28F016SCR(L95)@RTSOP40 [(SA409T)]  
LH28F016SCT-L95@TSOP40 [(SA409T)]  
LH28F016SUT@TSOP56 [(SA628-B011)]  
LH28F128BFHBD@CSP72 [(SA642E-B052A-T072F001)]  
LH28F128BFHE@TSOP48 [(SA247-B005)]

LH28F128BFHT(PBTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTLITA)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PWTL80)@TSOP56 [(SA628-B045)]  
LH28F128BFND@PSOP44 [(SA638)]  
LH28F128SPHTD@TSOP56 [(SA628-B018)]  
LH28F160BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGE(B)@TSOP48 [(SA247-B005)]  
LH28F160BGE(T)@TSOP48 [(SA247-B005)]  
LH28F160BJBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJD  
LH28F160BJEB@TSOP48 [(SA247-B005)]  
LH28F160BJET@TSOP48 [(SA247-B005)]  
LH28F160BJHBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHEB@TSOP48 [(SA247-B005)]  
LH28F160BJHET@TSOP48 [(SA247-B005)]  
LH28F160BVE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160BVEB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVEB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVHE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVHE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160S3HNS@SSOP56 [(SA629A-B013)]  
LH28F160S3HT@TSOP56 [(SA628-B011)]  
LH28F160S3NS@SSOP56 [(SA629A-B013)]  
LH28F160S3T@TSOP56 [(SA628-B011)]  
LH28F160S5HNS@SSOP56 [(SA629A-B013)]  
LH28F160S5HT@TSOP56 [(SA628-B011)]  
LH28F160S5NS@SSOP56 [(SA629A-B013)]  
LH28F160S5T@TSOP56 [(SA628-B011)]  
LH28F160SKT@TSOP56 [(SA628-B011)]  
LH28F320BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHB(PB)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHB(PT)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]  
LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]

LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BJD  
LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJN@PSOP44 [(SA638)]  
LH28F320S3HNS@SSOP56 [(SA629A-B013)]  
LH28F320S3HT@TSOP56 [(SA628-B011)]  
LH28F320S3NS@SSOP56 [(SA629A-B013)]  
LH28F320S3T@TSOP56 [(SA628-B011)]  
LH28F320S3TD@TSOP56 [(SA628-B011)]  
LH28F320S5HNS@SSOP56 [(SA629A-B013)]  
LH28F320S5HT@TSOP56 [(SA628-B011)]  
LH28F320S5NS@SSOP56 [(SA629A-B013)]  
LH28F320S5T@TSOP56 [(SA628-B011)]  
LH28F320SKTD@TSOP56 [(SA628-B011)]  
LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGN(B)@PSOP44 [(SA638)] LH28F400BGN(T)@PSOP44 [(SA638)]  
LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVN(B)@PSOP44 [(SA638)] LH28F400BVN(T)@PSOP44 [(SA638)]  
LH28F640BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]



LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]  
LH28F640BFHG@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]  
LH28F640SPHT@TSOP56 [(SA628-B018)]  
LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGN(B)@PSOP44 [(SA638)] LH28F800BGN(T)@PSOP44 [(SA638)]  
LH28F800BH-B@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]  
LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BV-B@TSOP48 [(SA247-B005)]  
LH28F800BVE(B)@TSOP48 [(SA247-B005)]  
LH28F800BVE(T)@TSOP48 [(SA247-B005)]  
LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]  
LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVHB@TSOP48 [(SA247-B005)]  
LH28F800BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BVHE(T)@TSOP48 [(SA247-B005)]  
LH28F800BVHT@TSOP48 [(SA247-B005)]  
LH28F800BVN(B)@PSOP44 [(SA638)] LH28F800BVN(T)@PSOP44 [(SA638)]  
LH28F800BVN(TV85)@PSOP44 [(SA638)]  
LH28F800BV-T@TSOP48 [(SA247-B005)]  
LH28F800SG(L100)@TSOP48 [(SA247)]  
LH28F800SG(L120)@TSOP48 [(SA247)]  
LH28F800SG(L70)@TSOP48 [(SA247)] LH28F800SG(L80)@TSOP48 [(SA247)]  
LH28F800SG(L85)@TSOP48 [(SA247)]

LH28F800SGH(L100)@TSOP48 [(SA247)]  
LH28F800SGH(L120)@TSOP48 [(SA247)]  
LH28F800SGH(L70)@TSOP48 [(SA247)]  
LH28F800SGH(L80)@TSOP48 [(SA247)]  
LH28F800SGH(L85)@TSOP48 [(SA247)]  
LH28F800SUT@TSOP56 [(SA628-B011)]  
LHF00L03@PLCC32 [(SA015A1T)] LHF00L04@TSOP40 [(SA409T)]  
LHF00L06@TSOP40 [(SA409T)] LHF00L07@PLCC32 [(SA015A1T)]  
LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]  
LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]  
LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]  
LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]  
LRS1311@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1315@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1316@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1317@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1330A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1336@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1339@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1341@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1342@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1348B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1350@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1356@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1360@FBGA72 [(SA642B-B023A-Y072F001)]

LRS1360C@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370B@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1380@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1381@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1382@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383F@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1384@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1385@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1386@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1387@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1391@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1392A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1393A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1393C@FBGA72 [(SA642E-B023A-T072F001N)]  
LRS1395@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1396@TSOP56 [(SA628-B178)]  
LRS13A0@FBGA72 [(SA642E-B052A-T072F001)]  
LRS13A1@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A2@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A3@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A4@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A5@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A6@FBGA72 [(SA642E-B023A-T072F001)]  
LRS13A8@TSOP56 [(SA628-B216)]  
LRS1805A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1806A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1806F@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1807A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1808A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1811@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1812@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1816@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1816A@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1822@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1825@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1826@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1826A@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1827@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1828@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1829@FBGA72 [(SA642E-B052A-T072F001)]

LRS1832@FBGA72 [(SA642E-B052A-T072F001)]  
LRS1844@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1845@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1850@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1851@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1852@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1853@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1871@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1872@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1875@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1876@FBGA72 [(SA642B-B023A-Y072F001Y)]  
LRS18B0@FBGA72 [(SA642E-B141A-T072F001Y)]  
LRS18BK@FBGA88 [(SA642A-B091A-Y096F001)]  
LRS18BL@FBGA88 [(SA642A-B091A-Y096F001)]  
LRS18BS@FBGA72 [(SA642B-B023A-Y072F001)]

## SHARP-CUSTOMER

### E(E)PROM/FRAM/NVRAM

LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]

## SIEMENS

### E(E)PROM/FRAM/NVRAM

SDA2526	SDA2526@SOIC8 [(SA602A)]
SDA2546	SDA2546@SOIC8 [(SA602A)]
SDA25X26	SDA25X26@SOIC8 [(SA602A)]
SDA25X46	SDA25X46@SOIC8 [(SA602A)]
SDE2526	SDE2526@SOIC8 [(SA602A)]
SDE2546	SDE2546@SOIC8 [(SA602A)]
SDE25X26	SDE25X26@SOIC8 [(SA602A)]
SDE25X46	SDE25X46@SOIC8 [(SA602A)]
SLA24C01	SLA24C01@SOIC8 [(SA602A)]
SLA24C02	SLA24C02@SOIC8 [(SA602A)]
SLA24C04	SLA24C04@SOIC8 [(SA602A)]
SLA24C08	SLA24C08@SOIC8 [(SA602A)]
SLA24C16	SLA24C16@SOIC8 [(SA602A)]
SLA24C164	SLA24C164@SOIC8 [(SA602A)]

SLA24C32	SLA24C32@SOIC8 [(SA602A)]
SLA24C64	SLA24C64@SOIC8 [(SA602A)]
SLA25010	SLA25010@SOIC8 [(SA602A)]
SLA25020	SLA25020@SOIC8 [(SA602A)]
SLA25040	SLA25040@SOIC8 [(SA602A)]
SLA25080	SLA25080@SOIC8 [(SA602A)]
SLA25160	SLA25160@SOIC8 [(SA602A)]
SLE24C01	SLE24C01@SOIC8 [(SA602A)]
SLE24C02	SLE24C02@SOIC8 [(SA602A)]
SLE24C04	SLE24C04@SOIC8 [(SA602A)]
SLE24C08	SLE24C08@SOIC8 [(SA602A)]
SLE24C16	SLE24C16@SOIC8 [(SA602A)]
SLE24C164	SLE24C164@SOIC8 [(SA602A)]
SLE24C32	SLE24C32@SOIC8 [(SA602A)]
SLE24C64	SLE24C64@SOIC8 [(SA602A)]
SLE25010	SLE25010@SOIC8 [(SA602A)]
SLE25020	SLE25020@SOIC8 [(SA602A)]
SLE25040	SLE25040@SOIC8 [(SA602A)]
SLE25080	SLE25080@SOIC8 [(SA602A)]
SLE25160	SLE25160@SOIC8 [(SA602A)]

## SIGNETICS

### E(E)PROM/FRAM/NVRAM

27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]
27C210	27C210@PLCC44 [(SA244)]
27C240	27C240@PLCC44 [(SA244)]
27C256	27C256@PLCC32 [(SA015A1T)]
27C512	27C512@PLCC32 [(SA015A1T)]
27C64A	27C64A@PLCC32 [(SA015A1T)]
27HC641	27HC641@PLCC28 [(SA008A)]
27HC642	27HC642@PLCC28 [(SA008A)]
PCA8582A	PCA8582A@SOIC8 [(SA602A)]
PCA8582B	PCA8582B@SOIC8 [(SA602A)]
PCA8582C	PCA8582C@SOIC8 [(SA602A)]
PCA8582D	PCA8582D@SOIC8 [(SA602A)]
PCA8582E	PCA8582E@SOIC8 [(SA602A)]
PCD8582A	PCD8582A@SOIC8 [(SA602A)]
PCD8582B	PCD8582B@SOIC8 [(SA602A)]

PCD8582C	PCD8582C@SOIC8 [(SA602A)]
PCD8582D	PCD8582D@SOIC8 [(SA602A)]
PCD8582E	PCD8582E@SOIC8 [(SA602A)]
PCF8582A	PCF8582A@SOIC8 [(SA602A)]
PCF8582B	PCF8582B@SOIC8 [(SA602A)]
PCF8582C	PCF8582C@SOIC8 [(SA602A)]
PCF8582D	PCF8582D@SOIC8 [(SA602A)]
PCF8582E	PCF8582E@SOIC8 [(SA602A)]
PCF8594	PCF8594@SOIC8 [(SA626A)]
PCF8594C	PCF8594C@SOIC8 [(SA626A)]
PCF8594D	PCF8594D@SOIC8 [(SA626A)]
PCF8594E	PCF8594E@SOIC8 [(SA626A)]
PCF8598	PCF8598@SOIC8 [(SA626A)]
PCF8598C	PCF8598C@SOIC8 [(SA626A)]
PCF8598D	PCF8598D@SOIC8 [(SA626A)]
PCF8598E	PCF8598E@SOIC8 [(SA626A)]

## MICROCONTROLLER

S87C51	S87C51@PLCC44 [(SA244)]
S87C51@TQFP44 [(SA245A)]	S87C51FA
S87C51FA@PLCC44 [(SA244)]	S87C51FA@TQFP44 [(SA245A)]
S87C51FB	S87C51FB@PLCC44 [(SA244)]
S87C51FB@TQFP44 [(SA245A)]	S87C51FC
S87C51FC@PLCC44 [(SA244)]	S87C51FC@TQFP44 [(SA245A)]
S87C52	S87C52@PLCC44 [(SA244)]
S87C52@TQFP44 [(SA245A)]	S87C524
S87C524@PLCC44 [(SA244)]	S87C524@TQFP44 [(SA245A)]
S87C528	S87C528@PLCC44 [(SA244)]
S87C528@TQFP44 [(SA245A)]	S87C54
S87C54@PLCC44 [(SA244)]	S87C54@TQFP44 [(SA245A)]
S87C550	S87C550@PLCC44 [(SA244)]
S87C552@PLCC68(*) [(SA648-B6806)]	
S87C554@PLCC68(*) [(SA648-B6806)]	
S87C575	S87C575@PLCC44 [(SA244)]
S87C575@TQFP44 [(SA245A)]	S87C576
S87C576@PLCC44 [(SA244)]	S87C576@TQFP44 [(SA245A)]
S87C58	S87C58@PLCC44 [(SA244)]
S87C58@TQFP44 [(SA245A)]	S87C591@PLCC44 [(SA244)]
S87C591@TQFP44 [(SA245A)]	S87C652
S87C652@PLCC44 [(SA244)]	S87C652@TQFP44 [(SA245A)]
S87C654	S87C654@PLCC44 [(SA244)]

S87C654@TQFP44 [(SA245A)]      S87C748  
 S87C748@PLCC28 [(SA008A)]      S87C749  
 S87C749@PLCC28 [(SA008A)]      S87C750  
 S87C750@PLCC28 [(SA008A)]      S87C750@SSOP24 [(SA626A)]  
 S87C751                      S87C751@PLCC28 [(SA008A)]  
 S87C751@SSOP24 [(SA626A)]      S87C752  
 S87C752@PLCC28 [(SA008A)]      S87C752@SSOP28 [(SA626A)]  
 S87C754                      S87C754@PLCC28 [(SA008A)]  
 S87C754@SSOP28 [(SA626A)]      S87L51FA  
 S87L51FA@PLCC44 [(SA244)]      S87L51FA@TQFP44 [(SA245A)]  
 S87L51FB                      S87L51FB@PLCC44 [(SA244)]  
 S87L51FB@TQFP44 [(SA245A)]

## Silicon Laboratories

### MICROCONTROLLER

C8051F000@TQFP64(ISP) [(PEP+S616)]  
 C8051F001@TQFP48 [(SA248)]      C8051F001@TQFP48(ISP) [(SA248)]  
 C8051F002@TQFP32 [(SA663)]      C8051F002@TQFP32(ISP) [(SA663)]  
 C8051F005@TQFP64(ISP) [(PEP+S616)]  
 C8051F006@TQFP48 [(SA248)]      C8051F006@TQFP48(ISP) [(SA248)]  
 C8051F007@TQFP32 [(SA663)]      C8051F007@TQFP32(ISP) [(SA663)]  
 C8051F010@TQFP64(ISP) [(PEP+S616)]  
 C8051F011@TQFP48 [(SA248)]      C8051F011@TQFP48(ISP) [(SA248)]  
 C8051F012@TQFP32 [(SA663)]      C8051F012@TQFP32(ISP) [(SA663)]  
 C8051F015@TQFP64(ISP) [(PEP+S616)]  
 C8051F016@TQFP48 [(SA248)]      C8051F016@TQFP48(ISP) [(SA248)]  
 C8051F017@TQFP32 [(SA663)]      C8051F017@TQFP32(ISP) [(SA663)]  
 C8051F018@TQFP64(ISP) [(PEP+S616)]  
 C8051F019@TQFP48 [(SA248)]      C8051F019@TQFP48(ISP) [(SA248)]  
 C8051F020@TQFP100(ISP) [ISP-HEADER01]  
 C8051F021@TQFP64(ISP) [ISP-HEADER01]  
 C8051F022@TQFP100(ISP) [ISP-HEADER01]  
 C8051F023@TQFP64(ISP) [ISP-HEADER01]  
 C8051F040@TQFP100(ISP) [ISP-HEADER01]  
 C8051F041@TQFP64(ISP) [ISP-HEADER01]  
 C8051F042@TQFP100(ISP) [ISP-HEADER01]  
 C8051F043@TQFP64(ISP) [ISP-HEADER01]  
 C8051F044@TQFP100(ISP) [ISP-HEADER01]  
 C8051F045@TQFP64(ISP) [ISP-HEADER01]  
 C8051F046@TQFP100(ISP) [ISP-HEADER01]

C8051F047@TQFP64(ISP) [ISP-HEADER01]  
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48 [(SA248)]  
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48 [(SA248)]  
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32 [(SA663)]  
C8051F236@TQFP48 [(SA248)] C8051F300 [(SA695A)]  
C8051F301 [(SA695A)] C8051F302 [(SA695A)]  
C8051F303 [(SA695A)] C8051F304 [(SA695A)]  
C8051F305 [(SA695A)] C8051F310@TQFP32 [(SA663)]  
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-B006)]  
C8051F311-GM@QFN28 [(SA697-B006)]  
C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32 [(SA663)]  
C8051F313@QFN28 [(SA697-B006)]  
C8051F313-GM@QFN28 [(SA697-B006)]  
C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32 [(SA663)]  
C8051F315@QFN28 [(SA697-B006)]  
C8051F315-GM@QFN28 [(SA697-B006)]  
C8051F316-GM@QFN24 [(SA710-B006)]  
C8051F317-GM@QFN24 [(SA710-B006)]  
C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-B006)]  
C8051F326@QFN28 [(SA697-B006)]  
C8051F326-GQ@QFN28 [(SA697-B006)]  
C8051F327@QFN28 [(SA697-B006)]  
C8051F327-GQ@QFN28 [(SA697-B006)]  
C8051F330@MLP20 [(SA692)] C8051F330D  
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20 [(SA692)]  
C8051F333-GM@MLP20 [(SA692)] C8051F334-GM@MLP20 [(SA692)]  
C8051F335-GM@MLP20 [(SA692)] C8051F336-GM@QFN20 [(SA692)]  
C8051F337-GM@QFN20 [(SA692)] C8051F338-GM@QFN24 [(SA710)]  
C8051F339-GM@QFN24 [(SA710)] C8051F340-GQ@TQFP48 [(SA248)]  
C8051F341-GQ@TQFP48 [(SA248)] C8051F342-GQ@LQFP32 [(SA663)]  
C8051F343-GQ@LQFP32 [(SA663)] C8051F344-GQ@TQFP48 [(SA248)]  
C8051F345-GQ@TQFP48 [(SA248)] C8051F346-GQ@LQFP32 [(SA663)]  
C8051F347-GQ@LQFP32 [(SA663)] C8051F350-GQ@LQFP32 [(SA663)]  
C8051F351-GM@QFN28 [(SA697-B006)]  
C8051F352-GQ@LQFP32 [(SA663)]  
C8051F353-GM@QFN28 [(SA697-B006)]  
C8051F360@QFP48 [(SA248)] C8051F361@QFP32 [(SA663)]  
C8051F362@QFN28 [(SA697)] C8051F363@QFP48 [(SA248)]  
C8051F364@QFP32 [(SA663)] C8051F365@QFN28 [(SA697)]  
C8051F366@QFP32 [(SA663)] C8051F367@QFN28 [(SA697)]  
C8051F368@QFP32 [(SA663)] C8051F369@QFN28 [(SA697)]  
C8051F410-GQ@LQFP32 [ordering number is marked above]  
C8051F411-GM@QFN28 [ordering number is marked above]



C8051F412-GQ@LQFP32 [ordering number is marked above]  
C8051F413-GM@QFN28 [ordering number is marked above]  
C8051F520-IM@QFN10 [(SA695A)]      C8051F521-IM@QFN10 [(SA695A)]  
C8051F523-IM@QFN10 [(SA695A)]      C8051F524-IM@QFN10 [(SA695A)]  
C8051F526-IM@QFN10 [(SA695A)]      C8051F527-IM@QFN10 [(SA695A)]  
C8051F530-IM@QFN20 [(SA692)]      C8051F530-IT@TSSOP20 [(SA026)]  
C8051F531-IM@QFN20 [(SA692)]      C8051F531-IT@TSSOP20 [(SA026)]  
C8051F533-IM@QFN20 [(SA692)]      C8051F533-IT@TSSOP20 [(SA026)]  
C8051F534-IM@QFN20 [(SA692)]      C8051F534-IT@TSSOP20 [(SA026)]  
C8051F536-IM@QFN20 [(SA692)]      C8051F536-IT@TSSOP20 [(SA026)]  
C8051F537-IM@QFN20 [(SA692)]      C8051F537-IT@TSSOP20 [(SA026)]  
C8051F610-GQ@QFP32 [(SA663)]  
C8051F611-GM@QFN28 [(SA697-B006)]  
C8051F612-GQ@QFP32 [(SA663)]  
C8051F613-GM@QFN28 [(SA697-B006)]  
C8051F614-GQ@QFP32 [(SA663)]  
C8051F615-GM@QFN28 [(SA697-B006)]  
C8051F616-GM@QFN24 [(SA710-B006)]  
C8051F617-GM@QFN24 [(SA710-B006)]  
C8051T600@QFN11 [(SA695A)]      C8051T600@SOIC14 [(SA602)]  
C8051T601@QFN11 [(SA695A)]      C8051T601@SOIC14 [(SA602)]  
C8051T602@SOIC14 [(SA602)]      C8051T603@SOIC14 [(SA602)]  
C8051T604@QFN11 [(SA695A)]      C8051T604@SOIC14 [(SA602)]  
C8051T605@QFN11 [(SA695A)]      C8051T605@SOIC14 [(SA602)]  
SI8250@LQFP32 [(SA663)]      SI8250@QFN28 [(SA697)]  
SI8251@LQFP32 [(SA663)]      SI8251@QFN28 [(SA697)]  
SI8252@LQFP32 [(SA663)]      SI8252@QFN28 [(SA697)]

## SILICON7

### E(E)PROM/FRAM/NVRAM

SV4E1602UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E1602UTA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E1604UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E1604UTA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E1608UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E1608UTA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E3204UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E3204UTA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E3208UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E3208UTA@FBGA56 [(SA642P-B079A-W056F001Y)]

SV4E3216UBA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4E3216UTA@FBGA56 [(SA642P-B079A-W056F001Y)]  
SV4F1602UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F1602UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F1604UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F1604UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F1608UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F1608UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3204UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3204UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3208UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3208UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3216UBA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV4F3216UTA@FBGA66 [(SA642R-B041A-T096F001Y)]  
SV5C2832UCR@FBGA72 [(SA642E-B052A-T072F001)]  
SV5C3238UBA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV5C3238UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV5C3238UTA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV5C3238UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV5C6416UBB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UBB@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UBR@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UTB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UTB@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6416UTR@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6432UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5C6432UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]  
SV5D2832UCA@FBGA88 [(SA642A-B081A-Y096F001)]  
SV6C2832UBA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6C2832UTA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6C6416UBA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6C6416UTA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6C6432UBA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6C6432UTA@FBGA72 [(SA642E-B023A-T072F001Y)]  
SV6D2832UBA@FBGA88 [(SA642A-B124A-Y096F001Y)]  
SV6D2832UTA@FBGA88 [(SA642A-B124A-Y096F001Y)]  
SV7C1602UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C1602UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C1604UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C1604UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C1608UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]

SV7C1608UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3204UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3204UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3208UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3208UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3216UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7C3216UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]  
SV7E1602UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E1602UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E1604UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E1604UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E1608UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E1608UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3204UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3204UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3208UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3208UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3216UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
SV7E3216UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]

## SIMTEK

### E(E)PROM/FRAM/NVRAM

STK10C48  
STK10C48@SOIC28(300 mil) [(SA404)]  
STK10C48@SOIC28(350 mil) [(SA630)]  
STK10C68                    STK10C68@PLCC28 [(SA008A)]  
STK10C68@SOIC28(350 mil) [(SA630)]  
STK11C48  
STK11C48@SOIC28(300 mil) [(SA404)]  
STK11C48@SOIC28(350 mil) [(SA630)]  
STK11C68                    STK11C68@PLCC28 [(SA008A)]  
STK11C68@SOIC28(350 mil) [(SA630)]  
STK11C88                    STK11C88(3V)  
STK11C88(3V)@SOIC28(300 mil) [(SA404)]  
STK11C88(3V)@SOIC28(350 mil) [(SA630)]  
STK11C88@SOIC28(300 mil) [(SA404)]  
STK11C88@SOIC28(350 mil) [(SA630)]  
STK12C68                    STK12C68@PLCC28 [(SA008A)]  
STK12C68@SOIC28(350 mil) [(SA630)]  
STK14C88                    STK14C88(3V)

STK14C88(3V)@PLCC32 [(SA015A1T)]  
STK14C88(3V)@SOIC32(300 mil) [(SA715)]  
STK14C88(3V)@SOIC32(350 mil) [(SA630)]  
STK14C88@PLCC32 [(SA015A1T)]  
STK14C88@SOIC32(300 mil) [(SA715)]  
STK14C88@SOIC32(350 mil) [(SA630)]  
STK14CA8                      STK14CA8@SOIC32 [(SA715)]  
STK14CA8@SSOP48 [(SA669)]      STK14D88@SOIC32 [(SA715)]  
STK14D88@SSOP48 [(SA669)]      STK15C68  
STK15C68@SOIC28(350 mil) [(SA630)]  
STK15C88  
STK15C88@SOIC28(300 mil) [(SA404)]  
STK15C88@SOIC28(350 mil) [(SA630)]  
STK16C68                      STK16C88  
STK16C88(3V)                      STK16CA8  
STK20C04                      STK22C48  
STK22C48@SOIC28(300 mil) [(SA404)]  
STK22C48@SOIC28(350 mil) [(SA630)]  
STK25C48

## SMOS

## E(E)PROM/FRAM/NVRAM

SPM27128                      SPM27128C  
SPM27C256                      SPM27C64  
SPM27C64H

## SONIX

## MICROCONTROLLER

SN8P1504                      SN8P1504@SOP18 [(SA404)]  
SN8P1504@SOP28 [(SA404)]      SN8P1506  
SN8P1507@TQFP44 [(SA245A)]      SN8P1602  
SN8P1602@SOP18 [(SA404)]      SN8P1602@SSOP20 [(SA674-B005)]  
SN8P1603                      SN8P1603@SOP18 [(SA404)]  
SN8P1603@SSOP20 [(SA674-B005)]      SN8P1604  
SN8P1604@SOP28 [(SA404)]      SN8P1702  
SN8P1702@SOP18 [(SA404)]      SN8P1702@SSOP20 [(SA674-B005)]

SN8P1704A SN8P1704A@SOP28 [(SA404)]  
SN8P1704B SN8P1704B@SOP28 [(SA404)]  
SN8P1706A SN8P1706B  
SN8P1707A SN8P1707A@TQFP44 [(SA245A)]  
SN8P1707B@TQFP44 [(SA245A)] SN8P1708A  
SN8P1708A@SSOP48 [(SA669)] SN8P1708B  
SN8P1708B@SSOP48 [(SA669)] SN8P1714  
SN8P1714@SOP18 [(SA404)] SN8P1714@SOP28 [(SA404)]  
SN8P1716 SN8P1717@TQFP44 [(SA245A)]  
SN8P2501AP SN8P2501AS@SOP14 [(SA602)]  
SN8P2501AX@TSSOP16 [(SA026)] SN8P2501BP  
SN8P2501BS@SOP14 [(SA602)] SN8P2501BX@TSSOP16 [(SA026)]  
SN8P2502AP SN8P2502AS@SOP14 [(SA602)]  
SN8P2502AX@TSSOP16 [(SA026)] SN8P2502BP  
SN8P2502BS@SOP14 [(SA602)] SN8P2502BX@TSSOP16 [(SA026)]  
SN8P2602AP SN8P2602AS@SOP18 [(SA023A)]  
SN8P2602AX@SSOP20 [(SA674)] SN8P2602BP  
SN8P2602BS@SOP18 [(SA023A)] SN8P2602BX@SSOP20 [(SA674)]  
SN8P2603AP SN8P2603AS@SOP18 [(SA023A)]  
SN8P2603AX@SSOP20 [(SA674)] SN8P2603BP  
SN8P2603BS@SOP18 [(SA023A)] SN8P2603BX@SSOP20 [(SA674)]  
SN8P26042AP SN8P26042AS@SOP20 [(SA023A)]  
SN8P26042AX@SSOP20 [(SA674)] SN8P26042BP  
SN8P26042BS@SOP20 [(SA023A)] SN8P26042BX@SSOP20 [(SA674)]  
SN8P26042P SN8P26042S@SOP20 [(SA023A)]  
SN8P26042X@SSOP20 [(SA674)] SN8P2604AK  
SN8P2604AS@SOP28 [(SA404)] SN8P2604AX@SSOP28 [(SA626A)]  
SN8P2604BK SN8P2604BS@SOP28 [(SA404)]  
SN8P2604BX@SSOP28 [(SA626A)] SN8P2604K  
SN8P2604S@SOP28 [(SA404)] SN8P2604X@SSOP28 [(SA626A)]  
SN8P2606P SN8P2608P  
SN8P2608X@SSOP48 [(SA669)] SN8P2622P  
SN8P2622S@SOP18 [(SA023A)] SN8P2622X@SSOP20 [(SA674)]  
SN8P2624K SN8P2624S@SOP28 [(SA404)]  
SN8P2624X@SSOP28 [(SA626A)] SN8P2704AK@SDIP28 [(SA653)]  
SN8P2704AP SN8P2704AS@SOP28 [(SA723)]  
SN8P2705AP SN8P2705AS@SOP32 [(SA687)]  
SN8P2706AP SN8P2707AQ@QFP44 [(SA245A)]  
SN8P2708AP SN8P2708AQ@LQFP48 [(SA248)]  
SN8P2708AX@TSOP48 [(SA669)] SN8P2722P  
SN8P2722S@SOP20 [(SA023A)] SN8P2722X@SSOP20 [(SA674)]

# SONY

## E(E)PROM/FRAM/NVRAM

CXK1011M@SOIC8 [(SA602A)]      CXK1011P  
CXK1012P                      CXK1013P  
CXK1023P                      CXK27C4001

## DRAM & SRAM

CXK581000                      CXK581000@SOIC32 [(SA630)]

# SPACE ELECTRONICS[SEi]

## E(E)PROM/FRAM/NVRAM

28C010                      28C010@PLCC32 [(SA015A1T)]  
28C010@TSOP32 [(SA410T)]      28C010T  
28C010T@PLCC32 [(SA015A1T)]      28C010T@TSOP32 [(SA410T)]  
28C011                      28C011@PLCC32 [(SA015A1T)]  
28C011@TSOP32 [(SA410T)]      28C011T  
28C011T@PLCC32 [(SA015A1T)]      28C011T@TSOP32 [(SA410T)]

# SPANSION

## E(E)PROM/FRAM/NVRAM

AM29BL162CB@SSOP56 [(SA629A-B022)]  
AM29BL802CB@SSOP56 [(SA629A-B022)]  
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL161DB@TSOP48 [(SA247-B005)]  
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL161DT@TSOP48 [(SA247-B005)]  
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]

AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162CB@TSOP48 [(SA247-B005)]  
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162CT@TSOP48 [(SA247-B005)]  
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL162DB@TSOP48 [(SA247-B005)]  
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL162DT@TSOP48 [(SA247-B005)]  
AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CB@TSOP48 [(SA247-B005)]  
AM29DL163CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163CT@TSOP48 [(SA247-B005)]  
AM29DL163DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL163DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL163DB@TSOP48 [(SA247-B005)]  
AM29DL163DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL163DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL163DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL163DT@TSOP48 [(SA247-B005)]  
AM29DL163DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CB@TSOP48 [(SA247-B005)]  
AM29DL164CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164CT@TSOP48 [(SA247-B005)]  
AM29DL164DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DB@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL164DB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL164DB@TSOP48 [(SA247-B005)]  
AM29DL164DB@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL164DT@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL164DT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL164DT@TSOP48 [(SA247-B005)]  
AM29DL164DT@VFBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL320GB@FBGA48 [(SA642B-B026A-Y072F001)]

AM29DL320GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL320GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL320GB@TSOP48 [(SA247-B005)]  
AM29DL320GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL320GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL320GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL320GT@TSOP48 [(SA247-B005)]  
AM29DL321CB@TSOP48 [(SA247-B005)]  
AM29DL321CT@TSOP48 [(SA247-B005)]  
AM29DL322CB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322CB@TSOP48 [(SA247-B005)]  
AM29DL322CT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322CT@TSOP48 [(SA247-B005)]  
AM29DL322DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322DB@TSOP48 [(SA247-B005)]  
AM29DL322DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL322DT@TSOP48 [(SA247-B005)]  
AM29DL322GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL322GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL322GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL322GB@TSOP48 [(SA247-B005)]  
AM29DL322GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL322GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL322GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL322GT@TSOP48 [(SA247-B005)]  
AM29DL323CB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323CB@TSOP48 [(SA247-B005)]  
AM29DL323CT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323CT@TSOP48 [(SA247-B005)]  
AM29DL323DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323DB@TSOP48 [(SA247-B005)]  
AM29DL323DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL323DT@TSOP48 [(SA247-B005)]  
AM29DL323GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL323GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL323GB@TSOP48 [(SA247-B005)]  
AM29DL323GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL323GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL323GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL323GT@TSOP48 [(SA247-B005)]



AM29DL324CB@TSOP48 [(SA247-B005)]  
AM29DL324CT@TSOP48 [(SA247-B005)]  
AM29DL324DB@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL324DB@TSOP48 [(SA247-B005)]  
AM29DL324DT@FBGA63 [(SA642E-B026A-T056N001)]  
AM29DL324DT@TSOP48 [(SA247-B005)]  
AM29DL324GB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL324GB@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL324GB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL324GB@TSOP48 [(SA247-B005)]  
AM29DL324GT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DL324GT@FBGA63 [(SA642L-B026A-W080F001Y)]  
AM29DL324GT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29DL324GT@TSOP48 [(SA247-B005)]  
AM29DL400BB@PSOP44 [(SA638-B006)]  
AM29DL400BB@TSOP48 [(SA247-B005)]  
AM29DL400BT@PLCC44 [(SA638-B006)]  
AM29DL400BT@TSOP48 [(SA247-B005)]  
AM29DL640D@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL640D@TSOP48 [(SA247-B005)]  
AM29DL640G@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL640G@FBGA64 [(SA655A-B044A-T064N001)]  
AM29DL640G@TSOP48 [(SA247-B005)]  
AM29DL642G@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]  
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29DL800BB@PSOP44 [(SA638)]  
AM29DL800BB@TSOP48 [(SA247-B005)]  
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29DL800BT@PSOP44 [(SA638)]  
AM29DL800BT@TSOP48 [(SA247-B005)]  
AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]  
AM29DS163CB@TSOP48 [(SA247-B005)]  
AM29DS163CT@TSOP48 [(SA247-B005)]  
AM29DS163DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS163DB@TSOP48 [(SA247-B005)]  
AM29DS163DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS163DT@TSOP48 [(SA247-B005)]  
AM29DS323DB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS323DB@TSOP48 [(SA247-B005)]  
AM29DS323DT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29DS323DT@TSOP48 [(SA247-B005)]  
AM29F002B AM29F002B@PLCC32 [(SA015A1T)]

AM29F002B@TSOP32 [(SA410T)] AM29F002BB  
AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32 [(SA410T)]  
AM29F002BT AM29F002BT@PLCC32 [(SA015A1T)]  
AM29F002BT@TSOP32 [(SA410T)] AM29F002NB  
AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32 [(SA410T)]  
AM29F002NBB AM29F002NBB@PLCC32 [(SA015A1T)]  
AM29F002NBB@TSOP32 [(SA410T)] AM29F002NBT  
AM29F002NBT@PLCC32 [(SA015A1T)] AM29F002NBT@TSOP32 [(SA410T)]  
AM29F002NT AM29F002NT@PLCC32 [(SA015A1T)]  
AM29F002NT@TSOP32 [(SA410T)] AM29F002T  
AM29F002T@PLCC32 [(SA015A1T)] AM29F002T@TSOP32 [(SA410T)]  
AM29F004BB@PLCC32 [(SA015A1T)] AM29F004BB@TSOP32 [(SA410T)]  
AM29F004BT@PLCC32 [(SA015A1T)] AM29F004BT@TSOP32 [(SA410T)]  
AM29F010 AM29F010@PLCC32 [(SA015A1T)]  
AM29F010@TSOP32 [(SA410T)] AM29F010A  
AM29F010A@PLCC32 [(SA015A1T)] AM29F010A@TSOP32 [(SA410T)]  
AM29F010B AM29F010B@PLCC32 [(SA015A1T)]  
AM29F010B@TSOP32 [(SA410T)] AM29F016@PSOP44 [(SA638)]  
AM29F016@TSOP40 [(SA409T)] AM29F016@TSOP48 [(SA247-B005)]  
AM29F016B@PSOP44 [(SA638)] AM29F016B@TSOP40 [(SA409T)]  
AM29F016B@TSOP48 [(SA247-B005)]  
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]  
AM29F016D@PSOP44 [(SA638)] AM29F016D@TSOP40 [(SA409T)]  
AM29F016D@TSOP48 [(SA247-B005)] AM29F017B@TSOP48 [(SA247-B005)]  
AM29F017D@TSOP40 [(SA409T)] AM29F017D@TSOP48 [(SA247-B005)]  
AM29F032B@PSOP44 [(SA638)] AM29F032B@TSOP40 [(SA409T)]  
AM29F040 AM29F040@PLCC32 [(SA015A1T)]  
AM29F040@TSOP32 [(SA410T)] AM29F040A  
AM29F040A@PLCC32 [(SA015A1T)] AM29F040A@TSOP32 [(SA410T)]  
AM29F040B  
AM29F040B(Reverse)@TSOP32 [(SA410T)]  
AM29F040B@PLCC32 [(SA015A1T)] AM29F040B@TSOP32 [(SA410T)]  
AM29F080@PSOP44 [(SA638)] AM29F080@TSOP40 [(SA409T)]  
AM29F080B@PSOP44 [(SA638)] AM29F080B@TSOP40 [(SA409T)]  
AM29F100BE@PSOP44 [(SA638-B006)] AM29F100BE@TSOP48 [(SA247-B005)]  
AM29F100BS@PSOP44 [(SA638-B006)] AM29F100BS@TSOP48 [(SA247-B005)]  
AM29F100TE@PSOP44 [(SA638-B006)] AM29F100TE@TSOP48 [(SA247-B005)]  
AM29F100TS@PSOP44 [(SA638-B006)] AM29F100TS@TSOP48 [(SA247-B005)]  
AM29F160DB@TSOP48 [(SA247-B005)] AM29F160DT@TSOP48 [(SA247-B005)]  
AM29F200AB@PSOP44 [(SA638-B006)] AM29F200AB@TSOP48 [(SA247-B005)]  
AM29F200AT@PSOP44 [(SA638-B006)] AM29F200AT@TSOP48 [(SA247-B005)]  
AM29F200BB@PSOP44 [(SA638-B006)] AM29F200BB@TSOP48 [(SA247-B005)]  
AM29F200BE@PSOP44 [(SA638-B006)] AM29F200BE@TSOP48 [(SA247-B005)]

AM29F200BS@PSOP44 [(SA638-B006)] AM29F200BS@TSOP48 [(SA247-B005)]  
AM29F200BT@PSOP44 [(SA638-B006)] AM29F200BT@TSOP48 [(SA247-B005)]  
AM29F200TE@PSOP44 [(SA638-B006)] AM29F200TE@TSOP48 [(SA247-B005)]  
AM29F200TS@PSOP44 [(SA638-B006)] AM29F200TS@TSOP48 [(SA247-B005)]  
AM29F400AB@PSOP44 [(SA638-B006)] AM29F400AB@TSOP48 [(SA247-B005)]  
AM29F400AT@PSOP44 [(SA638-B006)] AM29F400AT@TSOP48 [(SA247-B005)]  
AM29F400BB@PSOP44 [(SA638-B006)] AM29F400BB@TSOP48 [(SA247-B005)]  
AM29F400BBE@PSOP44 [(SA638-B006)]  
AM29F400BBE@TSOP48 [(SA247-B005)]  
AM29F400BBF@PSOP44 [(SA638-B006)]  
AM29F400BBF@TSOP48 [(SA247-B005)]  
AM29F400BBS@PSOP44 [(SA638-B006)]  
AM29F400BBS@TSOP48 [(SA247-B005)]  
AM29F400BE@PSOP44 [(SA638-B006)] AM29F400BE@TSOP48 [(SA247-B005)]  
AM29F400BF@PSOP44 [(SA638-B006)] AM29F400BF@TSOP48 [(SA247-B005)]  
AM29F400BS@PSOP44 [(SA638-B006)] AM29F400BS@TSOP48 [(SA247-B005)]  
AM29F400BT@PSOP44 [(SA638-B006)] AM29F400BT@TSOP48 [(SA247-B005)]  
AM29F400BTE@PSOP44 [(SA638-B006)]  
AM29F400BTE@TSOP48 [(SA247-B005)]  
AM29F400BTF@PSOP44 [(SA638-B006)]  
AM29F400BTF@TSOP48 [(SA247-B005)]  
AM29F400BTS@PSOP44 [(SA638-B006)]  
AM29F400BTS@TSOP48 [(SA247-B005)]  
AM29F800B@PSOP44 [(SA638-B006)] AM29F800B@TSOP48 [(SA247-B005)]  
AM29F800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BB@PSOP44 [(SA638-B006)] AM29F800BB@TSOP48 [(SA247-B005)]  
AM29F800BBF@PSOP44 [(SA638-B006)]  
AM29F800BBF@TSOP48 [(SA247-B005)]  
AM29F800BF@PSOP44 [(SA638-B006)] AM29F800BF@TSOP48 [(SA247-B005)]  
AM29F800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29F800BT@PSOP44 [(SA638-B006)] AM29F800BT@TSOP48 [(SA247-B005)]  
AM29F800BTF@PSOP44 [(SA638-B006)]  
AM29F800BTF@TSOP48 [(SA247-B005)]  
AM29F800T@PSOP44 [(SA638-B006)] AM29F800T@TSOP48 [(SA247-B005)]  
AM29F800TB@PSOP44 [(SA638-B006)] AM29F800TB@TSOP48 [(SA247-B005)]  
AM29F800TF@PSOP44 [(SA638-B006)] AM29F800TF@TSOP48 [(SA247-B005)]  
AM29LL800B@TSOP48 [(SA247-B005)]  
AM29LL800BB@TSOP48 [(SA247-B005)]  
AM29LL800BT@TSOP48 [(SA247-B005)]  
AM29LL800T@TSOP48 [(SA247-B005)] AM29LV001BB@PLCC32 [(SA015A1T)]  
AM29LV001BB@TSOP32 [(SA410T)] AM29LV001BT@PLCC32 [(SA015A1T)]  
AM29LV001BT@TSOP32 [(SA410T)] AM29LV002@TSOP40 [(SA409T)]  
AM29LV002B@TSOP40 [(SA409T)] AM29LV002BB@TSOP40 [(SA409T)]

AM29LV002BT@TSOP40 [(SA409T)] AM29LV004B@PSOP44 [(SA638)]  
AM29LV004B@TSOP40 [(SA409T)] AM29LV004BB@TSOP40 [(SA409T)]  
AM29LV004BT@TSOP40 [(SA409T)] AM29LV004T@PSOP44 [(SA638)]  
AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44 [(SA638)]  
AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40 [(SA409T)]  
AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44 [(SA638)]  
AM29LV008T@TSOP40 [(SA409T)] AM29LV010B@PLCC32 [(SA015A1T)]  
AM29LV010B@TSOP32 [(SA410T)] AM29LV017B@TSOP40 [(SA409T)]  
AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32 [(SA015A1T)]  
AM29LV020B@TSOP32 [(SA410T)]  
AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]  
AM29LV033C@TSOP40 [(SA409T)]  
AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32 [(SA015A1T)]  
AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32 [(SA015A1T)]  
AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32 [(SA015A1T)]  
AM29LV040J@TSOP32 [(SA410T)]  
AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29LV065D@TSOP48 [(SA247-B005)]  
AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]  
AM29LV065MU@TSOP48 [(SA247-B005)]  
AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40 [(SA409T)]  
AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40 [(SA409T)]  
AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40 [(SA409T)]  
AM29LV116DT@TSOP40 [(SA409T)]  
AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV128MH@TSOP56 [(SA628-B067)]  
AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV128ML@TSOP56 [(SA628-B067)]  
AM29LV160BB@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160BB@PSOP44 [(SA638)]  
AM29LV160BB@TSOP48 [(SA247-B005)]  
AM29LV160BT@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160BT@PSOP44 [(SA638)]  
AM29LV160BT@TSOP48 [(SA247-B005)]  
AM29LV160DB(REVERSE)@TSOP48 [(SA247-B005)]  
AM29LV160DB@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160DB@PSOP44 [(SA638)]  
AM29LV160DB@TSOP48 [(SA247-B005)]  
AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]  
AM29LV160DT@FBGA48 [(SA642B-B026A-Y072F001N)]  
AM29LV160DT@PSOP44 [(SA638)]

AM29LV160DT@TSOP48 [(SA247-B005)]  
AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MB@PSOP44 [(SA638)]  
AM29LV160MB@TSOP48 [(SA247-B005)]  
AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]  
AM29LV160MT@PSOP44 [(SA638)]  
AM29LV160MT@TSOP48 [(SA247-B005)]  
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]  
AM29LV200BB@PSOP44 [(SA638-B006)]  
AM29LV200BB@TSOP48 [(SA247-B005)]  
AM29LV200BE@PSOP44 [(SA638-B006)]  
AM29LV200BE@TSOP48 [(SA247-B005)]  
AM29LV200BF@PSOP44 [(SA638-B006)]  
AM29LV200BF@TSOP48 [(SA247-B005)]  
AM29LV200BS@PSOP44 [(SA638-B006)]  
AM29LV200BS@TSOP48 [(SA247-B005)]  
AM29LV200BT@PSOP44 [(SA638-B006)]  
AM29LV200BT@TSOP48 [(SA247-B005)]  
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]  
AM29LV200TE@PSOP44 [(SA638-B006)]  
AM29LV200TE@TSOP48 [(SA247-B005)]  
AM29LV200TF@PSOP44 [(SA638-B006)]  
AM29LV200TF@TSOP48 [(SA247-B005)]  
AM29LV200TS@PSOP44 [(SA638-B006)]  
AM29LV200TS@TSOP48 [(SA247-B005)]  
AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256MH@TSOP56 [(SA628-B067)]  
AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
AM29LV256ML@TSOP56 [(SA628-B067)]  
AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DB@TSOP48 [(SA247-B005)]  
AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29LV320DT@TSOP48 [(SA247-B005)]  
AM29LV320FB@TSOP48 [(SA247-B005)]  
AM29LV320FT@TSOP48 [(SA247-B005)]  
AM29LV320MB@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29LV320MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MB@TSOP48 [(SA247-B005)]  
AM29LV320MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MH@TSOP56 [(SA628-B067)]  
AM29LV320ML@FBGA64 [(SA655D-B044A-W064F001Y)]

AM29LV320ML@TSOP56 [(SA628-B067)]  
AM29LV320MT@FBGA48 [(SA642HH-B026A-T048F001Y)]  
AM29LV320MT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV320MT@TSOP48 [(SA247-B005)]  
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]  
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29LV400BB@PSOP44 [(SA638-B006)]  
AM29LV400BB@TSOP48 [(SA247-B005)]  
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29LV400BT@PSOP44 [(SA638-B006)]  
AM29LV400BT@TSOP48 [(SA247-B005)]  
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]  
AM29LV640DH@SSOP56 [(SA629A-B020)]  
AM29LV640DL@SSOP56 [(SA629A-B020)]  
AM29LV640DU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640DU@FBGA64 [(SA655D-B044A-W064F001)]  
AM29LV640GU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640GU@FBGA64 [(SA655D-B044A-W064F001)]  
AM29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MB@TSOP48 [(SA247-B005)]  
AM29LV640MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MH@TSOP56 [(SA628-B067)]  
AM29LV640ML@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640ML@TSOP56 [(SA628-B067)]  
AM29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MT@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV640MT@TSOP48 [(SA247-B005)]  
AM29LV640MU@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV640MU@FBGA64 [(SA655D-B044A-W064F001Y)]  
AM29LV641DH@TSOP48 [(SA247-B005)]  
AM29LV641DHR@TSOP48 [(SA247-B005)]  
AM29LV641DL@TSOP48 [(SA247-B005)]  
AM29LV641DLR@TSOP48 [(SA247-B005)]  
AM29LV641GH@TSOP48 [(SA247-B005)]  
AM29LV641GHR@TSOP48 [(SA247-B005)]  
AM29LV641GL@TSOP48 [(SA247-B005)]  
AM29LV641GLR@TSOP48 [(SA247-B005)]  
AM29LV641MH@TSOP48 [(SA247-B005)]  
AM29LV641ML@TSOP48 [(SA247-B005)]  
AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]  
AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]  
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]

AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800BB@PSOP44 [(SA638-B006)]  
AM29LV800BB@TSOP48 [(SA247-B005)]  
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800BT@PSOP44 [(SA638-B006)]  
AM29LV800BT@TSOP48 [(SA247-B005)]  
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29LV800DB@PSOP44 [(SA638)]  
AM29LV800DB@TSOP48 [(SA247-B005)]  
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29LV800DT@PSOP44 [(SA638)]  
AM29LV800DT@TSOP48 [(SA247-B005)]  
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]  
AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PL160CB@PSOP44 [(SA638-B006)]  
AM29PL160CB@TSOP48 [(SA247-B005)]  
AM29PL160CT@PSOP44 [(SA638-B006)]  
AM29PL160CT@TSOP48 [(SA247-B005)]  
AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CB@TSOP48 [(SA247-B005)]  
AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CT@TSOP48 [(SA247-B005)]  
AM29SL400CB@TSOP48 [(SA247-B005)]  
AM29SL400CT@TSOP48 [(SA247-B005)]  
AM29SL800BB@TSOP48 [(SA247-B005)]  
AM29SL800BT@TSOP48 [(SA247-B005)]  
AM29SL800CB@TSOP48 [(SA247-B005)]  
AM29SL800CT@TSOP48 [(SA247-B005)]  
AM29SL800DB@TSOP48 [(SA247-B005)]  
AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM29SL800DT@TSOP48 [(SA247-B005)]  
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]

DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M420000070(AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000071(AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072(AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073(AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074(AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075(AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076(AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077(AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M490000030(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000031(AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]



MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21193DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21193EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21193EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21194DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21194EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21194EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD22180FA@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22180FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22181A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22181EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22181EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22181FM@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD22182A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22182EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22182EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22183A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22183EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22183EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22184EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22184FM@FBGA56 [(SA642E-B032A-T072F001)]  
MB84VD22190FA@FBGA59 [(SA642F-B032A-T064F001)]

MB84VD22190FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22191A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22191EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22191EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22191FM@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD22192A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22192EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22192EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22193A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22193EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22193EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194A@FBGA77 [(SA642A-B032A-Y096N001)]  
MB84VD22194EC@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194EE@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD22194FM@FBGA56 [(SA642E-B032A-T072F001)]  
MB84VD22280FE@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22282EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22283EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22284EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22290FM@FBGA59 [(SA642F-B032A-T064F001)]  
MB84VD22292EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22293EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22294EE@FBGA71 [(SA642E-B032A-T072F001)]  
MB84VD22386EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22387EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22388EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]  
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]  
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161BD@TSOP48 [(SA247-B005)]

MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@TSOP48 [(SA247-B005)]  
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@TSOP48 [(SA247-B005)]  
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BE@TSOP48 [(SA247-B005)]  
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TD@TSOP48 [(SA247-B005)]  
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TE@TSOP48 [(SA247-B005)]  
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BD@TSOP48 [(SA247-B005)]  
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BE@TSOP48 [(SA247-B005)]  
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TD@TSOP48 [(SA247-B005)]  
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TE@TSOP48 [(SA247-B005)]  
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BD@TSOP48 [(SA247-B005)]  
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BE@TSOP48 [(SA247-B005)]  
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TD@TSOP48 [(SA247-B005)]  
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TE@TSOP48 [(SA247-B005)]  
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320BF@TSOP48 [(SA247-B005)]  
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320TF@TSOP48 [(SA247-B005)]  
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321BD@TSOP48 [(SA247-B005)]  
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321TD@TSOP48 [(SA247-B005)]  
MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL322BD@TSOP48 [(SA247-B005)]  
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BE@TSOP48 [(SA247-B005)]  
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]

MBM29DL322TD@TSOP48 [(SA247-B005)]  
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322TE@TSOP48 [(SA247-B005)]  
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323BD@TSOP48 [(SA247-B005)]  
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323BE@TSOP48 [(SA247-B005)]  
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323BF@TSOP48 [(SA247-B005)]  
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323TD@TSOP48 [(SA247-B005)]  
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323TE@TSOP48 [(SA247-B005)]  
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323TF@TSOP48 [(SA247-B005)]  
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324BD@TSOP48 [(SA247-B005)]  
MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL324BE@TSOP48 [(SA247-B005)]  
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324TD@TSOP48 [(SA247-B005)]  
MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL324TE@TSOP48 [(SA247-B005)]  
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL32BF@TSOP48 [(SA247-B005)]  
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL32TF@TSOP48 [(SA247-B005)]  
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL34BF@TSOP48 [(SA247-B005)]  
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]  
MBM29DL34TF@TSOP48 [(SA247-B005)]  
MBM29DL400BB@PSOP44 [(SA638-B006)]  
MBM29DL400BB@TSOP48 [(SA247-B005)]  
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL400BC@PSOP44 [(SA638)]  
MBM29DL400BC@TSOP48 [(SA247-B005)]  
MBM29DL400BT@PSOP44 [(SA638-B006)]  
MBM29DL400BT@TSOP48 [(SA247-B005)]  
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL400TC@PSOP44 [(SA638)]  
MBM29DL400TC@TSOP48 [(SA247-B005)]  
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]  
MBM29DL640E@TSOP48 [(SA247-B005)]

MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]  
MBM29DL64DF@TSOP48 [(SA247-B005)]  
MBM29DL800B@PSOP44 [(SA638-B006)]  
MBM29DL800B@TSOP48 [(SA247-B005)]  
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL800BA@TSOP48 [(SA247-B005)]  
MBM29DL800BB@PSOP44 [(SA638-B006)]  
MBM29DL800BB@TSOP48 [(SA247-B005)]  
MBM29DL800BT@PSOP44 [(SA638-B006)]  
MBM29DL800BT@TSOP48 [(SA247-B005)]  
MBM29DL800T@PSOP44 [(SA638-B006)]  
MBM29DL800T@TSOP48 [(SA247-B005)]  
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29DL800TA@TSOP48 [(SA247-B005)]  
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
MBM29DS163BE@TSOP48 [(SA247-B005)]  
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
MBM29DS163TE@TSOP48 [(SA247-B005)]  
MBM29F001B MBM29F001B@PLCC32 [(SA015A1T)]  
MBM29F001B@TSOP32 [(SA410T)] MBM29F001T  
MBM29F001T@PLCC32 [(SA015A1T)] MBM29F001T@TSOP32 [(SA410T)]  
MBM29F002B MBM29F002B@PLCC32 [(SA015A1T)]  
MBM29F002B@TSOP32 [(SA410T)] MBM29F002NB  
MBM29F002NB@PLCC32 [(SA015A1T)] MBM29F002NB@TSOP32 [(SA410T)]  
MBM29F002NT MBM29F002NT@PLCC32 [(SA015A1T)]  
MBM29F002NT@TSOP32 [(SA410T)] MBM29F002T  
MBM29F002T@PLCC32 [(SA015A1T)] MBM29F002T@TSOP32 [(SA410T)]  
MBM29F010 MBM29F010@PLCC32 [(SA015A1T)]  
MBM29F010@TSOP32 [(SA410T)] MBM29F010A  
MBM29F010A@PLCC32 [(SA015A1T)] MBM29F010A@TSOP32 [(SA410T)]  
MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40 [(SA409T)]  
MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44 [(SA638)]  
MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-B005)]  
MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40 [(SA409T)]  
MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-B005)]  
MBM29F017D@TSOP40 [(SA409T)] MBM29F017D@TSOP48 [(SA247-B005)]  
MBM29F032B@PSOP44 [(SA638)] MBM29F032B@TSOP40 [(SA409T)]  
MBM29F033C@TSOP40 [(SA409T)] MBM29F040  
MBM29F040@PLCC32 [(SA015A1T)] MBM29F040@TSOP32 [(SA410T)]  
MBM29F040B MBM29F040B@PLCC32 [(SA015A1T)]  
MBM29F040B@TSOP32 [(SA410T)] MBM29F040C@PLCC32 [(SA015A1T)]  
MBM29F040C@TSOP32 [(SA410T)] MBM29F080@PSOP44 [(SA638)]  
MBM29F080@TSOP40 [(SA409T)] MBM29F080A@TSOP48 [(SA247-B005)]

MBM29F080B@PSOP44 [(SA638)] MBM29F080B@TSOP40 [(SA409T)]  
MBM29F100B@PSOP44 [(SA638-B006)] MBM29F100B@TSOP48 [(SA247-B005)]  
MBM29F100T@PSOP44 [(SA638-B006)] MBM29F100T@TSOP48 [(SA247-B005)]  
MBM29F160BE@TSOP48 [(SA247-B005)]  
MBM29F160TE@TSOP48 [(SA247-B005)]  
MBM29F200AB@PSOP44 [(SA638-B006)]  
MBM29F200AB@TSOP48 [(SA247-B005)]  
MBM29F200AT@PSOP44 [(SA638-B006)]  
MBM29F200AT@TSOP48 [(SA247-B005)]  
MBM29F200B@PSOP44 [(SA638-B006)] MBM29F200B@TSOP48 [(SA247-B005)]  
MBM29F200T@PSOP44 [(SA638-B006)] MBM29F200T@TSOP48 [(SA247-B005)]  
MBM29F400AB@PSOP44 [(SA638-B006)]  
MBM29F400AB@TSOP48 [(SA247-B005)]  
MBM29F400AT@PSOP44 [(SA638-B006)]  
MBM29F400AT@TSOP48 [(SA247-B005)]  
MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]  
MBM29F400BB@PSOP44 [(SA638-B006)]  
MBM29F400BB@TSOP48 [(SA247-B005)]  
MBM29F400BT@PSOP44 [(SA638-B006)]  
MBM29F400BT@TSOP48 [(SA247-B005)]  
MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]  
MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]  
MBM29F800BB@PSOP44 [(SA638-B006)]  
MBM29F800BB@TSOP48 [(SA247-B005)]  
MBM29F800BT@PSOP44 [(SA638-B006)]  
MBM29F800BT@TSOP48 [(SA247-B005)]  
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]  
MBM29LL800B@TSOP48 [(SA247-B005)]  
MBM29LL800BB@TSOP48 [(SA247-B005)]  
MBM29LL800BT@TSOP48 [(SA247-B005)]  
MBM29LL800T@TSOP48 [(SA247-B005)]  
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32 [(SA015A1T)]  
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]  
MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]  
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32 [(SA410T)]  
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32 [(SA410T)]  
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40 [(SA409T)]  
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40 [(SA409T)]  
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40 [(SA409T)]  
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40 [(SA409T)]  
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40 [(SA409T)]  
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40 [(SA409T)]  
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40 [(SA409T)]

MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40 [(SA409T)]  
MBM29LV016B@TSOP40 [(SA409T)]  
MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]  
MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40 [(SA409T)]  
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40 [(SA409T)]  
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40 [(SA409T)]  
MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40 [(SA409T)]  
MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46(\*)  
MBM29LV160BB@PSOP44 [(SA638-B006)]  
MBM29LV160BB@TSOP48 [(SA247-B005)]  
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160BE@TSOP48 [(SA247-B005)]  
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160BM@TSOP48 [(SA247-B005)]  
MBM29LV160BT@PSOP44 [(SA638-B006)]  
MBM29LV160BT@TSOP48 [(SA247-B005)]  
MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46(\*)  
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160TE@TSOP48 [(SA247-B005)]  
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV160TM@TSOP48 [(SA247-B005)]  
MBM29LV200B@PSOP44 [(SA638-B006)]  
MBM29LV200B@TSOP48 [(SA247-B005)]  
MBM29LV200BB@PSOP44 [(SA638-B006)]  
MBM29LV200BB@TSOP48 [(SA247-B005)]  
MBM29LV200BC@PSOP44 [(SA638)]  
MBM29LV200BC@TSOP48 [(SA247-B005)]  
MBM29LV200BT@PSOP44 [(SA638-B006)]  
MBM29LV200BT@TSOP48 [(SA247-B005)]  
MBM29LV200T@PSOP44 [(SA638-B006)]  
MBM29LV200T@TSOP48 [(SA247-B005)]  
MBM29LV200TC@PSOP44 [(SA638)]  
MBM29LV200TC@TSOP48 [(SA247-B005)]  
MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29LV320BE@TSOP48 [(SA247-B005)]  
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29LV320TE@TSOP48 [(SA247-B005)]  
MBM29LV400B@PSOP44 [(SA638-B006)]  
MBM29LV400B@TSOP48 [(SA247-B005)]  
MBM29LV400BB@PSOP44 [(SA638-B006)]  
MBM29LV400BB@TSOP48 [(SA247-B005)]  
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29LV400BC@PSOP44 [(SA638)]

MBM29LV400BC@TSOP48 [(SA247-B005)]  
MBM29LV400BT@PSOP44 [(SA638-B006)]  
MBM29LV400BT@TSOP48 [(SA247-B005)]  
MBM29LV400T@PSOP44 [(SA638-B006)]  
MBM29LV400T@TSOP48 [(SA247-B005)]  
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]  
MBM29LV400TC@PSOP44 [(SA638)]  
MBM29LV400TC@TSOP48 [(SA247-B005)]  
MBM29LV650UE@TSOP48 [(SA247-B005)]  
MBM29LV651UE@TSOP48 [(SA247-B005)]  
MBM29LV652UE@FBGA63 [(SA642C-B026A-Y056F001)]  
MBM29LV800B@PSOP44 [(SA638-B006)]  
MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46(\*)  
MBM29LV800B@TSOP48 [(SA247-B005)]  
MBM29LV800BA@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800BA@PSOP44 [(SA638)]  
MBM29LV800BA@TSOP48 [(SA247-B005)]  
MBM29LV800BB@PSOP44 [(SA638-B006)]  
MBM29LV800BB@TSOP48 [(SA247-B005)]  
MBM29LV800BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800BE@PSOP44 [(SA638)]  
MBM29LV800BE@TSOP48 [(SA247-B005)]  
MBM29LV800BT@PSOP44 [(SA638-B006)]  
MBM29LV800BT@TSOP48 [(SA247-B005)]  
MBM29LV800T@PSOP44 [(SA638-B006)]  
MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46(\*)  
MBM29LV800T@TSOP48 [(SA247-B005)]  
MBM29LV800TA@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800TA@PSOP44 [(SA638)]  
MBM29LV800TA@TSOP48 [(SA247-B005)]  
MBM29LV800TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29LV800TE@PSOP44 [(SA638)]  
MBM29LV800TE@TSOP48 [(SA247-B005)]  
MBM29PDS323B@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29PDS323T@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29PL12LM@TSOP56 [(SA628-B102)]  
MBM29PL160BD@PSOP44 [(SA638)]  
MBM29PL160BD@TSOP48 [(SA247-B005)]  
MBM29PL160TD@PSOP44 [(SA638)]  
MBM29PL160TD@TSOP48 [(SA247-B005)]  
MBM29PL32BM@FBGA48 [(SA642G-B026A-T048F001)]  
MBM29PL32BM@TSOP48 [(SA247-B005)]  
MBM29PL32TM@FBGA48 [(SA642G-B026A-T048F001)]



MBM29PL32TM@TSOP48 [(SA247-B005)]  
MBM29PL64LM@TSOP48 [(SA247-B005)]  
MBM29PL64LM@TSOP56 [(SA628-B067)]  
MBM29QM12DH@FBGA88 [(SA642J-B101A-W080F001)]  
MBM29QM12DH@TSOP56 [(SA628-B097)]  
MBM29SL160BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29SL160BD@TSOP48 [(SA247-B005)]  
MBM29SL160TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29SL160TD@TSOP48 [(SA247-B005)]  
MBM29SL800BB@TSOP48 [(SA247-B005)]  
MBM29SL800BT@TSOP48 [(SA247-B005)]  
PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
PL032J55BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J55BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J55BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J55BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J55BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J55BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J55BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J55BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J60BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J60BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J60BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J60BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J60BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J60BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J60BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J60BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J70BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J70BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J70BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL032J70BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL032J70BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]

PL064J55BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J55BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J55BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J60BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J60BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL064J70BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
PL064J70BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
PL127J55BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J55BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J55BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J60BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J60BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]

PL127J65BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S19MN02GP30TFP00@TSOP48 [(SA247-B005)]  
S19MN256P30TFP00@TSOP48 [(SA247-B005)]  
S19MN512P30TFP00@TSOP48 [(SA247-B005)]  
S25FL001D@SOIC8 [(SA602A)]      S25FL001D@USON8 [(SA683)]  
S25FL002A@SOIC8 [(SA605A)]      S25FL002A@USON8 [(SA683)]  
S25FL002D@SOIC8 [(SA602A)]      S25FL002D@USON8 [(SA683)]  
S25FL004A@SOIC8 [(SA605A)]      S25FL004A@USON8 [(SA683)]  
S25FL004D@SOIC8 [(SA602A)]      S25FL004D@USON8 [(SA683)]  
S25FL008A@SOIC8 [(SA605A)]      S25FL008A@USON8 [(SA683)]  
S25FL008D@SOIC8 [(SA602A)]      S25FL008D@USON8 [(SA683)]  
S25FL016A@SOIC16 [(SA404)]  
S25FL016A@SOIC16(ISP) [ISP-HEADER01]  
S25FL016A@SOIC8 [(SA605A)]  
S25FL016A@SOIC8(ISP) [ISP-HEADER01]  
S25FL016A@WSON8 [(SA684)]  
S25FL016A@WSON8(ISP) [ISP-HEADER01]  
S25FL020A@SOIC8(4.0) [(SA602A)]      S25FL020A@SOIC8(5.4) [(SA605A)]  
S25FL020A@USON8 [(SA683)]      S25FL032A@SOIC16 [(SA404)]  
S25FL032A@SOIC16(ISP) [ISP-HEADER01]  
S25FL032A@WSON8 [(SA684)]  
S25FL032A@WSON8(ISP) [ISP-HEADER01]  
S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]

S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Bottom Boot)@USON8 [(SA683)]  
S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]  
S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Top Boot)@USON8 [(SA683)]  
S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4) [(SA605A)]  
S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16 [(SA404)]  
S25FL064A@SOIC16(ISP) [ISP-HEADER01]  
S25FL064A@WSON8 [(SA684)]  
S25FL064A@WSON8(ISP) [ISP-HEADER01]  
S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4) [(SA605A)]  
S25FL080A@USON8 [(SA683)]  
S25FL128P(256 KB)@SOIC16 [(SA404)]  
S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(256 KB)@WSON8 [(SA684)]  
S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@SOIC16 [(SA404)]  
S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@WSON8 [(SA684)]  
S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8 [(SA683)]  
S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFV01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFV02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DMFA01@PSOP44 [(SA638)] S29AD016DMFA02@PSOP44 [(SA638)]  
S29AD016DMFB01@PSOP44 [(SA638)] S29AD016DMFB02@PSOP44 [(SA638)]  
S29AD016DMFI01@PSOP44 [(SA638)] S29AD016DMFI02@PSOP44 [(SA638)]  
S29AD016DMFV01@PSOP44 [(SA638)] S29AD016DMFV02@PSOP44 [(SA638)]  
S29AD016DTFA01@TSOP48 [(SA247-B005)]  
S29AD016DTFA02@TSOP48 [(SA247-B005)]  
S29AD016DTFB01@TSOP48 [(SA247-B005)]  
S29AD016DTFB02@TSOP48 [(SA247-B005)]  
S29AD016DTFI01@TSOP48 [(SA247-B005)]  
S29AD016DTFI02@TSOP48 [(SA247-B005)]  
S29AD016DTFV01@TSOP48 [(SA247-B005)]  
S29AD016DTFV02@TSOP48 [(SA247-B005)]  
S29AL002BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL002BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]

S29AL002BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL002BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL002BMAI01@PSOP44 [(SA638)] S29AL002BMAI02@PSOP44 [(SA638)]  
S29AL002BMFI01@PSOP44 [(SA638)] S29AL002BMFI02@PSOP44 [(SA638)]  
S29AL002BTAI01@TSOP48 [(SA247-B005)]  
S29AL002BTAI02@TSOP48 [(SA247-B005)]  
S29AL002BTFI01@TSOP48 [(SA247-B005)]  
S29AL002BTFI02@TSOP48 [(SA247-B005)]  
S29AL004BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004BMAI01@PSOP44 [(SA638)] S29AL004BMAI02@PSOP44 [(SA638)]  
S29AL004BMFI01@PSOP44 [(SA638)] S29AL004BMFI02@PSOP44 [(SA638)]  
S29AL004BTAI01@TSOP48 [(SA247-B005)]  
S29AL004BTAI02@TSOP48 [(SA247-B005)]  
S29AL004BTFI01@TSOP48 [(SA247-B005)]  
S29AL004BTFI02@TSOP48 [(SA247-B005)]  
S29AL004DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL004DMAI01@PSOP44 [(SA638)] S29AL004DMAI02@PSOP44 [(SA638)]  
S29AL004DMAN01@PSOP44 [(SA638)] S29AL004DMAN02@PSOP44 [(SA638)]  
S29AL004DMANR1@PSOP44 [(SA638)] S29AL004DMANR2@PSOP44 [(SA638)]  
S29AL004DMFI01@PSOP44 [(SA638)] S29AL004DMFI02@PSOP44 [(SA638)]  
S29AL004DMFN01@PSOP44 [(SA638)] S29AL004DMFN02@PSOP44 [(SA638)]  
S29AL004DMFNR1@PSOP44 [(SA638)] S29AL004DMFNR2@PSOP44 [(SA638)]  
S29AL004DTAI01@TSOP48 [(SA247-B005)]  
S29AL004DTAI02@TSOP48 [(SA247-B005)]  
S29AL004DTAN01@TSOP48 [(SA247-B005)]  
S29AL004DTAN02@TSOP48 [(SA247-B005)]  
S29AL004DTANR1@TSOP48 [(SA247-B005)]  
S29AL004DTANR2@TSOP48 [(SA247-B005)]  
S29AL004DTFI01@TSOP48 [(SA247-B005)]

S29AL004DTFI02@TSOP48 [(SA247-B005)]  
S29AL004DTFN01@TSOP48 [(SA247-B005)]  
S29AL004DTFN02@TSOP48 [(SA247-B005)]  
S29AL004DTFNR1@TSOP48 [(SA247-B005)]  
S29AL004DTFNR2@TSOP48 [(SA247-B005)]  
S29AL008DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008DMAI01@PSOP44 [(SA638)] S29AL008DMAI02@PSOP44 [(SA638)]  
S29AL008DMAN01@PSOP44 [(SA638)] S29AL008DMAN02@PSOP44 [(SA638)]  
S29AL008DMANR1@PSOP44 [(SA638)] S29AL008DMANR2@PSOP44 [(SA638)]  
S29AL008DMFI01@PSOP44 [(SA638)] S29AL008DMFI02@PSOP44 [(SA638)]  
S29AL008DMFN01@PSOP44 [(SA638)] S29AL008DMFN02@PSOP44 [(SA638)]  
S29AL008DMFNR1@PSOP44 [(SA638)] S29AL008DMFNR2@PSOP44 [(SA638)]  
S29AL008DTAI01@TSOP48 [(SA247-B005)]  
S29AL008DTAI02@TSOP48 [(SA247-B005)]  
S29AL008DTAN01@TSOP48 [(SA247-B005)]  
S29AL008DTAN02@TSOP48 [(SA247-B005)]  
S29AL008DTANR1@TSOP48 [(SA247-B005)]  
S29AL008DTANR2@TSOP48 [(SA247-B005)]  
S29AL008DTFI01@TSOP48 [(SA247-B005)]  
S29AL008DTFI02@TSOP48 [(SA247-B005)]  
S29AL008DTFN01@TSOP48 [(SA247-B005)]  
S29AL008DTFN02@TSOP48 [(SA247-B005)]  
S29AL008DTFNR1@TSOP48 [(SA247-B005)]  
S29AL008DTFNR2@TSOP48 [(SA247-B005)]  
S29AL008JBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]

S29AL008JBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL008JTFI01@TSOP48 [(SA247-B005)]  
S29AL008JTFI02@TSOP48 [(SA247-B005)]  
S29AL008JTFI03@TSOP48 [(SA247-B005)]  
S29AL008JTFI04@TSOP48 [(SA247-B005)]  
S29AL008JTFIR1@TSOP48 [(SA247-B005)]  
S29AL008JTFIR2@TSOP48 [(SA247-B005)]  
S29AL008JTFN01@TSOP48 [(SA247-B005)]  
S29AL008JTFN02@TSOP48 [(SA247-B005)]  
S29AL008JTFNR1@TSOP48 [(SA247-B005)]  
S29AL008JTFNR2@TSOP48 [(SA247-B005)]  
S29AL016DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016DMAI01@PSOP44 [(SA638)] S29AL016DMAI02@PSOP44 [(SA638)]  
S29AL016DMAN01@PSOP44 [(SA638)] S29AL016DMAN02@PSOP44 [(SA638)]  
S29AL016DMFI01@PSOP44 [(SA638)] S29AL016DMFI02@PSOP44 [(SA638)]  
S29AL016DMFN01@PSOP44 [(SA638)] S29AL016DMFN02@PSOP44 [(SA638)]  
S29AL016DTAI01@TSOP48 [(SA247-B005)]  
S29AL016DTAI02@TSOP48 [(SA247-B005)]  
S29AL016DTAN01@TSOP48 [(SA247-B005)]  
S29AL016DTAN02@TSOP48 [(SA247-B005)]  
S29AL016DTFI01@TSOP48 [(SA247-B005)]  
S29AL016DTFI02@TSOP48 [(SA247-B005)]  
S29AL016DTFN01@TSOP48 [(SA247-B005)]  
S29AL016DTFN02@TSOP48 [(SA247-B005)]  
S29AL016JBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JTFI01@TSOP48 [(SA247-B005)]

S29AL016JTFI02@TSOP48 [(SA247-B005)]  
S29AL016JTFI03@TSOP48 [(SA247-B005)]  
S29AL016JTFI04@TSOP48 [(SA247-B005)]  
S29AL016JTFIR1@TSOP48 [(SA247-B005)]  
S29AL016JTFIR2@TSOP48 [(SA247-B005)]  
S29AL016JTFFN01@TSOP48 [(SA247-B005)]  
S29AL016JTFFN02@TSOP48 [(SA247-B005)]  
S29AL016JTFFNR1@TSOP48 [(SA247-B005)]  
S29AL016JTFFNR2@TSOP48 [(SA247-B005)]  
S29AL016MBAI01@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAI02@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAIR1@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAIR2@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFI01@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFI02@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFIR1@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFIR2@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MFAI01@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAI02@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFI01@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFI02@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MTAI01@TSOP48 [(SA247-B005)]  
S29AL016MTAI02@TSOP48 [(SA247-B005)]  
S29AL016MTAIR1@TSOP48 [(SA247-B005)]  
S29AL016MTAIR2@TSOP48 [(SA247-B005)]  
S29AL016MTFI01@TSOP48 [(SA247-B005)]  
S29AL016MTFI02@TSOP48 [(SA247-B005)]  
S29AL016MTFIR1@TSOP48 [(SA247-B005)]  
S29AL016MTFIR2@TSOP48 [(SA247-B005)]  
S29AL032DBAI00@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBAI03@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBAI04@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI00@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI03@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI04@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DTAI00@TSOP40 [(SA409T)]  
S29AL032DTAI03@TSOP48 [(SA247-B005)]  
S29AL032DTAI04@TSOP48 [(SA247-B005)]  
S29AL032DTFI00@TSOP40 [(SA409T)]



S29AL032DTFI03@TSOP48 [(SA247-B005)]  
S29AL032DTFI04@TSOP48 [(SA247-B005)]  
S29GL016ABAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIW1@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABAIW2@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIW1@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABFIW2@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016AFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016ATAI01@TSOP48 [(SA247-B005)]  
S29GL016ATAI02@TSOP48 [(SA247-B005)]  
S29GL016ATAI03@TSOP48 [(SA247-B005)]  
S29GL016ATAI04@TSOP48 [(SA247-B005)]  
S29GL016ATAIR1@TSOP48 [(SA247-B005)]  
S29GL016ATAIR2@TSOP48 [(SA247-B005)]  
S29GL016ATAIR3@TSOP48 [(SA247-B005)]  
S29GL016ATAIR4@TSOP48 [(SA247-B005)]  
S29GL016ATFI01@TSOP48 [(SA247-B005)]

S29GL016ATFI02@TSOP48 [(SA247-B005)]  
S29GL016ATFI03@TSOP48 [(SA247-B005)]  
S29GL016ATFI04@TSOP48 [(SA247-B005)]  
S29GL016ATFIR1@TSOP48 [(SA247-B005)]  
S29GL016ATFIR2@TSOP48 [(SA247-B005)]  
S29GL016ATFIR3@TSOP48 [(SA247-B005)]  
S29GL016ATFIR4@TSOP48 [(SA247-B005)]  
S29GL032ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIR4(Normal)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIW3@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABAIW4@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABFIW3@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABFIW4@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFAIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFFIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032ATAIR1@TSOP56 [(SA628-B102)]  
S29GL032ATAIR2@TSOP56 [(SA628-B102)]  
S29GL032ATAIR3@TSOP48 [(SA247-B005)]  
S29GL032ATAIR4@TSOP48 [(SA247-B005)]  
S29GL032ATFIR1@TSOP56 [(SA628-B102)]  
S29GL032ATFIR2@TSOP56 [(SA628-B102)]  
S29GL032ATFIR3@TSOP48 [(SA247-B005)]  
S29GL032ATFIR4(Normal)@TSOP48 [(SA247-B005)]  
S29GL032ATFIR4@TSOP48 [(SA247-B005)]  
S29GL032MBACR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBACR0@FBGA48 [(SA642AA-B026A-W064F001N)]

S29GL032MBACR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]

S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTACR0@TSOP40 [(SA409T)]  
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR1@TSOP56 [(SA628-B067)]  
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR2@TSOP56 [(SA628-B067)]  
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR3@TSOP48 [(SA247-B005)]  
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR4@TSOP48 [(SA247-B005)]  
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTAIR0@TSOP40 [(SA409T)]

S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR1@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2@TSOP56 [(SA628-B067)]  
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR3@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4@TSOP48 [(SA247-B005)]  
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFCR0@TSOP40 [(SA409T)]  
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR1@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2@TSOP56 [(SA628-B067)]  
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR3@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4@TSOP48 [(SA247-B005)]  
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFIR0@TSOP40 [(SA409T)]  
S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR1@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2@TSOP56 [(SA628-B067)]  
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR3@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL032NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NTAI01@TSOP56 [(SA628-B102)]  
S29GL032NTAI02@TSOP56 [(SA628-B102)]  
S29GL032NTAI03@TSOP48 [(SA247-B005)]  
S29GL032NTAI04@TSOP48 [(SA247-B005)]  
S29GL032NTAIR1@TSOP56 [(SA628-B102)]  
S29GL032NTAIR2@TSOP56 [(SA628-B102)]  
S29GL032NTAIR3@TSOP48 [(SA247-B005)]  
S29GL032NTAIR4@TSOP48 [(SA247-B005)]  
S29GL032NTAIV1@TSOP56 [(SA628-B102)]  
S29GL032NTAIV2@TSOP56 [(SA628-B102)]  
S29GL032NTFI01@TSOP56 [(SA628-B102)]  
S29GL032NTFI02@TSOP56 [(SA628-B102)]  
S29GL032NTFI03@TSOP48 [(SA247-B005)]  
S29GL032NTFI04@TSOP48 [(SA247-B005)]  
S29GL032NTFIR1@TSOP56 [(SA628-B102)]  
S29GL032NTFIR2@TSOP56 [(SA628-B102)]  
S29GL032NTFIR3@TSOP48 [(SA247-B005)]  
S29GL032NTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NTFIV1@TSOP56 [(SA628-B102)]  
S29GL032NTFIV2@TSOP56 [(SA628-B102)]  
S29GL064ABAIR3@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABAIR4@FBGA48 [(SA642B-B026A-Y072F001N)]

S29GL064ABAIR5@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR3@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR4@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR5@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS2(29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFAIS4(29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS2(29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFFIS4(29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064ATAIR1@TSOP56 [(SA628-B102)]  
S29GL064ATAIR2@TSOP56 [(SA628-B102)]  
S29GL064ATAIR3@TSOP48 [(SA247-B005)]  
S29GL064ATAIR4@TSOP48 [(SA247-B005)]  
S29GL064ATAIR6@TSOP48 [(SA247-B005)]  
S29GL064ATAIR7@TSOP48 [(SA247-B005)]  
S29GL064ATAIR8@TSOP48 [(SA247-B005)]  
S29GL064ATAIR9@TSOP48 [(SA247-B005)]  
S29GL064ATFIR1@TSOP56 [(SA628-B102)]  
S29GL064ATFIR2@TSOP56 [(SA628-B102)]  
S29GL064ATFIR3@TSOP48 [(SA247-B005)]  
S29GL064ATFIR4@TSOP48 [(SA247-B005)]  
S29GL064ATFIR6@TSOP48 [(SA247-B005)]  
S29GL064ATFIR7@TSOP48 [(SA247-B005)]  
S29GL064ATFIR8@TSOP48 [(SA247-B005)]  
S29GL064ATFIR9@TSOP48 [(SA247-B005)]  
S29GL064MBAIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]

S29GL064MBAIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR0@TSOP48 [(SA247-B005)]  
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]



S29GL064MTAIR1@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2@TSOP56 [(SA628-B067)]  
S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR3@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0@TSOP48 [(SA247-B005)]  
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR1@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2@TSOP56 [(SA628-B067)]  
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR3@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL064NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NTAI01@TSOP56 [(SA628-B102)]  
S29GL064NTAI02@TSOP56 [(SA628-B102)]  
S29GL064NTAI03@TSOP48 [(SA247-B005)]  
S29GL064NTAI04@TSOP48 [(SA247-B005)]  
S29GL064NTAI06@TSOP48 [(SA247-B005)]  
S29GL064NTAI07@TSOP48 [(SA247-B005)]  
S29GL064NTAIR1@TSOP56 [(SA628-B102)]  
S29GL064NTAIR2@TSOP56 [(SA628-B102)]  
S29GL064NTAIR3@TSOP48 [(SA247-B005)]  
S29GL064NTAIR4@TSOP48 [(SA247-B005)]  
S29GL064NTAIR6@TSOP48 [(SA247-B005)]  
S29GL064NTAIR7@TSOP48 [(SA247-B005)]  
S29GL064NTAIV1@TSOP56 [(SA628-B102)]  
S29GL064NTAIV2@TSOP56 [(SA628-B102)]  
S29GL064NTAIV6@TSOP48 [(SA247-B005)]  
S29GL064NTAIV7@TSOP48 [(SA247-B005)]  
S29GL064NTFI01@TSOP56 [(SA628-B102)]  
S29GL064NTFI02@TSOP56 [(SA628-B102)]  
S29GL064NTFI03@TSOP48 [(SA247-B005)]  
S29GL064NTFI04(Low)@TSOP48 [(SA247-B005)]  
S29GL064NTFI04@TSOP48 [(SA247-B005)]  
S29GL064NTFI06@TSOP48 [(SA247-B005)]  
S29GL064NTFI07@TSOP48 [(SA247-B005)]  
S29GL064NTFIR1@TSOP56 [(SA628-B102)]  
S29GL064NTFIR2@TSOP56 [(SA628-B102)]

S29GL064NTFIR3@TSOP48 [(SA247-B005)]  
S29GL064NTFIR4@TSOP48 [(SA247-B005)]  
S29GL064NTFIR6@TSOP48 [(SA247-B005)]  
S29GL064NTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NTFIV1@TSOP56 [(SA628-B102)]  
S29GL064NTFIV2@TSOP56 [(SA628-B102)]  
S29GL064NTFIV6@TSOP48 [(SA247-B005)]  
S29GL064NTFIV7@TSOP48 [(SA247-B005)]  
S29GL128MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MTAIR1@TSOP56 [(SA628-B067)]  
S29GL128MTAIR2@TSOP56 [(SA628-B067)]  
S29GL128MTFIR1@TSOP56 [(SA628-B067)]  
S29GL128MTFIR2@TSOP56 [(SA628-B067)]  
S29GL128NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAI0H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAW01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAW02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAWIH@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFI0H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFW01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFW02@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL128NTAI01@TSOP56 [(SA628-B102)]  
S29GL128NTAI02@TSOP56 [(SA628-B102)]  
S29GL128NTAIR1@TSOP56 [(SA628-B102)]  
S29GL128NTAIR2@TSOP56 [(SA628-B102)]  
S29GL128NTAIV1@TSOP56 [(SA628-B102)]  
S29GL128NTAIV2@TSOP56 [(SA628-B102)]  
S29GL128NTAW01@TSOP56 [(SA628-B102)]  
S29GL128NTAW02@TSOP56 [(SA628-B102)]  
S29GL128NTFI01@TSOP56 [(SA628-B102)]  
S29GL128NTFI02@TSOP56 [(SA628-B102)]  
S29GL128NTFIR1@TSOP56 [(SA628-B102)]  
S29GL128NTFIR2@TSOP56 [(SA628-B102)]  
S29GL128NTFIV1@TSOP56 [(SA628-B102)]  
S29GL128NTFIV2@TSOP56 [(SA628-B102)]  
S29GL128NTFW01@TSOP56 [(SA628-B102)]  
S29GL128NTFW02@TSOP56 [(SA628-B102)]  
S29GL128PFACR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFACR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFCR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFCR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PTACR1@TSOP56 [(SA628-B102)]  
S29GL128PTACR2@TSOP56 [(SA628-B102)]  
S29GL128PTAI01@TSOP56 [(SA628-B102)]  
S29GL128PTAI02@TSOP56 [(SA628-B102)]  
S29GL128PTAIR1@TSOP56 [(SA628-B102)]  
S29GL128PTAIR2@TSOP56 [(SA628-B102)]  
S29GL128PTAIV1@TSOP56 [(SA628-B102)]  
S29GL128PTAIV2@TSOP56 [(SA628-B102)]  
S29GL128PTFCR1@TSOP56 [(SA628-B102)]  
S29GL128PTFCR2@TSOP56 [(SA628-B102)]  
S29GL128PTFI01@TSOP56 [(SA628-B102)]



S29GL256PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PTACR1@TSOP56 [(SA628-B102)]  
S29GL256PTACR2@TSOP56 [(SA628-B102)]  
S29GL256PTAI01@TSOP56 [(SA628-B102)]  
S29GL256PTAI02@TSOP56 [(SA628-B102)]  
S29GL256PTAIR1@TSOP56 [(SA628-B102)]  
S29GL256PTAIR2@TSOP56 [(SA628-B102)]  
S29GL256PTAIV1@TSOP56 [(SA628-B102)]  
S29GL256PTAIV2@TSOP56 [(SA628-B102)]  
S29GL256PTFCR1@TSOP56 [(SA628-B102)]  
S29GL256PTFCR2@TSOP56 [(SA628-B102)]  
S29GL256PTFI01@TSOP56 [(SA628-B102)]  
S29GL256PTFI02@TSOP56 [(SA628-B102)]  
S29GL256PTFIR1@TSOP56 [(SA628-B102)]  
S29GL256PTFIR2@TSOP56 [(SA628-B102)]  
S29GL256PTFIV1@TSOP56 [(SA628-B102)]  
S29GL256PTFIV2@TSOP56 [(SA628-B102)]  
S29GL512NFA01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFA02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFF01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFF02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NTA01@TSOP56 [(SA628-B102)]  
S29GL512NTA02@TSOP56 [(SA628-B102)]  
S29GL512NTAV1@TSOP56 [(SA628-B102)]  
S29GL512NTAV2@TSOP56 [(SA628-B102)]  
S29GL512NTF01@TSOP56 [(SA628-B102)]  
S29GL512NTF02@TSOP56 [(SA628-B102)]  
S29GL512NTFV1@TSOP56 [(SA628-B102)]  
S29GL512NTFV2@TSOP56 [(SA628-B102)]  
S29GL512PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL512PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PTAI01@TSOP56 [(SA628-B102)]  
S29GL512PTAI02@TSOP56 [(SA628-B102)]  
S29GL512PTAIV1@TSOP56 [(SA628-B102)]  
S29GL512PTAIV2@TSOP56 [(SA628-B102)]  
S29GL512PTFI01@TSOP56 [(SA628-B102)]  
S29GL512PTFI02@TSOP56 [(SA628-B102)]  
S29GL512PTFIV1@TSOP56 [(SA628-B102)]  
S29GL512PTFIV2@TSOP56 [(SA628-B102)]  
S29JL032HBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI21@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI22@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI31@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI32@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI41@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI42@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI21@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI22@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI31@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI32@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI41@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBFI42@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HTAI01@TSOP48 [(SA247-B005)]  
S29JL032HTAI02@TSOP48 [(SA247-B005)]  
S29JL032HTAI21@TSOP48 [(SA247-B005)]  
S29JL032HTAI22@TSOP48 [(SA247-B005)]  
S29JL032HTAI31@TSOP48 [(SA247-B005)]  
S29JL032HTAI32@TSOP48 [(SA247-B005)]  
S29JL032HTAI41@TSOP48 [(SA247-B005)]  
S29JL032HTAI42@TSOP48 [(SA247-B005)]  
S29JL032HTFI01@TSOP48 [(SA247-B005)]  
S29JL032HTFI02@TSOP48 [(SA247-B005)]  
S29JL032HTFI21@TSOP48 [(SA247-B005)]  
S29JL032HTFI22@TSOP48 [(SA247-B005)]

S29JL032HTFI31@TSOP48 [(SA247-B005)]  
S29JL032HTFI32@TSOP48 [(SA247-B005)]  
S29JL032HTFI41@TSOP48 [(SA247-B005)]  
S29JL032HTFI42@TSOP48 [(SA247-B005)]  
S29JL064HBAI00@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29JL064HBFI00@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29JL064HTAI00@TSOP48 [(SA247-B005)]  
S29JL064HTAN00@TSOP48 [(SA247-B005)]  
S29JL064HTFI00@TSOP48 [(SA247-B005)]  
S29JL064HTFN00@TSOP48 [(SA247-B005)]  
S29PL127J55TAI13@TSOP56 [(SA628-B097)]  
S29PL127J55TAW13@TSOP56 [(SA628-B097)]  
S29PL127J55TFI13@TSOP56 [(SA628-B097)]  
S29PL127J55TFW13@TSOP56 [(SA628-B097)]  
S29PL127J60TAI13@TSOP56 [(SA628-B097)]  
S29PL127J60TAW13@TSOP56 [(SA628-B097)]  
S29PL127J60TFI13@TSOP56 [(SA628-B097)]  
S29PL127J60TFW13@TSOP56 [(SA628-B097)]  
S29PL127J70TAI13@TSOP56 [(SA628-B097)]  
S29PL127J70TAW13@TSOP56 [(SA628-B097)]  
S29PL127J70TFI13@TSOP56 [(SA628-B097)]  
S29PL127J70TFW13@TSOP56 [(SA628-B097)]  
S29VS016K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29WS064J0PBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBF00@FBGA80 [(SA642T-B093A-W080F001Y)]



S29WS064J0PBF101@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1ABAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS128J0PBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF100@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF101@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF110@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF111@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]

S29WS128J0SBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFI00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFI01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S30ML01GP30TFE00@TSOP48 [(SA247-B005)]  
S30ML01GP30TFE50@TSOP48 [(SA247-B005)]  
S30ML01GP50TFE01@TSOP48 [(SA247-B005)]  
S30ML01GP50TFE51@TSOP48 [(SA247-B005)]  
S30ML02GP30TFE00@TSOP48 [(SA247-B005)]  
S30ML02GP30TFE50@TSOP48 [(SA247-B005)]  
S30ML02GP50TFE01@TSOP48 [(SA247-B005)]  
S30ML02GP50TFE51@TSOP48 [(SA247-B005)]  
S30ML128P30TFE00@TSOP48 [(SA247-B005)]  
S30ML128P30TFE50@TSOP48 [(SA247-B005)]  
S30ML128P50TFE01@TSOP48 [(SA247+B005)]

S30ML128P50TFE51@TSOP48 [(SA247+B005)]  
S30ML256P30TFE00@TSOP48 [(SA247-B005)]  
S30ML256P30TFE50@TSOP48 [(SA247-B005)]  
S30ML256P50TFE01@TSOP48 [(SA247+B005)]  
S30ML256P50TFE51@TSOP48 [(SA247+B005)]  
S30ML512P50TFE01@TSOP48 [(SA247+B005)]  
S30ML512P50TFE51@TSOP48 [(SA247+B005)]  
S30MS01GP25TFW00@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW010@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW50@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW510@TSOP48 [(SA247-B005)]  
S70PL254J00BAW91@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAW93@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAWA1@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAWA3@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFW91@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFW93@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFWA1@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFWA3@FBGA84 [(SA642A-B079A-Y096F001)]  
S71AL016D02BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71GL016A40BAW1J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BAW3J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BFW1J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BFW3J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]

S71GL032AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032M40BAIBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032N40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N40BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]

S71GL064A80BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NB0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL128NB0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAW9J@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9K@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9N@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9T@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9Y@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BAWAJ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAK@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAN@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAP@FBGA84 [(SA642A-B108A-Y096F001)]

S71GL128NB0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BF EAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BF EAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFW9J@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9K@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9N@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9T@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9Y@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71GL128NB0BFWAJ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAK@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAN@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAP@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NB0BFW E J@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW ET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NB0BFW EZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL128NC0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]

S71GL128NC0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BAZAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL128NC0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAJ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAK@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAN@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAP@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFWAJ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAK@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAN@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAP@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NB0BFW EJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFW EK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFW EN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFW EP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFW ET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFW EU@FBGA84 [(SA642A-B108A-Y096N001)]

S71GL256NB0BFWWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NB0BFWWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NC0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NC0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL512NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NB0BFWWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71JL064H80BAW01(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW02(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW03(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW04(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW10(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW11(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW12(DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW01(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW02(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]



S71JL064HA0BAW10(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW11(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW12(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW00(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW01(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW02(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL128HB0BAW00(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW01(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW02(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW03(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HC0BAW00(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW01(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW02(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW03(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71PL032J04BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAE0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAWQ7@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL032J80BAWQF@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFWQ7@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BFWQF@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAE07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAE0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BAWQF@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032JA0BFWQF@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABAW0S@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J0ABFW0S@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL064J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAI9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]

S71PL127JA0BAW9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JA0BFI9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JA0BFW9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BFI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127NB0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NB0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NB0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NB0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NC0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NC0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NC0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NC0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JA0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]

S71PL129JA0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NB0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NB0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NB0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NB0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NC0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NC0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NC0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NC0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL191HB0BAI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HB0BAW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HB0BFI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HB0BFW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HC0BAI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HC0BAW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HC0BFI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HC0BFW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL193HB0BAI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HB0BAW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HB0BFI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HB0BFW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HC0BAI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HC0BAW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HC0BFI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HC0BFW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL254HC0BAW00@FBGA84 [(SA642A-B079A-Y096N001)]  
S71PL254JB0BAIT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BAWT7@FBGA84 [(SA642A-B079A-Y096F001)]

S71PL254JB0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFIT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFWT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAITZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAWTZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFITZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFWTZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JD0BAWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]  
S71PL254JD0BFWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]  
S71PL256NC0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256NC0HAW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256NC0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256NC0HFW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256ND0GAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256ND0GFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256ND0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL256ND0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
S71PL258HC0BAW00@FBGA84 [(SA642A-B088A-Y096N001)]  
S71PL512ND0JAW5B@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71PL512ND0JFW5B@FBGA84 [(SA642A-B158A-Y096F001Y)]  
S71VS032K80ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032K80ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS032KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]  
S71VS064KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]  
S71WS064JA0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]

S71WS064JA0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JA0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JA0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JA0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JA0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JA0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JA0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JB0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JB0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JB0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JB0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JB0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JB0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS064JB0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
S71WS064JB0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
S71WS128JA0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JA0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JA0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JA0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JA0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JA0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JA0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JA0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JB0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JB0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JB0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JB0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JB0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JB0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JB0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JC0BAE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BAIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JC0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JC0BAWA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]

S71WS128JC0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JC0BFE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BFIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JC0BFIA Y@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128JC0BFWA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
S71WS128JC0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS128JC0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS128NB0BAWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BAWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BAWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BAWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BAWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NB0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BAWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS128NC0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256JC0BAIA6@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS256JC0BAIT6@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAITJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAITY@FBGA84 [(SA642A-B086A-Y096F001)]  
S71WS256JC0BAWA6@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
S71WS256JC0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]





S71WS256NC0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAU@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256NC0BFWAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71WS256ND0BAIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYH@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYJ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYM@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYN@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BAWYP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWE3@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWE7@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWEK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWEP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWEU@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWYH@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWYJ@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWYK@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWYM@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS256ND0BFWYN@FBGA84 [(SA642CC-B139A-W080F001Y)]

S71WS256ND0BFWYP@FBGA84 [(SA642CC-B139A-W080F001Y)]  
S71WS512NC0BAIAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAIAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAIAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAIAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAIAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAIAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512ND0BAIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]

S71WS512ND0BAWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S75PL127JBDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50005(2\*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]  
S99-50011(2\*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]

S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)]  
S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
S99-50074(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
S99-50089(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50109(2\*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)]  
S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)]  
S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]

## SPANSION-CUSTOMER

### E(E)PROM/FRAM/NVRAM

S71PL129JB0BFW9U(ZX)@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S75PL127JBEBAWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]

## SSSC

### MICROCONTROLLER

SSU7301                   SSU7301@PLCC44 [(SA244)]  
SSU7301@TQFP44 [(SA245A)]

## SST

### E(E)PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [(SA602A)]   SST25LF010@SOIC8(5.4) [(SA605B)]  
SST25LF010@WSON8 [(SA683)]  
SST25LF010A@SOIC8(4.0) [(SA602A)]  
SST25LF010A@SOIC8(5.4) [(SA605B)]  
SST25LF010A@WSON8 [(SA683)]  
SST25LF016A@SOIC8(4.0) [(SA602A)]  
SST25LF016A@SOIC8(5.4) [(SA605A)]  
SST25LF016A@WSON8 [(SA683)]  
SST25LF016B@SOIC8(4.0) [(SA602A)]  
SST25LF016B@SOIC8(5.4) [(SA605A)]  
SST25LF016B@WSON8 [(SA683)]       SST25LF020@SOIC8(4.0) [(SA602A)]  
SST25LF020@SOIC8(5.4) [(SA605B)]   SST25LF020@WSON8 [(SA683)]  
SST25LF020A@SOIC8(4.0) [(SA602A)]  
SST25LF020A@SOIC8(5.4) [(SA605B)]  
SST25LF020A@WSON8 [(SA683)]       SST25LF040@SOIC8(4.0) [(SA602A)]  
SST25LF040@SOIC8(5.4) [(SA605B)]   SST25LF040@WSON8 [(SA683)]  
SST25LF040A@SOIC8(4.0) [(SA602A)]  
SST25LF040A@SOIC8(5.4) [(SA605B)]  
SST25LF040A@WSON8 [(SA683)]       SST25LF080@SOIC8(4.0) [(SA602A)]  
SST25LF080@SOIC8(5.4) [(SA605B)]   SST25LF080@WSON8 [(SA683)]  
SST25LF080A@SOIC8(4.0) [(SA602A)]  
SST25LF080A@SOIC8(5.4) [(SA605B)]

SST25LF080A@WSON8 [(SA683)]      SST25VF010@SOIC8(4.0) [(SA602A)]  
 SST25VF010@SOIC8(5.4) [(SA605B)]      SST25VF010@WSON8 [(SA683)]  
 SST25VF010A@SOIC8(4.0) [(SA602A)]  
 SST25VF010A@SOIC8(5.4) [(SA605B)]  
 SST25VF010A@WSON8 [(SA683)]  
 SST25VF016B@SOIC8(4.0) [(SA602A)]  
 SST25VF016B@SOIC8(5.4) [(SA605A)]  
 SST25VF016B@WSON8 [(SA683)]      SST25VF020@SOIC8(4.0) [(SA602A)]  
 SST25VF020@SOIC8(5.4) [(SA605B)]      SST25VF020@WSON8 [(SA683)]  
 SST25VF032B@SOIC8(4.0) [(SA602A)]  
 SST25VF032B@SOIC8(5.4) [(SA605A)]  
 SST25VF032B@WSON8 [(SA683)]      SST25VF040@SOIC8(4.0) [(SA602A)]  
 SST25VF040@SOIC8(5.4) [(SA605B)]      SST25VF040@WSON8 [(SA683)]  
 SST25VF040B@SOIC8(4.0) [(SA602A)]  
 SST25VF040B@SOIC8(5.4) [(SA605A)]  
 SST25VF040B@WSON8 [(SA683)]      SST25VF080@SOIC8(4.0) [(SA602A)]  
 SST25VF080@SOIC8(5.4) [(SA605B)]      SST25VF080@WSON8 [(SA683)]  
 SST25VF080B@SOIC8(4.0) [(SA602A)]  
 SST25VF080B@SOIC8(5.4) [(SA605A)]  
 SST25VF080B@WSON8 [(SA683)]      SST25VF512@SOIC8(4.0) [(SA602A)]  
 SST25VF512@SOIC8(5.4) [(SA605B)]      SST25VF512@WSON8 [(SA683)]  
 SST25VF512A@SOIC8(4.0) [(SA602A)]  
 SST25VF512A@SOIC8(5.4) [(SA605B)]  
 SST25VF512A@WSON8 [(SA683)]      SST25WF010@SOIC8 [(SA602A)]  
 SST25WF020@SOIC8 [(SA602A)]      SST25WF040@SOIC8 [(SA602A)]  
 SST25WF080@SOIC8 [(SA602A)]      SST25WF512@SOIC8 [(SA602A)]  
 SST27SF010      SST27SF010@PLCC32 [(SA015A1T)]  
 SST27SF010@TSOP32 [(SA410T)]      SST27SF020  
 SST27SF020@PLCC32 [(SA015A1T)]      SST27SF020@TSOP32 [(SA410T)]  
 SST27SF256      SST27SF256@PLCC32 [(SA015A1T)]  
 SST27SF256@VSOP32 [(SA620)]      SST27SF512  
 SST27SF512@PLCC32 [(SA015A1T)]      SST27SF512@VSOP32 [(SA620)]  
 SST27VF010      SST27VF010@PLCC32 [(SA015A1T)]  
 SST27VF010@TSOP32 [(SA410T)]      SST27VF020  
 SST27VF020@PLCC32 [(SA015A1T)]      SST27VF020@TSOP32 [(SA410T)]  
 SST27VF040      SST27VF040@PLCC32 [(SA015A1T)]  
 SST27VF040@TSOP32 [(SA410T)]      SST27VF256  
 SST27VF256@PLCC32 [(SA015A1T)]      SST27VF256@VSOP32 [(SA620)]  
 SST27VF512      SST27VF512@PLCC32 [(SA015A1T)]  
 SST27VF512@VSOP32 [(SA620)]      SST28EE011  
 SST28EE011@PLCC32 [(SA015A1T)]      SST28EE011@TSOP32 [(SA410T)]  
 SST28LE011      SST28LE011@PLCC32 [(SA015A1T)]  
 SST28LE011@TSOP32 [(SA410T)]      SST28LF040

SST28LF040@PLCC32 [(SA015A1T)] SST28LF040@TSOP32 [(SA410T)]  
SST28SF040 SST28SF040@PLCC32 [(SA015A1T)]  
SST28SF040@TSOP32 [(SA410T)] SST28SF040A  
SST28SF040A@PLCC32 [(SA015A1T)] SST28SF040A@TSOP32 [(SA410T)]  
SST28VE011 SST28VE011@PLCC32 [(SA015A1T)]  
SST28VE011@TSOP32 [(SA410T)] SST28VF040  
SST28VF040@PLCC32 [(SA015A1T)] SST28VF040@TSOP32 [(SA410T)]  
SST28VF040A SST28VF040A@PLCC32 [(SA015A1T)]  
SST28VF040A@TSOP32 [(SA410T)] SST29EE010  
SST29EE010@PLCC32 [(SA015A1T)] SST29EE010@TSOP32 [(SA410T)]  
SST29EE020 SST29EE020@PLCC32 [(SA015A1T)]  
SST29EE020@TSOP32 [(SA410T)] SST29EE512  
SST29EE512@PLCC32 [(SA015A1T)] SST29EE512@TSOP32 [(SA410T)]  
SST29LE010 SST29LE010@PLCC32 [(SA015A1T)]  
SST29LE010@TSOP32 [(SA410T)] SST29LE020  
SST29LE020@PLCC32 [(SA015A1T)] SST29LE020@TSOP32 [(SA410T)]  
SST29LE512 SST29LE512@PLCC32 [(SA015A1T)]  
SST29LE512@TSOP32 [(SA410T)] SST29SF010  
SST29SF010@PLCC32 [(SA015A1T)] SST29SF010@VSOP32 [(SA620)]  
SST29SF020 SST29SF020@PLCC32 [(SA015A1T)]  
SST29SF020@VSOP32 [(SA620)] SST29SF040  
SST29SF040@PLCC32 [(SA015A1T)] SST29SF040@VSOP32 [(SA620)]  
SST29SF512 SST29SF512@PLCC32 [(SA015A1T)]  
SST29SF512@VSOP32 [(SA620)] SST29VE010  
SST29VE010@PLCC32 [(SA015A1T)] SST29VE010@TSOP32 [(SA410T)]  
SST29VE020 SST29VE020@PLCC32 [(SA015A1T)]  
SST29VE020@TSOP32 [(SA410T)] SST29VE512  
SST29VE512@PLCC32 [(SA015A1T)] SST29VE512@TSOP32 [(SA410T)]  
SST29VF010 SST29VF010@PLCC32 [(SA015A1T)]  
SST29VF010@VSOP32 [(SA620)] SST29VF020  
SST29VF020@PLCC32 [(SA015A1T)] SST29VF020@VSOP32 [(SA620)]  
SST29VF040 SST29VF040@PLCC32 [(SA015A1T)]  
SST29VF040@VSOP32 [(SA620)] SST29VF512  
SST29VF512@PLCC32 [(SA015A1T)] SST29VF512@VSOP32 [(SA620)]  
SST31LF021@VSOP32 [(SA620)] SST31LF041@VSOP40 [(SA623)]  
SST31LF041A@VSOP32 [(SA620)] SST31LF043@VSOP40 [(SA623)]  
SST31LF043A@VSOP32 [(SA620)]  
SST32HF162@LFBGA48 [(SA655E-B026A-T064F001)]  
SST32HF162@LFBGA48(SST adapter) SST32HF162@TSOP48 [(SA247-B005)]  
SST32HF1621C@LFBGA62 [(SA642R-B083A-T096F001Y)]  
SST32HF1621C@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1622C@LFBGA62 [(SA642R-B083A-T096F001Y)]  
SST32HF1622C@LFBGA63 [(SA642R-B032A-T096F001Y)]



SST32HF164@LFBGA48 [(SA655E-B026A-T064F001)]  
SST32HF164@LFBGA48(SST adapter) SST32HF164@TSOP48 [(SA247-B005)]  
SST32HF1641@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF1641@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1641C@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF1641C@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1642@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF1642@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1642C@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF1642C@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1681@LFBGA62 [(SA642R-B083A-T096F001Y)]  
SST32HF1681@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF1682@LFBGA62 [(SA642R-B083A-T096F001Y)]  
SST32HF1682@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF200@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF201@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF202@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF324@LFBGA62 [(SA642E-B023A-T072F001)]  
SST32HF324@LFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF324@TFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF3241@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3241@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3241C@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3241C@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3242@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3242@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3242C@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3242C@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST32HF324C@LFBGA62 [(SA642E-B023A-T072F001)]  
SST32HF324C@LFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF324C@TFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF328@LFBGA62 [(SA642E-B023A-T072F001)]  
SST32HF328@LFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF328@TFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF3281@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3281@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3281C@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3281C@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3282@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF3282C@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST32HF3282C@FBGA63 [(SA642R-B032A-T096F001Y)]

SST32HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST32HF328C@LFBGA62 [(SA642E-B023A-T072F001)]  
SST32HF328C@LFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF328C@TFBGA63 [(SA642E-B032A-T072F001)]  
SST32HF32A1@LFBGA62 [(SA642R-B083A-T096F001Y)]  
SST32HF32A1@LFBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST32HF400@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF401@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF402@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF64161@LFBGA64 [(SA642R-B083A-T096F001Y)]  
SST32HF64161C@LFBGA64 [(SA642R-B083A-T096F001Y)]  
SST32HF6481@LFBGA64 [(SA642R-B083A-T096F001Y)]  
SST32HF6481C@LFBGA64 [(SA642R-B083A-T096F001Y)]  
SST32HF6482@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF6482@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF6482C@FBGA63 [(SA642R-B032A-T096F001Y)]  
SST32HF6482C@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF64A1@FBGA63 [(SA642I-B032A-W080F001Y)]  
SST32HF64A1@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF64A2@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST32HF64A2@FBGA63 [(SA642I-B032A-W080F001Y)]  
SST32HF64A2@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF64B1@FBGA63 [(SA642I-B032A-W080F001Y)]  
SST32HF64B1@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF64B2@FBGA63 [(SA642I-B032A-W080F001Y)]  
SST32HF64B2@FBGA64 [(SA642R-B023A-T096F001Y)]  
SST32HF800@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF802@LBGA48 [(SA655E-B026A-T064F001)]  
SST32HF802@LFBGA48 [(SA642B-B026A-Y072F001)]  
SST32HF802@LFBGA48(SST adapter)  
SST34HF1601B@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1601B@TSOP48 [(SA247-B005)]  
SST34HF1601C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1601C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1602C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1602C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1621@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1621A@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1621A@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF1621C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1621C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1621S@FBGA56 [(SA642E-B032A-T072F001)]

SST34HF1622@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1622C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1622C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1622S@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF162C@LBGA48 [(SA655E-B026A-T064F001)]  
SST34HF162G@LBGA48 [(SA655E-B026A-T064F001)]  
SST34HF162G@LFBGA48 [(SA642G-B026A-T048F001)]  
SST34HF1641@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1641A@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1641A@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF1641C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1641C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1641D@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1641D@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1641J@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1641J@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF1641S@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1642@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1642C@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1642C@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1642D@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1642D@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1642S@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF164C@LBGA48 [(SA655E-B026A-T064F001)]  
SST34HF164G@LBGA48 [(SA655E-B026A-T064F001)]  
SST34HF164G@LFBGA48 [(SA642G-B026A-T048F001)]  
SST34HF1681@LFBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1681@LFBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF1681D@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1681D@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF1681J@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF1681J@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF1682D@FBGA56 [(SA642E-B032A-T072F001)]  
SST34HF1682D@FBGA62 [(SA642E-B023A-T072F001)]  
SST34HF3243C@FBGA56 [(SA642I-B032A-W080F001Y)]  
SST34HF3243C@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF3244@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF3244@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF3244C@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF3282@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF3283@FBGA56 [(SA642I-B032A-W080F001Y)]

SST34HF3283@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF3284@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST34HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]  
SST34HF32A4@FBGA62 [(SA642R-B023A-T096F001Y)]  
SST36VF1601(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST36VF1601(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]  
SST36VF1601@TSOP48 [(SA247-B005)]  
SST36VF1601C@FBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1601C@TSOP48 [(SA247-B005)]  
SST36VF1601E@FBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1601E@TSOP48 [(SA247-B005)]  
SST36VF1601G@LFBGA56 [(SA642A-B032A)]  
SST36VF1601G@TFBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1601G@TSOP48 [(SA247-B005)]  
SST36VF1602(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST36VF1602(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]  
SST36VF1602@TSOP48 [(SA247-B005)]  
SST36VF1602C@FBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1602C@TSOP48 [(SA247-B005)]  
SST36VF1602E@FBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1602E@TSOP48 [(SA247-B005)]  
SST36VF1602G@LFBGA56 [(SA642A-B032A)]  
SST36VF1602G@TFBGA48 [(SA642G-B026A-T048F001)]  
SST36VF1602G@TSOP48 [(SA247-B005)]  
SST36VF3203@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST36VF3203@TSOP48 [(SA247-B005)]  
SST36VF3204@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST36VF3204@TSOP48 [(SA247-B005)]  
SST37VF010 SST37VF010@PLCC32 [(SA015A1T)]  
SST37VF010@VSOP32 [(SA620)] SST37VF020  
SST37VF020@PLCC32 [(SA015A1T)] SST37VF020@VSOP32 [(SA620)]  
SST37VF040 SST37VF040@PLCC32 [(SA015A1T)]  
SST37VF040@VSOP32 [(SA620)] SST37VF512  
SST37VF512@PLCC32 [(SA015A1T)] SST37VF512@VSOP32 [(SA620)]  
SST39LF010@PLCC32 [(SA015A1T)]  
SST39LF010@TFBGA48 [(SA642G-B026A-T048F001)]  
SST39LF010@VSOP32 [(SA620)]  
SST39LF010@WFBGA48 [(SA716A-B120A-M048F001Y)]  
SST39LF016@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39LF016@TSOP40 [(SA409T)] SST39LF020@PLCC32 [(SA015A1T)]  
SST39LF020@TFBGA48 [(SA642G-B026A-T048F001)]  
SST39LF020@VSOP32 [(SA620)]

SST39LF020@WFBGA48 [(SA716A-B120A-M048F001Y)]  
SST39LF040@PLCC32 [(SA015A1T)] SST39LF040@VSOP32 [(SA620)]  
SST39LF080@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39LF080@TSOP40 [(SA409T)] SST39LF080Q@TSOP40 [(SA409T)]  
SST39LF100@FBGA48 [(SA642B-B026A-Y072F001)]  
SST39LF100@VSOP40 [(SA623)]  
SST39LF160@TFBGA48 [(SA642B-B026A-Y072F001)]  
SST39LF160@TSOP48 [(SA247-B005)]  
SST39LF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39LF200A@TSOP48 [(SA247-B005)]  
SST39LF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39LF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39LF400A@TSOP48 [(SA247-B005)]  
SST39LF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39LF512@PLCC32 [(SA015A1T)] SST39LF512@VSOP32 [(SA620)]  
SST39LF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39LF800A@TSOP48 [(SA247-B005)]  
SST39LF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39LH010 SST39LH010@PLCC32 [(SA015A1T)]  
SST39LH010@TSOP32 [(SA410T)] SST39LH040  
SST39LH040@PLCC32 [(SA015A1T)] SST39LH040@TSOP32 [(SA410T)]  
SST39LH512 SST39LH512@PLCC32 [(SA015A1T)]  
SST39LH512@TSOP32 [(SA410T)] SST39SF010  
SST39SF010@PLCC32 [(SA015A1T)] SST39SF010@VSOP32 [(SA620)]  
SST39SF010A SST39SF010A@PLCC32 [(SA015A1T)]  
SST39SF010A@VSOP32 [(SA620)] SST39SF020  
SST39SF020@PLCC32 [(SA015A1T)] SST39SF020@VSOP32 [(SA620)]  
SST39SF020A SST39SF020A@PLCC32 [(SA015A1T)]  
SST39SF020A@VSOP32 [(SA620)] SST39SF020P  
SST39SF020P@PLCC32 [(SA015A1T)] SST39SF020P@VSOP32 [(SA620)]  
SST39SF040 SST39SF040@PLCC32 [(SA015A1T)]  
SST39SF040@VSOP32 [(SA620)] SST39SF040P  
SST39SF040P@PLCC32 [(SA015A1T)] SST39SF040P@VSOP32 [(SA620)]  
SST39SF512 SST39SF512@PLCC32 [(SA015A1T)]  
SST39SF512@VSOP32 [(SA620)] SST39SF512A  
SST39SF512A@PLCC32 [(SA015A1T)] SST39SF512A@VSOP32 [(SA620)]  
SST39VF010 SST39VF010@PLCC32 [(SA015A1T)]  
SST39VF010@TFBGA48 [(SA642G-B026A-T048F001)]  
SST39VF010@VSOP32 [(SA620)]  
SST39VF016@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF016@TSOP40 [(SA409T)] SST39VF016Q@TSOP40 [(SA409T)]  
SST39VF020 SST39VF020@PLCC32 [(SA015A1T)]  
SST39VF020@TFBGA48 [(SA642G-B026A-T048F001)]

SST39VF020@VSOP32 [(SA620)] SST39VF020P  
SST39VF020P@PLCC32 [(SA015A1T)] SST39VF020P@VSOP32 [(SA620)]  
SST39VF040 SST39VF040@PLCC32 [(SA015A1T)]  
SST39VF040@VSOP32 [(SA620)] SST39VF040P  
SST39VF040P@PLCC32 [(SA015A1T)] SST39VF040P@VSOP32 [(SA620)]  
SST39VF080@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF080@TSOP40 [(SA409T)] SST39VF080Q@TSOP40 [(SA409T)]  
SST39VF088@TSOP48 [(SA247-B005)]  
SST39VF100@FBGA48 [(SA642B-B026A-Y072F001)]  
SST39VF100@VSOP40 [(SA623)]  
SST39VF160@TFBGA48 [(SA642B-B026A-Y072F001)]  
SST39VF160@TSOP48 [(SA247-B005)]  
SST39VF1601@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF1601@TSOP48 [(SA247-B005)]  
SST39VF1602@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF1602@TSOP48 [(SA247-B005)]  
SST39VF160Q@TSOP48 [(SA247-B005)]  
SST39VF1681@TFBGA48 [(SA642B-B026A-Y072F001)]  
SST39VF1681@TSOP48 [(SA247-B005)]  
SST39VF1682@TFBGA48 [(SA642B-B026A-Y072F001)]  
SST39VF1682@TSOP48 [(SA247-B005)]  
SST39VF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF200A@TSOP48 [(SA247-B005)]  
SST39VF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39VF320@TFBGA48 [(SA642G-B026A-T048F001)]  
SST39VF320@TSOP48 [(SA247-B005)]  
SST39VF3201@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF3201@TSOP48 [(SA247-B005)]  
SST39VF3202@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF3202@TSOP48 [(SA247-B005)]  
SST39VF400@TSOP48 [(SA247-B005)]  
SST39VF400A(Low)@TSOP48 [(SA247)]  
SST39VF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF400A@TSOP48 [(SA247-B005)]  
SST39VF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39VF400Q@TSOP48 [(SA247-B005)]  
SST39VF512 SST39VF512@PLCC32 [(SA015A1T)]  
SST39VF512@VSOP32 [(SA620)]  
SST39VF6401@TFBGA48 [(SA642R-B026A-T096F001Y)]  
SST39VF6401@TSOP48 [(SA247-B005)]  
SST39VF6401B@FBGA48 [(SA642R-B026A-T096F001Y)]  
SST39VF6401B@TSOP48 [(SA247-B005)]  
SST39VF6402@TFBGA48 [(SA642R-B026A-T096F001Y)]

SST39VF6402@TSOP48 [(SA247-B005)]  
SST39VF6402B@FBGA48 [(SA642R-B026A-T096F001Y)]  
SST39VF6402B@TSOP48 [(SA247-B005)]  
SST39VF800@TSOP48 [(SA247-B005)]  
SST39VF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39VF800A@TSOP48 [(SA247-B005)]  
SST39VF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39VF800Q@TSOP48 [(SA247-B005)]  
SST39WF1601@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39WF1601@WFBGA48 [(SA716C-B119A-T048F001Y)]  
SST39WF1602@FBGA48 [(SA642G-B026A-T048F001Y)]  
SST39WF1602@WFBGA48 [(SA716C-B119A-T048F001Y)]  
SST39WF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39WF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39WF800A(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
SST39WF800A(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39WF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST39WF800B(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
SST39WF800B(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
SST39WF800B@TFBGA48 [(SA642G-B026A-T048F001Y)]  
SST45LF010@SOIC8 [(SA602A)]      SST45LF010@WSON8 [(SA683)]  
SST45VF010@SOIC8 [(SA602A)]      SST45VF020@SOIC8 [(SA602A)]  
SST45VF512@SOIC8 [(SA602A)]      SST49LF002@PLCC32 [(SA015A1T)]  
SST49LF002@VSOP32 [(SA620)]      SST49LF002A@PLCC32 [(SA015A1T)]  
SST49LF002A@VSOP32 [(SA620)]      SST49LF002B@PLCC32 [(SA015A1T)]  
SST49LF003A@PLCC32 [(SA015A1T)]      SST49LF003A@VSOP32 [(SA620)]  
SST49LF003B@PLCC32 [(SA015A1T)]      SST49LF004@PLCC32 [(SA015A1T)]  
SST49LF004@VSOP32 [(SA620)]      SST49LF004A@PLCC32 [(SA015A1T)]  
SST49LF004A@VSOP32 [(SA620)]      SST49LF004B@PLCC32 [(SA015A1T)]  
SST49LF004B@VSOP32 [(SA620)]      SST49LF004B@VSOP40 [(SA409T)]  
SST49LF004C@PLCC32 [(SA015A1T)]      SST49LF004C@VSOP32 [(SA620)]  
SST49LF008@PLCC32 [(SA015A1T)]      SST49LF008@VSOP32 [(SA620)]  
SST49LF008A@PLCC32 [(SA015A1T)]      SST49LF008A@TSOP40 [(SA409T)]  
SST49LF008A@VSOP32 [(SA620)]      SST49LF008C@PLCC32 [(SA015A1T)]  
SST49LF008C@VSOP32 [(SA620)]      SST49LF016C@PLCC32 [(SA015A1T)]  
SST49LF016C@TSOP40 [(SA409T)]      SST49LF016C@VSOP32 [(SA620)]  
SST49LF020@PLCC32 [(SA015A1T)]      SST49LF020@VSOP32 [(SA620)]  
SST49LF020A@PLCC32 [(SA015A1T)]      SST49LF020A@VSOP32 [(SA620)]  
SST49LF030A@PLCC32 [(SA015A1T)]      SST49LF030A@VSOP32 [(SA620)]  
SST49LF040@PLCC32 [(SA015A1T)]      SST49LF040@VSOP32 [(SA620)]  
SST49LF040A@PLCC32 [(SA015A1T)]      SST49LF040A@VSOP32 [(SA620)]  
SST49LF040B@PLCC32 [(SA015A1T)]      SST49LF040B@TSOP40 [(SA409T)]  
SST49LF040B@VSOP32 [(SA620)]      SST49LF080A@PLCC32 [(SA015A1T)]

SST49LF080A@VSOP32 [(SA620)]      SST49LF160C@PLCC32 [(SA015A1T)]  
 SST49LF160C@TSOP32 [(SA620)]

## MICROCONTROLLER

SST65P542R@SOIC28 [(SA404)]      SST89C54  
 SST89C54@PLCC44 [(SA244)]      SST89C54@TQFP44 [(SA245A)]  
 SST89C58      SST89C58@PLCC44 [(SA244)]  
 SST89C58@TQFP44 [(SA245A)]      SST89C58RC@PLCC44 [(SA244)]  
 SST89C58RC@TQFP44 [(SA245A)]      SST89C58RC@WQFN40 [(SA245A)]  
 SST89E516RD      SST89E516RD@PLCC44 [(SA244)]  
 SST89E516RD@TQFP44 [(SA245A)]      SST89E516RD2  
 SST89E516RD2@PLCC44 [(SA244)]      SST89E516RD2@TQFP44 [(SA245A)]  
 SST89E52RC      SST89E52RC@PLCC44 [(SA244)]  
 SST89E52RC@TQFP44 [(SA245A)]      SST89E52RD  
 SST89E52RD@PLCC44 [(SA244)]      SST89E52RD@TQFP44 [(SA245A)]  
 SST89E52RD2      SST89E52RD2@PLCC44 [(SA244)]  
 SST89E52RD2@TQFP44 [(SA245A)]      SST89E54RC  
 SST89E54RC@PLCC44 [(SA244)]      SST89E54RC@TQFP44 [(SA245A)]  
 SST89E54RD      SST89E54RD@PLCC44 [(SA244)]  
 SST89E54RD@TQFP44 [(SA245A)]      SST89E54RD2  
 SST89E54RD2@PLCC44 [(SA244)]      SST89E54RD2@TQFP44 [(SA245A)]  
 SST89E554RC      SST89E554RC@PLCC44 [(SA244)]  
 SST89E554RC@TQFP44 [(SA245A)]      SST89E564RD  
 SST89E564RD@PLCC44 [(SA244)]      SST89E564RD@TQFP44 [(SA245A)]  
 SST89E58RD      SST89E58RD@PLCC44 [(SA244)]  
 SST89E58RD@TQFP44 [(SA245A)]      SST89E58RD2  
 SST89E58RD2@PLCC44 [(SA244)]      SST89E58RD2@TQFP44 [(SA245A)]  
 SST89V516RD      SST89V516RD@PLCC44 [(SA244)]  
 SST89V516RD@TQFP44 [(SA245A)]      SST89V516RD2  
 SST89V516RD2@PLCC44 [(SA244)]      SST89V516RD2@TQFP44 [(SA245A)]  
 SST89V52RD      SST89V52RD@PLCC44 [(SA244)]  
 SST89V52RD@TQFP44 [(SA245A)]      SST89V52RD2  
 SST89V52RD2@PLCC44 [(SA244)]      SST89V52RD2@TQFP44 [(SA245A)]  
 SST89V54RD2      SST89V54RD2@PLCC44 [(SA244)]  
 SST89V54RD2@TQFP44 [(SA245A)]      SST89V554RC  
 SST89V554RC@PLCC44 [(SA244)]      SST89V554RC@TQFP44 [(SA245A)]  
 SST89V564RD      SST89V564RD@PLCC44 [(SA244)]  
 SST89V564RD@TQFP44 [(SA245A)]      SST89V58RD2  
 SST89V58RD2@PLCC44 [(SA244)]      SST89V58RD2@TQFP44 [(SA245A)]



ST

## E(E)PROM/FRAM/NVRAM

ET2716	ETC2716
ETC2732	M24128
M24128@MLP8 [(SA724)]	M24128@SOIC8 [(SA602A)]
M24128@TSOP8 [(SA026)]	M24164
M24164@SOIC8 [(SA602A)]	M24256
M24256@MLP8 [(SA724)]	M24256@TSOP8 [(SA026)]
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8 [(SA605A)]
M24512	M24512@SOIC8 [(SA605A)]
M24512@TSOP8 [(SA026)]	M24C01
M24C01@MLP8 [(SA724)]	M24C01@SOIC8 [(SA602A)]
M24C01R	M24C01R@MLP8 [(SA724)]
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8 [(SA026)]
M24C01W	M24C01W@MLP8 [(SA724)]
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8 [(SA026)]
M24C02	M24C02@MLP8 [(SA724)]
M24C02@SOIC8 [(SA602A)]	M24C02R
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8 [(SA602A)]
M24C02R@TSOP8 [(SA026)]	M24C02W
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8 [(SA602A)]
M24C02W@TSOP8 [(SA026)]	M24C04
M24C04@MLP8 [(SA724)]	M24C04@SOIC8 [(SA602A)]
M24C04R	M24C04R@MLP8 [(SA724)]
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8 [(SA026)]
M24C04W	M24C04W@MLP8 [(SA724)]
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8 [(SA026)]
M24C08	M24C08@MLP8 [(SA724)]
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8 [(SA602A)]
M24C08@TSOP8 [(SA026)]	M24C08R
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8 [(SA695A)]
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8 [(SA026)]
M24C08W	M24C08W@MLP8 [(SA724)]
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8 [(SA602A)]
M24C08W@TSOP8 [(SA026)]	M24C128(BN)
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8 [(SA602A)]
M24C128@MLP8 [(SA724)]	M24C128B(BN)
M24C128B(MN)@SOIC8 [(SA605A)]	M24C128B(MW)@SOIC8 [(SA602A)]
M24C128B@MLP8 [(SA724)]	M24C16
M24C16@MLP8 [(SA724)]	M24C16@SOIC8 [(SA602A)]
M24C16R	M24C16R@MLP8 [(SA724)]

M24C16R@SOIC8 [(SA602A)] M24C16R@TSOP8 [(SA026)]  
M24C16W M24C16W@MLP8 [(SA724)]  
M24C16W@SOIC8 [(SA602A)] M24C16W@TSOP8 [(SA026)]  
M24C256(BN) M24C256(MN)@SOIC8 [(SA605A)]  
M24C256(MW)@SOIC8 [(SA602A)] M24C256@MLP8 [(SA724)]  
M24C256A(BN) M24C256A(MN)@SOIC8 [(SA605A)]  
M24C256A(MW)@SOIC8 [(SA602A)] M24C256A@MLP8 [(SA724)]  
M24C256B(BN) M24C256B(MN)@SOIC8 [(SA605A)]  
M24C256B(MW)@SOIC8 [(SA602A)] M24C256B@MLP8 [(SA724)]  
M24C256W(BN) M24C256W(MN)@SOIC8 [(SA605A)]  
M24C256W(MW)@SOIC8 [(SA602A)] M24C256W@MLP8 [(SA724)]  
M24C32(BN) M24C32(DL)@TSSOP14 [(SA026)]  
M24C32(DW)@TSSOP8 [(SA602A)] M24C32(MN)@SOIC8 [(SA605A)]  
M24C32(MW)@SOIC8 [(SA602A)] M24C32@MLP8 [(SA724)]  
M24C32W(BN) M24C32W(DL)@TSSOP14 [(SA026)]  
M24C32W(DW)@TSSOP8 [(SA602A)] M24C32W(MN)@SOIC8 [(SA605A)]  
M24C32W(MW)@SOIC8 [(SA602A)] M24C32W@MLP8 [(SA724)]  
M24C64(BN) M24C64(DL)@TSSOP14 [(SA026)]  
M24C64(DW)@TSSOP8 [(SA602A)] M24C64(MN)@SOIC8 [(SA605A)]  
M24C64(MW)@SOIC8 [(SA602A)] M24C64@MLP8 [(SA724)]  
M24C64W(BN) M24C64W(DL)@TSSOP14 [(SA026)]  
M24C64W(DW)@TSSOP8 [(SA602A)] M24C64W(MN)@SOIC8 [(SA605A)]  
M24C64W(MW)@SOIC8 [(SA602A)] M24C64W@MLP8 [(SA724)]  
M24CL04B M24CL04B@MLP8 [(SA724)]  
M24CL04B@SOIC8 [(SA602A)] M24CL04B@TSOP8 [(SA026)]  
M24E16 M24E32(BN)  
M24E32(DW)@TSSOP8 [(SA602A)] M24E32(MN)@SOIC8 [(SA605A)]  
M24E32(MW)@SOIC8 [(SA602A)] M24W01  
M24W01@SOIC8 [(SA602A)] M24W02  
M24W02@SOIC8 [(SA602A)] M24W04  
M24W04@SOIC8 [(SA602A)] M24W08  
M24W08@SOIC8 [(SA602A)] M24W16  
M24W16@SOIC8 [(SA602A)] M25C01  
M25C02 M25C04  
M25C08 M25C16  
M25E16 M25P05@SOIC8 [(SA602A)]  
M25P05@VQFPN8 [(SA683)] M25P05-A@SOIC8 [(SA602A)]  
M25P05-A@TSSOP8 [(SA605A)] M25P05-A@VDFPN8 [(SA684)]  
M25P10@SOIC8 [(SA602A)] M25P10@VQFPN8 [(SA683)]  
M25P10-A@SOIC8 [(SA602A)] M25P10-A@VFQFPN8 [(SA684)]  
M25P128@SOIC16 [(SA404)]  
M25P128@SOIC16(ISP) [ISP-HEADER01]  
M25P128@VDFPN8 [(SA684)]

M25P128@VDFPN8(ISP) [ISP-HEADER01]  
M25P16@SOIC16 [(SA404)]  
M25P16@SOIC16(ISP) [ISP-HEADER01]  
M25P16@SOIC8(150mil) [(SA602A)]  
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]  
M25P16@SOIC8(200mil) [(SA605A)]  
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]  
M25P16@VDFPN8 [(SA684)]  
M25P16@VDFPN8(ISP) [ISP-HEADER01]  
M25P16@VFQFPN8 [(SA683)]  
M25P16@VFQFPN8(ISP) [ISP-HEADER01]  
M25P20@SOIC8 [(SA602A)]          M25P20@SOIC8(ISP) [ISP-HEADER01]  
M25P20@VFQFPN8 [(SA683)]  
M25P20@VFQFPN8(ISP) [ISP-HEADER01]  
M25P32(Fast Mode)@SOIC16 [(SA404)]  
M25P32(Fast Mode)@VQFPN8 [(SA684)]  
M25P32@SOIC16 [(SA404)]  
M25P32@SOIC16(ISP) [ISP-HEADER01]  
M25P32@SOIC8 [(SA605A)]          M25P32@SOIC8(ISP) [ISP-HEADER01]  
M25P32@VDFPN8 [(SA684)]  
M25P32@VDFPN8(ISP) [ISP-HEADER01]  
M25P32@VFQFPN8 [(SA683)]  
M25P32@VFQFPN8(ISP) [ISP-HEADER01]  
M25P40@SOIC8 [(SA602A)]          M25P40@SOIC8(ISP) [ISP-HEADER01]  
M25P40@VFQFPN8 [(SA683)]  
M25P40@VFQFPN8(ISP) [ISP-HEADER01]  
M25P64(Fast Mode)@SOIC16 [(SA404)]  
M25P64(Fast Mode)@VDFPN8 [(SA684)]  
M25P64@SOIC16 [(SA404)]  
M25P64@SOIC16(ISP) [ISP-HEADER01]  
M25P64@VDFPN8 [(SA684)]  
M25P64@VDFPN8(ISP) [ISP-HEADER01]  
M25P80@SOIC16 [(SA404)]  
M25P80@SOIC16(ISP) [ISP-HEADER01]  
M25P80@SOIC8 [(SA605A)]          M25P80@SOIC8(ISP) [ISP-HEADER01]  
M25P80@VFQFPN8 [(SA683)]  
M25P80@VFQFPN8(ISP) [ISP-HEADER01]  
M25PE10@SOIC8 [(SA602A)]  
M25PE10@SOIC8(ISP) [ISP-HEADER01]  
M25PE10@VQFPN8 [(SA683)]  
M25PE10@VQFPN8(ISP) [ISP-HEADER01]  
M25PE16@SOIC8 [(SA023A)]          M25PE16@VQFPN8 [(SA683)]  
M25PE20@SOIC8 [(SA602A)]

M25PE20@SOIC8(ISP) [ISP-HEADER01]  
M25PE20@VQFPN8 [(SA683)]  
M25PE20@VQFPN8(ISP) [ISP-HEADER01]  
M25PE40@SOIC8 [(SA023A)]  
M25PE40@SOIC8(ISP) [ISP-HEADER01]  
M25PE40@VQFPN8 [(SA683)]  
M25PE40@VQFPN8(ISP) [ISP-HEADER01]  
M25PE80@SOIC8 [(SA023A)]  
M25PE80@SOIC8(ISP) [ISP-HEADER01]  
M25PE80@VQFPN8 [(SA683)]  
M25PE80@VQFPN8(ISP) [ISP-HEADER01]  
M25PX32@SOIC16 [(SA404)]      M25PX32@SOIC8 [(SA023A)]  
M25PX32@VFQFPN8 [(SA683)]      M25PX64@SOIC16 [(SA404)]  
M25PX64@VDFPN8 [(SA684)]      M25W01  
M25W02                      M25W04  
M25W08                      M25W16  
M25W166                    M27128A  
M2716                      M2716F1  
M27256                      M27256A  
M2732A                      M27512  
M2764                      M2764A  
M27C1000                    M27C1000@PLCC32 [(SA015A1T)]  
M27C1000@TSOP32 [(SA410T)]      M27C1001  
M27C1001@PLCC32 [(SA015A1T)]      M27C1001@TSOP32 [(SA410T)]  
M27C1024                    M27C1024@PLCC44 [(SA244)]  
M27C128B                    M27C16  
M27C160                    M27C160@PLCC44 [(SA244)]  
M27C160@PSOP44 [(SA638)]      M27C160K  
M27C160K@PLCC44 [(SA244)]      M27C160K@PSOP44 [(SA638)]  
M27C2001                    M27C2001@PLCC32 [(SA015A1T)]  
M27C2001@TSOP32 [(SA410T)]      M27C202  
M27C202@PLCC44 [(SA244)]      M27C202@TSOP40 [(SA409T)]  
M27C256B                    M27C256B@PLCC32 [(SA015A1T)]  
M27C32                      M27C322  
M27C322@SDIP42 [(SA028)]      M27C400  
M27C4001                    M27C4001@PLCC32 [(SA015A1T)]  
M27C4001@TSOP32 [(SA410T)]      M27C4002  
M27C4002@PLCC44 [(SA244)]      M27C405  
M27C405@PLCC32 [(SA015A1T)]      M27C405@TSOP32 [(SA410T)]  
M27C512                    M27C512@PLCC32 [(SA015A1T)]  
M27C513                    M27C516  
M27C516@PLCC44 [(SA244)]      M27C64A  
M27C64A@PLCC32 [(SA015A1T)]      M27C800

M27C800@PLCC44 [(SA244)]      M27C800@PSOP44 [(SA638)]  
M27C801      M27C801@PLCC32 [(SA015A1T)]  
M27C801@TSOP32 [(SA410T)]      M27HC641  
M27HC641@PLCC28 [(SA008A)]      M27HC642  
M27HC642@PLCC28 [(SA008A)]      M27V101  
M27V101@PLCC32 [(SA015A1T)]      M27V101@TSOP32 [(SA410T)]  
M27V102      M27V102@PLCC44 [(SA244)]  
M27V160      M27V160@PLCC44 [(SA244)]  
M27V160@PSOP44 [(SA638)]      M27V160K  
M27V160K@PLCC44 [(SA244)]      M27V160K@PSOP44 [(SA638)]  
M27V201      M27V201@PLCC32 [(SA015A1T)]  
M27V201@TSOP32 [(SA410T)]      M27V256  
M27V322      M27V322@SDIP42 [(SA028)]  
M27V401      M27V401@PLCC32 [(SA015A1T)]  
M27V401@TSOP32 [(SA410T)]      M27V402  
M27V402@PLCC44 [(SA244)]      M27V402@TSOP40 [(SA409T)]  
M27V405      M27V405@PLCC32 [(SA015A1T)]  
M27V405@TSOP32 [(SA410T)]      M27V512  
M27V512@PLCC32 [(SA015A1T)]      M27V512@TSOP28 [(SA430T)]  
M27V800      M27V800@PLCC44 [(SA244)]  
M27V801      M27V801@PLCC32 [(SA015A1T)]  
M27V801@TSOP32 [(SA410T)]      M27W016@PSOP44 [(SA638)]  
M27W016@TSOP48 [(SA247-B005)]      M27W032@PSOP44 [(SA638)]  
M27W032@TSOP48 [(SA247-B005)]      M27W064@PSOP44 [(SA638)]  
M27W064@TSOP48 [(SA247-B005)]      M27W101  
M27W101@PLCC32 [(SA015A1T)]      M27W101@TSOP32 [(SA410T)]  
M27W102      M27W102@PLCC44 [(SA244)]  
M27W160      M27W160@PLCC44 [(SA244)]  
M27W160@PSOP44 [(SA638)]      M27W201  
M27W201@PLCC32 [(SA015A1T)]      M27W201@TSOP32 [(SA410T)]  
M27W202      M27W202@PLCC44 [(SA244)]  
M27W202@TSOP40 [(SA409T)]      M27W400  
M27W400@PLCC44 [(SA244)]      M27W401  
M27W401@PLCC32 [(SA015A1T)]      M27W401@TSOP32 [(SA410T)]  
M27W402      M27W402@PLCC44 [(SA244)]  
M27W402@TSOP40 [(SA409T)]      M27W512  
M27W512@PLCC32 [(SA015A1T)]      M27W512@TSOP28 [(SA430T)]  
M27W800      M27W800@PLCC44 [(SA244)]  
M27W801      M27W801@PLCC32 [(SA015A1T)]  
M27W801@TSOP32 [(SA410T)]      M28010  
M28010@PLCC32 [(SA015A1T)]      M28010@TSOP32 [(SA410T)]  
M28010R      M28010R@PLCC32 [(SA015A1T)]  
M28010R@TSOP32 [(SA410T)]      M28010W

M28010W@PLCC32 [(SA015A1T)] M28010W@TSOP32 [(SA410T)]  
M28256 M28256@PLCC32 [(SA015A1T)]  
M28256@TSOP28 [(SA430T)] M28C010  
M28C010@PLCC32 [(SA015A1T)] M28C010@TSOP32 [(SA410T)]  
M28C010R M28C010R@PLCC32 [(SA015A1T)]  
M28C010R@TSOP32 [(SA410T)] M28C010W  
M28C010W@PLCC32 [(SA015A1T)] M28C010W@TSOP32 [(SA410T)]  
M28C16@PLCC32 [(SA015A1T)] M28C17@SOIC28 [(SA404)]  
M28C64 M28C64@PLCC32 [(SA015A1T)]  
M28C64@TSOP28 [(SA430T)] M28C64C  
M28C64C@PLCC32 [(SA015A1T)] M28C64C@SOIC28 [(SA404)]  
M28C64C@TSOP28 [(SA430T)] M28C64X  
M28C64X@PLCC32 [(SA015A1T)] M28C64X@TSOP28 [(SA430T)]  
M28F101 M28F101@PLCC32 [(SA015A1T)]  
M28F101@TSOP32 [(SA410T)] M28F102  
M28F102@PLCC44 [(SA244)] M28F102@TSOP40 [(SA409T)]  
M28F151 M28F151@PLCC32 [(SA015A1T)]  
M28F151@TSOP32 [(SA410T)] M28F201  
M28F201@PLCC32 [(SA015A1T)] M28F201@TSOP32 [(SA410T)]  
M28F211@TSOP40 [(SA409T)] M28F220@PSOP44 [(SA638)]  
M28F220@TSOP48 [(SA247-B005)] M28F221@TSOP40 [(SA409T)]  
M28F256 M28F256@PLCC32 [(SA015A1T)]  
M28F256@TSOP32 [(SA410T)] M28F411@TSOP40 [(SA409T)]  
M28F421@TSOP40 [(SA409T)] M28F512  
M28F512@PLCC32 [(SA015A1T)] M28F512@TSOP32 [(SA410T)]  
M28LV64 M28LV64@PLCC32 [(SA015A1T)]  
M28LV64@TSOP28 [(SA430T)]  
M28R400CB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28R400CT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28V411@TSOP40 [(SA409T)] M28V421@TSOP40 [(SA409T)]  
M28W160B@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160B@TSOP48 [(SA247-B005)]  
M28W160BB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160BB@TSOP48 [(SA247-B005)]  
M28W160BT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160BT@TSOP48 [(SA247-B005)]  
M28W160CB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160CB@TSOP48 [(SA247-B005)]  
M28W160CT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160CT@TSOP48 [(SA247-B005)]  
M28W160ECB@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W160ECB@TSOP48 [(SA247-B005)]  
M28W160ECT@FBGA48 [(SA634A-B005A-Y048F001Y)]

M28W160ECT@TSOP48 [(SA247-B005)]  
M28W160T@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W160T@TSOP48 [(SA247-B005)]  
M28W320CB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W320CB@TSOP48 [(SA247-B005)]  
M28W320CT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W320CT@TSOP48 [(SA247-B005)]  
M28W320ECB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W320ECB@TSOP48 [(SA247-B005)]  
M28W320ECT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W320ECT@TSOP48 [(SA247-B005)]  
M28W320FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W320FCB@TSOP48 [(SA247-B005)]  
M28W320FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W320FCT@TSOP48 [(SA247-B005)]  
M28W320FSB@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320FSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FST@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320FST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSB@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HST@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSU@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640ECB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W640ECB@TSOP48 [(SA247-B005)]  
M28W640ECT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W640ECT@TSOP48 [(SA247-B005)]  
M28W640FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W640FCB@TSOP48 [(SA247-B005)]  
M28W640FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W640FCT@TSOP48 [(SA247-B005)]  
M28W640FSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640FST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640FSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640HSB@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640HST@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HST@FBGA64 [(SA655E-B090A-T064F001Y)]

M28W640HSU@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W800B@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800B@TSOP48 [(SA247-B005)]  
M28W800BB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800BB@TSOP48 [(SA247-B005)]  
M28W800BT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800BT@TSOP48 [(SA247-B005)]  
M28W800CB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800CB@TSOP48 [(SA247-B005)]  
M28W800CT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800CT@TSOP48 [(SA247-B005)]  
M28W800T@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800T@TSOP48 [(SA247-B005)]  
M29DW128F@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29DW128F@TSOP56 [(SA628-B102)]  
M29DW323DB@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW323DB@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW323DB@TSOP48 [(SA247-B005)]  
M29DW323DT@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW323DT@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW323DT@TSOP48 [(SA247-B005)]  
M29DW324DB@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DB@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DB@TSOP48 [(SA247-B005)]  
M29DW324DT@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DT@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DT@TSOP48 [(SA247-B005)]  
M29DW640D@FBGA63 [(SA642E-B026A-T072F001N)]  
M29DW640D@TSOP48 [(SA247-B005)]  
M29DW640F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW640F@TSOP48 [(SA247-B005)]  
M29DW641F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW641F@TSOP48 [(SA247-B005)] M29F002B  
M29F002B@PLCC32 [(SA015A1T)] M29F002B@TSOP32 [(SA410T)]  
M29F002BB M29F002BB@PLCC32 [(SA015A1T)]  
M29F002BB@TSOP32 [(SA410T)] M29F002BNT  
M29F002BNT@PLCC32 [(SA015A1T)] M29F002BNT@TSOP32 [(SA410T)]  
M29F002BT M29F002BT@PLCC32 [(SA015A1T)]  
M29F002BT@TSOP32 [(SA410T)] M29F002T  
M29F002T@PLCC32 [(SA015A1T)] M29F002T@TSOP32 [(SA410T)]  
M29F010B M29F010B@PLCC32 [(SA015A1T)]  
M29F010B@TSOP32 [(SA410T)] M29F016B@PSOP44 [(SA638)]



M29F016B@TSOP40 [(SA409T)] M29F016D@PSOP44 [(SA638)]  
M29F016D@TSOP40 [(SA409T)] M29F032D@TSOP40 [(SA409T)]  
M29F040 M29F040@PLCC32 [(SA015A1T)]  
M29F040@TSOP32 [(SA410T)] M29F040B  
M29F040B@PLCC32 [(SA015A1T)] M29F040B@TSOP32 [(SA410T)]  
M29F080A@PSOP44 [(SA638)] M29F080A@TSOP40 [(SA409T)]  
M29F080D@PSOP44 [(SA638)] M29F080D@TSOP40 [(SA409T)]  
M29F100B@PSOP44 [(SA638-B006)] M29F100B@TSOP48 [(SA247-B005)]  
M29F100T@PSOP44 [(SA638-B006)] M29F100T@TSOP48 [(SA247-B005)]  
M29F102B@PLCC44 [(SA244)] M29F102B@TSOP40 [(SA623)]  
M29F102BB@PLCC44 [(SA244)] M29F102BB@TSOP40 [(SA623)]  
M29F160BB@TSOP48 [(SA247-B005)] M29F160BT@TSOP48 [(SA247-B005)]  
M29F200B@PSOP44 [(SA638-B006)] M29F200B@TSOP48 [(SA247-B005)]  
M29F200BB@PSOP44 [(SA638-B006)] M29F200BB@TSOP48 [(SA247-B005)]  
M29F200BT@PSOP44 [(SA638-B006)] M29F200BT@TSOP48 [(SA247-B005)]  
M29F200T@PSOP44 [(SA638-B006)] M29F200T@TSOP48 [(SA247-B005)]  
M29F400B@PSOP44 [(SA638-B006)] M29F400B@TSOP48 [(SA247-B005)]  
M29F400BB@PSOP44 [(SA638-B006)] M29F400BB@TSOP48 [(SA247-B005)]  
M29F400BT@PSOP44 [(SA638-B006)] M29F400BT@TSOP48 [(SA247-B005)]  
M29F400T@PSOP44 [(SA638-B006)] M29F400T@TSOP48 [(SA247-B005)]  
M29F512B@PLCC32 [(SA015A1T)] M29F512B@TSOP32 [(SA620)]  
M29F800AB@PSOP44 [(SA638-B006)] M29F800AB@TSOP48 [(SA247-B005)]  
M29F800AT@PSOP44 [(SA638-B006)] M29F800AT@TSOP48 [(SA247-B005)]  
M29F800DB@PSOP44 [(SA638)] M29F800DB@TSOP48 [(SA247-B005)]  
M29F800DT@PSOP44 [(SA638)] M29F800DT@TSOP48 [(SA247-B005)]  
M29KW016E@PSOP44 [(SA638)]  
M29KW016E@TFBGA48 [(SA642E-B026A-T072F001)]  
M29KW016E@TSOP48 [(SA247-B005)]  
M29KW032E@TFBGA48 [(SA642E-B026A-T072F001)]  
M29KW032E@TSOP48 [(SA247-B005)]  
M29KW064E@TFBGA48 [(SA642E-B026A-T072F001)]  
M29KW064E@TSOP48 [(SA247-B005)] M29V040@PLCC32 [(SA015A1T)]  
M29V040@TSOP32 [(SA410T)] M29W004B@TSOP40 [(SA409T)]  
M29W004BB@TSOP40 [(SA409T)] M29W004BT@TSOP40 [(SA409T)]  
M29W004T@TSOP40 [(SA409T)] M29W008AB@TSOP40 [(SA409T)]  
M29W008AT@TSOP40 [(SA409T)] M29W008B@TSOP40 [(SA409T)]  
M29W008T@TSOP40 [(SA409T)] M29W010B@PLCC32 [(SA015A1T)]  
M29W010B@TSOP32 [(SA410T)]  
M29W017D@TFBGA48 [(SA642B-B026A-Y072F001)]  
M29W017D@TSOP40 [(SA409T)] M29W022BB  
M29W022BB@PLCC32 [(SA015A1T)] M29W022BB@TSOP32 [(SA410T)]  
M29W022BT M29W022BT@PLCC32 [(SA015A1T)]  
M29W022BT@TSOP32 [(SA410T)] M29W040@PLCC32 [(SA015A1T)]

M29W040@TSOP32 [(SA410T)]      M29W040B@PLCC32 [(SA015A1T)]  
M29W040B@TSOP32 [(SA410T)]      M29W102BB@TSOP40 [(SA623)]  
M29W102BT@TSOP40 [(SA623)]      M29W116BB@TSOP40 [(SA409T)]  
M29W116BT@TSOP40 [(SA409T)]  
M29W128FH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128FH@TSOP56 [(SA628-B102)]  
M29W128FL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128FL@TSOP56 [(SA628-B102)]  
M29W128GH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128GH@TSOP56 [(SA628-B102)]  
M29W128GL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128GL@TSOP56 [(SA628-B102)]  
M29W128GSH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128GSH@TSOP56 [(SA628-B102)]  
M29W128GSL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W128GSL@TSOP56 [(SA628-B102)]  
M29W160BB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160BB@PSOP44 [(SA638)]      M29W160BB@TSOP48 [(SA247-B005)]  
M29W160BT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160BT@PSOP44 [(SA638)]      M29W160BT@TSOP48 [(SA247-B005)]  
M29W160DB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160DB@PSOP44 [(SA638)]      M29W160DB@TSOP48 [(SA247-B005)]  
M29W160DT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160DT@PSOP44 [(SA638)]      M29W160DT@TSOP48 [(SA247-B005)]  
M29W160EB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160EB@PSOP44 [(SA638)]      M29W160EB@TSOP48 [(SA247-B005)]  
M29W160ET@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W160ET@PSOP44 [(SA638)]      M29W160ET@TSOP48 [(SA247-B005)]  
M29W160FB@TSOP48 [(SA247-B005)]      M29W160FT@TSOP48 [(SA247-B005)]  
M29W200BB@PSOP44 [(SA638)]      M29W200BB@TSOP48 [(SA247-B005)]  
M29W200BT@PSOP44 [(SA638)]      M29W200BT@TSOP48 [(SA247-B005)]  
M29W320DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W320DB@FBGA63 [(SA642DD-B026A-W063F001Y)]  
M29W320DB@TSOP48 [(SA247-B005)]  
M29W320DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W320DT@FBGA63 [(SA642DD-B026A-W063F001Y)]  
M29W320DT@TSOP48 [(SA247-B005)]  
M29W320EB@FBGA48 [(SA642G-B026A-T048F001)]  
M29W320EB@TSOP48 [(SA247-B005)]  
M29W320ET@FBGA48 [(SA642G-B026A-T048F001)]  
M29W320ET@TSOP48 [(SA247-B005)]      M29W400B@PSOP44 [(SA638)]  
M29W400B@TSOP48 [(SA247-B005)]  
M29W400BB@LBGA48 [(SA642G-B026A-T048F001Y)]

M29W400BB@PSOP44 [(SA638)]      M29W400BB@TSOP48 [(SA247-B005)]  
M29W400BT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400BT@PSOP44 [(SA638)]      M29W400BT@TSOP48 [(SA247-B005)]  
M29W400DB(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]  
M29W400DB(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400DB@PSOP44 [(SA638)]      M29W400DB@TSOP48 [(SA247-B005)]  
M29W400DT(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]  
M29W400DT(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400DT@PSOP44 [(SA638)]      M29W400DT@TSOP48 [(SA247-B005)]  
M29W400T@PSOP44 [(SA638)]      M29W400T@TSOP48 [(SA247-B005)]  
M29W512B@PLCC32 [(SA015A1T)]      M29W512B@TSOP32 [(SA620)]  
M29W640DB@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DB@TSOP48 [(SA247-B005)]  
M29W640DT@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DT@TSOP48 [(SA247-B005)]  
M29W640FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FB@TSOP48 [(SA247-B005)]  
M29W640FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FT@TSOP48 [(SA247-B005)]  
M29W640GB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GB@TSOP48 [(SA247-B005)]      M29W640GB@TSOP56 [(SA628-B102)]  
M29W640GH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GH@TSOP48 [(SA247-B005)]      M29W640GH@TSOP56 [(SA628-B102)]  
M29W640GL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GL@TSOP48 [(SA247-B005)]      M29W640GL@TSOP56 [(SA628-B102)]  
M29W640GSB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSB@TSOP48 [(SA247-B005)]      M29W640GSB@TSOP56 [(SA628-B102)]  
M29W640GSH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSH@TSOP48 [(SA247-B005)]      M29W640GSH@TSOP56 [(SA628-B102)]  
M29W640GSL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSL@TSOP48 [(SA247-B005)]      M29W640GSL@TSOP56 [(SA628-B102)]  
M29W640GST@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GST@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GST@TSOP48 [(SA247-B005)]      M29W640GST@TSOP56 [(SA628-B102)]  
M29W640GT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GT@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GT@TSOP48 [(SA247-B005)]      M29W640GT@TSOP56 [(SA628-B102)]

M29W641DH@TSOP48 [(SA247-B005)] M29W641DL@TSOP48 [(SA247-B005)]  
M29W641DU@FBGA63 [(SA642E-B026A-T072F001)]  
M29W800AB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AB@PSOP44 [(SA638)] M29W800AB@TSOP48 [(SA247-B005)]  
M29W800AT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AT@PSOP44 [(SA638)] M29W800AT@TSOP48 [(SA247-B005)]  
M29W800B@PSOP44 [(SA638)] M29W800B@TSOP48 [(SA247-B005)]  
M29W800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DB@PSOP44 [(SA638)] M29W800DB@TSOP48 [(SA247-B005)]  
M29W800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DT@PSOP44 [(SA638)] M29W800DT@TSOP48 [(SA247-B005)]  
M29W800T@PSOP44 [(SA638)] M29W800T@TSOP48 [(SA247-B005)]  
M30L0R7000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R7000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30W0R6600T0@LFBGA88 [(SA642A-B061A-Y096F001)]  
M30WR128B@LFBGA88 [(SA642A-B061A-Y096F001)]  
M34C02 M34C02@MSOP8 [(SA666)]  
M34C02@SOIC8 [(SA602A)] M34C02@TSOP8 [(SA026)]  
M34D32 M34D32@SOIC8 [(SA602A)]  
M34D32@TSSOP8 [(SA026)] M34D64  
M34D64@SOIC8 [(SA602A)] M34D64@TSSOP8 [(SA026)]  
M34E02 M34E02@MSOP8 [(SA666)]  
M34E02@SOIC8 [(SA602A)] M34E02@TSOP8 [(SA026)]  
M35080 M35080@SOIC8 [(SA602A)]  
M36A0W5020B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5020T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]

M36D0R6040B0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36LLR8760B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860D1@FBGA88 [(SA642R-B113A-T096F001Y)]

M36LLR8860M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870D0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870D1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870M0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870M1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870T0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870T1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36W0R5020B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040U5@TFBGA88 [(SA642R-B180-T096F001Y)]

M36W0R6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050L0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050U0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W216BI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W216TI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432BG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432TG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M45PE10@SOIC8 [(SA602A)]            M45PE10@VQFPN8 [(SA683)]  
M45PE16@SOIC8 [(SA023A)]           M45PE16@VQFPN8 [(SA683)]  
M45PE20@SOIC8 [(SA602A)]  
M45PE20@SOIC8(ISP) [ISP-HEADER01]  
M45PE20@VQFPN8 [(SA683)]  
M45PE20@VQFPN8(ISP) [ISP-HEADER01]  
M45PE40@SOIC8 [(SA023A)]  
M45PE40@SOIC8(ISP) [ISP-HEADER01]  
M45PE40@VQFPN8 [(SA683)]  
M45PE40@VQFPN8(ISP) [ISP-HEADER01]  
M45PE80@SOIC16 [(SA023A)]  
M45PE80@SOIC16(ISP) [ISP-HEADER01]  
M45PE80@SOIC8 [(SA023A)]  
M45PE80@SOIC8(ISP) [ISP-HEADER01]  
M45PE80@VQFPN8 [(SA683)]

## M45PE80@VQFPN8(ISP) [ISP-HEADER01]

M48C02	M48C02B
M48C12	M48C12B
M48T02	M48T02B
M48T08	M48T12
M48T128V	M48T128Y
M48T129V	M48T129Y
M48T12B	M48T18
M48T30	M48T30Y
M48T32	M48T32Y
M48T35	M48T35@SOIC28 [(SA404)]
M48T35AV	M48T35AV@SOIC28 [(SA630)]
M48T35AY	M48T35AY@SOIC28 [(SA630)]
M48T35Y	M48T35Y@SOIC28 [(SA404)]
M48T512AV	M48T512AY
M48T512V	M48T512Y
M48T513V	M48T513Y
M48T559	M48T559@SOIC28 [(SA630)]
M48T559Y	M48T559Y@SOIC28 [(SA630)]
M48T58	M48T58@SOIC28 [(SA404)]
M48T58Y	M48T58Y@SOIC28 [(SA404)]
M48T59	M48T59@SOIC28 [(SA404)]
M48T59V	M48T59V@SOIC28 [(SA404)]
M48T59Y	M48T59Y@SOIC28 [(SA404)]
M48Z02	M48Z02B
M48Z08	M48Z09
M48Z12	M48Z128
M48Z128V	M48Z128Y
M48Z129V	M48Z129Y
M48Z12B	M48Z18
M48Z19	M48Z30
M48Z30Y	M48Z32
M48Z32Y	M48Z35
M48Z35@SOIC28 [(SA630)]	M48Z35Y
M48Z35Y@SOIC28 [(SA630)]	M48Z512AV
M48Z512AY	M48Z512V
M48Z512Y	M48Z513V
M48Z513Y	M48Z58
M48Z58@SOIC28 [(SA404)]	M48Z58Y
M48Z58Y@SOIC28 [(SA404)]	M48Z59
M48Z59@SOIC28 [(SA404)]	M48Z59W
M48Z59W@SOIC28 [(SA404)]	M48Z59Y
M48Z59Y@SOIC28 [(SA404)]	M50FLW040A@PLCC32 [(SA015A1T)]



M50FLW040A@TSOP40 [(SA409T)] M50FLW040A@VSOP32 [(SA620)]  
M50FLW040B@PLCC32 [(SA015A1T)] M50FLW040B@TSOP40 [(SA409T)]  
M50FLW040B@VSOP32 [(SA620)] M50FLW080A@PLCC32 [(SA015A1T)]  
M50FLW080A@TSOP40 [(SA409T)] M50FLW080A@VSOP32 [(SA620)]  
M50FLW080B@PLCC32 [(SA015A1T)] M50FLW080B@TSOP40 [(SA409T)]  
M50FLW080B@VSOP32 [(SA620)] M50FW002@PLCC32 [(SA015A1T)]  
M50FW016@TSOP40 [(SA409T)] M50FW020@PLCC32 [(SA015A1T)]  
M50FW040@PLCC32 [(SA015A1T)] M50FW040@TSOP40 [(SA409T)]  
M50FW080@PLCC32 [(SA015A1T)] M50FW080@TSOP40 [(SA409T)]  
M50FW080@VSOP32 [(SA620)] M50LPW002@PLCC32 [(SA015A1T)]  
M50LPW012@PLCC32 [(SA015A1T)] M50LPW020@PLCC32 [(SA015A1T)]  
M50LPW040@PLCC32 [(SA015A1T)] M50LPW040@TSOP40 [(SA409T)]  
M50LPW041@PLCC32 [(SA015A1T)] M50LPW041@TSOP40 [(SA409T)]  
M50LPW080@PLCC32 [(SA015A1T)] M50LPW080@TSOP40 [(SA409T)]  
M50LPW116@TSOP40 [(SA409T)]  
M58LR128FB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128FT@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GT@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LT128GB@FBGA56 [(SA644A-B025B-Y072F001Y)]  
M58LT128GSB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT128GST@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT128GT@FBGA56 [(SA644A-B025B-Y072F001Y)]  
M58LT256GB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256GT@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256JSB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256JST@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LW032A@TSOP56 [(SA628-B031)]  
M58LW032C@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW032C@TSOP56 [(SA628-B031)]  
M58LW032D@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW032D@TSOP56 [(SA628-B018)]  
M58LW064C@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW064C@TSOP56 [(SA628-B063)]  
M58LW064D@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW064D@TSOP56 [(SA628-B018)] M58LW128A@TSOP56 [(SA628-B018)]  
M58WR016QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR016QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]

M58WR032EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008E@TSOP48 [(SA247-B005)]  
M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008F@TSOP48 [(SA247-B005)]  
M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59PW016@PSOP44 [(SA638)] M59PW016@SDIP42 [(SA028)]  
M59PW016@TSOP48 [(SA247-B005)] M59PW032@PSOP44 [(SA638)]  
M59PW032@PSOP44(Fast) [(SA638+B006)]  
M59PW032@TSOP48 [(SA247-B005)] M59PW064@PSOP44 [(SA638)]  
M59PW1282@PSOP44 [(SA638)]  
M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]  
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]

M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M87C257 M87C257@PLCC32 [(SA015A1T)]  
M93C06(08bit) M93C06(08bit)@SOIC8 [(SA602A)]  
M93C06(16bit) M93C06(16bit)@SOIC8 [(SA602A)]  
M93C46(08bit) M93C46(08bit)@MLP8 [(SA694)]  
M93C46(08bit)@MSOP8 [(SA666)] M93C46(08bit)@SOIC8 [(SA602A)]  
M93C46(08bit)@TSSOP8 [(SA026)] M93C46(16bit)  
M93C46(16bit)@MLP8 [(SA694)] M93C46(16bit)@MSOP8 [(SA666)]  
M93C46(16bit)@SOIC8 [(SA602A)] M93C46(16bit)@TSSOP8 [(SA026)]  
M93C46R(08bit) M93C46R(08bit)@MLP8 [(SA694)]  
M93C46R(08bit)@MSOP8 [(SA666)] M93C46R(08bit)@SOIC8 [(SA602A)]  
M93C46R(08bit)@TSSOP8 [(SA026)] M93C46R(16bit)  
M93C46R(16bit)@MLP8 [(SA694)] M93C46R(16bit)@MSOP8 [(SA666)]  
M93C46R(16bit)@SOIC8 [(SA602A)] M93C46R(16bit)@TSSOP8 [(SA026)]  
M93C46W(08bit) M93C46W(08bit)@MLP8 [(SA694)]  
M93C46W(08bit)@MSOP8 [(SA666)] M93C46W(08bit)@SOIC8 [(SA602A)]  
M93C46W(08bit)@TSSOP8 [(SA026)] M93C46W(16bit)  
M93C46W(16bit)@MLP8 [(SA694)] M93C46W(16bit)@MSOP8 [(SA666)]  
M93C46W(16bit)@SOIC8 [(SA602A)] M93C46W(16bit)@TSSOP8 [(SA026)]  
M93C56(08bit) M93C56(08bit)@MLP8 [(SA694)]  
M93C56(08bit)@MSOP8 [(SA666)] M93C56(08bit)@SOIC8 [(SA602A)]  
M93C56(08bit)@TSSOP8 [(SA026)] M93C56(16bit)  
M93C56(16bit)@MLP8 [(SA694)] M93C56(16bit)@MSOP8 [(SA666)]  
M93C56(16bit)@SOIC8 [(SA602A)] M93C56(16bit)@TSSOP8 [(SA026)]  
M93C56R(08bit) M93C56R(08bit)@MLP8 [(SA694)]  
M93C56R(08bit)@MSOP8 [(SA666)] M93C56R(08bit)@SOIC8 [(SA602A)]  
M93C56R(08bit)@TSSOP8 [(SA026)] M93C56R(16bit)  
M93C56R(16bit)@MLP8 [(SA694)] M93C56R(16bit)@MSOP8 [(SA666)]  
M93C56R(16bit)@SOIC8 [(SA602A)] M93C56R(16bit)@TSSOP8 [(SA026)]  
M93C56W(08bit) M93C56W(08bit)@MLP8 [(SA694)]  
M93C56W(08bit)@MSOP8 [(SA666)] M93C56W(08bit)@SOIC8 [(SA602A)]  
M93C56W(08bit)@TSSOP8 [(SA026)] M93C56W(16bit)  
M93C56W(16bit)@MLP8 [(SA694)] M93C56W(16bit)@MSOP8 [(SA666)]  
M93C56W(16bit)@SOIC8 [(SA602A)] M93C56W(16bit)@TSSOP8 [(SA026)]  
M93C66(08bit) M93C66(08bit)@MLP8 [(SA694)]  
M93C66(08bit)@MSOP8 [(SA666)] M93C66(08bit)@SOIC8 [(SA602A)]  
M93C66(08bit)@TSSOP8 [(SA026)] M93C66(16bit)

M93C66(16bit)@MLP8 [(SA694)]      M93C66(16bit)@MSOP8 [(SA666)]  
M93C66(16bit)@SOIC8 [(SA602A)]      M93C66(16bit)@TSSOP8 [(SA026)]  
M93C66R(08bit)                      M93C66R(08bit)@MLP8 [(SA694)]  
M93C66R(08bit)@MSOP8 [(SA666)]      M93C66R(08bit)@SOIC8 [(SA602A)]  
M93C66R(08bit)@TSSOP8 [(SA026)]      M93C66R(16bit)  
M93C66R(16bit)@MLP8 [(SA694)]      M93C66R(16bit)@MSOP8 [(SA666)]  
M93C66R(16bit)@SOIC8 [(SA602A)]      M93C66R(16bit)@TSSOP8 [(SA026)]  
M93C66W(08bit)                      M93C66W(08bit)@MLP8 [(SA694)]  
M93C66W(08bit)@MSOP8 [(SA666)]      M93C66W(08bit)@SOIC8 [(SA602A)]  
M93C66W(08bit)@TSSOP8 [(SA026)]      M93C66W(16bit)  
M93C66W(16bit)@MLP8 [(SA694)]      M93C66W(16bit)@MSOP8 [(SA666)]  
M93C66W(16bit)@SOIC8 [(SA602A)]      M93C66W(16bit)@TSSOP8 [(SA026)]  
M93C76(08bit)                      M93C76(08bit)@MLP8 [(SA694)]  
M93C76(08bit)@MSOP8 [(SA666)]      M93C76(08bit)@SOIC8 [(SA602A)]  
M93C76(08bit)@TSSOP8 [(SA026)]      M93C76(16bit)  
M93C76(16bit)@MLP8 [(SA694)]      M93C76(16bit)@MSOP8 [(SA666)]  
M93C76(16bit)@SOIC8 [(SA602A)]      M93C76(16bit)@TSSOP8 [(SA026)]  
M93C76R(08bit)                      M93C76R(08bit)@MLP8 [(SA694)]  
M93C76R(08bit)@MSOP8 [(SA666)]      M93C76R(08bit)@SOIC8 [(SA602A)]  
M93C76R(08bit)@TSSOP8 [(SA026)]      M93C76R(16bit)  
M93C76R(16bit)@MLP8 [(SA694)]      M93C76R(16bit)@MSOP8 [(SA666)]  
M93C76R(16bit)@SOIC8 [(SA602A)]      M93C76R(16bit)@TSSOP8 [(SA026)]  
M93C76W(08bit)                      M93C76W(08bit)@MLP8 [(SA694)]  
M93C76W(08bit)@MSOP8 [(SA666)]      M93C76W(08bit)@SOIC8 [(SA602A)]  
M93C76W(08bit)@TSSOP8 [(SA026)]      M93C76W(16bit)  
M93C76W(16bit)@MLP8 [(SA694)]      M93C76W(16bit)@MSOP8 [(SA666)]  
M93C76W(16bit)@SOIC8 [(SA602A)]      M93C76W(16bit)@TSSOP8 [(SA026)]  
M93C86(08bit)                      M93C86(08bit)@MLP8 [(SA694)]  
M93C86(08bit)@MSOP8 [(SA666)]      M93C86(08bit)@SOIC8 [(SA602A)]  
M93C86(08bit)@TSSOP8 [(SA026)]      M93C86(16bit)  
M93C86(16bit)@MLP8 [(SA694)]      M93C86(16bit)@MSOP8 [(SA666)]  
M93C86(16bit)@SOIC8 [(SA602A)]      M93C86(16bit)@TSSOP8 [(SA026)]  
M93C86R(08bit)                      M93C86R(08bit)@MLP8 [(SA694)]  
M93C86R(08bit)@MSOP8 [(SA666)]      M93C86R(08bit)@SOIC8 [(SA602A)]  
M93C86R(08bit)@TSSOP8 [(SA026)]      M93C86R(16bit)  
M93C86R(16bit)@MLP8 [(SA694)]      M93C86R(16bit)@MSOP8 [(SA666)]  
M93C86R(16bit)@SOIC8 [(SA602A)]      M93C86R(16bit)@TSSOP8 [(SA026)]  
M93C86W(08bit)                      M93C86W(08bit)@MLP8 [(SA694)]  
M93C86W(08bit)@MSOP8 [(SA666)]      M93C86W(08bit)@SOIC8 [(SA602A)]  
M93C86W(08bit)@TSSOP8 [(SA026)]      M93C86W(16bit)  
M93C86W(16bit)@MLP8 [(SA694)]      M93C86W(16bit)@MSOP8 [(SA666)]  
M93C86W(16bit)@SOIC8 [(SA602A)]      M93C86W(16bit)@TSSOP8 [(SA026)]  
M93CS566                              M93CS566@SOIC8 [(SA602A)]

M93S46 M93S46@SOIC8 [(SA602A)]  
M93S46@TSSOP8 [(SA026)] M93S46R  
M93S46R@SOIC8 [(SA602A)] M93S46R@TSSOP8 [(SA026)]  
M93S46W M93S46W@SOIC8 [(SA602A)]  
M93S46W@TSSOP8 [(SA026)] M93S56  
M93S56@SOIC8 [(SA602A)] M93S56@TSSOP8 [(SA026)]  
M93S56R M93S56R@SOIC8 [(SA602A)]  
M93S56R@TSSOP8 [(SA026)] M93S56W  
M93S56W@SOIC8 [(SA602A)] M93S56W@TSSOP8 [(SA026)]  
M93S66 M93S66@SOIC8 [(SA602A)]  
M93S66@TSSOP8 [(SA026)] M93S66R  
M93S66R@SOIC8 [(SA602A)] M93S66R@TSSOP8 [(SA026)]  
M93S66W M93S66W@SOIC8 [(SA602A)]  
M93S66W@TSSOP8 [(SA026)] M95010  
M95010(ISP) [ISP-HEADER01] M95010@SOIC8 [(SA602A)]  
M95010@SOIC8(ISP) [ISP-HEADER01] M95010@TSSOP8 [(SA026)]  
M95010@TSSOP8(ISP) [ISP-HEADER01]  
M95020 M95020(ISP) [ISP-HEADER01]  
M95020@SOIC8 [(SA602A)] M95020@SOIC8(ISP) [ISP-HEADER01]  
M95020@TSSOP8 [(SA026)]  
M95020@TSSOP8(ISP) [ISP-HEADER01]  
M95040 M95040(ISP) [ISP-HEADER01]  
M95040@SOIC8 [(SA602A)] M95040@SOIC8(ISP) [ISP-HEADER01]  
M95040@TSSOP8 [(SA026)]  
M95040@TSSOP8(ISP) [ISP-HEADER01]  
M95080 M95080(ISP) [ISP-HEADER01]  
M95080@SOIC8 [(SA602A)] M95080@SOIC8(ISP) [ISP-HEADER01]  
M95080@TSSOP14 [(SA026)]  
M95080@TSSOP14(ISP) [ISP-HEADER01]  
M95080@TSSOP8 [(SA026)]  
M95080@TSSOP8(ISP) [ISP-HEADER01]  
M95128 M95128(ISP) [ISP-HEADER01]  
M95128@TSSOP14 [(SA026)]  
M95128@TSSOP14(ISP) [ISP-HEADER01]  
M95128@TSSOP8 [(SA026)]  
M95128@TSSOP8(ISP) [ISP-HEADER01]  
M95128[150mil]@SOIC8 [(SA602A)]  
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]  
M95128[200mil]@SOIC8 [(SA023A)]  
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95160 M95160(ISP) [ISP-HEADER01]  
M95160@SOIC8 [(SA602A)] M95160@SOIC8(ISP) [ISP-HEADER01]  
M95160@TSSOP14 [(SA026)]

M95160@TSSOP14(ISP) [ISP-HEADER01]  
M95160@TSSOP8 [(SA026)]  
M95160@TSSOP8(ISP) [ISP-HEADER01]  
M95256 M95256(ISP) [ISP-HEADER01]  
M95256@TSSOP14 [(SA026)]  
M95256@TSSOP14(ISP) [ISP-HEADER01]  
M95256@TSSOP8 [(SA026)]  
M95256@TSSOP8(ISP) [ISP-HEADER01]  
M95256[150mil]@SOIC8 [(SA602A)]  
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]  
M95256[200mil]@SOIC8 [(SA023A)]  
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95320 M95320(ISP) [ISP-HEADER01]  
M95320@SOIC8 [(SA602A)] M95320@SOIC8(ISP) [ISP-HEADER01]  
M95320@TSSOP14 [(SA026)]  
M95320@TSSOP14(ISP) [ISP-HEADER01]  
M95320@TSSOP8 [(SA026)]  
M95320@TSSOP8(ISP) [ISP-HEADER01]  
M95512@SOIC8 [(SA602A)] M95512@SOIC8(ISP) [ISP-HEADER01]  
M95512@TSSOP8 [(SA026)]  
M95512@TSSOP8(ISP) [ISP-HEADER01]  
M95640 M95640(ISP) [ISP-HEADER01]  
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-HEADER01]  
M95640@TSSOP14 [(SA026)]  
M95640@TSSOP14(ISP) [ISP-HEADER01]  
M95640@TSSOP8 [(SA026)]  
M95640@TSSOP8(ISP) [ISP-HEADER01]  
M95M01[150mil]@SOIC8 [(SA602A)] M95P02  
M95P02@SOIC8 [(SA602A)] M95P04  
M95P04@SOIC8 [(SA602A)] M95P08  
M95P08@SOIC8 [(SA602A)] MK48C02  
MK48C02B MK48C12  
MK48C12B MK48T02  
MK48T02B MK48T08  
MK48T12 MK48T12B  
MK48T18 MK48T32  
MK48T32Y MK48T35  
MK48T35@SOIC28 [(SA630)] MK48T35Y  
MK48T35Y@SOIC28 [(SA630)] MK48T512V  
MK48T512Y MK48Z02  
MK48Z02B MK48Z08  
MK48Z12 MK48Z12B  
MK48Z18 MK48Z32

MK48Z32Y                   MK48Z35  
MK48Z35@SOIC28 [(SA630)]       MK48Z35Y  
MK48Z35Y@SOIC28 [(SA630)]       MK48Z512V  
MK48Z512Y                   MKI48Z02  
MKI48Z02B                   MKI48Z12  
MKI48Z12B                   MKI48Z18  
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]  
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]  
NAND01GW3B2AN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]  
NAND02GR3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND02GR3B2DZA6@FBGA63 [(SA642KK-B280A-W048F001Y)]  
NAND02GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND04GW3B2BN6@TSOP48 [(SA247-B005)]  
NAND04GW3C2AN1@TSOP48 [(SA247-B005)]  
NAND08GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND128W3A0AN6@TSOP48 [(SA247-B005)]  
NAND128W3A2BN6@TSOP48 [(SA247-B005)]  
NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A0AN6@TSOP48 [(SA247-B005)]  
NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2BN6@TSOP48 [(SA247-B005)]  
NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]  
NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND512W3A0AN6@TSOP48 [(SA247-B005)]  
NAND512W3A2BN6@TSOP48 [(SA247-B005)]  
NAND512W3A2CN6@TSOP48 [(SA247-B005)]  
NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]  
ST24C01                    ST24C01@SOIC8 [(SA602A)]  
ST24C02A                   ST24C02A@SOIC8 [(SA602A)]  
ST24C16                    ST24C16@SOIC8 [(SA602A)]  
ST24FC21                   ST24FC21@SOIC8 [(SA602A)]  
ST24FW21                   ST24FW21@SOIC8 [(SA602A)]  
ST24LC21B                   ST24LC21B@SOIC8 [(SA602A)]  
ST24LW21                   ST24LW21@SOIC8 [(SA602A)]

ST24W01	ST24W01@SOIC8 [(SA602A)]
ST24W02	ST24W02@SOIC8 [(SA602A)]
ST24W04C	ST24W04C@SOIC8 [(SA602A)]
ST26C201	ST26C201@PLCC32 [(SA015A1T)]
ST26C201@TSOP32 [(SA410T)]	ST27128A
ST27256	ST2764A
ST27C256	ST93C06(08bit)
ST93C06(08bit)@SOIC8 [(SA602A)]	ST93C06(16bit)
ST93C06(16bit)@SOIC8 [(SA602A)]	ST93C46(08bit)
ST93C46(08bit)@SOIC8 [(SA602A)]	ST93C46(16bit)
ST93C46(16bit)@SOIC8 [(SA602A)]	ST93C46A(08bit)
ST93C46A(08bit)@SOIC8 [(SA602A)]	ST93C46A(16bit)
ST93C46A(16bit)@SOIC8 [(SA602A)]	ST93C46C(08bit)
ST93C46C(08bit)@SOIC8 [(SA602A)]	ST93C46C(16bit)
ST93C46C(16bit)@SOIC8 [(SA602A)]	ST93C46T(08bit)
ST93C46T(08bit)@SOIC8 [(SA602A)]	ST93C46T(16bit)
ST93C46T(16bit)@SOIC8 [(SA602A)]	ST93C47C(08bit)
ST93C47C(08bit)@SOIC8 [(SA602A)]	ST93C47C(16bit)
ST93C47C(16bit)@SOIC8 [(SA602A)]	ST93C47T(08bit)
ST93C47T(08bit)@SOIC8 [(SA602A)]	ST93C47T(16bit)
ST93C47T(16bit)@SOIC8 [(SA602A)]	ST93C56(08bit)
ST93C56(08bit)@SOIC8 [(SA602A)]	ST93C56(16bit)
ST93C56(16bit)@SOIC8 [(SA602A)]	ST93C56B(08bit)
ST93C56B(08bit)@SOIC8 [(SA602A)]	ST93C56B(16bit)
ST93C56B(16bit)@SOIC8 [(SA602A)]	ST93C56C(08bit)
ST93C56C(08bit)@SOIC8 [(SA602A)]	ST93C56C(16bit)
ST93C56C(16bit)@SOIC8 [(SA602A)]	ST93C57C(08bit)
ST93C57C(08bit)@SOIC8 [(SA602A)]	ST93C57C(16bit)
ST93C57C(16bit)@SOIC8 [(SA602A)]	ST93C66(08bit)
ST93C66(08bit)@SOIC8 [(SA602A)]	ST93C66(16bit)
ST93C66(16bit)@SOIC8 [(SA602A)]	ST93C67(08bit)
ST93C67(08bit)@SOIC8 [(SA602A)]	ST93C67(16bit)
ST93C67(16bit)@SOIC8 [(SA602A)]	ST93C76(08bit)
ST93C76(08bit)@SOIC8 [(SA602A)]	ST93C76(16bit)
ST93C76(16bit)@SOIC8 [(SA602A)]	ST93C86(08bit)
ST93C86(08bit)@SOIC8 [(SA602A)]	ST93C86(16bit)
ST93C86(16bit)@SOIC8 [(SA602A)]	ST93CS46
ST93CS46@SOIC8 [(SA602A)]	ST93CS47
ST93CS47@SOIC8 [(SA602A)]	ST93CS56
ST93CS56@SOIC8 [(SA602A)]	ST93CS566
ST93CS566@SOIC8 [(SA602A)]	ST93CS57
ST93CS57@SOIC8 [(SA602A)]	ST93CS66
ST93CS66@SOIC14 [(SA602)]	ST93CS67



ST93CS67@SOIC14 [(SA602)]      TS27C256  
 TS27C64                      TS27C64@PLCC32 [(SA015A1T)]  
 TS27C64A                    TS27C64A@PLCC32 [(SA015A1T)]  
 TS28C16A                    TS28C17A

## MICROCONTROLLER

ST62E01                      ST62E01@SOIC16 [(SA404)]  
 ST62E01CF1                ST62E18CF1  
 ST62E20                    ST62E20@SOIC20 [(SA404)]  
 ST62E20CF1                ST62E25  
 ST62E25@SOIC28 [(SA404)]      ST62E25CF1  
 ST62E28CF1                ST62E30BF1  
 ST62E32BF1@SDIP42 [(SA028)]      ST62E60B  
 ST62E60B@SOIC20 [(SA404)]      ST62E62CF1  
 ST62E65B                    ST62E65B@SOIC28 [(SA404)]  
 ST62E65CF1                ST62T00  
 ST62T00@SOIC16 [(SA404)]      ST62T00C(B6)  
 ST62T00C(M6)@SOIC16 [(SA404)]      ST62T00C(N6)@SSOP16 [(SA626A)]  
 ST62T01                    ST62T01@SOIC16 [(SA404)]  
 ST62T01C(B3)                ST62T01C(B6)  
 ST62T01C(M3)@SOIC16 [(SA404)]      ST62T01C(M6)@SOIC16 [(SA404)]  
 ST62T01C(N3)@SSOP16 [(SA626A)]      ST62T01C(N6)@SSOP16 [(SA626A)]  
 ST62T03                    ST62T03@SOIC16 [(SA404)]  
 ST62T03C(B6)                ST62T03C(M3)@SOIC16 [(SA404)]  
 ST62T03C(M6)@SOIC16 [(SA404)]      ST62T03C(N6)@SSOP16 [(SA626A)]  
 ST62T08                    ST62T08@SOIC20 [(SA404)]  
 ST62T08C(B6)                ST62T08C(M6)@SOIC20 [(SA404)]  
 ST62T09                    ST62T09@SOIC20 [(SA404)]  
 ST62T09C(B3)                ST62T09C(B6)  
 ST62T09C(M3)@SOIC20 [(SA404)]      ST62T09C(M6)@SOIC20 [(SA404)]  
 ST62T10                    ST62T10@SOIC20 [(SA404)]  
 ST62T10C(B6)                ST62T10C(M6)@SOIC20 [(SA404)]  
 ST62T15                    ST62T15@SOIC28 [(SA404)]  
 ST62T15C(B6)                ST62T15C(M6)@SOIC28 [(SA404)]  
 ST62T18C(B6)                ST62T18C(M3)@SOIC20 [(SA404)]  
 ST62T18C(M6)@SOIC20 [(SA404)]      ST62T20  
 ST62T20@SOIC20 [(SA404)]      ST62T20C(B3)  
 ST62T20C(B6)                ST62T20C(M3)@SOIC20 [(SA404)]  
 ST62T20C(M6)@SOIC20 [(SA404)]      ST62T25  
 ST62T25@SOIC28 [(SA404)]      ST62T25C(B3)  
 ST62T25C(B6)                ST62T25C(M3)@SOIC28 [(SA404)]

ST62T25C(M6)@SOIC28 [(SA404)] ST62T25C(N6)@SSOP28 [(SA626A)]  
ST62T28C(B6) ST62T28C(M3)@SOIC28 [(SA404)]  
ST62T28C(M6)@SOIC28 [(SA404)] ST62T28C(N6)@SSOP28 [(SA626A)]  
ST62T30B(B3) ST62T30B(B6)  
ST62T30B(M6)@SOIC28 [(SA404)] ST62T32B(B6)@SDIP42 [(SA028)]  
ST62T52C(B6) ST62T52C(M3)@SOIC16 [(SA404)]  
ST62T52C(M6)@SOIC16 [(SA404)] ST62T52C(N3)@SSOP16 [(SA626A)]  
ST62T52C(N6)@SSOP16 [(SA626A)] ST62T53B  
ST62T53B@SOIC20 [(SA404)] ST62T53C(B6)  
ST62T53C(M6)@SOIC20 [(SA404)] ST62T55C(B6)  
ST62T55C(M6)@SOIC28 [(SA404)] ST62T55C(N6)@SSOP28 [(SA626A)]  
ST62T60B ST62T60B@SOIC20 [(SA404)]  
ST62T60C6 ST62T62C(B6)  
ST62T62C(M3)@SOIC16 [(SA404)] ST62T62C(M6)@SOIC16 [(SA404)]  
ST62T62C(N3)@SSOP16 [(SA626A)] ST62T62C(N6)@SSOP16 [(SA626A)]  
ST62T63B ST62T63B@SOIC20 [(SA404)]  
ST62T63C(B6) ST62T63C(M6)@SOIC20 [(SA404)]  
ST62T65B ST62T65B@SOIC28 [(SA404)]  
ST62T65C(B3) ST62T65C(B6)  
ST62T65C(M3)@SOIC28 [(SA404)] ST62T65C(M6)@SOIC28 [(SA404)]  
ST62T65C(N6)@SSOP28 [(SA626A)] ST63E73@SDIP42 [(SA028)]  
ST63T73@SDIP42 [(SA028)] ST72C104G1B@SDIP32 [(SA653)]  
ST72C104G1M@SOIC28 [(SA404)] ST72C104G2B@SDIP32 [(SA653)]  
ST72C104G2M@SOIC28 [(SA404)] ST72C124J2B@SDIP42 [(SA028)]  
ST72C124J2T@TQFP44 [(SA245A)] ST72C124J4B@SDIP42 [(SA028)]  
ST72C124J4T@TQFP44 [(SA245A)] ST72C215G1B@SDIP32 [(SA653)]  
ST72C215G1M@SOIC28 [(SA404)] ST72C215G2B@SDIP32 [(SA653)]  
ST72C215G2M@SOIC28 [(SA404)] ST72C216G1B@SDIP32 [(SA653)]  
ST72C216G1M@SOIC28 [(SA404)] ST72C216G2B@SDIP32 [(SA653)]  
ST72C216G2M@SOIC28 [(SA404)] ST72C254G1B@SDIP32 [(SA653)]  
ST72C254G1M@SOIC28 [(SA404)] ST72C254G2B@SDIP32 [(SA653)]  
ST72C254G2M@SOIC28 [(SA404)] ST72C314J2B@SDIP42 [(SA028)]  
ST72C314J2T@TQFP44 [(SA245A)] ST72C314J4B@SDIP42 [(SA028)]  
ST72C314J4T@TQFP44 [(SA245A)] ST72C334J2B@SDIP42 [(SA028)]  
ST72C334J2T@TQFP44 [(SA245A)] ST72C334J4B@SDIP42 [(SA028)]  
ST72C334J4T@TQFP44 [(SA245A)] ST72F260G1B6@SDIP32 [(SA653)]  
ST72F260G1M6@SOIC28 [(SA404)] ST72F262G1B6@SDIP32 [(SA653)]  
ST72F262G1M6@SOIC28 [(SA404)] ST72F262G2B6@SDIP32 [(SA653)]  
ST72F262G2M6@SOIC28 [(SA404)] ST72F264G1B6@SDIP32 [(SA653)]  
ST72F264G1M6@SOIC28 [(SA404)] ST72F264G2B6@SDIP32 [(SA653)]  
ST72F264G2H1@LFBGA36 [(SA642G-B026A-T048F001N)]  
ST72F264G2H6@LFBGA36 [(SA642G-B026A-T048F001N)]  
ST72F264G2M6@SOIC28 [(SA404)] ST72F324BJ2B5@SDIP42 [(SA028)]

ST72F324BJ2B6@SDIP42 [(SA028)] ST72F324BJ2T3@TQFP44 [(SA245A)]  
ST72F324BJ2T5@TQFP44 [(SA245A)] ST72F324BJ2T6@TQFP44 [(SA245A)]  
ST72F324BJ4B5@SDIP42 [(SA028)] ST72F324BJ4B6@SDIP42 [(SA028)]  
ST72F324BJ4T3@TQFP44 [(SA245A)] ST72F324BJ4T6@TQFP44 [(SA245A)]  
ST72F324BJ6B5@SDIP42 [(SA028)] ST72F324BJ6B6@SDIP42 [(SA028)]  
ST72F324BJ6T3@TQFP44 [(SA245A)] ST72F324BJ6T6@TQFP44 [(SA245A)]  
ST72F324BK2B5@SDIP32 [(SA653)] ST72F324BK2B6@SDIP32 [(SA653)]  
ST72F324BK2T3@TQFP32 [(SA663)] ST72F324BK2T5@TQFP32 [(SA663)]  
ST72F324BK2T6@TQFP32 [(SA663)] ST72F324BK4B5@SDIP32 [(SA653)]  
ST72F324BK4B6@SDIP32 [(SA653)] ST72F324BK4T3@TQFP32 [(SA663)]  
ST72F324BK4T6@TQFP32 [(SA663)] ST72F324BK6B5@SDIP32 [(SA653)]  
ST72F324BK6B6@SDIP32 [(SA653)] ST72F324BK6T3@TQFP32 [(SA663)]  
ST72F324BK6T6@TQFP32 [(SA663)] ST72F324J2B5@SDIP42 [(SA028)]  
ST72F324J2B5@SDIP42(ISP) [ISP-HEADER01]  
ST72F324J2T6@TQFP44 [(SA245A)]  
ST72F324J2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J2TA@TQFP44 [(SA245A)]  
ST72F324J2TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J4B5@SDIP42 [(SA028)]  
ST72F324J4B5@SDIP42(ISP) [ISP-HEADER01]  
ST72F324J4T6@TQFP44 [(SA245A)]  
ST72F324J4T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J4TA@TQFP44 [(SA245A)]  
ST72F324J4TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6B5@SDIP42 [(SA028)]  
ST72F324J6B5@SDIP42(ISP) [ISP-HEADER01]  
ST72F324J6T3@TQFP44 [(SA245A)]  
ST72F324J6T3@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6T5@TQFP44 [(SA245A)]  
ST72F324J6T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6T6@TQFP44 [(SA245A)]  
ST72F324J6T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TA@TQFP44 [(SA245A)]  
ST72F324J6TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TC@TQFP44 [(SA245A)]  
ST72F324J6TC@TQFP44(ISP) [ISP-HEADER01]  
ST72F324K2B5@SDIP32 [(SA653)]  
ST72F324K2B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2B6@SDIP32 [(SA653)]  
ST72F324K2B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2T6@TQFP32 [(SA663)]  
ST72F324K2T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K2TA@TQFP32 [(SA663)]

ST72F324K2TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4B5@SDIP32 [(SA653)]  
ST72F324K4B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4B6@SDIP32 [(SA653)]  
ST72F324K4B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4T6@TQFP32 [(SA663)]  
ST72F324K4T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4TA@TQFP32 [(SA663)]  
ST72F324K4TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6B5@SDIP32 [(SA653)]  
ST72F324K6B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6B6@SDIP32 [(SA653)]  
ST72F324K6B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6T5@TQFP32 [(SA663)]  
ST72F324K6T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6T6@TQFP32 [(SA663)]  
ST72F324K6T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TA@TQFP32 [(SA663)]  
ST72F324K6TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TC@TQFP32 [(SA663)]  
ST72F324K6TC@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LJ2T5@TQFP44 [(SA245A)]  
ST72F324LJ2T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ2T6@TQFP44 [(SA245A)]  
ST72F324LJ2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T5@TQFP44 [(SA245A)]  
ST72F324LJ4T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T6@TQFP44 [(SA245A)]  
ST72F324LJ4T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6T5@TQFP44 [(SA245A)]  
ST72F324LJ6T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6T6@TQFP44 [(SA245A)]  
ST72F324LJ6T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6TA@TQFP44 [(SA245A)]  
ST72F324LJ6TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LK2T5@TQFP32 [(SA663)]  
ST72F324LK2T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK2T6@TQFP32 [(SA663)]  
ST72F324LK2T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK4T5@TQFP32 [(SA663)]  
ST72F324LK4T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK4T6@TQFP32 [(SA663)]  
ST72F324LK4T6@TQFP32(ISP) [ISP-HEADER01]

ST72F324LK6B5@SDIP32 [(SA653)]  
ST72F324LK6B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324LK6T5@TQFP32 [(SA663)]  
ST72F324LK6T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK6T6@TQFP32 [(SA663)]  
ST72F324LK6T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK6TA@TQFP32 [(SA663)]  
ST72F324LK6TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48 [(SA248)]  
ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48 [(SA248)]  
ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42 [(SA028)]  
ST72F325J6B6@SDIP42 [(SA028)]  
ST72F325J6B6@SDIP42(ISP) [ISP-HEADER01]  
ST72F325J6T6@TQFP44 [(SA245A)] ST72F325J7T6@TQFP44 [(SA245A)]  
ST72F325J9T6@TQFP44 [(SA245A)] ST72F325K4B5@SDIP32 [(SA653)]  
ST72F325K4T6@TQFP32 [(SA663)] ST72F325K6B5@SDIP32 [(SA653)]  
ST72F325K6B6@SDIP32 [(SA653)]  
ST72F325K6B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F325K6T6@TQFP32 [(SA663)] ST72F32AJ1B5@SDIP42 [(SA028)]  
ST72F32AJ1B6@SDIP42 [(SA028)] ST72F32AJ1T5@TQFP44 [(SA245A)]  
ST72F32AJ1T6@TQFP44 [(SA245A)] ST72F32AJ2B5@SDIP42 [(SA028)]  
ST72F32AJ2B6@SDIP42 [(SA028)] ST72F32AJ2T5@TQFP44 [(SA245A)]  
ST72F32AJ2T6@TQFP44 [(SA245A)] ST72F32AJ2TA@TQFP44 [(SA245A)]  
ST72F32AJ2TB@TQFP44 [(SA245A)] ST72F32AJ2TC@TQFP44 [(SA245A)]  
ST72F32AK1B5@SDIP32 [(SA653)] ST72F32AK1B6@SDIP32 [(SA653)]  
ST72F32AK1T5@TQFP32 [(SA663)] ST72F32AK1T6@TQFP32 [(SA663)]  
ST72F32AK2B5@SDIP32 [(SA653)] ST72F32AK2B6@SDIP32 [(SA653)]  
ST72F32AK2T5@TQFP32 [(SA663)] ST72F32AK2T6@TQFP32 [(SA663)]  
ST72F32AK2TA@TQFP32 [(SA663)] ST72F32AK2TB@TQFP32 [(SA663)]  
ST72F32AK2TC@TQFP32 [(SA663)] ST72F60D4U1@QFN40 [(SA750)]  
ST72F60D4U1@QFN40(ISP) [ISP-HEADER01]  
ST72F60D6U1@QFN40 [(SA750)]  
ST72F60D6U1@QFN40(ISP) [ISP-HEADER01]  
ST72F60E1M1@SOIC24 [(SA404)]  
ST72F60E1M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E2M1@SOIC24 [(SA404)]  
ST72F60E2M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E4M1@SOIC24 [(SA404)]  
ST72F60E4M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E6M1@SOIC24 [(SA404)]  
ST72F60E6M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60K1U1@QFN40 [(SA750)]  
ST72F60K1U1@QFN40(ISP) [ISP-HEADER01]

ST72F60K2U1@QFN40 [(SA750)]  
ST72F60K2U1@QFN40(ISP) [ISP-HEADER01]  
ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44 [(SA245A)]  
ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34 [(SA658)]  
ST72F622L2M1@SOIC34 [(SA658)] ST72F623F2B1  
ST72F623F2M1@SOIC20 [(SA404)] ST72F63BD4U1@QFN40 [(SA750)]  
ST72F63BD4U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BD6U1@QFN40 [(SA750)]  
ST72F63BD6U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BE1M1@SOP24 [(SA404)]  
ST72F63BE1M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE2M1@SOP24 [(SA404)]  
ST72F63BE2M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE4M1@SOP24 [(SA404)]  
ST72F63BE4M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE6M1@SOP24 [(SA404)]  
ST72F63BE6M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BH1T1@QFP48 [(SA248)]  
ST72F63BH1T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH2T1@QFP48 [(SA248)]  
ST72F63BH2T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH4T1@QFP48 [(SA248)]  
ST72F63BH4T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH6T1@QFP48 [(SA248)]  
ST72F63BH6T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BK1B1@SOIC34 [(SA653)]  
ST72F63BK1B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK1M1@SOIC34 [(SA658)]  
ST72F63BK1M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK1U1@QFN40 [(SA750)]  
ST72F63BK1U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BK2B1@SOIC34 [(SA653)]  
ST72F63BK2B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK2M1@SOIC34 [(SA658)]  
ST72F63BK2M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK2U1@QFN40 [(SA750)]  
ST72F63BK2U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BK4B1@SOIC34 [(SA653)]  
ST72F63BK4B1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK4M1@SOIC34 [(SA658)]  
ST72F63BK4M1@SOIC34(ISP) [ISP-HEADER01]  
ST72F63BK6B1@SOIC34 [(SA653)]  
ST72F63BK6B1@SOIC34(ISP) [ISP-HEADER01]

ST72F63BK6M1@SOIC34 [(SA658)]  
ST72F63BK6M1@SOIC34(ISP) [ISP-HEADER01]  
ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28 [(SA404)]  
ST72T101G2B@SDIP32 [(SA653)] ST72T101G2M@SOIC28 [(SA404)]  
ST72T121J2B@SDIP42 [(SA028)] ST72T121J2T@TQFP44 [(SA245A)]  
ST72T121J4B@SDIP42 [(SA028)] ST72T121J4T@TQFP44 [(SA245A)]  
ST72T141K2B@SDIP32 [(SA653)] ST72T141K2M@SSOP34 [(SA658)]  
ST72T212G2B@SDIP32 [(SA653)] ST72T212G2M@SOIC28 [(SA404)]  
ST72T213G1B@SDIP32 [(SA653)] ST72T213G1M@SOIC28 [(SA404)]  
ST72T251G1B@SDIP32 [(SA653)] ST72T251G1M@SOIC28 [(SA404)]  
ST72T251G2B@SDIP32 [(SA653)] ST72T251G2M@SOIC28 [(SA404)]  
ST72T272K4B@SDIP32 [(SA653)] ST72T272K4M@SSOP34 [(SA658)]  
ST72T311J2B@SDIP42 [(SA028)] ST72T311J2T@TQFP44 [(SA245A)]  
ST72T311J4B@SDIP42 [(SA028)] ST72T311J4T@TQFP44 [(SA245A)]  
ST72T331J2B@SDIP42 [(SA028)] ST72T331J2T@TQFP44 [(SA245A)]  
ST72T331J4B@SDIP42 [(SA028)] ST72T331J4T@TQFP44 [(SA245A)]  
ST72T371N4B@SDIP56(\*) [(SA627-B5601)]  
ST72T372J4B@SDIP42 [(SA028)] ST72T631K4B1@SDIP32 [(SA653)]  
ST72T631K4M1@SSOP34 [(SA658)] ST72T632K2B1@SDIP32 [(SA653)]  
ST72T632K2M1@SSOP34 [(SA658)] ST72T633K1B1@SDIP32 [(SA653)]  
ST72T633K1M1@SSOP34 [(SA658)]  
ST72T671N6B@SDIP56(\*) [(SA627-B5601)]  
ST72T751N9B@SDIP56(\*) [(SA627-B5601)]  
ST72T752J6B@SDIP42 [(SA028)] ST72T753L6M@SSOP34 [(SA658)]  
ST72T771N9B@SDIP56(\*) [(SA627-B5601)]  
ST7FDALIF2M6@SOIC20 [(SA404)]  
ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLIT10BF0B3 ST7FLIT10BF0B6  
ST7FLIT10BF0M3@SOIC20 [(SA404)] ST7FLIT10BF0M6@SOIC20 [(SA404)]  
ST7FLIT10BF1B3 ST7FLIT10BF1B6  
ST7FLIT10BF1M3@SOIC20 [(SA404)] ST7FLIT10BF1M6@SOIC20 [(SA404)]  
ST7FLIT10BY0B3 ST7FLIT10BY0B6  
ST7FLIT10BY0M3@SOIC16 [(SA602)] ST7FLIT10BY0M6@SOIC16 [(SA602)]  
ST7FLIT10BY1B3 ST7FLIT10BY1B6  
ST7FLIT10BY1M3@SOIC16 [(SA602)] ST7FLIT10BY1M6@SOIC16 [(SA602)]  
ST7FLIT15BF0B3 ST7FLIT15BF0B6  
ST7FLIT15BF0M3@SOIC20 [(SA404)] ST7FLIT15BF0M6@SOIC20 [(SA404)]  
ST7FLIT15BF1B3 ST7FLIT15BF1B6  
ST7FLIT15BF1M3@SOIC20 [(SA404)] ST7FLIT15BF1M6@SOIC20 [(SA404)]  
ST7FLIT15BF1U6TR@QFN20 [(BBBB)] ST7FLIT15BY0B3  
ST7FLIT15BY0B6 ST7FLIT15BY0M3@SOIC16 [(SA602)]  
ST7FLIT15BY0M6@SOIC16 [(SA602)] ST7FLIT15BY1B3  
ST7FLIT15BY1B6 ST7FLIT15BY1M3@SOIC16 [(SA602)]

ST7FLIT15BY1M6@SOIC16 [(SA602)] ST7FLIT19BF0B3  
ST7FLIT19BF0B6 ST7FLIT19BF0M3@SOIC20 [(SA404)]  
ST7FLIT19BF0M6@SOIC20 [(SA404)] ST7FLIT19BF1B3  
ST7FLIT19BF1B6 ST7FLIT19BF1M3@SOIC20 [(SA404)]  
ST7FLIT19BF1M6@SOIC20 [(SA404)] ST7FLIT19BF1U6TR@QFN20 [(BBBB)]  
ST7FLIT19BY0B3 ST7FLIT19BY0B6  
ST7FLIT19BY0M3@SOIC16 [(SA602)] ST7FLIT19BY0M6@SOIC16 [(SA602)]  
ST7FLIT19BY1B3 ST7FLIT19BY1B6  
ST7FLIT19BY1M3@SOIC16 [(SA602)] ST7FLIT19BY1M6@SOIC16 [(SA602)]  
ST7FLITE02B6 ST7FLITE02B6(ISP) [ISP-HEADER01]  
ST7FLITE02M6@SOIC16 [(SA602)]  
ST7FLITE02M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE02Y0B6  
ST7FLITE02Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE02Y0M6@SOIC16 [(SA602)]  
ST7FLITE02Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05B6 ST7FLITE05B6(ISP) [ISP-HEADER01]  
ST7FLITE05M6@SOIC16 [(SA602)]  
ST7FLITE05M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05Y0B6  
ST7FLITE05Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE05Y0M6@SOIC16 [(SA602)]  
ST7FLITE05Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09B6 ST7FLITE09B6(ISP) [ISP-HEADER01]  
ST7FLITE09M6@SOIC16 [(SA602)]  
ST7FLITE09M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09Y0B6  
ST7FLITE09Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE09Y0M6@SOIC16 [(SA602)]  
ST7FLITE09Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE10F1B6  
ST7FLITE10F1B6(ISP) [ISP-HEADER01]  
ST7FLITE10F1M6@SOIC20 [(SA404)]  
ST7FLITE10F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE15F1B6  
ST7FLITE15F1B6(ISP) [ISP-HEADER01]  
ST7FLITE15F1M6@SOIC20 [(SA404)]  
ST7FLITE15F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE19F1B6  
ST7FLITE19F1B6(ISP) [ISP-HEADER01]  
ST7FLITE19F1M6@SOIC20 [(SA404)]  
ST7FLITE19F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE20F2B6



ST7FLITE20F2B6(ISP) [ISP-HEADER01]  
ST7FLITE20F2M6@SOIC20 [(SA404)]  
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE25F2B6  
ST7FLITE25F2B6(ISP) [ISP-HEADER01]  
ST7FLITE25F2M6@SOIC20 [(SA404)]  
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE29F2B6  
ST7FLITE29F2B6(ISP) [ISP-HEADER01]  
ST7FLITE29F2M6@SOIC20 [(SA404)]  
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE30F2B6  
ST7FLITE30F2B6(ISP) [ISP-HEADER01]  
ST7FLITE30F2M6@SOIC20 [(SA404)]  
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE35F2B6  
ST7FLITE35F2B6(ISP) [ISP-HEADER01]  
ST7FLITE35F2M6@SOIC20 [(SA404)]  
ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE39F2B6  
ST7FLITE39F2B6(ISP) [ISP-HEADER01]  
ST7FLITE39F2M6@SOIC20 [(SA404)]  
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITEBC                   ST7FLITEBCM6@SOIC16 [(SA602)]  
ST7FLITES0                   ST7FLITES0@SOIC16 [(SA602)]  
ST7FLITES2B6                ST7FLITES2B6(ISP) [ISP-HEADER01]  
ST7FLITES2M6@SOIC16 [(SA602)]  
ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES2Y0B6  
ST7FLITES2Y0B6(ISP) [ISP-HEADER01]  
ST7FLITES2Y0M6@SOIC16 [(SA602)]  
ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES5B6                ST7FLITES5B6(ISP) [ISP-HEADER01]  
ST7FLITES5M6@SOIC16 [(SA602)]  
ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES5Y0B6  
ST7FLITES5Y0B6(ISP) [ISP-HEADER01]  
ST7FLITES5Y0M6@SOIC16 [(SA602)]  
ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITEUS2B6                ST7FLITEUS2M6@SOIC8 [(SA602A)]  
ST7FLITEUS2M6TR@SOIC8 [(SA602A)] ST7FLITEUS2U6TR@DFN8 [(BBBB)]  
ST7FLITEUS5B6                ST7FLITEUS5M6@SOIC8 [(SA602A)]  
ST7FLITEUS5M6TR@SOIC8 [(SA602A)] ST7FLITEUS5U6TR@DFN8 [(BBBB)]

ST7FLU05B6                    ST7FLU05BAE  
ST7FLU05BATRE                ST7FLU05BCE  
ST7FLU05BCTRE                ST7FLU05M6@SOIC8 [(SA602A)]  
ST7FLU05MAE@SOIC8 [(SA602A)]    ST7FLU05MATRE@SOIC8 [(SA602A)]  
ST7FLU05MCE@SOIC8 [(SA602A)]    ST7FLU05MCTRE@SOIC8 [(SA602A)]  
ST7FLU09B6                    ST7FLU09BAE  
ST7FLU09BATRE                ST7FLU09BCE  
ST7FLU09BCTRE                ST7FLU09M6@SOIC8 [(SA602A)]  
ST7FLU09MAE@SOIC8 [(SA602A)]    ST7FLU09MATRE@SOIC8 [(SA602A)]  
ST7FLU09MCE@SOIC8 [(SA602A)]    ST7FLU09MCTRE@SOIC8 [(SA602A)]  
ST7FLUS5B6                    ST7FLUS5BAE  
ST7FLUS5BATRE                ST7FLUS5BCE  
ST7FLUS5BCTRE                ST7FLUS5M6@SOIC8 [(SA602A)]  
ST7FLUS5MAE@SOIC8 [(SA602A)]    ST7FLUS5MATRE@SOIC8 [(SA602A)]  
ST7FLUS5MCE@SOIC8 [(SA602A)]    ST7FLUS5MCTRE@SOIC8 [(SA602A)]  
ST7FSCR1E4M1@SOIC24(\*) [(SA404-B140)]

## STC

### MICROCONTROLLER

STC89C516RD                    STC89C516RD@PLCC44 [(SA244)]  
STC89C516RD@TQFP44 [(SA245A)]    STC89C58RD  
STC89C58RD@PLCC44 [(SA244)]    STC89C58RD@TQFP44 [(SA245A)]  
STC89LE516AD                    STC89LE516AD@PLCC44 [(SA244)]  
STC89LE516AD@TQFP44 [(SA245A)]    STC89LE516X2  
STC89LE516X2@PLCC44 [(SA244)]    STC89LE516X2@TQFP44 [(SA245A)]  
STC89LE52AD                    STC89LE52AD@PLCC44 [(SA244)]  
STC89LE52AD@TQFP44 [(SA675)]    STC89LE54AD  
STC89LE54AD@PLCC44 [(SA244)]    STC89LE54AD@TQFP44 [(SA675)]  
STC89LE556AD                    STC89LE556AD@PLCC44 [(SA244)]  
STC89LE556AD@TQFP44 [(SA245A)]    STC89LE556X2  
STC89LE556X2@PLCC44 [(SA244)]    STC89LE556X2@TQFP44 [(SA245A)]  
STC89LE58AD                    STC89LE58AD@PLCC44 [(SA244)]  
STC89LE58AD@TQFP44 [(SA675)]    STC89LV516RD  
STC89LV516RD@PLCC44 [(SA244)]    STC89LV516RD@TQFP44 [(SA245A)]  
STC89LV58RD                    STC89LV58RD@PLCC44 [(SA244)]  
STC89LV58RD@TQFP44 [(SA245A)]

## ST-CUSTOMER

## E(E)PROM/FRAM/NVRAM

M36L0R7050B0\_B1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R7050T0\_T1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R8060B3(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M58LR128FB\_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 M58LR128FT\_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]  
 NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]

## SUMMIT

## E(E)PROM/FRAM/NVRAM

S24022	S24022@SOIC8 [(SA602A)]
S24023	S24023@SOIC8 [(SA602A)]
S24042	S24042@SOIC8 [(SA602A)]
S24043	S24043@SOIC8 [(SA602A)]
S24162	S24162@SOIC8 [(SA602A)]
S24VP02	S24VP02@SOIC8 [(SA602A)]
S24VP04	S24VP04@SOIC8 [(SA602A)]
S24VP08	S24VP08@SOIC8 [(SA602A)]
S24VP16	S24VP16@SOIC8 [(SA602A)]
S93462(08bit)	S93462(08bit)@SOIC8 [(SA602A)]
S93462(16bit)	S93462(16bit)@SOIC8 [(SA602A)]
S93463(08bit)	S93463(08bit)@SOIC8 [(SA602A)]
S93463(16bit)	S93463(16bit)@SOIC8 [(SA602A)]
S93662(08bit)	S93662(08bit)@SOIC8 [(SA602A)]
S93662(16bit)	S93662(16bit)@SOIC8 [(SA602A)]
S93663(08bit)	S93663(08bit)@SOIC8 [(SA602A)]
S93663(16bit)	S93663(16bit)@SOIC8 [(SA602A)]
S93WD462(08bit)	S93WD462(08bit)@SOIC8 [(SA602A)]
S93WD462(16bit)	S93WD462(16bit)@SOIC8 [(SA602A)]
S93WD463(08bit)	S93WD463(08bit)@SOIC8 [(SA602A)]
S93WD463(16bit)	S93WD463(16bit)@SOIC8 [(SA602A)]
S93WD662(08bit)	S93WD662(08bit)@SOIC8 [(SA602A)]
S93WD662(16bit)	S93WD662(16bit)@SOIC8 [(SA602A)]
S93WD663(08bit)	S93WD663(08bit)@SOIC8 [(SA602A)]
S93WD663(16bit)	S93WD663(16bit)@SOIC8 [(SA602A)]

## MICROCONTROLLER

I-SMM465F-249@TQFP48(ISP) [ISP-HEADER01]  
SMM465F-249@TQFP48 [(SA248)] SMM665BFC-266@TQFP48 [(SA248)]  
SMM665BFC-266@TQFP48(ISP) [ISP-HEADER01]

## SUNPLUS

## E(E)PROM/FRAM/NVRAM

SPHE6400A SPHE6400A@SOIC8 [(SA602A)]

## MICROCONTROLLER

SPMC65P2102A(dip18)  
SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]  
SPMC65P2102A@SOP18 [(SA404)]  
SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]  
SPMC65P2104A(dip18)  
SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]  
SPMC65P2104A@SOP18 [(SA404)]  
SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip16)  
SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip20)  
SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP16 [(SA404)]  
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP20 [(SA404)]  
SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip16)  
SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip20)  
SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP16 [(SA404)]  
SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP20 [(SA404)]  
SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip20)

SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip28)  
SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP20 [(SA404)]  
SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP28 [(SA404)]  
SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip28)  
SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip32)  
SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP28 [(SA404)]  
SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP32 [(SA603)]  
SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

## SYNCMOS

### E(E)PROM/FRAM/NVRAM

F29C31004B            F29C31004B@PLCC32 [(SA015A1T)]  
F29C31004B@TSOP32 [(SA410T)]    F29C31004T  
F29C31004T@PLCC32 [(SA015A1T)]    F29C31004T@TSOP32 [(SA410T)]  
F29C51000B            F29C51000B@PLCC32 [(SA015A1T)]  
F29C51000T            F29C51000T@PLCC32 [(SA015A1T)]  
F29C51001B            F29C51001B@PLCC32 [(SA015A1T)]  
F29C51001B@TSOP32 [(SA410T)]    F29C51001T  
F29C51001T@PLCC32 [(SA015A1T)]    F29C51001T@TSOP32 [(SA410T)]  
F29C51002B            F29C51002B@PLCC32 [(SA015A1T)]  
F29C51002B@TSOP32 [(SA410T)]    F29C51002T  
F29C51002T@PLCC32 [(SA015A1T)]    F29C51002T@TSOP32 [(SA410T)]  
F29C51004B            F29C51004B@PLCC32 [(SA015A1T)]  
F29C51004B@TSOP32 [(SA410T)]    F29C51004T  
F29C51004T@PLCC32 [(SA015A1T)]    F29C51004T@TSOP32 [(SA410T)]  
F29LC51000            F29LC51000@PLCC32 [(SA015A1T)]  
F29LC51001            F29LC51001@PLCC32 [(SA015A1T)]  
F29LC51002            F29LC51002@PLCC32 [(SA015A1T)]  
S29C31001B            S29C31001B@PLCC32 [(SA015A1T)]  
S29C31001B@TSOP32 [(SA410T)]    S29C31001T  
S29C31001T@PLCC32 [(SA015A1T)]    S29C31001T@TSOP32 [(SA410T)]  
S29C31002B            S29C31002B@PLCC32 [(SA015A1T)]  
S29C31002B@TSOP32 [(SA410T)]    S29C31002T

S29C31002T@PLCC32 [(SA015A1T)] S29C31002T@TSOP32 [(SA410T)]  
 S29C31004B S29C31004B@PLCC32 [(SA015A1T)]  
 S29C31004B@TSOP32 [(SA410T)] S29C31004T  
 S29C31004T@PLCC32 [(SA015A1T)] S29C31004T@TSOP32 [(SA410T)]  
 S29C51001B S29C51001B@PLCC32 [(SA015A1T)]  
 S29C51001B@TSOP32 [(SA410T)] S29C51001T  
 S29C51001T@PLCC32 [(SA015A1T)] S29C51001T@TSOP32 [(SA410T)]  
 S29C51002B S29C51002B@PLCC32 [(SA015A1T)]  
 S29C51002B@TSOP32 [(SA410T)] S29C51002T  
 S29C51002T@PLCC32 [(SA015A1T)] S29C51002T@TSOP32 [(SA410T)]  
 S29C51004B S29C51004B@PLCC32 [(SA015A1T)]  
 S29C51004B@TSOP32 [(SA410T)] S29C51004T  
 S29C51004T@PLCC32 [(SA015A1T)] S29C51004T@TSOP32 [(SA410T)]

## MICROCONTROLLER

MSU1958 MSU1958@PLCC44 [(SA244)]  
 MSU1958@TQFP44 [(SA245A)] MSU2952  
 MSU2952@PLCC44 [(SA244)] MSU2952@TQFP44 [(SA245A)]  
 MSU2964 MSU2964@PLCC44 [(SA244)]  
 MSU2964@TQFP44 [(SA245A)] SM2958  
 SM2958@PLCC44 [(SA244)] SM2958@TQFP44 [(SA245A)]  
 SM2965 SM2965@PLCC44 [(SA244)]  
 SM2965@TQFP44 [(SA245A)] SM59064  
 SM59064@PLCC44 [(SA244)] SM59064@TQFP44 [(SA245A)]  
 SM59128C SM59128C@PLCC44 [(SA244)]  
 SM59128C@TQFP44 [(SA245A)] SM59128L  
 SM59128L@PLCC44 [(SA244)] SM59128L@TQFP44 [(SA245A)]  
 SM59164 SM59164@PLCC44 [(SA244)]  
 SM59164@TQFP44 [(SA245A)] SM59264  
 SM59264@PLCC44 [(SA244)] SM59264@TQFP44 [(SA245A)]  
 SM5964 SM5964@PLCC44 [(SA244)]  
 SM5964@TQFP44 [(SA245A)] SM5964A  
 SM5964A@PLCC44 [(SA244)] SM5964A@TQFP44 [(SA245A)]  
 SM5964AC SM5964AC@PLCC44 [(SA244)]  
 SM5964AC@TQFP44 [(SA245A)] SM5964AL  
 SM5964AL@PLCC44 [(SA244)] SM5964AL@TQFP44 [(SA245A)]  
 SM5964C SM5964C@PLCC44 [(SA244)]  
 SM5964C@TQFP44 [(SA245A)] SM5964D0  
 SM5964D0@PLCC44 [(SA244)] SM5964D0@TQFP44 [(SA245A)]  
 SM5964D0A SM5964D0A@PLCC44 [(SA244)]  
 SM5964D0A@TQFP44 [(SA245A)] SM5964D1A

SM5964D1A@PLCC44 [(SA244)] SM5964D1A@TQFP44 [(SA245A)]  
SM59D02G2C SM59D02G2C(ISP) [ISP-HEADER01]  
SM59D02G2C@LQFP44 [(SA675-B005)]  
SM59D02G2C@LQFP44(ISP) [ISP-HEADER01]  
SM59D02G2C@PLCC44 [(SA244-B002)]  
SM59D02G2C@PLCC44(ISP) [ISP-HEADER01]  
SM59D02G2L SM59D02G2L(ISP) [ISP-HEADER01]  
SM59D02G2L@LQFP44 [(SA675-B005)]  
SM59D02G2L@LQFP44(ISP) [ISP-HEADER01]  
SM59D02G2L@PLCC44 [(SA244-B002)]  
SM59D02G2L@PLCC44(ISP) [ISP-HEADER01]  
SM59D03G2C SM59D03G2C(ISP) [ISP-HEADER01]  
SM59D03G2C@LQFP44 [(SA675-B005)]  
SM59D03G2C@LQFP44(ISP) [ISP-HEADER01]  
SM59D03G2C@PLCC44 [(SA244-B002)]  
SM59D03G2C@PLCC44(ISP) [ISP-HEADER01]  
SM59D03G2L SM59D03G2L(ISP) [ISP-HEADER01]  
SM59D03G2L@LQFP44 [(SA675-B005)]  
SM59D03G2L@LQFP44(ISP) [ISP-HEADER01]  
SM59D03G2L@PLCC44 [(SA244-B002)]  
SM59D03G2L@PLCC44(ISP) [ISP-HEADER01]  
SM59D04G2C SM59D04G2C(ISP) [ISP-HEADER01]  
SM59D04G2C@LQFP44 [(SA675-B005)]  
SM59D04G2C@LQFP44(ISP) [ISP-HEADER01]  
SM59D04G2C@PLCC44 [(SA244-B002)]  
SM59D04G2C@PLCC44(ISP) [ISP-HEADER01]  
SM59D04G2L SM59D04G2L(ISP) [ISP-HEADER01]  
SM59D04G2L@LQFP44 [(SA675-B005)]  
SM59D04G2L@LQFP44(ISP) [ISP-HEADER01]  
SM59D04G2L@PLCC44 [(SA244-B002)]  
SM59D04G2L@PLCC44(ISP) [ISP-HEADER01]  
SM59R08A2@TQFP64(\*) [(SA732-B292)]  
SM59R16A2@TQFP64(\*) [(SA732-B292)]  
SM7908 SM7908@PLCC44 [(SA244)]  
SM7908@TQFP44 [(SA245A)] SM79108  
SM79108@PLCC44 [(SA244)] SM79108@TQFP44 [(SA245A)]  
SM79164 SM79164@PLCC44 [(SA244)]  
SM79164@TQFP44 [(SA245A)] SM79164L  
SM79164L@PLCC44 [(SA244)] SM79164L@TQFP44 [(SA245A)]  
SM79164V SM79164V@PLCC44 [(SA244)]  
SM79164V@TQFP44 [(SA245A)] SM7932  
SM7932@PLCC44 [(SA244)] SM7932@TQFP44 [(SA245A)]  
SM7964 SM7964@PLCC44 [(SA244)]

SM7964@TQFP44 [(SA245A)] SM894051  
SM894051@SOIC20 [ordering number is marked above]  
SM8951 SM8951@PLCC44 [(SA244)]  
SM8951@TQFP44 [(SA245A)] SM89516  
SM89516@PLCC44 [(SA244)] SM89516@TQFP44 [(SA245A)]  
SM89516A SM89516A@PLCC44 [(SA244)]  
SM89516A@TQFP44 [(SA245A)] SM89516AL  
SM89516AL@PLCC44 [(SA244)] SM89516AL@TQFP44 [(SA245A)]  
SM89516B SM89516B@PLCC44 [(SA244)]  
SM89516B@TQFP44 [(SA245A)] SM89516BL  
SM89516BL@PLCC44 [(SA244)] SM89516BL@TQFP44 [(SA245A)]  
SM89516L SM89516L@PLCC44 [(SA244)]  
SM89516L@TQFP44 [(SA245A)] SM8951A  
SM8951A@PLCC44 [(SA244)] SM8951A@TQFP44 [(SA245A)]  
SM8951AL SM8951AL@PLCC44 [(SA244)]  
SM8951AL@TQFP44 [(SA245A)] SM8951B  
SM8951B@PLCC44 [(SA244)] SM8951B@TQFP44 [(SA245A)]  
SM8951BL SM8951BL@PLCC44 [(SA244)]  
SM8951BL@TQFP44 [(SA245A)] SM8951L  
SM8951L@PLCC44 [(SA244)] SM8951L@TQFP44 [(SA245A)]  
SM8952 SM8952@PLCC44 [(SA244)]  
SM8952@TQFP44 [(SA245A)] SM8952A  
SM8952A@PLCC44 [(SA244)] SM8952A@TQFP44 [(SA245A)]  
SM8952AL SM8952AL@PLCC44 [(SA244)]  
SM8952AL@TQFP44 [(SA245A)] SM8952B  
SM8952B@PLCC44 [(SA244)] SM8952B@TQFP44 [(SA245A)]  
SM8952BL SM8952BL@PLCC44 [(SA244)]  
SM8952BL@TQFP44 [(SA245A)] SM8952L  
SM8952L@PLCC44 [(SA244)] SM8952L@TQFP44 [(SA245A)]  
SM8954 SM8954@PLCC44 [(SA244)]  
SM8954@TQFP44 [(SA245A)] SM8954A  
SM8954A@PLCC44 [(SA244)] SM8954A@TQFP44 [(SA245A)]  
SM8954AL SM8954AL@PLCC44 [(SA244)]  
SM8954AL@TQFP44 [(SA245A)] SM8954B  
SM8954B@PLCC44 [(SA244)] SM8954B@TQFP44 [(SA245A)]  
SM8954BL SM8954BL@PLCC44 [(SA244)]  
SM8954BL@TQFP44 [(SA245A)] SM8954L  
SM8954L@PLCC44 [(SA244)] SM8954L@TQFP44 [(SA245A)]  
SM8958 SM8958@PLCC44 [(SA244)]  
SM8958@TQFP44 [(SA245A)] SM8958A  
SM8958A@PLCC44 [(SA244)] SM8958A@TQFP44 [(SA245A)]  
SM8958AL SM8958AL@PLCC44 [(SA244)]  
SM8958AL@TQFP44 [(SA245A)] SM8958B



SM8958B@PLCC44 [(SA244)] SM8958B@TQFP44 [(SA245A)]  
SM8958BL SM8958BL@PLCC44 [(SA244)]  
SM8958BL@TQFP44 [(SA245A)] SM8958L  
SM8958L@PLCC44 [(SA244)] SM8958L@TQFP44 [(SA245A)]  
SM89S16R1C SM89S16R1C@PLCC44 [(SA244)]  
SM89S16R1C@TQFP44 [(SA245A)] SM89T04R1C  
SM89T04R1C@PLCC44 [(SA244)] SM89T04R1C@TQFP44 [(SA245A)]  
SM89T04R1L SM89T04R1L@PLCC44 [(SA244)]  
SM89T04R1L@TQFP44 [(SA245A)] SM89T08R1C  
SM89T08R1C@PLCC44 [(SA244)] SM89T08R1C@TQFP44 [(SA245A)]  
SM89T08R1L SM89T08R1L@PLCC44 [(SA244)]  
SM89T08R1L@TQFP44 [(SA245A)] SM89T16R1C  
SM89T16R1C@PLCC44 [(SA244)] SM89T16R1C@TQFP44 [(SA245A)]  
SM89T16R1L SM89T16R1L@PLCC44 [(SA244)]  
SM89T16R1L@TQFP44 [(SA245A)]

## SYNERTEK

### E(E)PROM/FRAM/NVRAM

SY2716

## SYNTEK

### MICROCONTROLLER

STK6011BP1-3V@PLCC44 [(SA244)] STK6011BP21-5V@PLCC44 [(SA244)]  
STK6011BP5-3V@TQFP44 [(SA245A)] STK6011P10-5V@LQFP48 [(SA248)]  
STK6011P1-3V@PLCC44 [(SA244)] STK6011P2-5V@PLCC44 [(SA244)]  
STK6011P3-3V@SDIP42 [(SA028)] STK6011P4-5V@SDIP42 [(SA028)]  
STK6011P5-3V@PQFP44 [(SA245A)] STK6011P6-5V@PQFP44 [(SA245A)]  
STK6011P7-3V STK6011P8-5V  
STK6011P9-3V@LQFP48 [(SA248)] STK6012BP1-3V@PLCC44 [(SA244)]  
STK6012BP22-5V@PLCC44 [(SA244)] STK6012BP5-3V@TQFP44 [(SA245A)]  
STK6012P10-5V@LQFP48 [(SA248)] STK6012P1-3V@PLCC44 [(SA244)]  
STK6012P2-5V@PLCC44 [(SA244)] STK6012P3-3V@SDIP42 [(SA028)]  
STK6012P4-5V@SDIP42 [(SA028)] STK6012P5-3V@PQFP44 [(SA245A)]  
STK6012P6-5V@PQFP44 [(SA245A)] STK6012P7-3V  
STK6012P8-5V STK6012P9-3V@LQFP48 [(SA248)]

## TECHCODE

### MICROCONTROLLER

T89C516                    T89C516@PLCC44 [(SA244)]  
T89C516@TQFP44 [(SA245A)]        T89C52  
T89C52@PLCC44 [(SA244)]        T89C52@TQFP44 [(SA245A)]  
T89C58                    T89C58@PLCC44 [(SA244)]  
T89C58@TQFP44 [(SA245A)]

## TEKMOS

### E(E)PROM/FRAM/NVRAM

TK17LV040@PLCC20 [(SA001A)]

## TEMIC

### MICROCONTROLLER

T89C51RD2                    T89C51RD2@PLCC44 [(SA244)]  
T89C51RD2@TQFP44 [(SA245A)]        T89F64  
T89F64@PLCC44 [(SA244)]        T89F64@TQFP44 [(SA245A)]  
TS87C51RB2                    TS87C51RB2@PLCC44 [(SA244)]  
TS87C51RB2@TQFP44 [(SA245A)]        TS87C51RC2  
TS87C51RC2@PLCC44 [(SA244)]        TS87C51RC2@TQFP44 [(SA245A)]  
TS87C51RD2                    TS87C51RD2@PLCC44 [(SA244)]  
TS87C51RD2@TQFP44 [(SA245A)]        TS87C51U2  
TS87C51U2@PLCC44 [(SA244)]        TS87C51U2@TQFP44 [(SA245A)]  
TS87C52X2                    TS87C52X2@PLCC44 [(SA244)]  
TS87C52X2@TQFP44 [(SA245A)]        TS87C54X2  
TS87C54X2@PLCC44 [(SA244)]        TS87C54X2@TQFP44 [(SA245A)]  
TS87C58X2                    TS87C58X2@PLCC44 [(SA244)]  
TS87C58X2@TQFP44 [(SA245A)]        TSC71RBX2  
TSC71RBX2@PLCC44 [(SA244)]        TSC71RBX2@TQFP44 [(SA245A)]  
TSC71RCX2                    TSC71RCX2@PLCC44 [(SA244)]  
TSC71RCX2@TQFP44 [(SA245A)]        TSC71RDX2  
TSC71RDX2@PLCC44 [(SA244)]        TSC71RDX2@TQFP44 [(SA245A)]  
TSC87251A1@PLCC44 [(SA244)]        TSC87251G1  
TSC87251G1@PLCC44 [(SA244)]        TSC87251G1A

TSC87251G1A@PLCC44 [(SA244)]      TSC87251G2D  
 TSC87251G2D@PLCC44 [(SA244)]      TSC87251G2D@TQFP44 [(SA245A)]  
 TSC87C51                      TSC87C51@PLCC44 [(SA244)]  
 TSC87C51@TQFP44 [(SA245A)]      TSC87C52  
 TSC87C52@PLCC44 [(SA244)]      TSC87C52@TQFP44 [(SA245A)]  
 TSC87C54                      TSC87C54@PLCC44 [(SA244)]  
 TSC87C54@TQFP44 [(SA245A)]      TSC87C58  
 TSC87C58@PLCC44 [(SA244)]      TSC87C58@TQFP44 [(SA245A)]

TI

## E(E)PROM/FRAM/NVRAM

BQ4010                      BQ4010Y  
 BQ4011                      BQ4011Y  
 BQ4013                      BQ4013Y  
 BQ4014                      BQ4014Y  
 BQ4015                      BQ4015Y  
 SMJ2516                      SMJ2532  
 SMJ2532A                      SMJ2564  
 SMJ2564@PLCC32 [(SA015A1T)]      SMJ2716  
 SMJ27C256                      SMJ27C256@PLCC32 [(SA015A1T)]  
 SMJ27C512                      SMJ27C512@PLCC32 [(SA015A1T)]  
 TMS2516                      TMS2516JLW  
 TMS2532                      TMS2532A  
 TMS2564                      TMS2564@PLCC32 [(SA015A1T)]  
 TMS25L32                      TMS27128  
 TMS27128A                      TMS2716  
 TMS2732                      TMS2732A  
 TMS2764                      TMS27C010  
 TMS27C010@PLCC32 [(SA015A1T)]      TMS27C010@TSOP32 [(SA410T)]  
 TMS27C010A                      TMS27C010A@PLCC32 [(SA015A1T)]  
 TMS27C010A@TSOP32 [(SA410T)]      TMS27C020  
 TMS27C020@PLCC32 [(SA015A1T)]      TMS27C020@TSOP32 [(SA410T)]  
 TMS27C040                      TMS27C040@PLCC32 [(SA015A1T)]  
 TMS27C040@TSOP32 [(SA410T)]      TMS27C128  
 TMS27C128@PLCC32 [(SA015A1T)]      TMS27C2001  
 TMS27C2001@PLCC32 [(SA015A1T)]      TMS27C2001@TSOP32 [(SA410T)]  
 TMS27C210                      TMS27C210@PLCC44 [(SA244)]  
 TMS27C210A                      TMS27C210A@PLCC44 [(SA244)]  
 TMS27C240                      TMS27C240@PLCC44 [(SA244)]  
 TMS27C256                      TMS27C256@PLCC32 [(SA015A1T)]

TMS27C291 TMS27C291@PLCC28 [(SA008A)]  
 TMS27C292 TMS27C292@PLCC28 [(SA008A)]  
 TMS27C32 TMS27C512  
 TMS27C512@PLCC32 [(SA015A1T)] TMS27C64  
 TMS27LV010A TMS27LV010A@PLCC32 [(SA015A1T)]  
 TMS27LV010A@TSOP32 [(SA410T)] TMS27P32A  
 TMS27P64 TMS27PC010  
 TMS27PC010@PLCC32 [(SA015A1T)] TMS27PC010@TSOP32 [(SA410T)]  
 TMS27PC010A TMS27PC010A@PLCC32 [(SA015A1T)]  
 TMS27PC010A@TSOP32 [(SA410T)] TMS27PC020  
 TMS27PC020@PLCC32 [(SA015A1T)] TMS27PC020@TSOP32 [(SA410T)]  
 TMS27PC040 TMS27PC040@PLCC32 [(SA015A1T)]  
 TMS27PC040@TSOP32 [(SA410T)] TMS27PC128  
 TMS27PC128@PLCC32 [(SA015A1T)] TMS27PC210  
 TMS27PC210@PLCC44 [(SA244)] TMS27PC210A  
 TMS27PC210A@PLCC44 [(SA244)] TMS27PC240  
 TMS27PC240@PLCC44 [(SA244)] TMS27PC256  
 TMS27PC256@PLCC32 [(SA015A1T)] TMS27PC291  
 TMS27PC291@PLCC28 [(SA008A)] TMS27PC32  
 TMS27PC32A TMS27PC512  
 TMS27PC512@PLCC32 [(SA015A1T)] TMS27PC64  
 TMS28F010 TMS28F010@PLCC32 [(SA015A1T)]  
 TMS28F010@TSOP32 [(SA410T)] TMS28F020  
 TMS28F020@PLCC32 [(SA015A1T)] TMS28F020@TSOP32 [(SA410T)]  
 TMS28F200BZ-B@PSOP44 [(SA638)] TMS28F200BZ-T@PSOP44 [(SA638)]  
 TMS28F210 TMS28F210@PLCC44 [(SA244)]  
 TMS28F210@TSOP40 [(SA409T)] TMS28F400AF-B@PSOP44 [(SA638)]  
 TMS28F400AF-T@PSOP44 [(SA638)] TMS28F400AS-B@PSOP44 [(SA638)]  
 TMS28F400AS-T@PSOP44 [(SA638)] TMS28F400BZ-B@PSOP44 [(SA638)]  
 TMS28F400BZ-T@PSOP44 [(SA638)] TMS28F512  
 TMS28F512@PLCC32 [(SA015A1T)] TMS28F512@TSOP32 [(SA410T)]  
 TMS29F040 TMS29F040@PLCC32 [(SA015A1T)]  
 TMS29F040@TSOP32 [(SA410T)] TMS29F259  
 TMS29F259@PLCC32 [(SA015A1T)] TMS29F259@TSOP32 [(SA410T)]  
 TMS29F512 TMS29F512@PLCC32 [(SA015A1T)]  
 TMS29F512@TSOP32 [(SA410T)] TMS87C257  
 TMS87C257@PLCC32 [(SA015A1T)]

## PLD

EP330 EP330@PLCC20 [(SA001A)]  
 EP910 EP910-P44 [(SA244)]

## MICROCONTROLLER

MSP430F1122@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F133@QFN64(ISP) [ISP-HEADER01]  
MSP430F133@TQFP64(ISP) [ISP-HEADER01]  
MSP430F135@QFN64(ISP) [ISP-HEADER01]  
MSP430F135@TQFP64(ISP) [ISP-HEADER01]  
MSP430F147@QFN64(ISP) [ISP-HEADER01]  
MSP430F147@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1471@QFN64(ISP) [ISP-HEADER01]  
MSP430F1471@TQFP64(ISP) [ISP-HEADER01]  
MSP430F148@QFN64(ISP) [ISP-HEADER01]  
MSP430F148@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1481@QFN64(ISP) [ISP-HEADER01]  
MSP430F1481@TQFP64(ISP) [ISP-HEADER01]  
MSP430F149@QFN64(ISP) [ISP-HEADER01]  
MSP430F149@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1491@QFN64(ISP) [ISP-HEADER01]  
MSP430F1491@TQFP64(ISP) [ISP-HEADER01]  
MSP430F155@QFN64(ISP) [ISP-HEADER01]  
MSP430F155@TQFP64(ISP) [ISP-HEADER01]  
MSP430F156@QFN64(ISP) [ISP-HEADER01]  
MSP430F156@TQFP64(ISP) [ISP-HEADER01]  
MSP430F157@QFN64(ISP) [ISP-HEADER01]  
MSP430F157@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1610@QFN64(ISP) [ISP-HEADER01]  
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1611@QFN64(ISP) [ISP-HEADER01]  
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1612@QFN64(ISP) [ISP-HEADER01]  
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]  
MSP430F167@QFN64(ISP) [ISP-HEADER01]  
MSP430F167@TQFP64(ISP) [ISP-HEADER01]  
MSP430F168@QFN64(ISP) [ISP-HEADER01]

MSP430F168@TQFP64(ISP) [ISP-HEADER01]  
MSP430F169@QFN64(ISP) [ISP-HEADER01]  
MSP430F169@TQFP64(ISP) [ISP-HEADER01]  
MSP430F412@QFN64(ISP) [ISP-HEADER01]  
MSP430F412@TQFP64(ISP) [ISP-HEADER01]  
MSP430F413@QFN64(ISP) [ISP-HEADER01]  
MSP430F413@TQFP64(ISP) [ISP-HEADER01]  
MSP430F435@TQFP100(ISP) [ISP-HEADER01]  
MSP430F435@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP80(ISP) [ISP-HEADER01]  
MSP430F436@TQFP100(ISP) [ISP-HEADER01]  
MSP430F436@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP80(ISP) [ISP-HEADER01]  
MSP430F437@TQFP100(ISP) [ISP-HEADER01]  
MSP430F437@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4371@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4371@TQFP80(ISP) [ISP-HEADER01]  
MSP430F447@TQFP100(ISP) [ISP-HEADER01]  
MSP430F448@TQFP100(ISP) [ISP-HEADER01]  
MSP430F449@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG4250@QFN48(ISP) [ISP-HEADER01]  
MSP430FG4260@QFN48(ISP) [ISP-HEADER01]  
MSP430FG4270@QFN48(ISP) [ISP-HEADER01]  
MSP430FG437@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG437@TQFP80(ISP) [ISP-HEADER01]  
MSP430FG438@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG438@TQFP80(ISP) [ISP-HEADER01]  
MSP430FG439@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG439@TQFP80(ISP) [ISP-HEADER01]

## TMC

### E(E)PROM/FRAM/NVRAM

24A01                    24A01@SOIC8 [(SA602A)]  
24A01@TSSOP8 [(SA026)]            24A02  
24A02@SOIC8 [(SA602A)]            24A02@TSSOP8 [(SA026)]  
24A04                    24A04@SOIC8 [(SA602A)]  
24A04@TSSOP8 [(SA026)]            24A08  
24A08@SOIC8 [(SA602A)]            24A08@TSSOP8 [(SA026)]

24A16                    24A16@SOIC8 [(SA602A)]  
24A16@TSSOP8 [(SA026)]            93LC46(08bit)  
93LC46(08bit)@SOIC8 [(SA602A)]    93LC46(08bit)@TSSOP8 [(SA026)]  
93LC46(16bit)                    93LC46(16bit)@SOIC8 [(SA602A)]  
93LC46(16bit)@TSSOP8 [(SA026)]    93LC56(08bit)  
93LC56(08bit)@SOIC8 [(SA602A)]    93LC56(08bit)@TSSOP8 [(SA026)]  
93LC56(16bit)                    93LC56(16bit)@SOIC8 [(SA602A)]  
93LC56(16bit)@TSSOP8 [(SA026)]    93LC57  
93LC57@SOIC8 [(SA602A)]            93LC57@TSSOP8 [(SA026)]  
93LC66(08bit)                    93LC66(08bit)@SOIC8 [(SA602A)]  
93LC66(08bit)@TSSOP8 [(SA026)]    93LC66(16bit)  
93LC66(16bit)@SOIC8 [(SA602A)]    93LC66(16bit)@TSSOP8 [(SA026)]  
93LC86(08bit)                    93LC86(08bit)@SOIC8 [(SA602A)]  
93LC86(08bit)@TSSOP8 [(SA026)]    93LC86(16bit)  
93LC86(16bit)@SOIC8 [(SA602A)]    93LC86(16bit)@TSSOP8 [(SA026)]

## TOPRO

### MICROCONTROLLER

TP2804H                    TP2804H@PLCC44 [(SA244)]  
TP2804H@TQFP44 [(SA245A)]            TP2804L  
TP2804L@PLCC44 [(SA244)]            TP2804L@TQFP44 [(SA245A)]  
TP2808H                    TP2808H@PLCC44 [(SA244)]  
TP2808H@TQFP44 [(SA245A)]            TP2808L  
TP2808L@PLCC44 [(SA244)]            TP2808L@TQFP44 [(SA245A)]  
TP2851  
TP2851@PLCC44 [ordering number is marked above]  
TP2851@TQFP44 [ordering number is marked above]  
TP2852  
TP2852@PLCC44 [ordering number is marked above]  
TP2852@TQFP44 [ordering number is marked above]

## TOSHIBA

### E(E)PROM/FRAM/NVRAM

TC541000AF@PLCC32 [(SA015A1T)]    TC541000AP  
TC541001AF@PLCC32 [(SA015A1T)]    TC541001AP  
TC54256AF                    TC54256AF@SOIC28 [(SA404)]

TC54256AP TC54256AP@SOIC28 [(SA404)]  
TC544000P TC54512AF  
TC54512AP TC571000  
TC571000AD TC571000D  
TC571001AD TC571001D  
TC571024D TC57256  
TC57256A TC57256AD  
TC57256ADI TC57256D  
TC574000D TC574096D  
TC574200D TC57512  
TC57512AD TC578200D  
TC57H1000AD TC57H1001AD  
TC57H256D TC58128AFT@TSOP48 [(SA247-B005)]  
TC58512FT@TSOP48 [(SA247-B005)]  
TC58DVG02A1FT00@TSOP48 [(SA247-B005)]  
TC58DVG02A2FT00@TSOP48 [(SA247-B005)]  
TC58DVM72A1FT00@TSOP48 [(SA247-B005)]  
TC58DVM72A1TG00@TSOP48 [(SA247-B005)]  
TC58DVM82A1FT00@TSOP48 [(SA247-B005)]  
TC58DVM82A1XBJ1@TFBGA56 [(SA642U-B197-T064F001Y)]  
TC58DVM92A1FT00@TSOP48 [(SA247-B005)]  
TC58F400@PSOP44 [(SA638-B006)] TC58F400@TSOP48 [(SA247-B005)]  
TC58F401@PSOP44 [(SA638-B006)] TC58F401@TSOP48 [(SA247-B005)]  
TC58FVB004FT@TSOP40 [(SA409T)] TC58FVB008FT@TSOP40 [(SA409T)]  
TC58FVB016FT@TSOP40 [(SA409T)]  
TC58FVB160AFT@TSOP48 [(SA247-B005)]  
TC58FVB160AXB@TFBGA48 [(SA642B\_B026A-Y072F001)]  
TC58FVB160FT@TSOP48 [(SA247-B005)]  
TC58FVB321FT@TSOP48 [(SA247-B005)]  
TC58FVB321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
TC58FVB400F@PSOP44 [(SA638)]  
TC58FVB400FT@TSOP48 [(SA247-B005)]  
TC58FVB641FT@TSOP48 [(SA247-B005)]  
TC58FVB641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
TC58FVB800F@PSOP44 [(SA638)]  
TC58FVB800FT@TSOP48 [(SA247-B005)]  
TC58FVM5B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]



TC58FVM5B3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM6B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM6B2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
TC58FVM6B5BTG@TSOP48 [(SA247-B005)]  
TC58FVM6B5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
TC58FVM6T2AFT@TSOP48 [(SA247-B005)]  
TC58FVM6T2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
TC58FVM6T5BTG@TSOP48 [(SA247-B005)]  
TC58FVM6T5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
TC58FVM7B2AFT@TSOP56 [(SA628-B045)]  
TC58FVM7B5BTG@TSOP56 [(SA628-B102)]  
TC58FVM7B5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
TC58FVM7T2AFT@TSOP56 [(SA628-B045)]  
TC58FVM7T5BTG@TSOP56 [(SA628-B102)]  
TC58FVM7T5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
TC58FVT004FT@TSOP40 [(SA409T)] TC58FVT008FT@TSOP40 [(SA409T)]  
TC58FVT016FT@TSOP40 [(SA409T)]  
TC58FVT160AFT@TSOP48 [(SA247-B005)]  
TC58FVT160AXB@TFBGA48 [(SA642B\_B026A-Y072F001)]  
TC58FVT160FT@TSOP48 [(SA247-B005)]  
TC58FVT321FT@TSOP48 [(SA247-B005)]  
TC58FVT321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
TC58FVT400F@PSOP44 [(SA638)]  
TC58FVT400FT@TSOP48 [(SA247-B005)]  
TC58FVT641FT@TSOP48 [(SA247-B005)]  
TC58FVT641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
TC58FVT800F@PSOP44 [(SA638)]  
TC58FVT800FT@TSOP48 [(SA247-B005)]  
TC58FYB160FT@TSOP48 [(SA247-B005)]  
TC58FYT160FT@TSOP48 [(SA247-B005)]  
TC58NVG0S3AFT05@TSOP48 [(SA247-B005)]  
TC58V64BFT@TSOP44 [(SA645-B005)] TC89101(08bit)  
TC89101(16bit) TC89102(08bit)  
TC89102(16bit) TC89121  
TC89121@SOIC8 [(SA602A)] TC89122

TC89122@SOIC8 [(SA602A)] TC97101  
TC9WMA1FK@US8 [(BBBB)] TC9WMA2FK@US8 [(BBBB)]  
TC9WMB1AFK@US8 [(BBBB)] TC9WMB1AFU@SM8 [(SA666)]  
TC9WMB1FK@US8 [(BBBB)] TC9WMB2AFK@US8 [(BBBB)]  
TC9WMB2AFU@SM8 [(SA666)] TC9WMB2FK@US8 [(BBBB)]  
TC9WMB4FU@SM8 [(SA666)] TC9WMB8FU@SM8 [(SA666)]  
TC9WMC1FK@US8 [(BBBB)] TC9WMC1FU@SM8 [(SA666)]  
TC9WMC2FK@US8 [(BBBB)] TC9WMC2FU@SM8 [(SA666)]  
TC9WMC4FK@US8 [(BBBB)] TC9WMC4FU@SM8 [(SA602A)]  
TH50VPF5582ADSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VPF5583ADSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VPF5682CDSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VPF5683CDSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VPF5782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TH50VPF5783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TH50VPF6782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TH50VPF6783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TH50VSF1480AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
TH50VSF1481AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
TH50VSF2480AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
TH50VSF2481AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
TH50VSF2580AASB@FBGA69 [(SA642A-B032A-Y096F001)]  
TH50VSF2581AASB@FBGA69 [(SA642A-B032A-Y096F001)]  
TH50VSF2582AASB@FBGA69 [(SA642A-B032A-Y096F001)]  
TH50VSF2582ADSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF2582BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF2583AASB@FBGA69 [(SA642A-B032A-Y096F001)]  
TH50VSF2583ADSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF2583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF2590AASB@FBGA69 [(SA642A-B032A-Y096F001)]  
TH50VSF2682BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF2683BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF3580AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3581AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3582AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3582BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF3583AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]  
TH50VSF3680AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3681AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3682AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF3682BDSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VSF3683AASB@FBGA69 [(SA642A-B032A-Y096N001)]

TH50VSF3683BDSB@FBGA73 [(SA642E-B032A-T072F001)]  
TH50VSF4682AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TH50VSF4683AASB@FBGA69 [(SA642A-B032A-Y096N001)]  
TMM24128 TMM24128A  
TMM24128AP TMM24256  
TMM24256A TMM24256AP  
TMM24256B TMM24512  
TMM24512A TMM24512P  
TMM2464AP TMM27128  
TMM27128A TMM27128ADI  
TMM27128AP TMM27256  
TMM27256A TMM27256AD  
TMM27256ADI TMM27256BD  
TMM27256BDI TMM27256D  
TMM27256DI TMM2732  
TMM2732A TMM2732D  
TMM27512 TMM27512AD  
TMM27512ADI TMM27512D  
TMM27512DI TMM2764  
TMM2764AD TMM2764ADI  
TMM2764AP TMM2764D  
TMM2764DI  
TV00560002ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00560002DDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560002EDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560003ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00569002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570002CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]  
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570003CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]  
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]

TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]  
TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]

## DRAM & SRAM

TC518128                      TC518128@SOIC32 [(SA630)]

TC518129	TC518129@SOIC32 [(SA630)]
TC51832	TC51832@SOIC28 [(SA630)]
TC518512	TC518512@SOIC32 [(SA630)]
TC551001FL	TC551001FL@SOIC32 [(SA630)]
TC551001PL	TC551001PL@SOIC32 [(SA630)]
TC55257	TC55257@SOIC28 [(SA630)]
TC55257L	TC55257L@SOIC28 [(SA630)]
TC55258	TC55258@SOIC28 [(SA630)]
TC55258L	TC55258L@SOIC28 [(SA630)]
TC55328	TC55328@SOIC28 [(SA630)]
TC5561P	TC5561P@SOJ24 [(SA646)]
TC5562P	TC5562P@SOJ24 [(SA646)]
TC5563APL	TC5563APL@SOIC28 [(SA630)]
TC5564APL	TC5564APL@SOIC28 [(SA630)]
TC5565AFL	TC5565AFL@SOIC28 [(SA630)]
TC5565APL	TC5565APL@SOIC28 [(SA630)]
TC5588	TC5588@SOIC28 [(SA630)]
TC55B88	TC55B88@SOIC28 [(SA630)]
TMM2018	TMM2018@PLCC32 [(SA015A1T)]
TMM2063	TMM2063@SOIC28 [(SA630)]

## MICROCONTROLLER

TMP87P808LM@SOP28(Toshiba) [(BM11116)]  
TMP87P808LN@SDIP28(Toshiba) [(BM11122)]  
TMP87P808M@SOP28(Toshiba) [(BM11116)]  
TMP87P808N@SDIP28(Toshiba) [(BM11122)]  
TMP87P844N@SDIP42(Toshiba) [(BM11108)]  
TMP87P844NG@SDIP42(Toshiba) [(BM11108)]  
TMP87PH00DF@QFP64(Toshiba) [(BM1173)]  
TMP87PH00F@QFP64(Toshiba) [(BM1137)]  
TMP87PH00LF@QFP64(Toshiba) [(BM1173)]  
TMP87PH00N@SDIP64(Toshiba) [(BM1136)]  
TMP87PH20F@QFP80(Toshiba) [(BM1138)]  
TMP87PH40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PH40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PH46N@SDIP42(Toshiba) [(BM1193)]  
TMP87PH47LU@QFP44(Toshiba) [(BM1194C)]  
TMP87PH47U@QFP44(Toshiba) [(BM1194C)]  
TMP87PM14F@QFP64(Toshiba) [(BM1199)]  
TMP87PM14N@SDIP64(Toshiba) [(BM1198)]  
TMP87PM20F@QFP80(Toshiba) [(BM1138)]

TMP87PM29U@LQFP64(Toshiba) [(BM11117)]  
TMP87PM34AN@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM36N@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41F@QFP64(Toshiba) [(BM1137)]  
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]  
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]  
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]  
TMP87PM74F@QFP80(Toshiba) [(BM11120)]  
TMP87PM75F@QFP100(Toshiba) [(BM11124)]  
TMP87PM78F@QFP100(Toshiba) [(BM1188)]  
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]  
TMP87PP21F@QFP80(Toshiba) [(BM11104)]  
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]  
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]  
TMP87PP71F@QFP80(Toshiba) [(BM11107)]  
TMP87PS38F@QFP44(Toshiba) [(BM11136)]  
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]  
TMP87PS39F@QFP64(Toshiba) [(BM11138)]  
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]  
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]  
TMP87PS71F@QFP80(Toshiba) [(BM11107)]

## TOSHIBA-CUSTOMER

### E(E)PROM/FRAM/NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]  
TC58DVM82A1@TSOP48 [(SA247-B005)]

## TURBO IC

### E(E)PROM/FRAM/NVRAM

TU24C01                    TU24C01@SOIC8 [(SA602A)]  
TU24C02                    TU24C02@SOIC8 [(SA602A)]

TU24C04	TU24C04@SOIC8 [(SA602A)]
TU24C08	TU24C08@SOIC8 [(SA602A)]
TU24C128	TU24C128@SOIC8 [(SA602A)]
TU24C16	TU24C16@SOIC8 [(SA602A)]
TU24C16@TSSOP8 [(SA026)]	TU24C256
TU24C256@SOIC8 [(SA602A)]	TU24C32
TU24C32@SOIC8 [(SA602A)]	TU24C64
TU24C64@SOIC8 [(SA602A)]	

## UBICOM

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)]	SX20AC/SS@SSOP20 [(SA626A)]
SX28AC/DP	SX28AC/DP/G
SX28AC/SS/G@SSOP28 [(SA626A)]	SX28AC/SS@SSOP28 [(SA626A)]
SX48BD/G@TQFP48 [(SA248)]	SX48BD@TQFP48 [(SA248)]

## UMC

### E(E)PROM/FRAM/NVRAM

2732	2764
------	------

### DRAM & SRAM

UM6116	UM6116@PLCC32 [(SA015A1T)]
UM6116A	UM6116A@PLCC32 [(SA015A1T)]
UM61256	UM61256@SOIC28 [(SA630)]
UM61257	UM61512
UM61512@SOIC32 [(SA630)]	UM6164
UM6164@SOIC28 [(SA630)]	UM6167
UM621024	UM621024@SOIC32 [(SA630)]
UM62256	UM62256@SOIC28 [(SA630)]
UM62256A	UM62256A@SOIC28 [(SA630)]
UM6264	UM6264@SOIC28 [(SA630)]
UM6264A	UM6264A@SOIC28 [(SA630)]

## UTRON

### E(E)PROM/FRAM/NVRAM

UT61256C                    UT61256C@SOIC28 [(SA630)]  
UT61256C@TSOP28 [(SA430T)]    UT6164C@SOIC28 [(SA630)]  
UT6164C@TSOP28 [(SA430T)]    UT61L256C  
UT61L256C@SOIC28 [(SA630)]    UT61L256C@TSOP28 [(SA430T)]  
UT62256C                    UT62256C@SOIC28 [(SA630)]  
UT62256C@TSOP28 [(SA430T)]    UT62256CE  
UT62256CE@SOIC28 [(SA630)]    UT62256CE@TSOP28 [(SA430T)]  
UT62257C                    UT62257C@SOIC28 [(SA630)]  
UT62257C@TSOP28 [(SA430T)]    UT6264C  
UT6264C@SOIC28 [(SA630)]    UT62L256C  
UT62L256C@SOIC28 [(SA630)]    UT62L256C@TSOP28 [(SA430T)]  
UT62L64C                    UT62L64C@SOIC28 [(SA630)]  
UT62W256C                    UT62W256C@SOIC28 [(SA630)]  
UT62W256C@TSOP28 [(SA430T)]    UT62W64C  
UT62W64C@SOIC28 [(SA630)]

## VANTIS

### PLD

PALCE20RA10                PALCE20RA10@PLCC28 [(SA008A)]  
PALCE20RA10@SOIC24 [(SA404)]    PALCE20RA10H  
PALCE20RA10H@PLCC28 [(SA008A)]    PALCE20RA10H@SOIC24 [(SA404)]  
PALCE20RA10Q                PALCE20RA10Q@PLCC28 [(SA008A)]  
PALCE20RA10Q@SOIC24 [(SA404)]

## VERSACHIPS

### MICROCONTROLLER

V87C54                    V87C54@PLCC44 [(SA244)]  
V87C54@TQFP44 [(SA245A)]    V87C58  
V87C58@PLCC44 [(SA244)]    V87C58@TQFP44 [(SA245A)]

## VLSI



## E(E)PROM/FRAM/NVRAM

VT27C128                    VT27C256  
VT27C512                    VT27C64  
VT28H64                     VT28HC64

## PLD

GAL16V8

## WELTREND

## MICROCONTROLLER

WT61P4K420@SDIP42 [(SA028)]      WT61P4K421@SDIP42 [(SA028)]  
WT61P4K422@SDIP42 [(SA028)]      WT61P4L440@PLCC44 [(SA244)]  
WT61P4N400                    WT61P4N401  
WT61P6K420@SDIP42 [(SA028)]      WT61P6L440@PLCC44 [(SA244)]  
WT61P6L441@PLCC44 [(SA244)]      WT62P1-K42@SDIP42 [(SA028)]  
WT62P1-N28(dip28)            WT62P1-N40(dip40)  
WT62P1-N42(dip42)            WT62P1-S44@PSOP44 [(SA638)]  
WT62P2-K42@SDIP42 [(SA028)]      WT62P2-L44@PLCC44 [(SA244)]  
WT62P2-N40(dip40)            WT62P2-N42(dip42)  
WT62P2-S44@PSOP44 [(SA638)]      WT65F1@SOIC28 [(SA404)]  
WT65F1@TQFP48 [(SA248)]        WT6702F@SOP16 [(SA602)]  
WT6702F@SOP20 [(SA404)]        WT6702F@SOP24 [(SA404)]  
WT6702F@SSOP20 [(SA674)]

## WHITE ELECTRONIC DESIGNS

## E(E)PROM/FRAM/NVRAM

WE128K8                    WE256K8  
WE512K8                    WF256K8  
WF256K8@CLCC32 [(SA015A1T)]      WF256K8@CSOJ32 [(SA661)]  
WF512K8                    WF512K8@CLCC32 [(SA015A1T)]  
WF512K8@CSOJ32 [(SA661)]        WME128K8  
WME128K8@CLCC32 [(SA015A1T)]      WME128K8@CSOJ32 [(SA661)]

WMF128K8 WMF128K8@CLCC32 [(SA015A1T)]  
WMF128K8@CSOJ32 [(SA661)] WMF256K8  
WMF256K8@CLCC32 [(SA015A1T)] WMF256K8@CSOJ32 [(SA661)]  
WMF512K8 WMF512K8@CLCC32 [(SA015A1T)]  
WMF512K8@CSOJ32 [(SA661)] WMS128K8  
WMS128K8@CLCC32 [(SA015A1T)] WMS128K8@CSOJ32 [(SA661)]  
WMS256K8 WMS256K8@CLCC32 [(SA015A1T)]  
WMS256K8@CSOJ32 [(SA661)] WMS512K8  
WMS512K8@CLCC32 [(SA015A1T)] WMS512K8@CSOJ32 [(SA661)]

## WINBOND

### E(E)PROM/FRAM/NVRAM

W15B020L W15B020L@SOIC8 [(SA602A)]  
W15B020M W15B020M@SOIC8 [(SA602A)]  
W15B040L W15B040L@SOIC8 [(SA602A)]  
W15B040M W15B040M@SOIC8 [(SA602A)]  
W19B160BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
W19B160BB@TSOP48 [(SA247-B005)]  
W19B160BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
W19B160BT@TSOP48 [(SA247-B005)]  
W19B320AB@FBGA48 [(SA642A-B026A-Y096F001Y)]  
W19B320AB@TSOP48 [(SA247-B005)]  
W19B320AT@FBGA48 [(SA642A-B026A-Y096F001Y)]  
W19B320AT@TSOP48 [(SA247-B005)]  
W19B320BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
W19B320BB@TSOP48 [(SA247-B005)]  
W19B320BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
W19B320BT@TSOP48 [(SA247-B005)]  
W19B320SB@FBGA48 [(SA642F-B026A-T064F001)]  
W19B320SB@TSOP48 [(SA247-B005)]  
W19B320ST@FBGA48 [(SA642F-B026A-T064F001)]  
W19B320ST@TSOP48 [(SA247-B005)]  
W19B322MB@FBGA48 [(SA642F-B026A-T064F001)]  
W19B322MB@TSOP48 [(SA247-B005)]  
W19B322MT@FBGA48 [(SA642F-B026A-T064F001)]  
W19B322MT@TSOP48 [(SA247-B005)]  
W19B323MB@FBGA48 [(SA642F-B026A-T064F001)]  
W19B323MB@TSOP48 [(SA247-B005)]  
W19B323MT@FBGA48 [(SA642F-B026A-T064F001)]  
W19B323MT@TSOP48 [(SA247-B005)]

W19B324MB@FBGA48 [(SA642F-B026A-T064F001)]  
W19B324MB@TSOP48 [(SA247-B005)]  
W19B324MT@FBGA48 [(SA642F-B026A-T064F001)]  
W19B324MT@TSOP48 [(SA247-B005)]  
W19L320SB@FBGA48 [(SA642F-B026A-T064F001)]  
W19L320SB@TSOP48 [(SA247-B005)]  
W19L320ST@FBGA48 [(SA642F-B026A-T064F001)]  
W19L320ST@TSOP48 [(SA247-B005)]  
W25B40(Bottom Boot)@SOIC8 [(SA602A)]  
W25B40(Bottom Boot)@WSON8 [(SA683)]  
W25B40(Top Boot)@SOIC8 [(SA602A)]  
W25B40(Top Boot)@WSON8 [(SA683)]  
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]  
W25B40A(Bottom Boot)@WSON8 [(SA683)]  
W25B40A(Top Boot)@SOIC8 [(SA602A)]  
W25B40A(Top Boot)@WSON8 [(SA683)]  
W25D10                   W25D10(SN)@SOIC8 [(SA602A)]  
W25D10(SS)@SOIC8 [(SA023A)]   W25D10(ZP)@WSON8 [(SA683)]  
W25D20                   W25D20(SN)@SOIC8 [(SA602A)]  
W25D20(SS)@SOIC8 [(SA023A)]   W25D20(ZP)@WSON8 [(SA683)]  
W25D40                   W25D40(SN)@SOIC8 [(SA602A)]  
W25D40(SS)@SOIC8 [(SA023A)]   W25D40(ZP)@WSON8 [(SA683)]  
W25D80                   W25D80(SN)@SOIC8 [(SA602A)]  
W25D80(SS)@SOIC8 [(SA023A)]   W25D80(ZP)@WSON8 [(SA683)]  
W25P10@SOIC8 [(SA602A)]       W25P10@WSON8 [(SA683)]  
W25P16@SOIC16 [(SA404)]  
W25P16@SOIC16(ISP) [ISP-HEADER01]  
W25P16@SOIC8 [(SA023A)]       W25P16@SOIC8(ISP) [ISP-HEADER01]  
W25P16@WSON8 [(SA683)]        W25P16@WSON8(ISP) [ISP-HEADER01]  
W25P20@SOIC8 [(SA602A)]       W25P20@WSON8 [(SA683)]  
W25P32@SOIC16 [(SA404)]  
W25P32@SOIC16(ISP) [ISP-HEADER01]  
W25P32@WSON8 [(SA683)]        W25P32@WSON8(ISP) [ISP-HEADER01]  
W25P40@SOIC8 [(SA602A)]       W25P40@WSON8 [(SA683)]  
W25P64@SOIC16 [(SA404)]  
W25P64@SOIC16(ISP) [ISP-HEADER01]  
W25P64@WSON8 [(SA683)]        W25P64@WSON8(ISP) [ISP-HEADER01]  
W25P80@SOIC8 [(SA602A)]       W25P80@WSON8 [(SA683)]  
W25Q16@SOIC16 [(SA404)]  
W25Q16@SOIC16(ISP) [ISP-HEADER01]  
W25Q16@SOIC8 [(SA023A)]       W25Q16@SOIC8(ISP) [ISP-HEADER01]  
W25Q16@WSON8 [(SA683)]        W25Q16@WSON8(ISP) [ISP-HEADER01]  
W25Q32@SOIC16 [(SA404)]

W25Q32@SOIC16(ISP) [ISP-HEADER01]  
W25Q32@WSON8 [(SA683)] W25Q32@WSON8(ISP) [ISP-HEADER01]  
W25Q80@SOIC8 [(SA602A)] W25Q80@WSON8 [(SA683)]  
W25X10 W25X10(SN)@SOIC8 [(SA602A)]  
W25X10(SS)@SOIC8 [(SA023A)] W25X10(ZP)@WSON8 [(SA683)]  
W25X10L W25X10L(SN)@SOIC8 [(SA602A)]  
W25X10L(ZP)@WSON8 [(SA683)] W25X10V  
W25X10V(SN)@SOIC8 [(SA602A)] W25X10V(SS)@SOIC8 [(SA023A)]  
W25X10V(ZP)@WSON8 [(SA683)] W25X16@SOIC16 [(SA404)]  
W25X16@SOIC16(ISP) [ISP-HEADER01]  
W25X16@SOIC8 [(SA023A)] W25X16@SOIC8(ISP) [ISP-HEADER01]  
W25X20 W25X20(SN)@SOIC8 [(SA602A)]  
W25X20(SS)@SOIC8 [(SA023A)] W25X20(ZP)@WSON8 [(SA683)]  
W25X20L W25X20L(SN)@SOIC8 [(SA602A)]  
W25X20L(ZP)@WSON8 [(SA683)] W25X20V  
W25X20V(SN)@SOIC8 [(SA602A)] W25X20V(SS)@SOIC8 [(SA023A)]  
W25X20V(ZP)@WSON8 [(SA683)] W25X32@SOIC16 [(SA404)]  
W25X32@SOIC16(ISP) [ISP-HEADER01]  
W25X32@SOIC8 [(SA023A)] W25X32@SOIC8(ISP) [ISP-HEADER01]  
W25X40 W25X40(SN)@SOIC8 [(SA602A)]  
W25X40(SS)@SOIC8 [(SA023A)] W25X40(ZP)@WSON8 [(SA683)]  
W25X40L W25X40L(SN)@SOIC8 [(SA602A)]  
W25X40L(SS)@SOIC8 [(SA023A)] W25X40L(ZP)@WSON8 [(SA683)]  
W25X40V W25X40V(SN)@SOIC8 [(SA602A)]  
W25X40V(SS)@SOIC8 [(SA023A)] W25X40V(ZP)@WSON8 [(SA683)]  
W25X64@SOIC16 [(SA404)]  
W25X64@SOIC16(ISP) [ISP-HEADER01]  
W25X64@SOIC8 [(SA023A)] W25X64@SOIC8(ISP) [ISP-HEADER01]  
W25X80 W25X80(SN)@SOIC8 [(SA602A)]  
W25X80(SS)@SOIC8 [(SA023A)] W25X80(ZP)@WSON8 [(SA683)]  
W25X80L W25X80L(SS)@SOIC8 [(SA023A)]  
W25X80L(ZP)@WSON8 [(SA683)] W25X80V  
W25X80V(SN)@SOIC8 [(SA602A)] W25X80V(SS)@SOIC8 [(SA023A)]  
W25X80V(ZP)@WSON8 [(SA683)] W27C01  
W27C01@PLCC32 [(SA015A1T)] W27C01@VSOP32 [(SA620)]  
W27C010 W27C010@PLCC32 [(SA015A1T)]  
W27C010@SOIC32 [(SA438T)] W27C02  
W27C02@PLCC32 [(SA015A1T)] W27C02@VSOP32 [(SA620)]  
W27C020 W27C020@PLCC32 [(SA015A1T)]  
W27C020M W27C020M@PLCC32 [(SA015A1T)]  
W27C257 W27C257@PLCC32 [(SA015A1T)]  
W27C4096 W27C4096@PLCC44 [(SA244)]  
W27C4096@TSOP40 [(SA409T)] W27C512

W27C512@PLCC32 [(SA015A1T)]      W27C512@TSOP28 [(SA430T)]  
W27C520@SOIC20 [(SA404)]      W27C520@TSSOP20 [(SA026)]  
W27E01      W27E01@PLCC32 [(SA015A1T)]  
W27E01@VSOP32 [(SA620)]      W27E010  
W27E010@PLCC32 [(SA015A1T)]      W27E010@SOIC32 [(SA438T)]  
W27E02      W27E02@PLCC32 [(SA015A1T)]  
W27E02@VSOP32 [(SA620)]      W27E020  
W27E020@PLCC32 [(SA015A1T)]      W27E040  
W27E040@PLCC32 [(SA015A1T)]      W27E040@SOIC32 [(SA438T)]  
W27E257      W27E257@PLCC32 [(SA015A1T)]  
W27E4096      W27E4096@PLCC44 [(SA244)]  
W27E4096@TSOP40 [(SA409T)]      W27E512  
W27E512@PLCC32 [(SA015A1T)]      W27E512@TSOP28 [(SA430T)]  
W27E520@SOIC20 [(SA404)]      W27E520@TSSOP20 [(SA026)]  
W27L01      W27L01@PLCC32 [(SA015A1T)]  
W27L01@VSOP32 [(SA620)]      W27L010  
W27L010@PLCC32 [(SA015A1T)]      W27L02  
W27L02@PLCC32 [(SA015A1T)]      W27L02@VSOP32 [(SA620)]  
W27L520@SOIC20 [(SA404)]      W27L520@TSSOP20 [(SA026)]  
W28F321BB@FBGA48 [(SA634A-B005A-Y048F001)]  
W28F321BT@TSOP48 [(SA247-B005)]  
W28F321TB@FBGA48 [(SA634A-B005A-Y048F001)]  
W28F321TT@TSOP48 [(SA247-B005)]  
W28F641BB@FBGA48 [(SA634A-B005A-Y048F001)]  
W28F641BT@TSOP48 [(SA247-B005)]  
W28F641TB@FBGA48 [(SA634A-B005A-Y048F001)]  
W28F641TT@TSOP48 [(SA247-B005)]      W28J160BT@TSOP48 [(SA247-B005)]  
W28J160TT@TSOP48 [(SA247-B005)]  
W28J161BB@TFBGA48 [(SA634A-B005A-Y048F001)]  
W28J161TB@TFBGA48 [(SA634A-B005A-Y048F001)]  
W28J320BT@TSOP48 [(SA247-B005)]      W28J320TT@TSOP48 [(SA247-B005)]  
W28J321BB@TFBGA48 [(SA634A-B005A-Y048F001)]  
W28J321TB@TFBGA48 [(SA634A-B005A-Y048F001)]  
W28J800BT@TSOP48 [(SA247-B005)]      W28J800TT@TSOP48 [(SA247-B005)]  
W28V400BT@TSOP48 [(SA247-B005)]      W28V400TT@TSOP48 [(SA247-B005)]  
W29C010      W29C010@PLCC32 [(SA015A1T)]  
W29C011A      W29C011A@PLCC32 [(SA015A1T)]  
W29C020      W29C020@PLCC32 [(SA015A1T)]  
W29C020@SOIC32 [(SA438T)]      W29C020@TSOP32 [(SA410T)]  
W29C020C  
W29C020C@PLCC32 [(SA015A1T-B001)]  
W29C020C@TSOP32 [(SA410T-B003)]      W29C020C@VSOP32 [(SA620-B005)]  
W29C040      W29C040@PLCC32 [(SA015A1T-B001)]

W29C040@TSOP32 [(SA410T-B003)] W29C040@VSOP32 [(SA620-B005)]  
W29C101 W29C101@PLCC44 [(SA244)]  
W29C101@TSOP40 [(SA409T)] W29C102  
W29C102@PLCC44 [(SA244)] W29C102@TSOP40 [(SA409T)]  
W29EE010 W29EE010@PLCC32 [(SA015A1T)]  
W29EE010@SOIC32 [(SA438T)] W29EE010@TSOP32 [(SA410T)]  
W29EE011 W29EE011@PLCC32 [(SA015A1T)]  
W29EE011@SOIC32 [(SA438T)] W29EE012  
W29EE012@PLCC32 [(SA015A1T)] W29EE012@SOIC32 [(SA438T)]  
W29EE512 W29EE512@PLCC32 [(SA015A1T)]  
W29EE512@SOIC32 [(SA438T)] W29EE512@TSOP32 [(SA410T)]  
W29F040 W29F040@PLCC32 [(SA015A1T)]  
W29F040@TSOP32 [(SA410T)] W29F102@PLCC44 [(SA244)]  
W29F102@TSOP40 [(SA623)] W29L102@PLCC44 [(SA244)]  
W29L102@TSOP40 [(SA623)] W39F010  
W39F010@PLCC32 [(SA015A1T-B001)]  
W39F010@TSOP32[12.4mm] [(SA620-B005)]  
W39F010@TSOP32[18.4mm] [(SA410T-B003)]  
W39L010@PLCC32 [(SA015A1T-B001)] W39L010@TSOP32 [(SA620-B005)]  
W39L020@PLCC32 [(SA015A1T-B001)]  
W39L020@TSOP32[12.4mm] [(SA620-B005)]  
W39L020@TSOP32[18.4mm] [(SA410T-B003)]  
W39L040@PLCC32 [(SA015A1T-B001)]  
W39L040@TSOP32[12.4mm] [(SA620-B005)]  
W39L040@TSOP32[18.4mm] [(SA410T-B003)]  
W39L040A W39L040A@PLCC32 [(SA015A1T)]  
W39L040A@TSOP32 [(SA410T)] W39L040A@VSOP32 [(SA620)]  
W39L512@PLCC32 [(SA015A1T-B001)] W39L512@TSOP32 [(SA620-B005)]  
W39V040AP@PLCC32 [(SA015A1T)] W39V040AQ@VSOP32 [(SA620)]  
W39V040B(P)@PLCC32 [(SA015A1T)] W39V040B(Q)@VSOP32 [(SA620)]  
W39V040CP@PLCC32 [(SA015A1T)] W39V040CPZ@PLCC32 [(SA015A1T)]  
W39V040CQ@VSOP32 [(SA620)] W39V040CQZ@VSOP32 [(SA620)]  
W39V040FAP@PLCC32 [(SA015A1T)] W39V040FAQ@VSOP32 [(SA620)]  
W39V040FAT@TSOP40 [(SA409T)] W39V040FB(P)@PLCC32 [(SA015A1T)]  
W39V040FB(Q)@VSOP32 [(SA620)] W39V040FCP@PLCC32 [(SA015A1T)]  
W39V040FCPZ@PLCC32 [(SA015A1T)] W39V040FCQ@VSOP32 [(SA620)]  
W39V040FCQZ@VSOP32 [(SA620)] W39V080A(P)@PLCC32 [(SA015A1T)]  
W39V080A(Q)@VSOP32 [(SA620)] W39V080A(T)@TSOP40 [(SA409T)]  
W39V080FA(P)@PLCC32 [(SA015A1T)] W39V080FA(Q)@VSOP32 [(SA620)]  
W39V080FA(T)@TSOP40 [(SA409T)] W45B012@PLCC32 [(SA015A1T)]  
W45B012@SON8 [(SA683)] W45B512@PLCC32 [(SA015A1T)]  
W45B512@SON8 [(SA683)] W49F002  
W49F002@PLCC32 [(SA015A1T-B001)] W49F002@TSOP32 [(SA410T-B003)]

W49F002B  
 W49F002B@PLCC32 [(SA015A1T-B001)]  
 W49F002B@TSOP32 [(SA410T-B003)] W49F002N  
 W49F002N@PLCC32 [(SA015A1T-B001)]  
 W49F002N@TSOP32 [(SA410T-B003)] W49F002U  
 W49F002U@PLCC32 [(SA015A1T-B001)]  
 W49F002U@TSOP32 [(SA410T-B003)] W49F020  
 W49F020@PLCC32 [(SA015A1T)] W49F020@TSOP32 [(SA410T)]  
 W49F102@PLCC44 [(SA244)] W49F102@TSOP40 [(SA623)]  
 W49F201@PSOP44 [(SA638)] W49F201@TSOP48 [(SA247-B005)]  
 W49L102@PLCC44 [(SA244)] W49L102@TSOP40 [(SA623)]  
 W49L201@PSOP44 [(SA638)] W49L201@TSOP48 [(SA247-B005)]  
 W49L401@PSOP44 [(SA638)] W49L401@TSOP48 [(SA247-B005)]  
 W49L401T@PSOP44 [(SA638)] W49L401T@TSOP48 [(SA247-B005)]  
 W49V002A@PLCC32 [(SA015A1T)] W49V002A@VSOP32 [(SA620)]  
 W49V002FA@PLCC32 [(SA015A1T)] W49V002FA@VSOP32 [(SA620)]  
 W49V002FP@PLCC32 [(SA015A1T)] W49V002FP@VSOP32 [(SA620)]  
 W49V002P@PLCC32 [(SA015A1T)] W49V002P@VSOP32 [(SA620)]  
 W55F05 W55F10A  
 W55F20

## MICROCONTROLLER

W77E058 W77E058@PLCC44 [(SA244)]  
 W77E058@TQFP44 [(SA245A)] W77E516  
 W77E516@PLCC44 [(SA244)] W77E516@TQFP44 [(SA245A)]  
 W77E532 W77E532@PLCC44 [(SA244)]  
 W77E532@TQFP44 [(SA245A)] W77E532A  
 W77E532A@PLCC44 [(SA244)] W77E532A@TQFP44 [(SA245A)]  
 W77E58 W77E58@PLCC44 [(SA244)]  
 W77E58@TQFP44 [(SA245A)] W77E58A  
 W77E58A@PLCC44 [(SA244)] W77E58A@TQFP44 [(SA245A)]  
 W77IE58 W77IE58@PLCC44 [(SA244)]  
 W77IE58@TQFP44 [(SA245A)] W77L058  
 W77L058@PLCC44 [(SA244)] W77L058@TQFP44 [(SA245A)]  
 W77L516A W77L516A@PLCC44 [(SA244)]  
 W77L516A@TQFP44 [(SA245A)] W77L532A  
 W77L532A@PLCC44 [(SA244)] W77L532A@TQFP44 [(SA245A)]  
 W77LE516 W77LE516@PLCC44 [(SA244)]  
 W77LE516@TQFP44 [(SA245A)] W77LE532  
 W77LE532@PLCC44 [(SA244)] W77LE532@TQFP44 [(SA245A)]  
 W77LE58 W77LE58@PLCC44 [(SA244)]

W77LE58@TQFP44 [(SA245A)]      W78E051B  
W78E051B@PLCC44 [(SA244)]      W78E051B@TQFP44 [(SA245A)]  
W78E051C      W78E051C@PLCC44 [(SA244)]  
W78E051C@TQFP44 [(SA245A)]      W78E051DDG  
W78E051DFG@TQFP44 [(SA245A)]  
W78E051DLG@TQFP48 [(SA248A-B005)]  
W78E051DPG@PLCC44 [(SA244)]      W78E052B  
W78E052B@PLCC44 [(SA244)]      W78E052B@TQFP44 [(SA245A)]  
W78E052C      W78E052C@PLCC44 [(SA244)]  
W78E052C@TQFP44 [(SA245A)]      W78E052DDG  
W78E052DFG@TQFP44 [(SA245A)]  
W78E052DLG@TQFP48 [(SA248A-B005)]  
W78E052DPG@PLCC44 [(SA244)]      W78E054B  
W78E054B@PLCC44 [(SA244)]      W78E054B@TQFP44 [(SA245A)]  
W78E054C      W78E054C@PLCC44 [(SA244)]  
W78E054C@TQFP44 [(SA245A)]      W78E054DDG  
W78E054DFG@TQFP44 [(SA245A)]  
W78E054DLG@TQFP48 [(SA248A-B005)]  
W78E054DPG@PLCC44 [(SA244)]      W78E058B  
W78E058B@PLCC44 [(SA244)]      W78E058B@TQFP44 [(SA245A)]  
W78E058DDG      W78E058DFG@TQFP44 [(SA245A)]  
W78E058DLG@TQFP48 [(SA248A-B005)]  
W78E058DPG@PLCC44 [(SA244)]      W78E065  
W78E065@PLCC44 [(SA244)]      W78E065@TQFP44 [(SA245A)]  
W78E354(dip40)      W78E354(dip48)  
W78E365      W78E365@PLCC44 [(SA244)]  
W78E365@TQFP44 [(SA245A)]      W78E374B  
W78E378      W78E378E  
W78E378P@PLCC44 [(SA244)]      W78E51  
W78E51@PLCC44 [(SA244)]      W78E51@TQFP44 [(SA245A)]  
W78E516      W78E516@PLCC44 [(SA244)]  
W78E516@TQFP44 [(SA245A)]      W78E516B  
W78E516B@PLCC44 [(SA244)]      W78E516B@TQFP44 [(SA245A)]  
W78E516DDG      W78E516DFG@TQFP44 [(SA245A)]  
W78E516DLG@TQFP48 [(SA248A-B005)]  
W78E516DPG@PLCC44 [(SA244)]      W78E51B  
W78E51B@PLCC44 [(SA244)]      W78E51B@TQFP44 [(SA245A)]  
W78E51C      W78E51C@PLCC44 [(SA244)]  
W78E51C@TQFP44 [(SA245A)]      W78E52  
W78E52@PLCC44 [(SA244)]      W78E52@TQFP44 [(SA245A)]  
W78E52B      W78E52B@PLCC44 [(SA244)]  
W78E52B@TQFP44 [(SA245A)]      W78E52C  
W78E52C@PLCC44 [(SA244)]      W78E52C@TQFP44 [(SA245A)]



W78E54 W78E54@PLCC44 [(SA244)]  
W78E54@TQFP44 [(SA245A)] W78E54B  
W78E54B@PLCC44 [(SA244)] W78E54B@TQFP44 [(SA245A)]  
W78E54C W78E54C@PLCC44 [(SA244)]  
W78E54C@TQFP44 [(SA245A)] W78E58  
W78E58@PLCC44 [(SA244)] W78E58@TQFP44 [(SA245A)]  
W78E58B W78E58B@PLCC44 [(SA244)]  
W78E58B@TQFP44 [(SA245A)] W78E62B  
W78E62B@PLCC44 [(SA244)] W78E62B@TQFP44 [(SA245A)]  
W78E65 W78E65@PLCC44 [(SA244)]  
W78E65@TQFP44 [(SA245A)] W78E858  
W78E858@PLCC44 [(SA244)] W78E858@TQFP44 [(SA245A)]  
W78ERD2 W78ERD2@PLCC44 [(SA244)]  
W78ERD2@TQFP44 [(SA245A)] W78I051DDG  
W78I051DFG@TQFP44 [(SA245A)]  
W78I051DLG@TQFP48 [(SA248A-B005)]  
W78I051DPG@PLCC44 [(SA244)] W78I052  
W78I052@PLCC44 [(SA244)] W78I052DDG  
W78I052DFG@TQFP44 [(SA245A)]  
W78I052DLG@TQFP48 [(SA248A-B005)]  
W78I052DPG@PLCC44 [(SA244)] W78I054  
W78I054@PLCC44 [(SA244)] W78I054DDG  
W78I054DFG@TQFP44 [(SA245A)]  
W78I054DLG@TQFP48 [(SA248A-B005)]  
W78I054DPG@PLCC44 [(SA244)] W78IE52  
W78IE52@PLCC44 [(SA244)] W78IE54  
W78IE54@PLCC44 [(SA244)] W78IRD2  
W78IRD2@PLCC44 [(SA244)] W78IRD2@TQFP44 [(SA245A)]  
W78L051 W78L051@PLCC44 [(SA244)]  
W78L051@TQFP44 [(SA245A)] W78L051C  
W78L051C@PLCC44 [(SA244)] W78L051C@TQFP44 [(SA245A)]  
W78L052 W78L052@PLCC44 [(SA244)]  
W78L052@TQFP44 [(SA245A)] W78L052C  
W78L052C@PLCC44 [(SA244)] W78L052C@TQFP44 [(SA245A)]  
W78L054 W78L054@PLCC44 [(SA244)]  
W78L054@TQFP44 [(SA245A)] W78L054C  
W78L054C@PLCC44 [(SA244)] W78L054C@TQFP44 [(SA245A)]  
W78L058 W78L058@PLCC44 [(SA244)]  
W78L058@TQFP44 [(SA245A)] W78L365  
W78L365@PLCC44 [(SA244)] W78L365@TQFP44 [(SA245A)]  
W78L365@TQFP48 [(SA248A-B005)] W78L516  
W78L516@PLCC44 [(SA244)] W78L516@TQFP44 [(SA245A)]  
W78L812 W78L812@PLCC44 [(SA244)]

W78L812@TQFP44 [(SA245A)]      W78LE365  
 W78LE365@PLCC44 [(SA244)]      W78LE365@TQFP44 [(SA245A)]  
 W78LE365@TQFP48 [(SA248A-B005)]      W78LE51  
 W78LE51@PLCC44 [(SA244)]      W78LE51@TQFP44 [(SA245A)]  
 W78LE516      W78LE516@PLCC44 [(SA244)]  
 W78LE516@TQFP44 [(SA675)]      W78LE51C  
 W78LE51C@PLCC44 [(SA244)]      W78LE51C@TQFP44 [(SA245A)]  
 W78LE52      W78LE52@PLCC44 [(SA244)]  
 W78LE52@TQFP44 [(SA245A)]      W78LE52C  
 W78LE52C@PLCC44 [(SA244)]      W78LE52C@TQFP44 [(SA245A)]  
 W78LE54      W78LE54@PLCC44 [(SA244)]  
 W78LE54@TQFP44 [(SA245A)]      W78LE54C  
 W78LE54C@PLCC44 [(SA244)]      W78LE54C@TQFP44 [(SA245A)]  
 W78LE58      W78LE58@PLCC44 [(SA244)]  
 W78LE58@TQFP44 [(SA245A)]      W78LE812  
 W78LE812@PLCC44 [(SA244)]      W78LE812@TQFP44 [(SA245A)]  
 W79E201      W79E201@PLCC44 [(SA244)]  
 W79E201@TQFP44 [(SA245A)]      W79E2051(dip14)  
 W79E2051(dip16)      W79E2051(dip20)  
 W79E2051@SOP20 [(SA404A)]      W79E2051@SSOP14 [(SA626A)]  
 W79E2051@SSOP16 [(SA626A)]      W79E2051@SSOP20 [(SA626A)]  
 W79E216AFG@PQFP100(\*) [(SA741-B226)]  
 W79E217AFG@PQFP100(\*) [(SA741-B226)]  
 W79E227A@LQFP48 [(SA248)]      W79E227A@PLCC44 [(SA244)]  
 W79E4051(dip14)      W79E4051(dip16)  
 W79E4051(dip20)      W79E4051@SOP20 [(SA404A)]  
 W79E4051@SSOP14 [(SA626A)]      W79E4051@SSOP16 [(SA626A)]  
 W79E4051@SSOP20 [(SA626A)]      W79E532  
 W79E532@PLCC44 [(SA244)]      W79E532@TQFP44 [(SA245A)]  
 W79E532A      W79E532A@PLCC44 [(SA244)]  
 W79E532A@TQFP44 [(SA245A)]      W79E632  
 W79E632@PLCC44 [(SA244)]      W79E632@TQFP44 [(SA245A)]  
 W79E633@PLCC44 [(SA244)]  
 W79E648A@PLCC68(\*) [(SA648-B6809)]  
 W79E649A@PLCC68(\*) [(SA648-B6809)]  
 W79E659A@PQFP100(\*) [(SA741-B233)]  
 W79E801A      W79E801A@SOIC20 [(SA404)]  
 W79E802A      W79E802A@SOIC20 [(SA404)]  
 W79E803A      W79E803A@SOIC20 [(SA404)]  
 W79E804A      W79E804A@SOIC20 [(SA404)]  
 W79E821A      W79E821A@SOIC20 [(SA404)]  
 W79E822A      W79E822A@SOIC20 [(SA404)]  
 W79E822B      W79E822B@SOIC20 [(SA404)]

W79E823A                    W79E823A@SOIC20 [(SA404)]  
 W79E823B                    W79E823B@SOIC20 [(SA404)]  
 W79E824A                    W79E824A@SOIC20 [(SA404)]  
 W79E825A                    W79E825A@SOIC20 [(SA404)]  
 W79E831A                    W79E831A@SOIC28 [(SA404)]  
 W79E832A                    W79E832A@SOIC28 [(SA404)]  
 W79E833A                    W79E833A@SOIC28 [(SA404)]  
 W79E834A                    W79E834A@SOIC28 [(SA404)]  
 W79L532                    W79L532@PLCC44 [(SA244)]  
 W79L532@TQFP44 [(SA245A)]    W79L632  
 W79L632@PLCC44 [(SA244)]    W79L632@TQFP44 [(SA245A)]  
 W79L633@PLCC44 [(SA244)]  
 W79L648A@PLCC68(\*) [(SA648-B6809)]  
 W79L649A@PLCC68(\*) [(SA648-B6809)]  
 W79L659A@PQFP100(\*) [(SA741-B233)]  
 W925EP01@PQFP100(\*) [(TA041-B006)]  
 W99100DG@TQFP48 [(SA248A-B005)]

## WSI

### E(E)PROM/FRAM/NVRAM

WS27C010L                    WS27C010L@PLCC32 [(SA015A1T)]  
 WS27C010L@TSOP32 [(SA410T)]    WS27C010R  
 WS27C010R@PLCC32 [(SA015A1T)]    WS27C010R@TSOP32 [(SA410T)]  
 WS27C040L                    WS27C040L@PLCC32 [(SA015A1T)]  
 WS27C040L@TSOP32 [(SA410T)]    WS27C128F  
 WS27C128F@PLCC32 [(SA015A1T)]    WS27C128L  
 WS27C128L@PLCC32 [(SA015A1T)]    WS27C210L  
 WS27C210L@PLCC44 [(SA244)]    WS27C256F  
 WS27C256F@PLCC32 [(SA015A1T)]    WS27C256L  
 WS27C256L@PLCC32 [(SA015A1T)]    WS27C512F  
 WS27C512F@PLCC32 [(SA015A1T)]    WS27C512L  
 WS27C512L@PLCC32 [(SA015A1T)]    WS27C64  
 WS27C64@PLCC32 [(SA015A1T)]    WS27C64F  
 WS27C64F@PLCC32 [(SA015A1T)]    WS27C64L  
 WS27C64L@PLCC32 [(SA015A1T)]    WS57C128  
 WS57C128@PLCC32 [(SA015A1T)]    WS57C128F  
 WS57C128F@PLCC32 [(SA015A1T)]    WS57C128FB  
 WS57C128FB@PLCC32 [(SA015A1T)]    WS57C191  
 WS57C191@PLCC28 [(SA008A)]    WS57C191B  
 WS57C191B@PLCC28 [(SA008A)]    WS57C191C

WS57C191C@PLCC28 [(SA008A)]	WS57C256F
WS57C256F@PLCC32 [(SA015A1T)]	WS57C256FB
WS57C256FB@PLCC32 [(SA015A1T)]	WS57C257
WS57C257@PLCC44 [(SA244)]	WS57C291
WS57C291@PLCC28 [(SA008A)]	WS57C291B
WS57C291B@PLCC28 [(SA008A)]	WS57C291C
WS57C291C@PLCC28 [(SA008A)]	WS57C43
WS57C43@PLCC28 [(SA008A)]	WS57C43B
WS57C43B@PLCC28 [(SA008A)]	WS57C43C
WS57C43C@PLCC28 [(SA008A)]	WS57C45
WS57C45@PLCC28 [(SA008A)]	WS57C49
WS57C49@PLCC28 [(SA008A)]	WS57C49B
WS57C49B@PLCC28 [(SA008A)]	WS57C49C
WS57C49C@PLCC28 [(SA008A)]	WS57C51
WS57C51@PLCC32 [(SA015A1T)]	WS57C51B
WS57C51B@PLCC32 [(SA015A1T)]	WS57C51C
WS57C51C@PLCC32 [(SA015A1T)]	WS57C64F
WS57C64F@PLCC32 [(SA015A1T)]	WS57C71C
WS57C71C@PLCC32 [(SA015A1T)]	WS57LV191C
WS57LV191C@PLCC28 [(SA008A)]	WS57LV291C
WS57LV291C@PLCC28 [(SA008A)]	

## XELTEK

### E(E)PROM/FRAM/NVRAM

S29GL032NTAI03@TSOP48 [(SA247-B005)]  
S29GL032NTAI04@TSOP48 [(SA247-B005)]  
S29GL032NTFI03@TSOP48 [(SA247-B005)]  
S29GL032NTFI04@TSOP48 [(SA247-B005)]  
S29GL064NTAI03@TSOP48 [(SA247-B005)]  
S29GL064NTAI04@TSOP48 [(SA247-B005)]  
S29GL064NTAI06@TSOP48 [(SA247-B005)]  
S29GL064NTAI07@TSOP48 [(SA247-B005)]  
S29GL064NTFI03@TSOP48 [(SA247-B005)]  
S29GL064NTFI04@TSOP48 [(SA247-B005)]  
S29GL064NTFI06@TSOP48 [(SA247-B005)]  
S29GL064NTFI07@TSOP48 [(SA247-B005)]  
S29GL128N10TAI01@TSOP56 [(SA628-B334)]  
S29GL128N10TAI02@TSOP56 [(SA628-B334)]  
S29GL128N10TFI01@TSOP56 [(SA628-B334)]  
S29GL128N10TFI02@TSOP56 [(SA628-B334)]

S29GL128N11TAI01@TSOP56 [(SA628-B334)]  
 S29GL128N11TAI02@TSOP56 [(SA628-B334)]  
 S29GL128N11TAIV1@TSOP56 [(SA628-B334)]  
 S29GL128N11TAIV2@TSOP56 [(SA628-B334)]  
 S29GL128N11TFI01@TSOP56 [(SA628-B334)]  
 S29GL128N11TFI02@TSOP56 [(SA628-B334)]  
 S29GL128N11TFIV1@TSOP56 [(SA628-B334)]  
 S29GL128N11TFIV2@TSOP56 [(SA628-B334)]  
 S29GL128N90TAIR1@TSOP56 [(SA628-B334)]  
 S29GL128N90TAIR2@TSOP56 [(SA628-B334)]  
 S29GL128N90TFIR1@TSOP56 [(SA628-B334)]  
 S29GL128N90TFIR2@TSOP56 [(SA628-B334)]

## MICROCONTROLLER

#####11111111111111111111 #####2222222222222222  
 #####33333333333333333333 #####4444444444444444  
 #####9999999999999999 ATMEGA168@TQFP32 [(SA636)]  
 ATMEGA48@TQFP32 [(SA636)] ATMEGA88@TQFP32 [(SA636)]  
 ATMEGA8L(fast)@TQFP32 [(SA636)] ATMEGA8L@TQFP32 [(SA636)]  
 MK68F15P MK68F15S@SOP18 [(SA023A)]  
 MK68F15X@SSOP20 [(SA674)] MK68F30K  
 MK68F30S@SOP28 [(SA404)] MK68F30X@SSOP28 [(SA626A)]

## XICOR

## E(E)PROM/FRAM/NVRAM

X2004 X2004@PLCC32 [(SA015A1T)]  
 X2004D X2004D@PLCC32 [(SA015A1T)]  
 X2004I X2004I@PLCC32 [(SA015A1T)]  
 X2210 X2210@SOIC16 [(SA404)]  
 X2210A X2210A@SOIC16 [(SA404)]  
 X2210I X2210I@SOIC16 [(SA404)]  
 X2212 X2212@SOIC20 [(SA404)]  
 X2212A X2212A@SOIC20 [(SA404)]  
 X2212I X2212I@SOIC20 [(SA404)]  
 X22C10 X22C10@SOIC16 [(SA404)]  
 X22C10I X22C10I@SOIC16 [(SA404)]  
 X22C12 X22C12@SOIC20 [(SA404)]  
 X22C12I X22C12I@SOIC20 [(SA404)]

X24012	X24012@SOIC8 [(SA602A)]
X24022	X24022@SOIC8 [(SA602A)]
X24026	X24026@SOIC8 [(SA602A)]
X24042	X24042@SOIC8 [(SA602A)]
X24164	X24164@SOIC8 [(SA602A)]
X24165	X24165@SOIC8 [(SA602A)]
X24325	X24325@SOIC8 [(SA602A)]
X24645	X24645@SOIC8 [(SA602A)]
X24C01	X24C01@MSOP8 [(SA666)]
X24C01@SOIC8 [(SA602A)]	X24C01A
X24C01A@SOIC8 [(SA602A)]	X24C01I
X24C01I@SOIC8 [(SA602A)]	X24C02
X24C02@SOIC8 [(SA602A)]	X24C02I
X24C02I@SOIC8 [(SA602A)]	X24C04
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8 [(SA602A)]
X24C04I	X24C04I@SOIC14 [(SA602)]
X24C04I@SOIC8 [(SA602A)]	X24C08
X24C08@SOIC14 [(SA602)]	X24C08@SOIC8 [(SA602A)]
X24C08I	X24C08I@SOIC14 [(SA602)]
X24C08I@SOIC8 [(SA602A)]	X24C16
X24C16@SOIC14 [(SA602)]	X24C16@SOIC8 [(SA602A)]
X24C16I	X24C16I@SOIC14 [(SA602)]
X24C16I@SOIC8 [(SA602A)]	X24C44
X24C44@SOIC8 [(SA602A)]	X24C44I
X24C44I@SOIC8 [(SA602A)]	X24C45
X24C45@SOIC8 [(SA602A)]	X24C45I
X24C45I@SOIC8 [(SA602A)]	X24F008(3V)
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14 [(SA602)]
X24F008(5V)	X24F008(5V)@SOIC8 [(SA602A)]
X24F008(5V)@TSSOP14 [(SA602)]	X24F016(3V)
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14 [(SA602)]
X24F016(5V)	X24F016(5V)@SOIC8 [(SA602A)]
X24F016(5V)@TSSOP14 [(SA602)]	X24F032(3V)
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14 [(SA602)]
X24F032(5V)	X24F032(5V)@SOIC8 [(SA602A)]
X24F032(5V)@TSSOP14 [(SA602)]	X24F064(3V)
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20 [(SA404)]
X24F064(5V)	X24F064(5V)@SOIC8 [(SA602A)]
X24F064(5V)@TSSOP20 [(SA404)]	X25020
X25020@SOIC8 [(SA602A)]	X25021
X25021@SOIC8 [(SA602A)]	X25040
X25040@SOIC8 [(SA602A)]	X25041
X25041@SOIC8 [(SA602A)]	X25043

X25043@MSOP8 [(SA666)]	X25043@SOIC8 [(SA602A)]
X25043@TSSOP14 [(SA026)]	X25045
X25045@MSOP8 [(SA666)]	X25045@SOIC8 [(SA602A)]
X25045@TSSOP14 [(SA026)]	X25057@MSOP8 [(SA666)]
X25057@TSSOP8 [(SA026)]	X25080
X25080@SOIC8 [(SA602A)]	X25080@TSSOP14 [(SA026)]
X25097@MSOP8 [(SA666)]	X25097@SOIC8 [(SA602A)]
X25097@TSSOP8 [(SA026)]	X25128
X25128@SOIC16 [(SA602)]	X25138
X25138@SOIC14 [(SA602)]	X25138@SOIC16 [(SA602)]
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8 [(SA026)]
X25160	X25160@SOIC8 [(SA602A)]
X25160@TSSOP14 [(SA026)]	X25163
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14 [(SA026)]
X25164	X25164@SOIC8 [(SA602A)]
X25164@TSSOP14 [(SA026)]	X25165
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14 [(SA026)]
X25166	X25166@SOIC8 [(SA602A)]
X25166@TSSOP14 [(SA026)]	X25168
X25168@SOIC8 [(SA602A)]	X25168@TSSOP14 [(SA026)]
X25169	X25169@SOIC8 [(SA602A)]
X25169@TSSOP14 [(SA026)]	X25256
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20 [(SA026)]
X25320	X25320@SOIC8 [(SA602A)]
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14 [(SA026)]
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14 [(SA026)]
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14 [(SA026)]
X25326@SOIC8 [(SA602A)]	X25328@SOIC8 [(SA602A)]
X25328@TSSOP14 [(SA026)]	X25329@SOIC8 [(SA602A)]
X25329@TSSOP14 [(SA026)]	X25330@SOIC8 [(SA602A)]
X25330@TSSOP14 [(SA026)]	X25401
X25401@SOIC8 [(SA602A)]	X25640
X25640@SOIC14 [(SA602)]	X25642
X25642@SOIC14 [(SA602)]	X25642@SOIC8 [(SA602A)]
X25642@TSSOP20 [(SA026)]	X25643@SOIC14 [(SA602)]
X25644@SOIC14 [(SA602)]	X25645
X25645@SOIC14 [(SA602)]	X25645@SOIC8 [(SA602A)]
X25645@TSSOP20 [(SA026)]	X25648@SOIC14 [(SA602)]
X25649@SOIC14 [(SA602)]	X25650
X25650@SOIC14 [(SA602)]	X25650@SOIC8 [(SA602A)]
X25650@TSSOP20 [(SA026)]	X25C02
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8 [(SA026)]
X25F008(3V)	X25F008(3V)@SOIC8 [(SA602A)]

X25F008(3V)@TSSOP14 [(SA602)] X25F008(3V)@TSSOP20 [(SA404)]  
X25F008(5V) X25F008(5V)@SOIC8 [(SA602A)]  
X25F008(5V)@TSSOP14 [(SA602)] X25F008(5V)@TSSOP20 [(SA404)]  
X25F016(3V) X25F016(3V)@SOIC8 [(SA602A)]  
X25F016(3V)@TSSOP14 [(SA602)] X25F016(3V)@TSSOP20 [(SA404)]  
X25F016(5V) X25F016(5V)@SOIC8 [(SA602A)]  
X25F016(5V)@TSSOP14 [(SA602)] X25F016(5V)@TSSOP20 [(SA404)]  
X25F032(3V) X25F032(3V)@SOIC8 [(SA602A)]  
X25F032(3V)@TSSOP14 [(SA602)] X25F032(3V)@TSSOP20 [(SA404)]  
X25F032(5V) X25F032(5V)@SOIC8 [(SA602A)]  
X25F032(5V)@TSSOP14 [(SA602)] X25F032(5V)@TSSOP20 [(SA404)]  
X25F047(3V) X25F047(3V)@MSOP8 [(SA666)]  
X25F047(3V)@SOIC8 [(SA602A)] X25F047(3V)@TSSOP8 [(SA026)]  
X25F047(5V) X25F047(5V)@MSOP8 [(SA666)]  
X25F047(5V)@SOIC8 [(SA602A)] X25F047(5V)@TSSOP8 [(SA026)]  
X25F064(3V) X25F064(3V)@SOIC8 [(SA602A)]  
X25F064(3V)@TSSOP14 [(SA602)] X25F064(3V)@TSSOP20 [(SA404)]  
X25F064(5V) X25F064(5V)@SOIC8 [(SA602A)]  
X25F064(5V)@TSSOP14 [(SA602)] X25F064(5V)@TSSOP20 [(SA404)]  
X25F087(3V) X25F087(3V)@MSOP8 [(SA666)]  
X25F087(3V)@SOIC8 [(SA602A)] X25F087(3V)@TSSOP8 [(SA026)]  
X25F087(5V) X25F087(5V)@MSOP8 [(SA666)]  
X25F087(5V)@SOIC8 [(SA602A)] X25F087(5V)@TSSOP8 [(SA026)]  
X25F128(3V) X25F128(3V)@SOIC16 [(SA602)]  
X25F128(5V) X25F128(5V)@SOIC16 [(SA602)]  
X28010 X28010@PLCC32 [(SA015A1T)]  
X28010@TSOP32 [(SA410T)] X2804A  
X2804A(I) X2804A(MB)  
X2816A X2816A@PLCC32 [(SA015A1T)]  
X2816B X2816B@PLCC32 [(SA015A1T)]  
X2816BI X2816BI@PLCC32 [(SA015A1T)]  
X2816BMB X2816C  
X2816C@PLCC32 [(SA015A1T)] X28256  
X28256@PLCC32 [(SA015A1T)] X28256I  
X28256I@PLCC32 [(SA015A1T)] X2864A  
X2864A(I) X2864A(I)@PLCC32 [(SA015A1T)]  
X2864A(M) X2864A(M)@PLCC32 [(SA015A1T)]  
X2864A(MB) X2864A(MB)@PLCC32 [(SA015A1T)]  
X2864A(T) X2864A(T)@PLCC32 [(SA015A1T)]  
X2864A@PLCC32 [(SA015A1T)] X2864B  
X2864B(I) X2864B(I)@PLCC32 [(SA015A1T)]  
X2864B(M) X2864B(M)@PLCC32 [(SA015A1T)]  
X2864B@PLCC32 [(SA015A1T)] X2864H



X2864H(I)	X2864H(I)@PLCC32 [(SA015A1T)]
X2864H@PLCC32 [(SA015A1T)]	X28C010
X28C010@PLCC32 [(SA015A1T)]	X28C16A
X28C16A@PLCC32 [(SA015A1T)]	X28C16B
X28C16B@PLCC32 [(SA015A1T)]	X28C16C
X28C16C@PLCC32 [(SA015A1T)]	X28C256
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28 [(SA430T)]
X28C512	X28C512@PLCC32 [(SA015A1T)]
X28C513	X28C513@PLCC32 [(SA015A1T)]
X28C64	X28C64@PLCC32 [(SA015A1T)]
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28 [(SA430T)]
X28HC16	X28HC16@PLCC32 [(SA015A1T)]
X28HC16@SOIC24 [(SA404)]	X28HC256
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28 [(SA430T)]
X28HC64	X28HC64@PLCC32 [(SA015A1T)]
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28 [(SA430T)]
X28LC512	X28LC512@PLCC32 [(SA015A1T)]
X28LC513	X28LC513@PLCC32 [(SA015A1T)]
X28VC256	X28VC256@PLCC32 [(SA015A1T)]
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16 [(SA404)]
X40233@SOIC16 [(SA404)]	X40235@SOIC16 [(SA404)]
X40237@SOIC16 [(SA404)]	X40239@SOIC16 [(SA404)]
X40430@SOIC14 [(SA404)]	X40430@TSSOP14 [(SA026)]
X40431@SOIC14 [(SA404)]	X40431@TSSOP14 [(SA026)]
X40434@SOIC14 [(SA404)]	X40434@TSSOP14 [(SA026)]
X40435@SOIC14 [(SA404)]	X40435@TSSOP14 [(SA026)]
X4C105@TSSOP20 [(SA026)]	X5043
X5043@MSOP8 [(SA666)]	X5043@SOIC8 [(SA602A)]
X5043@TSSOP14 [(SA026)]	X5045
X5045@MSOP8 [(SA666)]	X5045@SOIC8 [(SA602A)]
X5045@TSSOP14 [(SA026)]	X5083
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8 [(SA026)]
X5163	X5163@SOIC8 [(SA602A)]
X5163@TSSOP14 [(SA026)]	X51638
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14 [(SA026)]
X5165	X5165@SOIC8 [(SA602A)]
X5165@TSSOP14 [(SA026)]	X5168
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14 [(SA026)]
X5169	X5169@SOIC8 [(SA602A)]
X5169@TSSOP14 [(SA026)]	X5323
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14 [(SA026)]
X5325	X5325@SOIC8 [(SA602A)]
X5325@TSSOP14 [(SA026)]	X5328

X5328@SOIC8 [(SA602A)]	X5328@TSSOP14 [(SA026)]
X5329	X5329@SOIC8 [(SA602A)]
X5329@TSSOP14 [(SA026)]	X5643
X5643@SOIC14 [(SA602)]	X5643@SOIC8 [(SA602A)]
X5643@TSSOP20 [(SA026)]	X5645
X5645@SOIC14 [(SA602)]	X5645@SOIC8 [(SA602A)]
X5645@TSSOP20 [(SA026)]	X5648
X5648@SOIC14 [(SA602)]	X5649
X5649@SOIC14 [(SA602)]	X76F041
X76F041(3)	X76F041(3)@SOIC8 [(SA605)]
X76F041@SOIC8 [(SA605)]	X76F101
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8 [(SA602A)]
X76F400@TSSOP8 [(SA026)]	X84041
X84041@SOIC14 [(SA602)]	X84041@SOIC8 [(SA602A)]
X84047	X84047@TSSOP8 [(SA026)]
X84087	X84087@TSSOP8 [(SA026)]
X84128	X84128@SOIC14 [(SA602)]
X84128@TSSOP28 [(SA643)]	X84128@XBGA8 [(SA683)]
X84129	X84129@SOIC16 [(SA602)]
X84160	X84160@SOIC8 [(SA602A)]
X84160@TSSOP8 [(SA026)]	X84161
X84161@SOIC8 [(SA602A)]	X84161@TSSOP8 [(SA026)]
X84256	X84256@SOIC8 [(SA602A)]
X84256@TSSOP14 [(SA026)]	X84256@XBGA8 [(SA683)]
X84640	X84640@SOIC8 [(SA602A)]
X84640@TSSOP20 [(SA026)]	X84640@XBGA8 [(SA683)]
X84641	X84641@SOIC8 [(SA602A)]
X84641@TSSOP20 [(SA026)]	X84641@XBGA8 [(SA683)]
XD2210	XD2210@SOIC16 [(SA404)]
XM28C010	XM28C020
XM28C040	

## XILINX

### E(E)PROM/FRAM/NVRAM

XC1701	XC1701@PLCC20 [(SA001A)]
XC1701@PLCC44 [(SA244)]	XC1701@SOIC20 [(SA404)]
XC1701L	XC1701L@PLCC20 [(SA001A)]
XC1701L@PLCC44 [(SA244)]	XC1701L@SOIC20 [(SA404)]
XC1702L@PLCC44 [(SA244)]	XC1702L@TQFP44 [(SA245A)]
XC1704L@PLCC44 [(SA244)]	XC1704L@TQFP44 [(SA245A)]

XC17128 XC17128@SOIC8 [(SA602A)]  
XC17128D XC17128D@PLCC20 [(SA001A)]  
XC17128D@SOIC8 [(SA602A)] XC17128D@VOIC8 [(SA602A)]  
XC17128E XC17128E@PLCC20 [(SA001A)]  
XC17128E@VOIC8 [(SA602A)] XC17128EL  
XC17128EL@PLCC20 [(SA001A)] XC17128EL@VOIC8 [(SA602A)]  
XC17128L XC17128L@PLCC20 [(SA001A)]  
XC17128L@SOIC8 [(SA602A)] XC17128L@VOIC8 [(SA602A)]  
XC17128X XC17128X@PLCC20 [(SA001A)]  
XC17128X@SOIC8 [(SA602A)] XC17128X@VOIC8 [(SA602A)]  
XC1718D XC1718D@PLCC20 [(SA001A)]  
XC1718D@SOIC8 [(SA602A)] XC1718D@VOIC8 [(SA602A)]  
XC1718L XC1718L@PLCC20 [(SA001A)]  
XC1718L@SOIC8 [(SA602A)] XC1718L@VOIC8 [(SA602A)]  
XC17256D XC17256D@PLCC20 [(SA001A)]  
XC17256D@SOIC8 [(SA602A)] XC17256D@VOIC8 [(SA602A)]  
XC17256E XC17256E@PLCC20 [(SA001A)]  
XC17256E@VOIC8 [(SA602A)] XC17256EL  
XC17256EL@PLCC20 [(SA001A)] XC17256EL@VOIC8 [(SA602A)]  
XC17256L XC17256L@PLCC20 [(SA001A)]  
XC17256L@SOIC8 [(SA602A)] XC17256L@VOIC8 [(SA602A)]  
XC17256X XC17256X@PLCC20 [(SA001A)]  
XC17256X@SOIC8 [(SA602A)] XC17256X@VOIC8 [(SA602A)]  
XC1736 XC1736@SOIC8 [(SA602A)]  
XC1736A XC1736A@SOIC8 [(SA602A)]  
XC1736D XC1736D@PLCC20 [(SA001A)]  
XC1736D@SOIC8 [(SA602A)] XC1736D@VOIC8 [(SA602A)]  
XC1736E XC1736E@PLCC20 [(SA001A)]  
XC1736E@SOIC8 [(SA602A)] XC1736E@VOIC8 [(SA602A)]  
XC17512L XC17512L@PLCC20 [(SA001A)]  
XC17512L@PLCC44 [(SA244)] XC17512L@SOIC20 [(SA404)]  
XC1765 XC1765@SOIC8 [(SA602A)]  
XC1765D XC1765D@PLCC20 [(SA001A)]  
XC1765D@SOIC8 [(SA602A)] XC1765D@VOIC8 [(SA602A)]  
XC1765E XC1765E@PLCC20 [(SA001A)]  
XC1765E@SOIC8 [(SA602A)] XC1765E@VOIC8 [(SA602A)]  
XC1765EL XC1765EL@PLCC20 [(SA001A)]  
XC1765EL@SOIC8 [(SA602A)] XC1765EL@VOIC8 [(SA602A)]  
XC1765L XC1765L@PLCC20 [(SA001A)]  
XC1765L@SOIC8 [(SA602A)] XC1765L@VOIC8 [(SA602A)]  
XC1765X XC1765X@PLCC20 [(SA001A)]  
XC1765X@SOIC8 [(SA602A)] XC1765X@VOIC8 [(SA602A)]  
XC17S05 XC17S05@SOIC8 [(SA602A)]

XC17S05XL(L) XC17S05XL(L)@SOIC8 [(SA602A)]  
XC17S10 XC17S10@SOIC8 [(SA602A)]  
XC17S100A XC17S100A@SOIC20 [(SA404)]  
XC17S100A@SOIC8 [(SA602A)] XC17S100XL(L)  
XC17S100XL(L)@SOIC20 [(SA404)] XC17S10XL(L)  
XC17S10XL(L)@SOIC8 [(SA602A)] XC17S150A  
XC17S150A@SOIC20 [(SA404)] XC17S150A@SOIC8 [(SA602A)]  
XC17S150XL(L) XC17S150XL(L)@SOIC20 [(SA404)]  
XC17S15A XC17S15A@SOIC20 [(SA404)]  
XC17S15A@SOIC8 [(SA602A)] XC17S20  
XC17S20@SOIC8 [(SA602A)] XC17S200A  
XC17S200A@SOIC8 [(SA602A)] XC17S200A@TQFP44 [(SA245A)]  
XC17S20XL(L) XC17S20XL(L)@SOIC8 [(SA602A)]  
XC17S30 XC17S30@SOIC8 [(SA602A)]  
XC17S300A@TQFP44 [(SA245A)] XC17S30A  
XC17S30A@SOIC20 [(SA404)] XC17S30A@SOIC8 [(SA602A)]  
XC17S30XL(L) XC17S30XL(L)@SOIC8 [(SA602A)]  
XC17S40 XC17S40@SOIC20 [(SA404)]  
XC17S40XL(L) XC17S40XL(L)@SOIC20 [(SA404)]  
XC17S50A XC17S50A@SOIC20 [(SA404)]  
XC17S50A@SOIC8 [(SA602A)] XC17S50XL(L)  
XC17S50XL(L)@SOIC20 [(SA404)] XC17V01@PLCC20 [(SA001A)]  
XC17V01@SOIC20 [(SA404)] XC17V01@SOIC8 [(SA602A)]  
XC17V02@PLCC20 [(SA001A)] XC17V02@PLCC44 [(SA244)]  
XC17V02@TQFP44 [(SA245A)] XC17V04@PLCC20 [(SA001A)]  
XC17V04@PLCC44 [(SA244)] XC17V04@TQFP44 [(SA245A)]  
XC17V08@PLCC44 [(SA244)] XC17V08@TQFP44 [(SA245A)]  
XC17V16@PLCC44 [(SA244)] XC17V16@TQFP44 [(SA245A)]  
XCF01S(VO)@TSSOP20 [(SA026)] XCF01S(VOG)@TSSOP20 [(SA026)]  
XCF02S(VO)@TSSOP20 [(SA026)] XCF02S(VOG)@TSSOP20 [(SA026)]  
XCF04S(VO)@TSSOP20 [(SA026)] XCF04S(VOG)@TSSOP20 [(SA026)]  
XCF08P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
XCF08P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
XCF08P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
XCF08P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
XCF08P(VO)@TSOP48 [(SA247-B005)]  
XCF08P(VO)@TSOP48(ISP) [ISP-HEADER01]  
XCF08P(VOG)@TSOP48 [(SA247-B005)]  
XCF08P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
XCF16P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
XCF16P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
XCF16P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
XCF16P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]

XCF16P(VO)@TSOP48 [(SA247-B005)]  
 XCF16P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF16P(VOG)@TSOP48 [(SA247-B005)]  
 XCF16P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(VO)@TSOP48 [(SA247-B005)]  
 XCF32P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(VOG)@TSOP48 [(SA247-B005)]  
 XCF32P(VOG)@TSOP48(ISP) [ISP-HEADER01]

## PLD

XC2C32@PLCC44 [(SA244)]           XC2C32@QFG32 [(SA686)]  
 XC2C32@VQFP44 [(SA245A)]        XC2C32A@PLCC44 [(SA244)]  
 XC2C32A@QFG32 [(SA686)]         XC2C32A@VQFP44 [(SA245A)]  
 XC2C64@CSP56(\*) [(SA699A-B136B-W056F001Y)]  
 XC2C64@PLCC44 [(SA244)]         XC2C64@VQFP44 [(SA245A)]  
 XC2C64A@5QFG48C [(SA696)]       XC2C64A@5QFG48I [(SA696)]  
 XC2C64A@7QFG48C [(SA696)]       XC2C64A@7QFG48I [(SA696)]  
 XC2C64A@CSP56(\*) [(SA699A-B136B-W056F001Y)]  
 XC2C64A@PLCC44 [(SA244)]         XC2C64A@VQFP44 [(SA245A)]  
 XC9536@PLCC44 [(SA244)]         XC9536@TQFP44 [(SA245A)]  
 XC9536XL@BCSP48                 XC9536XL@PLCC44 [(SA244)]  
 XC9536XL@VQFP44 [(SA245A)]       XC9536XV@BCSP48 [(SA642A+B339)]  
 XC9536XV@PLCC44 [(SA244)]        XC9536XV@TQFP44 [(SA245A)]  
 XC9572@PLCC44 [(SA244)]         XC9572@TQFP44 [(SA245A)]  
 XC9572XL@BCSP48                 XC9572XL@PLCC44 [(SA244)]  
 XC9572XL@TQFP44 [(SA245A)]       XC9572XV@BCSP48  
 XC9572XV@PLCC44 [(SA244)]        XC9572XV@TQFP44 [(SA245A)]

## XILINX-CUSTOMER

### E(E)PROM/FRAM/NVRAM

XC17S100A                   XC17S100A@SOIC20 [(SA404)]  
 XC17S100A@SOIC8 [(SA602A)]     XC17S150A  
 XC17S150A@SOIC20 [(SA404)]     XC17S150A@SOIC8 [(SA602A)]  
 XC17S15A                    XC17S15A@SOIC20 [(SA404)]

XC17S15A@SOIC8 [(SA602A)]	XC17S200A
XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44 [(SA245A)]
XC17S300A@TQFP44 [(SA245A)]	XC17S30A
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8 [(SA602A)]
XC17S50A	XC17S50A@SOIC20 [(SA404)]
XC17S50A@SOIC8 [(SA602A)]	XC17V01@PLCC20 [(SA001A)]
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8 [(SA602A)]
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44 [(SA244)]
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20 [(SA001A)]
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44 [(SA245A)]
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44 [(SA245A)]
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44 [(SA245A)]

## YMC

### E(E)PROM/FRAM/NVRAM

Y24LC01	Y24LC01@SOIC8 [(SA602A)]
Y24LC01@TSSOP8 [(SA026)]	Y24LC02
Y24LC02@SOIC8 [(SA602A)]	Y24LC02@TSSOP8 [(SA026)]
Y24LC02A	Y24LC02A@SOIC8 [(SA602A)]
Y24LC02A@TSSOP8 [(SA026)]	Y24LC04
Y24LC04@SOIC8 [(SA602A)]	Y24LC04@TSSOP8 [(SA026)]
Y24LC08	Y24LC08@SOIC8 [(SA602A)]
Y24LC08@TSSOP8 [(SA026)]	Y24LC16
Y24LC16@SOIC8 [(SA602A)]	Y24LC16@TSSOP8 [(SA026)]
Y24LC32	Y24LC32@SOIC8 [(SA602A)]
Y24LC32@TSSOP8 [(SA026)]	Y24LC64
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8 [(SA026)]
Y93LC46(08bit)	Y93LC46(08bit)@SOIC8 [(SA602A)]
Y93LC46(08bit)@TSSOP8 [(SA026)]	Y93LC46(16bit)
Y93LC46(16bit)@SOIC8 [(SA602A)]	Y93LC46(16bit)@TSSOP8 [(SA026)]
Y93LC66(08bit)	Y93LC66(08bit)@SOIC8 [(SA602A)]
Y93LC66(08bit)@TSSOP8 [(SA026)]	Y93LC66(16bit)
Y93LC66(16bit)@SOIC8 [(SA602A)]	Y93LC66(16bit)@TSSOP8 [(SA026)]
Y93LC86(08bit)	Y93LC86(08bit)@SOIC8 [(SA602A)]
Y93LC86(08bit)@TSSOP8 [(SA026)]	Y93LC86(16bit)
Y93LC86(16bit)@SOIC8 [(SA602A)]	Y93LC86(16bit)@TSSOP8 [(SA026)]

## YSS

## E(E)PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8 [(SA683)]
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8 [(SA683)]

## ZHIXIN

## E(E)PROM/FRAM/NVRAM

PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]
PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]

## ZILOG

## MICROCONTROLLER

Z86733	Z86733@PLCC28 [(SA008A)]
Z86733@SOIC28 [(SA404)]	Z86743
Z86743@PLCC44 [(SA244)]	Z86C0208PEC
Z86C0208PSC	Z86C0208SEC@SOIC18 [(SA404)]
Z86C0208SSC@SOIC18 [(SA404)]	Z86E02
Z86E02@SOIC18 [(SA404)]	Z86E03
Z86E03@SOIC18 [(SA404)]	Z86E04
Z86E04@SOIC18 [(SA404)]	Z86E0412PEC
Z86E0412PEC1903	Z86E0412PSC1866
Z86E0412PSC1903	Z86E0412SEC [(SA404)]
Z86E0412SEC1903 [(SA404)]	Z86E0412SSC1866 [(SA404)]
Z86E0412SSC1903 [(SA404)]	Z86E06
Z86E06@SOIC18 [(SA404)]	Z86E07
Z86E07@SOIC18 [(SA404)]	Z86E08
Z86E08@SOIC18 [(SA404)]	Z86E0812PEC
Z86E0812PEC1903	Z86E0812PSC1866
Z86E0812PSC1903	Z86E0812SEC [(SA404)]
Z86E0812SEC1903 [(SA404)]	Z86E0812SSC1866 [(SA404)]
Z86E0812SSC1903 [(SA404)]	Z86E122
Z86E122@SOIC20 [(SA404)]	Z86E123
Z86E123@SOIC20 [(SA404)]	Z86E124
Z86E124@SOIC20 [(SA404)]	Z86E125
Z86E125@SOIC20 [(SA404)]	Z86E126
Z86E126@SOIC20 [(SA404)]	Z86E132

Z86E132@SOIC28 [(SA404)]      Z86E133  
Z86E133@SOIC28 [(SA404)]      Z86E134  
Z86E134@SOIC28 [(SA404)]      Z86E135  
Z86E135@SOIC28 [(SA404)]      Z86E136  
Z86E136@SOIC28 [(SA404)]      Z86E142  
Z86E142@TQFP44 [(SA245A)]      Z86E143  
Z86E143@TQFP44 [(SA245A)]      Z86E144  
Z86E144@TQFP44 [(SA245A)]      Z86E145  
Z86E145@TQFP44 [(SA245A)]      Z86E146  
Z86E146@TQFP44 [(SA245A)]      Z86E15  
Z86E21                      Z86E21@PLCC44 [(SA244)]  
Z86E21@TQFP44                      Z86E23  
Z86E23@PLCC44 [(SA244)]      Z86E23@TQFP44 [(SA245A)]  
Z86E3016PEC                      Z86E3016PSC  
Z86E3016SEC@SOIC28 [(SA404)]      Z86E3016SSC@SOIC28 [(SA404)]  
Z86E3016VEC@PLCC28 [(SA008A)]      Z86E3016VSC@PLCC28 [(SA008A)]  
Z86E3016VSG@PLCC28 [(SA008A)]      Z86E3116PEC  
Z86E3116PSC                      Z86E3116SEC@SOIC28 [(SA404)]  
Z86E3116SSC@SOIC28 [(SA404)]      Z86E3116VEC@PLCC28 [(SA008A)]  
Z86E3116VSC@PLCC28 [(SA008A)]      Z86E3116VSG@PLCC28 [(SA008A)]  
Z86E33                      Z86E33@PLCC28 [(SA008A)]  
Z86E33@SOIC28 [(SA404)]      Z86E34  
Z86E34@PLCC28 [(SA008A)]      Z86E34@SOIC28 [(SA404)]  
Z86E4016FEC@TQFP44 [(SA245A)]      Z86E4016FSC@TQFP44 [(SA245A)]  
Z86E4016PEC                      Z86E4016PSC  
Z86E4016VEC@PLCC44 [(SA244)]      Z86E4016VSC@PLCC44 [(SA244)]  
Z86E4016VSG@PLCC44 [(SA244)]      Z86E43  
Z86E43@PLCC44 [(SA244)]      Z86E43@TQFP44 [(SA245A)]  
Z86E44                      Z86E44@PLCC44 [(SA244)]  
Z86E44@TQFP44 [(SA245A)]      Z86E61FSC@TQFP44 [(SA245A)]  
Z86E61PSC                      Z86E61VSC@PLCC44 [(SA244)]  
Z86E63FSC@TQFP44 [(SA245A)]      Z86E63PSC  
Z86E63VSC@PLCC44 [(SA244)]      Z86E72  
Z86E72@PLCC44 [(SA244)]      Z86E72@TQFP44 [(SA245A)]  
Z86E73                      Z86E73@PLCC44 [(SA244)]  
Z86E73@TQFP44 [(SA245A)]      Z86E83  
Z86E83@PLCC28 [(SA008A)]      Z86E83@SOIC28 [(SA404)]  
Z86L0208PEC                      Z86L0208PSC  
Z86L0208SEC@SOIC18 [(SA404)]      Z86L0208SSC@SOIC18 [(SA404)]  
Z89371                      Z89371@PLCC44 [(SA244)]  
Z89371@TQFP44 [(SA245A)]      Z89371B  
Z89371B@PLCC44 [(SA244)]      Z89371B@TQFP44 [(SA245A)]  
Z8F0113HH005EC@SSOP20 [(SA626A)]      Z8F0113HH005EG@SSOP20 [(SA626A)]



Z8F0113HH005SC@SSOP20 [(SA626A)] Z8F0113HH005SG@SSOP20 [(SA626A)]  
Z8F0113HJ005EC@SSOP28 [(SA626A)] Z8F0113HJ005EG@SSOP28 [(SA626A)]  
Z8F0113HJ005SC@SSOP28 [(SA626A)] Z8F0113HJ005SG@SSOP28 [(SA626A)]  
Z8F0113PB005EC Z8F0113PB005EG  
Z8F0113PB005SC Z8F0113PB005SG  
Z8F0113PH005EC Z8F0113PH005EG  
Z8F0113PH005SC Z8F0113PH005SG  
Z8F0113PJ005EC Z8F0113PJ005EG  
Z8F0113PJ005SC Z8F0113PJ005SG  
Z8F0113QB005EC@QFN8 [(SA683)] Z8F0113QB005EG@QFN8 [(SA683)]  
Z8F0113QB005SC@QFN8 [(SA683)] Z8F0113QB005SG@QFN8 [(SA683)]  
Z8F0113SB005EC@SOIC8 [(SA602A)] Z8F0113SB005EG@SOIC8 [(SA602A)]  
Z8F0113SB005SC@SOIC8 [(SA602A)] Z8F0113SB005SG@SOIC8 [(SA602A)]  
Z8F0113SH005EC@SOIC20 [(SA404)] Z8F0113SH005EG@SOIC20 [(SA404)]  
Z8F0113SH005SC@SOIC20 [(SA404)] Z8F0113SH005SG@SOIC20 [(SA404)]  
Z8F0113SJ005EC@SOIC28 [(SA404)] Z8F0113SJ005EG@SOIC28 [(SA404)]  
Z8F0113SJ005SC@SOIC28 [(SA404)] Z8F0113SJ005SG@SOIC28 [(SA404)]  
Z8F011AHH020EC@SSOP20 [(SA626A)] Z8F011AHH020EG@SSOP20 [(SA626A)]  
Z8F011AHH020SC@SSOP20 [(SA626A)] Z8F011AHH020SG@SSOP20 [(SA626A)]  
Z8F011AHJ020EC@SSOP28 [(SA626A)] Z8F011AHJ020EG@SSOP28 [(SA626A)]  
Z8F011AHJ020SC@SSOP28 [(SA626A)] Z8F011AHJ020SG@SSOP28 [(SA626A)]  
Z8F011APB020EC Z8F011APB020EG  
Z8F011APB020SC Z8F011APB020SG  
Z8F011APH020EC Z8F011APH020EG  
Z8F011APH020SC Z8F011APH020SG  
Z8F011APJ020EC Z8F011APJ020EG  
Z8F011APJ020SC Z8F011APJ020SG  
Z8F011AQB020EC@QFN8 [(SA683)] Z8F011AQB020EG@QFN8 [(SA683)]  
Z8F011AQB020SC@QFN8 [(SA683)] Z8F011AQB020SG@QFN8 [(SA683)]  
Z8F011ASB020EC@SOIC8 [(SA602A)] Z8F011ASB020EG@SOIC8 [(SA602A)]  
Z8F011ASB020SC@SOIC8 [(SA602A)] Z8F011ASB020SG@SOIC8 [(SA602A)]  
Z8F011ASH020EC@SOIC20 [(SA404)] Z8F011ASH020EG@SOIC20 [(SA404)]  
Z8F011ASH020SC@SOIC20 [(SA404)] Z8F011ASH020SG@SOIC20 [(SA404)]  
Z8F011ASJ020EC@SOIC28 [(SA404)] Z8F011ASJ020EG@SOIC28 [(SA404)]  
Z8F011ASJ020SC@SOIC28 [(SA404)] Z8F011ASJ020SG@SOIC28 [(SA404)]  
Z8F0123HH005EC@SSOP20 [(SA626A)] Z8F0123HH005EG@SSOP20 [(SA626A)]  
Z8F0123HH005SC@SSOP20 [(SA626A)] Z8F0123HH005SG@SSOP20 [(SA626A)]  
Z8F0123HJ005EC@SSOP28 [(SA626A)] Z8F0123HJ005EG@SSOP28 [(SA626A)]  
Z8F0123HJ005SC@SSOP28 [(SA626A)] Z8F0123HJ005SG@SSOP28 [(SA626A)]  
Z8F0123PB005EC Z8F0123PB005EG  
Z8F0123PB005SC Z8F0123PB005SG  
Z8F0123PH005EC Z8F0123PH005EG  
Z8F0123PH005SC Z8F0123PH005SG

Z8F0123PJ005EC                    Z8F0123PJ005EG  
Z8F0123PJ005SC                    Z8F0123PJ005SG  
Z8F0123QB005EC@QFN8 [(SA683)]    Z8F0123QB005EG@QFN8 [(SA683)]  
Z8F0123QB005SC@QFN8 [(SA683)]    Z8F0123QB005SG@QFN8 [(SA683)]  
Z8F0123SB005EC@SOIC8 [(SA602A)]    Z8F0123SB005EG@SOIC8 [(SA602A)]  
Z8F0123SB005SC@SOIC8 [(SA602A)]    Z8F0123SB005SG@SOIC8 [(SA602A)]  
Z8F0123SH005EC@SOIC20 [(SA404)]    Z8F0123SH005EG@SOIC20 [(SA404)]  
Z8F0123SH005SC@SOIC20 [(SA404)]    Z8F0123SH005SG@SOIC20 [(SA404)]  
Z8F0123SJ005EC@SOIC28 [(SA404)]    Z8F0123SJ005EG@SOIC28 [(SA404)]  
Z8F0123SJ005SC@SOIC28 [(SA404)]    Z8F0123SJ005SG@SOIC28 [(SA404)]  
Z8F012AHH020EC@SSOP20 [(SA626A)]    Z8F012AHH020EG@SSOP20 [(SA626A)]  
Z8F012AHH020SC@SSOP20 [(SA626A)]    Z8F012AHH020SG@SSOP20 [(SA626A)]  
Z8F012AHJ020EC@SSOP28 [(SA626A)]    Z8F012AHJ020EG@SSOP28 [(SA626A)]  
Z8F012AHJ020SC@SSOP28 [(SA626A)]    Z8F012AHJ020SG@SSOP28 [(SA626A)]  
Z8F012APB020EC                    Z8F012APB020EG  
Z8F012APB020SC                    Z8F012APB020SG  
Z8F012APH020EC                    Z8F012APH020EG  
Z8F012APH020SC                    Z8F012APH020SG  
Z8F012APJ020EC                    Z8F012APJ020EG  
Z8F012APJ020SC                    Z8F012APJ020SG  
Z8F012AQB020EC@QFN8 [(SA683)]    Z8F012AQB020EG@QFN8 [(SA683)]  
Z8F012AQB020SC@QFN8 [(SA683)]    Z8F012AQB020SG@QFN8 [(SA683)]  
Z8F012ASB020EC@SOIC8 [(SA602A)]    Z8F012ASB020EG@SOIC8 [(SA602A)]  
Z8F012ASB020SC@SOIC8 [(SA602A)]    Z8F012ASB020SG@SOIC8 [(SA602A)]  
Z8F012ASH020EC@SOIC20 [(SA404)]    Z8F012ASH020EG@SOIC20 [(SA404)]  
Z8F012ASH020SC@SOIC20 [(SA404)]    Z8F012ASH020SG@SOIC20 [(SA404)]  
Z8F012ASJ020EC@SOIC28 [(SA404)]    Z8F012ASJ020EG@SOIC28 [(SA404)]  
Z8F012ASJ020SC@SOIC28 [(SA404)]    Z8F012ASJ020SG@SOIC28 [(SA404)]  
Z8F0130HH020EG@SSOP20 [(SA626A)]    Z8F0130HH020SG@SSOP20 [(SA626A)]  
Z8F0130HJ020EG@SSOP28 [(SA626A)]    Z8F0130HJ020SG@SSOP28 [(SA626A)]  
Z8F0130PH020EG                    Z8F0130PH020SG  
Z8F0130PJ020EG                    Z8F0130PJ020SG  
Z8F0130QH020EG@QFN20 [(SA759)]    Z8F0130QH020SG@QFN20 [(SA759)]  
Z8F0130QJ020EG@QFN28 [(SA697)]    Z8F0130QJ020SG@QFN28 [(SA697)]  
Z8F0130SH020EG@SOIC20 [(SA404)]    Z8F0130SH020SG@SOIC20 [(SA404)]  
Z8F0130SJ020EG@SOIC28 [(SA404)]    Z8F0130SJ020SG@SOIC28 [(SA404)]  
Z8F0131HH020EG@SSOP20 [(SA626A)]    Z8F0131HH020SG@SSOP20 [(SA626A)]  
Z8F0131HJ020EG@SSOP28 [(SA626A)]    Z8F0131HJ020SG@SSOP28 [(SA626A)]  
Z8F0131PH020EG                    Z8F0131PH020SG  
Z8F0131PJ020EG                    Z8F0131PJ020SG  
Z8F0131QH020EG@QFN20 [(SA759)]    Z8F0131QH020SG@QFN20 [(SA759)]  
Z8F0131QJ020EG@QFN28 [(SA697)]    Z8F0131QJ020SG@QFN28 [(SA697)]  
Z8F0131SH020EG@SOIC20 [(SA404)]    Z8F0131SH020SG@SOIC20 [(SA404)]

Z8F0131SJ020EG@SOIC28 [(SA404)] Z8F0131SJ020SG@SOIC28 [(SA404)]  
Z8F0213HH005EC@SSOP20 [(SA626A)] Z8F0213HH005EG@SSOP20 [(SA626A)]  
Z8F0213HH005SC@SSOP20 [(SA626A)] Z8F0213HH005SG@SSOP20 [(SA626A)]  
Z8F0213HJ005EC@SSOP28 [(SA626A)] Z8F0213HJ005EG@SSOP28 [(SA626A)]  
Z8F0213HJ005SC@SSOP28 [(SA626A)] Z8F0213HJ005SG@SSOP28 [(SA626A)]  
Z8F0213PB005EC Z8F0213PB005EG  
Z8F0213PB005SC Z8F0213PB005SG  
Z8F0213PH005EC Z8F0213PH005EG  
Z8F0213PH005SC Z8F0213PH005SG  
Z8F0213PJ005EC Z8F0213PJ005EG  
Z8F0213PJ005SC Z8F0213PJ005SG  
Z8F0213QB005EC@QFN8 [(SA683)] Z8F0213QB005EG@QFN8 [(SA683)]  
Z8F0213QB005SC@QFN8 [(SA683)] Z8F0213QB005SG@QFN8 [(SA683)]  
Z8F0213SB005EC@SOIC8 [(SA602A)] Z8F0213SB005EG@SOIC8 [(SA602A)]  
Z8F0213SB005SC@SOIC8 [(SA602A)] Z8F0213SB005SG@SOIC8 [(SA602A)]  
Z8F0213SH005EC@SOIC20 [(SA404)] Z8F0213SH005EG@SOIC20 [(SA404)]  
Z8F0213SH005SC@SOIC20 [(SA404)] Z8F0213SH005SG@SOIC20 [(SA404)]  
Z8F0213SJ005EC@SOIC28 [(SA404)] Z8F0213SJ005EG@SOIC28 [(SA404)]  
Z8F0213SJ005SC@SOIC28 [(SA404)] Z8F0213SJ005SG@SOIC28 [(SA404)]  
Z8F021AHH020EC@SSOP20 [(SA626A)] Z8F021AHH020EG@SSOP20 [(SA626A)]  
Z8F021AHH020SC@SSOP20 [(SA626A)] Z8F021AHH020SG@SSOP20 [(SA626A)]  
Z8F021AHJ020EC@SSOP28 [(SA626A)] Z8F021AHJ020EG@SSOP28 [(SA626A)]  
Z8F021AHJ020SC@SSOP28 [(SA626A)] Z8F021AHJ020SG@SSOP28 [(SA626A)]  
Z8F021APB020EC Z8F021APB020EG  
Z8F021APB020SC Z8F021APB020SG  
Z8F021APH020EC Z8F021APH020EG  
Z8F021APH020SC Z8F021APH020SG  
Z8F021APJ020EC Z8F021APJ020EG  
Z8F021APJ020SC Z8F021APJ020SG  
Z8F021AQB020EC@QFN8 [(SA683)] Z8F021AQB020EG@QFN8 [(SA683)]  
Z8F021AQB020SC@QFN8 [(SA683)] Z8F021AQB020SG@QFN8 [(SA683)]  
Z8F021ASB020EC@SOIC8 [(SA602A)] Z8F021ASB020EG@SOIC8 [(SA602A)]  
Z8F021ASB020SC@SOIC8 [(SA602A)] Z8F021ASB020SG@SOIC8 [(SA602A)]  
Z8F021ASH020EC@SOIC20 [(SA404)] Z8F021ASH020EG@SOIC20 [(SA404)]  
Z8F021ASH020SC@SOIC20 [(SA404)] Z8F021ASH020SG@SOIC20 [(SA404)]  
Z8F021ASJ020EC@SOIC28 [(SA404)] Z8F021ASJ020EG@SOIC28 [(SA404)]  
Z8F021ASJ020SC@SOIC28 [(SA404)] Z8F021ASJ020SG@SOIC28 [(SA404)]  
Z8F0223HH005EC@SSOP20 [(SA626A)] Z8F0223HH005EG@SSOP20 [(SA626A)]  
Z8F0223HH005SC@SSOP20 [(SA626A)] Z8F0223HH005SG@SSOP20 [(SA626A)]  
Z8F0223HJ005EC@SSOP28 [(SA626A)] Z8F0223HJ005EG@SSOP28 [(SA626A)]  
Z8F0223HJ005SC@SSOP28 [(SA626A)] Z8F0223HJ005SG@SSOP28 [(SA626A)]  
Z8F0223PB005EC Z8F0223PB005EG  
Z8F0223PB005SC Z8F0223PB005SG

Z8F0223PH005EC	Z8F0223PH005EG
Z8F0223PH005SC	Z8F0223PH005SG
Z8F0223PJ005EC	Z8F0223PJ005EG
Z8F0223PJ005SC	Z8F0223PJ005SG
Z8F0223QB005EC@QFN8 [(SA683)]	Z8F0223QB005EG@QFN8 [(SA683)]
Z8F0223QB005SC@QFN8 [(SA683)]	Z8F0223QB005SG@QFN8 [(SA683)]
Z8F0223SB005EC@SOIC8 [(SA602A)]	Z8F0223SB005EG@SOIC8 [(SA602A)]
Z8F0223SB005SC@SOIC8 [(SA602A)]	Z8F0223SB005SG@SOIC8 [(SA602A)]
Z8F0223SH005EC@SOIC20 [(SA404)]	Z8F0223SH005EG@SOIC20 [(SA404)]
Z8F0223SH005SC@SOIC20 [(SA404)]	Z8F0223SH005SG@SOIC20 [(SA404)]
Z8F0223SJ005EC@SOIC28 [(SA404)]	Z8F0223SJ005EG@SOIC28 [(SA404)]
Z8F0223SJ005SC@SOIC28 [(SA404)]	Z8F0223SJ005SG@SOIC28 [(SA404)]
Z8F022AHH020EC@SSOP20 [(SA626A)]	Z8F022AHH020EG@SSOP20 [(SA626A)]
Z8F022AHH020SC@SSOP20 [(SA626A)]	Z8F022AHH020SG@SSOP20 [(SA626A)]
Z8F022AHJ020EC@SSOP28 [(SA626A)]	Z8F022AHJ020EG@SSOP28 [(SA626A)]
Z8F022AHJ020SC@SSOP28 [(SA626A)]	Z8F022AHJ020SG@SSOP28 [(SA626A)]
Z8F022APB020EC	Z8F022APB020EG
Z8F022APB020SC	Z8F022APB020SG
Z8F022APH020EC	Z8F022APH020EG
Z8F022APH020SC	Z8F022APH020SG
Z8F022APJ020EC	Z8F022APJ020EG
Z8F022APJ020SC	Z8F022APJ020SG
Z8F022AQB020EC@QFN8 [(SA683)]	Z8F022AQB020EG@QFN8 [(SA683)]
Z8F022AQB020SC@QFN8 [(SA683)]	Z8F022AQB020SG@QFN8 [(SA683)]
Z8F022ASB020EC@SOIC8 [(SA602A)]	Z8F022ASB020EG@SOIC8 [(SA602A)]
Z8F022ASB020SC@SOIC8 [(SA602A)]	Z8F022ASB020SG@SOIC8 [(SA602A)]
Z8F022ASH020EC@SOIC20 [(SA404)]	Z8F022ASH020EG@SOIC20 [(SA404)]
Z8F022ASH020SC@SOIC20 [(SA404)]	Z8F022ASH020SG@SOIC20 [(SA404)]
Z8F022ASJ020EC@SOIC28 [(SA404)]	Z8F022ASJ020EG@SOIC28 [(SA404)]
Z8F022ASJ020SC@SOIC28 [(SA404)]	Z8F022ASJ020SG@SOIC28 [(SA404)]
Z8F0230HH020EG@SSOP20 [(SA626A)]	Z8F0230HH020SG@SSOP20 [(SA626A)]
Z8F0230HJ020EG@SSOP28 [(SA626A)]	Z8F0230HJ020SG@SSOP28 [(SA626A)]
Z8F0230PH020EG	Z8F0230PH020SG
Z8F0230PJ020EG	Z8F0230PJ020SG
Z8F0230QH020EG@QFN20 [(SA759)]	Z8F0230QH020SG@QFN20 [(SA759)]
Z8F0230QJ020EG@QFN28 [(SA697)]	Z8F0230QJ020SG@QFN28 [(SA697)]
Z8F0230SH020EG@SOIC20 [(SA404)]	Z8F0230SH020SG@SOIC20 [(SA404)]
Z8F0230SJ020EG@SOIC28 [(SA404)]	Z8F0230SJ020SG@SOIC28 [(SA404)]
Z8F0231HH020EG@SSOP20 [(SA626A)]	Z8F0231HH020SG@SSOP20 [(SA626A)]
Z8F0231HJ020EG@SSOP28 [(SA626A)]	Z8F0231HJ020SG@SSOP28 [(SA626A)]
Z8F0231PH020EG	Z8F0231PH020SG
Z8F0231PJ020EG	Z8F0231PJ020SG
Z8F0231QH020EG@QFN20 [(SA759)]	Z8F0231QH020SG@QFN20 [(SA759)]

Z8F0231QJ020EG@QFN28 [(SA697)]    Z8F0231QJ020SG@QFN28 [(SA697)]  
Z8F0231SH020EG@SOIC20 [(SA404)]    Z8F0231SH020SG@SOIC20 [(SA404)]  
Z8F0231SJ020EG@SOIC28 [(SA404)]    Z8F0231SJ020SG@SOIC28 [(SA404)]  
Z8F0411HH020EC@SSOP20 [(SA626A)]    Z8F0411HH020EG@SSOP20 [(SA626A)]  
Z8F0411HH020SC@SSOP20 [(SA626A)]    Z8F0411HH020SG@SSOP20 [(SA626A)]  
Z8F0411PH020EC                        Z8F0411PH020EG  
Z8F0411PH020SC                        Z8F0411PH020SG  
Z8F0412PJ020EC                        Z8F0412PJ020EG  
Z8F0412PJ020SC                        Z8F0412PJ020SG  
Z8F0412SJ020EC@SOIC28 [(SA404)]    Z8F0412SJ020EG@SOIC28 [(SA404)]  
Z8F0412SJ020SC@SOIC28 [(SA404)]    Z8F0412SJ020SG@SOIC28 [(SA404)]  
Z8F0413HH005EC@SSOP20 [(SA626A)]    Z8F0413HH005EG@SSOP20 [(SA626A)]  
Z8F0413HH005SC@SSOP20 [(SA626A)]    Z8F0413HH005SG@SSOP20 [(SA626A)]  
Z8F0413HJ005EC@SSOP28 [(SA626A)]    Z8F0413HJ005EG@SSOP28 [(SA626A)]  
Z8F0413HJ005SC@SSOP28 [(SA626A)]    Z8F0413HJ005SG@SSOP28 [(SA626A)]  
Z8F0413PB005EC                        Z8F0413PB005EG  
Z8F0413PB005SC                        Z8F0413PB005SG  
Z8F0413PH005EC                        Z8F0413PH005EG  
Z8F0413PH005SC                        Z8F0413PH005SG  
Z8F0413PJ005EC                        Z8F0413PJ005EG  
Z8F0413PJ005SC                        Z8F0413PJ005SG  
Z8F0413QB005EC@QFN8 [(SA683)]    Z8F0413QB005EG@QFN8 [(SA683)]  
Z8F0413QB005SC@QFN8 [(SA683)]    Z8F0413QB005SG@QFN8 [(SA683)]  
Z8F0413SB005EC@SOIC8 [(SA602A)]    Z8F0413SB005EG@SOIC8 [(SA602A)]  
Z8F0413SB005SC@SOIC8 [(SA602A)]    Z8F0413SB005SG@SOIC8 [(SA602A)]  
Z8F0413SH005EC@SOIC20 [(SA404)]    Z8F0413SH005EG@SOIC20 [(SA404)]  
Z8F0413SH005SC@SOIC20 [(SA404)]    Z8F0413SH005SG@SOIC20 [(SA404)]  
Z8F0413SJ005EC@SOIC28 [(SA404)]    Z8F0413SJ005EG@SOIC28 [(SA404)]  
Z8F0413SJ005SC@SOIC28 [(SA404)]    Z8F0413SJ005SG@SOIC28 [(SA404)]  
Z8F041AHH020EC@SSOP20 [(SA626A)]    Z8F041AHH020EG@SSOP20 [(SA626A)]  
Z8F041AHH020SC@SSOP20 [(SA626A)]    Z8F041AHH020SG@SSOP20 [(SA626A)]  
Z8F041AHJ020EC@SSOP28 [(SA626A)]    Z8F041AHJ020EG@SSOP28 [(SA626A)]  
Z8F041AHJ020SC@SSOP28 [(SA626A)]    Z8F041AHJ020SG@SSOP28 [(SA626A)]  
Z8F041APB020EC                        Z8F041APB020EG  
Z8F041APB020SC                        Z8F041APB020SG  
Z8F041APH020EC                        Z8F041APH020EG  
Z8F041APH020SC                        Z8F041APH020SG  
Z8F041APJ020EC                        Z8F041APJ020EG  
Z8F041APJ020SC                        Z8F041APJ020SG  
Z8F041AQB020EC@QFN8 [(SA683)]    Z8F041AQB020EG@QFN8 [(SA683)]  
Z8F041AQB020SC@QFN8 [(SA683)]    Z8F041AQB020SG@QFN8 [(SA683)]  
Z8F041ASB020EC@SOIC8 [(SA602A)]    Z8F041ASB020EG@SOIC8 [(SA602A)]  
Z8F041ASB020SC@SOIC8 [(SA602A)]    Z8F041ASB020SG@SOIC8 [(SA602A)]

Z8F041ASH020EC@SOIC20 [(SA404)] Z8F041ASH020EG@SOIC20 [(SA404)]  
Z8F041ASH020SC@SOIC20 [(SA404)] Z8F041ASH020SG@SOIC20 [(SA404)]  
Z8F041ASJ020EC@SOIC28 [(SA404)] Z8F041ASJ020EG@SOIC28 [(SA404)]  
Z8F041ASJ020SC@SOIC28 [(SA404)] Z8F041ASJ020SG@SOIC28 [(SA404)]  
Z8F0421HH020EC@SSOP20 [(SA626A)] Z8F0421HH020EG@SSOP20 [(SA626A)]  
Z8F0421HH020SC@SSOP20 [(SA626A)] Z8F0421HH020SG@SSOP20 [(SA626A)]  
Z8F0421PH020EC Z8F0421PH020EG  
Z8F0421PH020SC Z8F0421PH020SG  
Z8F0422PJ020EC Z8F0422PJ020EG  
Z8F0422PJ020SC Z8F0422PJ020SG  
Z8F0422SJ020EC@SOIC28 [(SA404)] Z8F0422SJ020EG@SOIC28 [(SA404)]  
Z8F0422SJ020SC@SOIC28 [(SA404)] Z8F0422SJ020SG@SOIC28 [(SA404)]  
Z8F0423HH005EC@SSOP20 [(SA626A)] Z8F0423HH005EG@SSOP20 [(SA626A)]  
Z8F0423HH005SC@SSOP20 [(SA626A)] Z8F0423HH005SG@SSOP20 [(SA626A)]  
Z8F0423HJ005EC@SSOP28 [(SA626A)] Z8F0423HJ005EG@SSOP28 [(SA626A)]  
Z8F0423HJ005SC@SSOP28 [(SA626A)] Z8F0423HJ005SG@SSOP28 [(SA626A)]  
Z8F0423PB005EC Z8F0423PB005EG  
Z8F0423PB005SC Z8F0423PB005SG  
Z8F0423PH005EC Z8F0423PH005EG  
Z8F0423PH005SC Z8F0423PH005SG  
Z8F0423PJ005EC Z8F0423PJ005EG  
Z8F0423PJ005SC Z8F0423PJ005SG  
Z8F0423QB005EC@QFN8 [(SA683)] Z8F0423QB005EG@QFN8 [(SA683)]  
Z8F0423QB005SC@QFN8 [(SA683)] Z8F0423QB005SG@QFN8 [(SA683)]  
Z8F0423SB005EC@SOIC8 [(SA602A)] Z8F0423SB005EG@SOIC8 [(SA602A)]  
Z8F0423SB005SC@SOIC8 [(SA602A)] Z8F0423SB005SG@SOIC8 [(SA602A)]  
Z8F0423SH005EC@SOIC20 [(SA404)] Z8F0423SH005EG@SOIC20 [(SA404)]  
Z8F0423SH005SC@SOIC20 [(SA404)] Z8F0423SH005SG@SOIC20 [(SA404)]  
Z8F0423SJ005EC@SOIC28 [(SA404)] Z8F0423SJ005EG@SOIC28 [(SA404)]  
Z8F0423SJ005SC@SOIC28 [(SA404)] Z8F0423SJ005SG@SOIC28 [(SA404)]  
Z8F042AHH020EC@SSOP20 [(SA626A)] Z8F042AHH020EG@SSOP20 [(SA626A)]  
Z8F042AHH020SC@SSOP20 [(SA626A)] Z8F042AHH020SG@SSOP20 [(SA626A)]  
Z8F042AHJ020EC@SSOP28 [(SA626A)] Z8F042AHJ020EG@SSOP28 [(SA626A)]  
Z8F042AHJ020SC@SSOP28 [(SA626A)] Z8F042AHJ020SG@SSOP28 [(SA626A)]  
Z8F042APB020EC Z8F042APB020EG  
Z8F042APB020SC Z8F042APB020SG  
Z8F042APH020EC Z8F042APH020EG  
Z8F042APH020SC Z8F042APH020SG  
Z8F042APJ020EC Z8F042APJ020EG  
Z8F042APJ020SC Z8F042APJ020SG  
Z8F042AQB020EC@QFN8 [(SA683)] Z8F042AQB020EG@QFN8 [(SA683)]  
Z8F042AQB020SC@QFN8 [(SA683)] Z8F042AQB020SG@QFN8 [(SA683)]  
Z8F042ASB020EC@SOIC8 [(SA602A)] Z8F042ASB020EG@SOIC8 [(SA602A)]

Z8F042ASB020SC@SOIC8 [(SA602A)]    Z8F042ASB020SG@SOIC8 [(SA602A)]  
Z8F042ASH020EC@SOIC20 [(SA404)]    Z8F042ASH020EG@SOIC20 [(SA404)]  
Z8F042ASH020SC@SOIC20 [(SA404)]    Z8F042ASH020SG@SOIC20 [(SA404)]  
Z8F042ASJ020EC@SOIC28 [(SA404)]    Z8F042ASJ020EG@SOIC28 [(SA404)]  
Z8F042ASJ020SC@SOIC28 [(SA404)]    Z8F042ASJ020SG@SOIC28 [(SA404)]  
Z8F0430HH020EG@SSOP20 [(SA626A)]    Z8F0430HH020SG@SSOP20 [(SA626A)]  
Z8F0430HJ020EG@SSOP28 [(SA626A)]    Z8F0430HJ020SG@SSOP28 [(SA626A)]  
Z8F0430PH020EG                        Z8F0430PH020SG  
Z8F0430PJ020EG                        Z8F0430PJ020SG  
Z8F0430QH020EG@QFN20 [(SA759)]    Z8F0430QH020SG@QFN20 [(SA759)]  
Z8F0430QJ020EG@QFN28 [(SA697)]    Z8F0430QJ020SG@QFN28 [(SA697)]  
Z8F0430SH020EG@SOIC20 [(SA404)]    Z8F0430SH020SG@SOIC20 [(SA404)]  
Z8F0430SJ020EG@SOIC28 [(SA404)]    Z8F0430SJ020SG@SOIC28 [(SA404)]  
Z8F0431HH020EG@SSOP20 [(SA626A)]    Z8F0431HH020SG@SSOP20 [(SA626A)]  
Z8F0431HJ020EG@SSOP28 [(SA626A)]    Z8F0431HJ020SG@SSOP28 [(SA626A)]  
Z8F0431PH020EG                        Z8F0431PH020SG  
Z8F0431PJ020EG                        Z8F0431PJ020SG  
Z8F0431QH020EG@QFN20 [(SA759)]    Z8F0431QH020SG@QFN20 [(SA759)]  
Z8F0431QJ020EG@QFN28 [(SA697)]    Z8F0431QJ020SG@QFN28 [(SA697)]  
Z8F0431SH020EG@SOIC20 [(SA404)]    Z8F0431SH020SG@SOIC20 [(SA404)]  
Z8F0431SJ020EG@SOIC28 [(SA404)]    Z8F0431SJ020SG@SOIC28 [(SA404)]  
Z8F0811HH020EC@SSOP20 [(SA626A)]    Z8F0811HH020EG@SSOP20 [(SA626A)]  
Z8F0811HH020SC@SSOP20 [(SA626A)]    Z8F0811HH020SG@SSOP20 [(SA626A)]  
Z8F0811PH020EC                        Z8F0811PH020EG  
Z8F0811PH020SC                        Z8F0811PH020SG  
Z8F0812PJ020EC                        Z8F0812PJ020EG  
Z8F0812PJ020SC                        Z8F0812PJ020SG  
Z8F0812SJ020EC@SOIC28 [(SA404)]    Z8F0812SJ020EG@SOIC28 [(SA404)]  
Z8F0812SJ020SC@SOIC28 [(SA404)]    Z8F0812SJ020SG@SOIC28 [(SA404)]  
Z8F0813HH005EC@SSOP20 [(SA626A)]    Z8F0813HH005EG@SSOP20 [(SA626A)]  
Z8F0813HH005SC@SSOP20 [(SA626A)]    Z8F0813HH005SG@SSOP20 [(SA626A)]  
Z8F0813HJ020EC@SSOP28 [(SA626A)]    Z8F0813HJ020EG@SSOP28 [(SA626A)]  
Z8F0813HJ020SC@SSOP28 [(SA626A)]    Z8F0813HJ020SG@SSOP28 [(SA626A)]  
Z8F0813PB005EC                        Z8F0813PB005EG  
Z8F0813PB005SC                        Z8F0813PB005SG  
Z8F0813PH005EC                        Z8F0813PH005EG  
Z8F0813PH005SC                        Z8F0813PH005SG  
Z8F0813PJ020EC                        Z8F0813PJ020EG  
Z8F0813PJ020SC                        Z8F0813PJ020SG  
Z8F0813QB005EC@QFN8 [(SA683)]    Z8F0813QB005EG@QFN8 [(SA683)]  
Z8F0813QB005SC@QFN8 [(SA683)]    Z8F0813QB005SG@QFN8 [(SA683)]  
Z8F0813SB005EC@SOIC8 [(SA602A)]    Z8F0813SB005EG@SOIC8 [(SA602A)]  
Z8F0813SB005SC@SOIC8 [(SA602A)]    Z8F0813SB005SG@SOIC8 [(SA602A)]

Z8F0813SH005EC@SOIC20 [(SA404)] Z8F0813SH005EG@SOIC20 [(SA404)]  
Z8F0813SH005SC@SOIC20 [(SA404)] Z8F0813SH005SG@SOIC20 [(SA404)]  
Z8F0813SJ020EC@SOIC28 [(SA404)] Z8F0813SJ020EG@SOIC28 [(SA404)]  
Z8F0813SJ020SC@SOIC28 [(SA404)] Z8F0813SJ020SG@SOIC28 [(SA404)]  
Z8F081AHH005EC@SSOP20 [(SA626A)] Z8F081AHH005EG@SSOP20 [(SA626A)]  
Z8F081AHH005SC@SSOP20 [(SA626A)] Z8F081AHH005SG@SSOP20 [(SA626A)]  
Z8F081AHJ020EC@SSOP28 [(SA626A)] Z8F081AHJ020EG@SSOP28 [(SA626A)]  
Z8F081AHJ020SC@SSOP28 [(SA626A)] Z8F081AHJ020SG@SSOP28 [(SA626A)]  
Z8F081APB020EC Z8F081APB020EG  
Z8F081APB020SC Z8F081APB020SG  
Z8F081APH005EC Z8F081APH005EG  
Z8F081APH005SC Z8F081APH005SG  
Z8F081APJ020EC Z8F081APJ020EG  
Z8F081APJ020SC Z8F081APJ020SG  
Z8F081AQB020EC@QFN8 [(SA683)] Z8F081AQB020EG@QFN8 [(SA683)]  
Z8F081AQB020SC@QFN8 [(SA683)] Z8F081AQB020SG@QFN8 [(SA683)]  
Z8F081ASB020EC@SOIC8 [(SA602A)] Z8F081ASB020EG@SOIC8 [(SA602A)]  
Z8F081ASB020SC@SOIC8 [(SA602A)] Z8F081ASB020SG@SOIC8 [(SA602A)]  
Z8F081ASH005EC@SOIC20 [(SA404)] Z8F081ASH005EG@SOIC20 [(SA404)]  
Z8F081ASH005SC@SOIC20 [(SA404)] Z8F081ASH005SG@SOIC20 [(SA404)]  
Z8F081ASJ020EC@SOIC28 [(SA404)] Z8F081ASJ020EG@SOIC28 [(SA404)]  
Z8F081ASJ020SC@SOIC28 [(SA404)] Z8F081ASJ020SG@SOIC28 [(SA404)]  
Z8F0821HH020EC@SSOP20 [(SA626A)] Z8F0821HH020EG@SSOP20 [(SA626A)]  
Z8F0821HH020SC@SSOP20 [(SA626A)] Z8F0821HH020SG@SSOP20 [(SA626A)]  
Z8F0821PH020EC Z8F0821PH020EG  
Z8F0821PH020SC Z8F0821PH020SG  
Z8F0822PJ020EC Z8F0822PJ020EG  
Z8F0822PJ020SC Z8F0822PJ020SG  
Z8F0822SJ020EC@SOIC28 [(SA404)] Z8F0822SJ020EG@SOIC28 [(SA404)]  
Z8F0822SJ020SC@SOIC28 [(SA404)] Z8F0822SJ020SG@SOIC28 [(SA404)]  
Z8F0823HH005EC@SSOP20 [(SA626A)] Z8F0823HH005EG@SSOP20 [(SA626A)]  
Z8F0823HH005SC@SSOP20 [(SA626A)] Z8F0823HH005SG@SSOP20 [(SA626A)]  
Z8F0823HJ020EC@SSOP28 [(SA626A)] Z8F0823HJ020EG@SSOP28 [(SA626A)]  
Z8F0823HJ020SC@SSOP28 [(SA626A)] Z8F0823HJ020SG@SSOP28 [(SA626A)]  
Z8F0823PB005EC Z8F0823PB005EG  
Z8F0823PB005SC Z8F0823PB005SG  
Z8F0823PH005EC Z8F0823PH005EG  
Z8F0823PH005SC Z8F0823PH005SG  
Z8F0823PJ020EC Z8F0823PJ020EG  
Z8F0823PJ020SC Z8F0823PJ020SG  
Z8F0823QB005EC@QFN8 [(SA683)] Z8F0823QB005EG@QFN8 [(SA683)]  
Z8F0823QB005SC@QFN8 [(SA683)] Z8F0823QB005SG@QFN8 [(SA683)]  
Z8F0823SB005EC@SOIC8 [(SA602A)] Z8F0823SB005EG@SOIC8 [(SA602A)]



Z8F0823SB005SC@SOIC8 [(SA602A)] Z8F0823SB005SG@SOIC8 [(SA602A)]  
Z8F0823SH005EC@SOIC20 [(SA404)] Z8F0823SH005EG@SOIC20 [(SA404)]  
Z8F0823SH005SC@SOIC20 [(SA404)] Z8F0823SH005SG@SOIC20 [(SA404)]  
Z8F0823SJ020EC@SOIC28 [(SA404)] Z8F0823SJ020EG@SOIC28 [(SA404)]  
Z8F0823SJ020SC@SOIC28 [(SA404)] Z8F0823SJ020SG@SOIC28 [(SA404)]  
Z8F082AHH005EC@SSOP20 [(SA626A)] Z8F082AHH005EG@SSOP20 [(SA626A)]  
Z8F082AHH005SC@SSOP20 [(SA626A)] Z8F082AHH005SG@SSOP20 [(SA626A)]  
Z8F082AHJ020EC@SSOP28 [(SA626A)] Z8F082AHJ020EG@SSOP28 [(SA626A)]  
Z8F082AHJ020SC@SSOP28 [(SA626A)] Z8F082AHJ020SG@SSOP28 [(SA626A)]  
Z8F082APB020EC Z8F082APB020EG  
Z8F082APB020SC Z8F082APB020SG  
Z8F082APH005EC Z8F082APH005EG  
Z8F082APH005SC Z8F082APH005SG  
Z8F082APJ020EC Z8F082APJ020EG  
Z8F082APJ020SC Z8F082APJ020SG  
Z8F082AQB020EC@QFN8 [(SA683)] Z8F082AQB020EG@QFN8 [(SA683)]  
Z8F082AQB020SC@QFN8 [(SA683)] Z8F082AQB020SG@QFN8 [(SA683)]  
Z8F082ASB020EC@SOIC8 [(SA602A)] Z8F082ASB020EG@SOIC8 [(SA602A)]  
Z8F082ASB020SC@SOIC8 [(SA602A)] Z8F082ASB020SG@SOIC8 [(SA602A)]  
Z8F082ASH005EC@SOIC20 [(SA404)] Z8F082ASH005EG@SOIC20 [(SA404)]  
Z8F082ASH005SC@SOIC20 [(SA404)] Z8F082ASH005SG@SOIC20 [(SA404)]  
Z8F082ASJ020EC@SOIC28 [(SA404)] Z8F082ASJ020EG@SOIC28 [(SA404)]  
Z8F082ASJ020SC@SOIC28 [(SA404)] Z8F082ASJ020SG@SOIC28 [(SA404)]  
Z8F0830HH020EG@SSOP20 [(SA626A)] Z8F0830HH020SG@SSOP20 [(SA626A)]  
Z8F0830HJ020EG@SSOP28 [(SA626A)] Z8F0830HJ020SG@SSOP28 [(SA626A)]  
Z8F0830PH020EG Z8F0830PH020SG  
Z8F0830PJ020EG Z8F0830PJ020SG  
Z8F0830QH020EG@QFN20 [(SA759)] Z8F0830QH020SG@QFN20 [(SA759)]  
Z8F0830QJ020EG@QFN28 [(SA697)] Z8F0830QJ020SG@QFN28 [(SA697)]  
Z8F0830SH020EG@SOIC20 [(SA404)] Z8F0830SH020SG@SOIC20 [(SA404)]  
Z8F0830SJ020EG@SOIC28 [(SA404)] Z8F0830SJ020SG@SOIC28 [(SA404)]  
Z8F0831HH020EG@SSOP20 [(SA626A)] Z8F0831HH020SG@SSOP20 [(SA626A)]  
Z8F0831HJ020EG@SSOP28 [(SA626A)] Z8F0831HJ020SG@SSOP28 [(SA626A)]  
Z8F0831PH020EG Z8F0831PH020SG  
Z8F0831PJ020EG Z8F0831PJ020SG  
Z8F0831QH020EG@QFN20 [(SA759)] Z8F0831QH020SG@QFN20 [(SA759)]  
Z8F0831QJ020EG@QFN28 [(SA697)] Z8F0831QJ020SG@QFN28 [(SA697)]  
Z8F0831SH020EG@SOIC20 [(SA404)] Z8F0831SH020SG@SOIC20 [(SA404)]  
Z8F0831SJ020EG@SOIC28 [(SA404)] Z8F0831SJ020SG@SOIC28 [(SA404)]  
Z8F1232HH020EG@SSOP20 [(SA626A)] Z8F1232HH020SG@SSOP20 [(SA626A)]  
Z8F1232HJ020EG@SSOP28 [(SA626A)] Z8F1232HJ020SG@SSOP28 [(SA626A)]  
Z8F1232PH020EG Z8F1232PH020SG  
Z8F1232PJ020EG Z8F1232PJ020SG

Z8F1232QH020EG@QFN20 [(SA759)] Z8F1232QH020SG@QFN20 [(SA759)]  
Z8F1232QJ020EG@QFN28 [(SA697)] Z8F1232QJ020SG@QFN28 [(SA697)]  
Z8F1232SH020EG@SOIC20 [(SA404)] Z8F1232SH020SG@SOIC20 [(SA404)]  
Z8F1232SJ020EG@SOIC28 [(SA404)] Z8F1232SJ020SG@SOIC28 [(SA404)]  
Z8F1233HH020EG@SSOP20 [(SA626A)] Z8F1233HH020SG@SSOP20 [(SA626A)]  
Z8F1233HJ020EG@SSOP28 [(SA626A)] Z8F1233HJ020SG@SSOP28 [(SA626A)]  
Z8F1233PH020EG Z8F1233PH020SG  
Z8F1233PJ020EG Z8F1233PJ020SG  
Z8F1233QH020EG@QFN20 [(SA759)] Z8F1233QH020SG@QFN20 [(SA759)]  
Z8F1233QJ020EG@QFN28 [(SA697)] Z8F1233QJ020SG@QFN28 [(SA697)]  
Z8F1233SH020EG@SOIC20 [(SA404)] Z8F1233SH020SG@SOIC20 [(SA404)]  
Z8F1233SJ020EG@SOIC28 [(SA404)] Z8F1233SJ020SG@SOIC28 [(SA404)]  
Z8F4801AN@TQFP44 [(SA245A)] Z8F4801PM  
Z8F4801VN@PLCC44 [(SA244)] Z8F6401AN@TQFP44 [(SA245A)]  
Z8F6401PM Z8F6401VN@PLCC44 [(SA244)]  
Z8F6421AN020EC@LQFP44 [(SA245A)] Z8F6421AN020SC@LQFP44 [(SA245A)]  
Z8F6421PM020EC Z8F6421PM020SC  
Z8F6421VN020EC@PLCC44 [(SA244)] Z8F6421VN020SC@PLCC44 [(SA244)]  
ZGP323HAH2004C@SSOP20 [(SA626A)] ZGP323HAH2004G@SSOP20 [(SA626A)]  
ZGP323HAH2008C@SSOP20 [(SA626A)] ZGP323HAH2008G@SSOP20 [(SA626A)]  
ZGP323HAH2016C@SSOP20 [(SA626A)] ZGP323HAH2016G@SSOP20 [(SA626A)]  
ZGP323HAH2032C@SSOP20 [(SA626A)] ZGP323HAH2032G@SSOP20 [(SA626A)]  
ZGP323HAH2804C@SSOP28 [(SA626A)] ZGP323HAH2804G@SSOP28 [(SA626A)]  
ZGP323HAH2808C@SSOP28 [(SA626A)] ZGP323HAH2808G@SSOP28 [(SA626A)]  
ZGP323HAH2816C@SSOP28 [(SA626A)] ZGP323HAH2816G@SSOP28 [(SA626A)]  
ZGP323HAH2832C@SSOP28 [(SA626A)] ZGP323HAH2832G@SSOP28 [(SA626A)]  
ZGP323HAH4804C@SSOP48 [(SA669)] ZGP323HAH4804G@SSOP48 [(SA669)]  
ZGP323HAH4808C@SSOP48 [(SA669)] ZGP323HAH4808G@SSOP48 [(SA669)]  
ZGP323HAH4816C@SSOP48 [(SA669)] ZGP323HAH4816G@SSOP48 [(SA669)]  
ZGP323HAH4832C@SSOP48 [(SA669)] ZGP323HAH4832G@SSOP48 [(SA669)]  
ZGP323HAP2004C ZGP323HAP2004G  
ZGP323HAP2008C ZGP323HAP2008G  
ZGP323HAP2016C ZGP323HAP2016G  
ZGP323HAP2032C ZGP323HAP2032G  
ZGP323HAP2804C ZGP323HAP2804G  
ZGP323HAP2808C ZGP323HAP2808G  
ZGP323HAP2816C ZGP323HAP2816G  
ZGP323HAP2832C ZGP323HAP2832G  
ZGP323HAP4004C ZGP323HAP4004G  
ZGP323HAP4008C ZGP323HAP4008G  
ZGP323HAP4016C ZGP323HAP4016G  
ZGP323HAP4032C ZGP323HAP4032G  
ZGP323HAS2004C@SOIC20 [(SA404)] ZGP323HAS2004G@SOIC20 [(SA404)]

ZGP323HAS2008C@SOIC20 [(SA404)]	ZGP323HAS2008G@SOIC20 [(SA404)]
ZGP323HAS2016C@SOIC20 [(SA404)]	ZGP323HAS2016G@SOIC20 [(SA404)]
ZGP323HAS2032C@SOIC20 [(SA404)]	ZGP323HAS2032G@SOIC20 [(SA404)]
ZGP323HAS2804C@SOIC28 [(SA404)]	ZGP323HAS2804G@SOIC28 [(SA404)]
ZGP323HAS2808C@SOIC28 [(SA404)]	ZGP323HAS2808G@SOIC28 [(SA404)]
ZGP323HAS2816C@SOIC28 [(SA404)]	ZGP323HAS2816G@SOIC28 [(SA404)]
ZGP323HAS2832C@SOIC28 [(SA404)]	ZGP323HAS2832G@SOIC28 [(SA404)]
ZGP323HEH2004C@SSOP20 [(SA626A)]	ZGP323HEH2004G@SSOP20 [(SA626A)]
ZGP323HEH2008C@SSOP20 [(SA626A)]	ZGP323HEH2008G@SSOP20 [(SA626A)]
ZGP323HEH2016C@SSOP20 [(SA626A)]	ZGP323HEH2016G@SSOP20 [(SA626A)]
ZGP323HEH2032C@SSOP20 [(SA626A)]	ZGP323HEH2032G@SSOP20 [(SA626A)]
ZGP323HEH2804C@SSOP28 [(SA626A)]	ZGP323HEH2804G@SSOP28 [(SA626A)]
ZGP323HEH2808C@SSOP28 [(SA626A)]	ZGP323HEH2808G@SSOP28 [(SA626A)]
ZGP323HEH2816C@SSOP28 [(SA626A)]	ZGP323HEH2816G@SSOP28 [(SA626A)]
ZGP323HEH2832C@SSOP28 [(SA626A)]	ZGP323HEH2832G@SSOP28 [(SA626A)]
ZGP323HEH4804C@SSOP48 [(SA669)]	ZGP323HEH4804G@SSOP48 [(SA669)]
ZGP323HEH4808C@SSOP48 [(SA669)]	ZGP323HEH4808G@SSOP48 [(SA669)]
ZGP323HEH4816C@SSOP48 [(SA669)]	ZGP323HEH4816G@SSOP48 [(SA669)]
ZGP323HEH4832C@SSOP48 [(SA669)]	ZGP323HEH4832G@SSOP48 [(SA669)]
ZGP323HEP2004C	ZGP323HEP2004G
ZGP323HEP2008C	ZGP323HEP2008G
ZGP323HEP2016C	ZGP323HEP2016G
ZGP323HEP2032C	ZGP323HEP2032G
ZGP323HEP2804C	ZGP323HEP2804G
ZGP323HEP2808C	ZGP323HEP2808G
ZGP323HEP2816C	ZGP323HEP2816G
ZGP323HEP2832C	ZGP323HEP2832G
ZGP323HEP4004C	ZGP323HEP4004G
ZGP323HEP4008C	ZGP323HEP4008G
ZGP323HEP4016C	ZGP323HEP4016G
ZGP323HEP4032C	ZGP323HEP4032G
ZGP323HES2004C@SOIC20 [(SA404)]	ZGP323HES2004G@SOIC20 [(SA404)]
ZGP323HES2008C@SOIC20 [(SA404)]	ZGP323HES2008G@SOIC20 [(SA404)]
ZGP323HES2016C@SOIC20 [(SA404)]	ZGP323HES2016G@SOIC20 [(SA404)]
ZGP323HES2032C@SOIC20 [(SA404)]	ZGP323HES2032G@SOIC20 [(SA404)]
ZGP323HES2804C@SOIC28 [(SA404)]	ZGP323HES2804G@SOIC28 [(SA404)]
ZGP323HES2808C@SOIC28 [(SA404)]	ZGP323HES2808G@SOIC28 [(SA404)]
ZGP323HES2816C@SOIC28 [(SA404)]	ZGP323HES2816G@SOIC28 [(SA404)]
ZGP323HES2832C@SOIC28 [(SA404)]	ZGP323HES2832G@SOIC28 [(SA404)]
ZGP323HSH2004C@SSOP20 [(SA626A)]	ZGP323HSH2004G@SSOP20 [(SA626A)]
ZGP323HSH2008C@SSOP20 [(SA626A)]	ZGP323HSH2008G@SSOP20 [(SA626A)]
ZGP323HSH2016C@SSOP20 [(SA626A)]	ZGP323HSH2016G@SSOP20 [(SA626A)]
ZGP323HSH2032C@SSOP20 [(SA626A)]	ZGP323HSH2032G@SSOP20 [(SA626A)]

ZGP323HSH2804C@SSOP28 [(SA626A)] ZGP323HSH2804G@SSOP28 [(SA626A)]  
ZGP323HSH2808C@SSOP28 [(SA626A)] ZGP323HSH2808G@SSOP28 [(SA626A)]  
ZGP323HSH2816C@SSOP28 [(SA626A)] ZGP323HSH2816G@SSOP28 [(SA626A)]  
ZGP323HSH2832C@SSOP28 [(SA626A)] ZGP323HSH2832G@SSOP28 [(SA626A)]  
ZGP323HSH4804C@SSOP48 [(SA669)] ZGP323HSH4804G@SSOP48 [(SA669)]  
ZGP323HSH4808C@SSOP48 [(SA669)] ZGP323HSH4808G@SSOP48 [(SA669)]  
ZGP323HSH4816C@SSOP48 [(SA669)] ZGP323HSH4816G@SSOP48 [(SA669)]  
ZGP323HSH4832C@SSOP48 [(SA669)] ZGP323HSH4832G@SSOP48 [(SA669)]  
ZGP323HSP2004C ZGP323HSP2004G  
ZGP323HSP2008C ZGP323HSP2008G  
ZGP323HSP2016C ZGP323HSP2016G  
ZGP323HSP2032C ZGP323HSP2032G  
ZGP323HSP2804C ZGP323HSP2804G  
ZGP323HSP2808C ZGP323HSP2808G  
ZGP323HSP2816C ZGP323HSP2816G  
ZGP323HSP2832C ZGP323HSP2832G  
ZGP323HSP4004C ZGP323HSP4004G  
ZGP323HSP4008C ZGP323HSP4008G  
ZGP323HSP4016C ZGP323HSP4016G  
ZGP323HSP4032C ZGP323HSP4032G  
ZGP323HSS2004C@SOIC20 [(SA404)] ZGP323HSS2004G@SOIC20 [(SA404)]  
ZGP323HSS2008C@SOIC20 [(SA404)] ZGP323HSS2008G@SOIC20 [(SA404)]  
ZGP323HSS2016C@SOIC20 [(SA404)] ZGP323HSS2016G@SOIC20 [(SA404)]  
ZGP323HSS2032C@SOIC20 [(SA404)] ZGP323HSS2032G@SOIC20 [(SA404)]  
ZGP323HSS2804C@SOIC28 [(SA404)] ZGP323HSS2804G@SOIC28 [(SA404)]  
ZGP323HSS2808C@SOIC28 [(SA404)] ZGP323HSS2808G@SOIC28 [(SA404)]  
ZGP323HSS2816C@SOIC28 [(SA404)] ZGP323HSS2816G@SOIC28 [(SA404)]  
ZGP323HSS2832C@SOIC28 [(SA404)] ZGP323HSS2832G@SOIC28 [(SA404)]  
ZGP323LAH2004C@SSOP20 [(SA626A)] ZGP323LAH2004G@SSOP20 [(SA626A)]  
ZGP323LAH2008C@SSOP20 [(SA626A)] ZGP323LAH2008G@SSOP20 [(SA626A)]  
ZGP323LAH2016C@SSOP20 [(SA626A)] ZGP323LAH2016G@SSOP20 [(SA626A)]  
ZGP323LAH2032C@SSOP20 [(SA626A)] ZGP323LAH2032G@SSOP20 [(SA626A)]  
ZGP323LAH2804C@SSOP28 [(SA626A)] ZGP323LAH2804G@SSOP28 [(SA626A)]  
ZGP323LAH2808C@SSOP28 [(SA626A)] ZGP323LAH2808G@SSOP28 [(SA626A)]  
ZGP323LAH2816C@SSOP28 [(SA626A)] ZGP323LAH2816G@SSOP28 [(SA626A)]  
ZGP323LAH2832C@SSOP28 [(SA626A)] ZGP323LAH2832G@SSOP28 [(SA626A)]  
ZGP323LAH4804C@SSOP48 [(SA669)] ZGP323LAH4804G@SSOP48 [(SA669)]  
ZGP323LAH4808C@SSOP48 [(SA669)] ZGP323LAH4808G@SSOP48 [(SA669)]  
ZGP323LAH4816C@SSOP48 [(SA669)] ZGP323LAH4816G@SSOP48 [(SA669)]  
ZGP323LAH4832C@SSOP48 [(SA669)] ZGP323LAH4832G@SSOP48 [(SA669)]  
ZGP323LAP2004C ZGP323LAP2004G  
ZGP323LAP2008C ZGP323LAP2008G  
ZGP323LAP2016C ZGP323LAP2016G

ZGP323LAP2032C	ZGP323LAP2032G
ZGP323LAP2804C	ZGP323LAP2804G
ZGP323LAP2808C	ZGP323LAP2808G
ZGP323LAP2816C	ZGP323LAP2816G
ZGP323LAP2832C	ZGP323LAP2832G
ZGP323LAP4004C	ZGP323LAP4004G
ZGP323LAP4008C	ZGP323LAP4008G
ZGP323LAP4016C	ZGP323LAP4016G
ZGP323LAP4032C	ZGP323LAP4032G
ZGP323LAS2004C@SOIC20 [(SA404)]	ZGP323LAS2004G@SOIC20 [(SA404)]
ZGP323LAS2008C@SOIC20 [(SA404)]	ZGP323LAS2008G@SOIC20 [(SA404)]
ZGP323LAS2016C@SOIC20 [(SA404)]	ZGP323LAS2016G@SOIC20 [(SA404)]
ZGP323LAS2032C@SOIC20 [(SA404)]	ZGP323LAS2032G@SOIC20 [(SA404)]
ZGP323LAS2804C@SOIC28 [(SA404)]	ZGP323LAS2804G@SOIC28 [(SA404)]
ZGP323LAS2808C@SOIC28 [(SA404)]	ZGP323LAS2808G@SOIC28 [(SA404)]
ZGP323LAS2816C@SOIC28 [(SA404)]	ZGP323LAS2816G@SOIC28 [(SA404)]
ZGP323LAS2832C@SOIC28 [(SA404)]	ZGP323LAS2832G@SOIC28 [(SA404)]
ZGP323LEH2004C@SSOP20 [(SA626A)]	ZGP323LEH2004G@SSOP20 [(SA626A)]
ZGP323LEH2008C@SSOP20 [(SA626A)]	ZGP323LEH2008G@SSOP20 [(SA626A)]
ZGP323LEH2016C@SSOP20 [(SA626A)]	ZGP323LEH2016G@SSOP20 [(SA626A)]
ZGP323LEH2032C@SSOP20 [(SA626A)]	ZGP323LEH2032G@SSOP20 [(SA626A)]
ZGP323LEH2804C@SSOP28 [(SA626A)]	ZGP323LEH2804G@SSOP28 [(SA626A)]
ZGP323LEH2808C@SSOP28 [(SA626A)]	ZGP323LEH2808G@SSOP28 [(SA626A)]
ZGP323LEH2816C@SSOP28 [(SA626A)]	ZGP323LEH2816G@SSOP28 [(SA626A)]
ZGP323LEH2832C@SSOP28 [(SA626A)]	ZGP323LEH2832G@SSOP28 [(SA626A)]
ZGP323LEH4804C@SSOP48 [(SA669)]	ZGP323LEH4804G@SSOP48 [(SA669)]
ZGP323LEH4808C@SSOP48 [(SA669)]	ZGP323LEH4808G@SSOP48 [(SA669)]
ZGP323LEH4816C@SSOP48 [(SA669)]	ZGP323LEH4816G@SSOP48 [(SA669)]
ZGP323LEH4832C@SSOP48 [(SA669)]	ZGP323LEH4832G@SSOP48 [(SA669)]
ZGP323LEP2004C	ZGP323LEP2004G
ZGP323LEP2008C	ZGP323LEP2008G
ZGP323LEP2016C	ZGP323LEP2016G
ZGP323LEP2032C	ZGP323LEP2032G
ZGP323LEP2804C	ZGP323LEP2804G
ZGP323LEP2808C	ZGP323LEP2808G
ZGP323LEP2816C	ZGP323LEP2816G
ZGP323LEP2832C	ZGP323LEP2832G
ZGP323LEP4004C	ZGP323LEP4004G
ZGP323LEP4008C	ZGP323LEP4008G
ZGP323LEP4016C	ZGP323LEP4016G
ZGP323LEP4032C	ZGP323LEP4032G
ZGP323LES2004C@SOIC20 [(SA404)]	ZGP323LES2004G@SOIC20 [(SA404)]
ZGP323LES2008C@SOIC20 [(SA404)]	ZGP323LES2008G@SOIC20 [(SA404)]

ZGP323LES2016C@SOIC20 [(SA404)]	ZGP323LES2016G@SOIC20 [(SA404)]
ZGP323LES2032C@SOIC20 [(SA404)]	ZGP323LES2032G@SOIC20 [(SA404)]
ZGP323LES2804C@SOIC28 [(SA404)]	ZGP323LES2804G@SOIC28 [(SA404)]
ZGP323LES2808C@SOIC28 [(SA404)]	ZGP323LES2808G@SOIC28 [(SA404)]
ZGP323LES2816C@SOIC28 [(SA404)]	ZGP323LES2816G@SOIC28 [(SA404)]
ZGP323LES2832C@SOIC28 [(SA404)]	ZGP323LES2832G@SOIC28 [(SA404)]
ZGP323LSH2004C@SSOP20 [(SA626A)]	ZGP323LSH2004G@SSOP20 [(SA626A)]
ZGP323LSH2008C@SSOP20 [(SA626A)]	ZGP323LSH2008G@SSOP20 [(SA626A)]
ZGP323LSH2016C@SSOP20 [(SA626A)]	ZGP323LSH2016G@SSOP20 [(SA626A)]
ZGP323LSH2032C@SSOP20 [(SA626A)]	ZGP323LSH2032G@SSOP20 [(SA626A)]
ZGP323LSH2804C@SSOP28 [(SA626A)]	ZGP323LSH2804G@SSOP28 [(SA626A)]
ZGP323LSH2808C@SSOP28 [(SA626A)]	ZGP323LSH2808G@SSOP28 [(SA626A)]
ZGP323LSH2816C@SSOP28 [(SA626A)]	ZGP323LSH2816G@SSOP28 [(SA626A)]
ZGP323LSH2832C@SSOP28 [(SA626A)]	ZGP323LSH2832G@SSOP28 [(SA626A)]
ZGP323LSH4804C@SSOP48 [(SA669)]	ZGP323LSH4804G@SSOP48 [(SA669)]
ZGP323LSH4808C@SSOP48 [(SA669)]	ZGP323LSH4808G@SSOP48 [(SA669)]
ZGP323LSH4816C@SSOP48 [(SA669)]	ZGP323LSH4816G@SSOP48 [(SA669)]
ZGP323LSH4832C@SSOP48 [(SA669)]	ZGP323LSH4832G@SSOP48 [(SA669)]
ZGP323LSK2032E	ZGP323LSK2032G
ZGP323LSK2832E	ZGP323LSK2832G
ZGP323LSK4032E	ZGP323LSK4032G
ZGP323LSP2004C	ZGP323LSP2004G
ZGP323LSP2008C	ZGP323LSP2008G
ZGP323LSP2016C	ZGP323LSP2016G
ZGP323LSP2032C	ZGP323LSP2032G
ZGP323LSP2804C	ZGP323LSP2804G
ZGP323LSP2808C	ZGP323LSP2808G
ZGP323LSP2816C	ZGP323LSP2816G
ZGP323LSP2832C	ZGP323LSP2832G
ZGP323LSP4004C	ZGP323LSP4004G
ZGP323LSP4008C	ZGP323LSP4008G
ZGP323LSP4016C	ZGP323LSP4016G
ZGP323LSP4032C	ZGP323LSP4032G
ZGP323LSS2004C@SOIC20 [(SA404)]	ZGP323LSS2004G@SOIC20 [(SA404)]
ZGP323LSS2008C@SOIC20 [(SA404)]	ZGP323LSS2008G@SOIC20 [(SA404)]
ZGP323LSS2016C@SOIC20 [(SA404)]	ZGP323LSS2016G@SOIC20 [(SA404)]
ZGP323LSS2032C@SOIC20 [(SA404)]	ZGP323LSS2032G@SOIC20 [(SA404)]
ZGP323LSS2804C@SOIC28 [(SA404)]	ZGP323LSS2804G@SOIC28 [(SA404)]
ZGP323LSS2808C@SOIC28 [(SA404)]	ZGP323LSS2808G@SOIC28 [(SA404)]
ZGP323LSS2816C@SOIC28 [(SA404)]	ZGP323LSS2816G@SOIC28 [(SA404)]
ZGP323LSS2832C@SOIC28 [(SA404)]	ZGP323LSS2832G@SOIC28 [(SA404)]
ZLP12840H2028C@SSOP20 [(SA626A)]	ZLP12840H2028G@SSOP20 [(SA626A)]
ZLP12840H2032C@SSOP20 [(SA626A)]	ZLP12840H2032G@SSOP20 [(SA626A)]

ZLP12840H2064C@SSOP20 [(SA626A)]	ZLP12840H2064G@SSOP20 [(SA626A)]
ZLP12840H2096C@SSOP20 [(SA626A)]	ZLP12840H2096G@SSOP20 [(SA626A)]
ZLP12840H2828C@SSOP28 [(SA626A)]	ZLP12840H2828G@SSOP28 [(SA626A)]
ZLP12840H2832C@SSOP28 [(SA626A)]	ZLP12840H2832G@SSOP28 [(SA626A)]
ZLP12840H2864C@SSOP28 [(SA626A)]	ZLP12840H2864G@SSOP28 [(SA626A)]
ZLP12840H2896C@SSOP28 [(SA626A)]	ZLP12840H2896G@SSOP28 [(SA626A)]
ZLP12840P2028C	ZLP12840P2028G
ZLP12840P2032C	ZLP12840P2032G
ZLP12840P2064C	ZLP12840P2064G
ZLP12840P2096C	ZLP12840P2096G
ZLP12840P2828C	ZLP12840P2828G
ZLP12840P2832C	ZLP12840P2832G
ZLP12840P2864C	ZLP12840P2864G
ZLP12840P2896C	ZLP12840P2896G
ZLP12840S2028C@SOIC20 [(SA404)]	ZLP12840S2028G@SOIC20 [(SA404)]
ZLP12840S2032C@SOIC20 [(SA404)]	ZLP12840S2032G@SOIC20 [(SA404)]
ZLP12840S2064C@SOIC20 [(SA404)]	ZLP12840S2064G@SOIC20 [(SA404)]
ZLP12840S2096C@SOIC20 [(SA404)]	ZLP12840S2096G@SOIC20 [(SA404)]
ZLP12840S2828C@SOIC28 [(SA404)]	ZLP12840S2828G@SOIC28 [(SA404)]
ZLP12840S2832C@SOIC28 [(SA404)]	ZLP12840S2832G@SOIC28 [(SA404)]
ZLP12840S2864C@SOIC28 [(SA404)]	ZLP12840S2864G@SOIC28 [(SA404)]
ZLP12840S2896C@SOIC28 [(SA404)]	ZLP12840S2896G@SOIC28 [(SA404)]
ZLP32300H2004C@SSOP20 [(SA626A)]	ZLP32300H2004G@SSOP20 [(SA626A)]
ZLP32300H2008C@SSOP20 [(SA626A)]	ZLP32300H2008G@SSOP20 [(SA626A)]
ZLP32300H2016C@SSOP20 [(SA626A)]	ZLP32300H2016G@SSOP20 [(SA626A)]
ZLP32300H2032C@SSOP20 [(SA626A)]	ZLP32300H2032G@SSOP20 [(SA626A)]
ZLP32300H2804C@SSOP28 [(SA626A)]	ZLP32300H2804G@SSOP28 [(SA626A)]
ZLP32300H2808C@SSOP28 [(SA626A)]	ZLP32300H2808G@SSOP28 [(SA626A)]
ZLP32300H2816C@SSOP28 [(SA626A)]	ZLP32300H2816G@SSOP28 [(SA626A)]
ZLP32300H2832C@SSOP28 [(SA626A)]	ZLP32300H2832G@SSOP28 [(SA626A)]
ZLP32300H4804C@SSOP48 [(SA669)]	ZLP32300H4804G@SSOP48 [(SA669)]
ZLP32300H4808C@SSOP48 [(SA669)]	ZLP32300H4808G@SSOP48 [(SA669)]
ZLP32300H4816C@SSOP48 [(SA669)]	ZLP32300H4816G@SSOP48 [(SA669)]
ZLP32300H4832C@SSOP48 [(SA669)]	ZLP32300H4832G@SSOP48 [(SA669)]
ZLP32300P2004C	ZLP32300P2004G
ZLP32300P2008C	ZLP32300P2008G
ZLP32300P2016C	ZLP32300P2016G
ZLP32300P2032C	ZLP32300P2032G
ZLP32300P2804C	ZLP32300P2804G
ZLP32300P2808C	ZLP32300P2808G
ZLP32300P2816C	ZLP32300P2816G
ZLP32300P2832C	ZLP32300P2832G
ZLP32300P4004C	ZLP32300P4004G

ZLP32300P4008C	ZLP32300P4008G
ZLP32300P4016C	ZLP32300P4016G
ZLP32300P4032C	ZLP32300P4032G
ZLP32300S2004C@SOIC20 [(SA404)]	ZLP32300S2004G@SOIC20 [(SA404)]
ZLP32300S2008C@SOIC20 [(SA404)]	ZLP32300S2008G@SOIC20 [(SA404)]
ZLP32300S2016C@SOIC20 [(SA404)]	ZLP32300S2016G@SOIC20 [(SA404)]
ZLP32300S2032C@SOIC20 [(SA404)]	ZLP32300S2032G@SOIC20 [(SA404)]
ZLP32300S2804C@SOIC28 [(SA404)]	ZLP32300S2804G@SOIC28 [(SA404)]
ZLP32300S2808C@SOIC28 [(SA404)]	ZLP32300S2808G@SOIC28 [(SA404)]
ZLP32300S2816C@SOIC28 [(SA404)]	ZLP32300S2816G@SOIC28 [(SA404)]
ZLP32300S2832C@SOIC28 [(SA404)]	ZLP32300S2832G@SOIC28 [(SA404)]

## ZMD

### E(E)PROM/FRAM/NVRAM

U62256	U6264
U6264@SOIC28 [(SA630)]	U6264A
U6264A@SOIC28 [(SA630)]	U62H256A@SOIC28 [(SA630)]
U62H256S@SOIC28 [(SA630)]	U62H64SA@SOIC28 [(SA630)]
U630H16	U630H16@SOIC28 [(SA630)]
U630H64	U630H64@SOIC28 [(SA630)]
U631H16	U631H16@SOIC24 [(SA404)]
U631H16@SOIC28 [(SA630)]	U631H256
U631H256@SOIC28 [(SA630)]	U631H64
U631H64@SOIC28 [(SA630)]	U632H16
U632H16@SOIC28 [(SA630)]	U632H64
U632H64@SOIC28 [(SA630)]	U634H256
U634H256@SOIC32 [(SA630)]	U635H16
U635H16@SOIC24 [(SA404)]	U635H256
U635H256@SOIC28 [(SA630)]	U635H64
U635H64@SOIC28 [(SA630)]	U63716
U637256	U63764
U637H256	UL62H256A@SOIC28 [(SA630)]
UL631H256@SOIC28 [(SA630)]	UL631H256@TSOP32 [(SA410T)]
UL634H256@SOIC32 [(SA630)]	UL634H256@TSOP32 [(SA410T)]
UL635H256@SOIC28 [(SA630)]	UL635H256@TSOP32 [(SA410T)]